


Gestetner® **LANIER**  **RICOH** **SAVIN**®



B089/B093
SERVICE MANUAL

001783MIU

Gestetner[®]
LANIER
RICOH[®]
SAVIN[®]

B089/B093
SERVICE MANUAL

RICOH GROUP COMPANIES

Gestetner[®] **LANIER**  **RICOH**[®] **SAVIN**[®]

B089/B093
SERVICE MANUAL

It is the reader's responsibility when discussing the information contained within this document to maintain a level of confidentiality that is in the best interest of Ricoh Corporation and its member companies.

NO PART OF THIS DOCUMENT MAY BE REPRODUCED IN ANY FASHION AND DISTRIBUTED WITHOUT THE PRIOR PERMISSION OF RICOH CORPORATION.

All product names, domain names or product illustrations, including desktop images, used in this document are trademarks, registered trademarks or the property of their respective companies.

They are used throughout this book in an informational or editorial fashion only and for the benefit of such companies. No such use, or the use of any trade name, or web site is intended to convey endorsement or other affiliation with Ricoh products.

WARNING

The Service Manual contains information regarding service techniques, procedures, processes and spare parts of office equipment distributed by Ricoh Corporation. Users of this manual should be either service trained or certified by successfully completing a Ricoh Technical Training Program.

Untrained and uncertified users utilizing information contained in this service manual to repair or modify Ricoh equipment risk personal injury, damage to property or loss of warranty protection.

Ricoh Corporation

LEGEND

PRODUCT CODE	COMPANY			
	GESTETNER	LANIER	RICOH	SAVIN
B089	DSm622	LD122	Aficio 2022	4022
B093	DSm627	LD127	Aficio 2027	4027

DOCUMENTATION HISTORY

REV. NO.	DATE	COMMENTS
*	10/2003	Original Printing

B089/B093

TABLE OF CONTENTS

OVERALL INFORMATION

1. OVERALL MACHINE INFORMATION.....	1-1
1.1 SPECIFICATIONS.....	1-1
1.2 MACHINE CONFIGURATION.....	1-4
1.2.1 SYSTEM COMPONENTS.....	1-4
1.2.2 INSTALLABLE OPTIONAL TABLE.....	1-6
Copier options.....	1-6
Fax option.....	1-6
Printer/scanner options.....	1-6
1.3 PAPER PATH.....	1-7
1.4 MECHANICAL COMPONENT LAYOUT.....	1-8
1.5 ELECTRICAL COMPONENT DESCRIPTIONS.....	1-10
1.6 DRIVE LAYOUT.....	1-13
1.7 COPY PROCESS.....	1-14
1.7.1 OVERVIEW.....	1-14
1.8 BOARD STRUCTURE.....	1-16
1.8.1 OVERVIEW.....	1-16
1.8.2 CONTROLLER.....	1-18

DETAILED DESCRIPTIONS

2. DETAILED SECTION DESCRIPTIONS.....	2-1
2.1 SUMMARY.....	2-1
2.2 SCANNING.....	2-2
2.2.1 OVERVIEW.....	2-2
2.2.2 SCANNER DRIVE.....	2-3
2.2.3 ORIGINAL SIZE DETECTION IN PLATEN MODE.....	2-4
2.3 IMAGE PROCESSING.....	2-6
2.3.1 OVERVIEW.....	2-6
2.3.2 SBU (SENSOR BOARD UNIT).....	2-7
2.3.3 AUTO IMAGE DENSITY.....	2-8
2.3.4 IPU (IMAGE PROCESSING UNIT).....	2-9
2.3.5 VIDEO CONTROL UNIT (VCU).....	2-21
2.4 LASER EXPOSURE.....	2-22
2.4.1 OVERVIEW.....	2-22
2.4.2 AUTO POWER CONTROL (APC).....	2-23
2.4.3 LD SAFETY SWITCH.....	2-24
2.5 PHOTOCONDUCTOR UNIT (PCU).....	2-25
2.5.1 OVERVIEW.....	2-25
2.5.2 DRIVE.....	2-26
2.5.3 NEW PCU DETECTION.....	2-27

2.6	DRUM CHARGE	2-28
2.6.1	OVERVIEW	2-28
2.6.1	CHARGE ROLLER VOLTAGE CORRECTION	2-29
2.6.2	ID SENSOR PATTERN PRODUCTION TIMING	2-30
2.6.3	DRUM CHARGE ROLLER CLEANING	2-31
2.7	DEVELOPMENT	2-32
2.7.1	OVERVIEW	2-32
2.7.2	DRIVE.....	2-33
2.7.3	DEVELOPER MIXING	2-34
2.7.4	DEVELOPMENT BIAS	2-35
2.7.5	TONER SUPPLY	2-36
2.7.6	TONER DENSITY CONTROL	2-38
2.7.7	TONER SUPPLY IN ABNORMAL SENSOR CONDITIONS	2-42
2.7.8	TONER NEAR END/END DETECTION AND RECOVERY	2-42
2.8	DRUM CLEANING AND TONER RECYCLING	2-44
2.8.1	DRUM CLEANING.....	2-44
2.8.2	TONER RECYCLING	2-45
2.9	PAPER FEED	2-46
2.9.1	OVERVIEW	2-46
2.9.2	PAPER FEED DRIVE MECHANISM	2-47
2.9.3	PAPER FEED AND SEPARATION MECHANISM.....	2-48
2.9.4	PAPER LIFT MECHANISM	2-49
2.9.5	PAPER END DETECTION	2-50
2.9.6	PAPER HEIGHT DETECTION	2-51
2.9.7	FEED PRESSURE ADJUSTMENT FOR PAPER SIZE	2-52
2.9.8	PAPER SIZE DETECTION.....	2-55
2.9.9	SPECIAL PAPER SETTING	2-56
2.9.10	SIDE AND END FENCES.....	2-57
2.9.11	PAPER REGISTRATION.....	2-58
2.10	IMAGE TRANSFER AND PAPER SEPARATION	2-59
2.10.1	OVERVIEW	2-59
2.10.2	IMAGE TRANSFER CURRENT TIMING	2-60
2.10.3	TRANSFER ROLLER CLEANING	2-61
2.10.4	PAPER SEPARATION MECHANISM.....	2-61
2.11	IMAGE FUSING AND PAPER EXIT	2-62
2.11.1	OVERVIEW	2-62
2.11.2	FUSING DRIVE AND RELEASE MECHANISM	2-63
2.11.3	FUSING ENTRANCE GUIDE SHIFT MECHANISM	2-64
2.11.4	PRESSURE ROLLER.....	2-65
2.11.5	CLEANING MECHANISM	2-65
2.11.6	FUSING TEMPERATURE CONTROL.....	2-66
2.11.7	OVERHEAT PROTECTION	2-68
2.11.8	PAPER EXIT	2-68
2.12	ENERGY SAVER MODES	2-69
2.12.1	OVERVIEW	2-69
2.12.2	ENERGY SAVER MODE.....	2-70
2.12.3	AUTO OFF MODE.....	2-71

INSTALLATION

3. INSTALLATION PROCEDURE.....	3-1
3.1 INSTALLATION REQUIREMENTS	3-1
3.1.1 ENVIRONMENT	3-1
3.1.2 MACHINE LEVEL	3-1
3.1.3 MINIMUM SPACE REQUIREMENTS.....	3-2
3.1.4 POWER REQUIREMENTS	3-3
3.2 COPIER INSTALLATION	3-4
3.2.1 POWER SOCKETS FOR PERIPHERALS	3-4
3.2.2 INSTALLATION FLOW CHART	3-5
3.2.3 ACCESSORY CHECK.....	3-6
3.2.4 INSTALLATION PROCEDURE	3-7
3.3 PAPER TRAY UNIT INSTALLATION	3-11
3.3.1 ACCESSORY CHECK.....	3-11
3.3.2 INSTALLATION PROCEDURE	3-11
3.4 LCT INSTALLATION	3-14
3.4.1 ACCESSORY CHECK.....	3-14
3.4.2 INSTALLATION PROCEDURE	3-14
3.5 AUTO REVERSE DOCUMENT FEEDER INSTALLATION.....	3-17
3.5.1 ACCESSORY CHECK.....	3-17
3.5.2 INSTALLATION PROCEDURE	3-18
3.6 INTERCHANGE UNIT INSTALLATION.....	3-22
3.6.1 COMPONENT CHECK.....	3-22
3.6.2 INSTALLATION PROCEDURE	3-23
3.7 1-BIN TRAY UNIT INSTALLATION	3-25
3.7.1 COMPONENT CHECK.....	3-25
3.7.2 INSTALLATION PROCEDURE	3-26
3.8 SHIFT TRAY.....	3-29
3.8.1 COMPONENT CHECK.....	3-29
3.8.2 INSTALLATION PROCEDURE	3-30
3.9 BY-PASS FEED UNIT INSTALLATION.....	3-32
3.9.1 COMPONENTS CHECK	3-32
3.9.2 INSTALLATION PROCEDURE	3-33
3.10 DUPLEX UNIT INSTALLATION	3-35
3.10.1 ACCESSORY CHECK.....	3-35
3.10.2 INSTALLATION PROCEDURE	3-36
3.11 BRIDGE UNIT INSTALLATION	3-38
3.11.1 ACCESSORY CHECK.....	3-38
3.11.2 INSTALLATION PROCEDURE	3-39
3.12 1000-SHEET FINISHER INSTALLATION	3-41
3.12.1 ACCESSORY CHECK.....	3-41
3.12.2 INSTALLATION PROCEDURE	3-42
3.13 500-SHEET FINISHER INSTALLATION	3-45
3.13.1 ACCESSORY CHECK.....	3-45
3.13.2 INSTALLATION PROCEDURE	3-46
3.14 PLATEN COVER INSTALLATION	3-48
3.15 KEY COUNTER INSTALLATION	3-49

3.16	OPTICS ANTI-CONDENSATION HEATER.....	3-51
3.17	TRAY HEATER	3-52
3.18	TRAY HEATER (OPTIONAL PAPER TRAY UNIT).....	3-54
3.19	TRAY HEATER (OPTIONAL LCT)	3-57
3.20	OPTIONAL BOARDS AND DIMMS.....	3-60
3.20.1	REMOVING THE COVERS.....	3-60
3.20.2	PRINTER/SCANNER MODULE (B577)	3-61
Printer/Scanner Module ROM DIMM Installation	3-62	
3.20.3	128 MB MEMORY (G331).....	3-63
3.20.4	HDD (B592).....	3-64
3.20.5	NIB (B525-17).....	3-66
3.20.6	IEEE 1394 INTERFACE KIT (G336).....	3-67
3.20.7	IEEE 802.11B INTERFACE KIT (B515).....	3-69
3.20.8	USB 2.0 BOARD (B525-01).....	3-73
3.20.9	BLUETOOTH UNIT 2045 (G354)	3-75
3.20.10	POSTSCRIPT 3 UNIT (G354-05)	3-77
3.20.11	FILE FORMAT CONVERTER (B519).....	3-78
3.20.12	CHECK ALL CONNECTIONS	3-79
3.20.12	USER ACCOUNT ENHANCEMENT UNIT (B443)	3-80

SERVICE TABLES

4.	SERVICE TABLES.....	4-1
4.1	GENERAL CAUTION	4-1
4.1.1	PCU (PHOTOCONDUCTOR UNIT)	4-1
4.1.2	TRANSFER ROLLER UNIT.....	4-1
4.1.3	SCANNER UNIT.....	4-1
4.1.4	LASER UNIT	4-2
4.1.5	FUSING UNIT.....	4-2
4.1.6	PAPER FEED	4-2
4.1.7	OTHERS.....	4-2
4.2	SERVICE PROGRAM MODE.....	4-3
4.2.1	SERVICE PROGRAM MODE OPERATION.....	4-3
Entering and Exiting SP mode	4-3	
SP Mode Button Summary	4-4	
Switching Between SP Mode and Copy Mode for Test Printing	4-5	
Selecting the Program Number.....	4-5	
4.2.2	SERVICE PROGRAM MODE TABLES	4-6
SP1XXX: Feed.....	4-7	
SP2XXX: Drum	4-16	
SP4-XXX: Scanner	4-27	
SP5XXX: Mode.....	4-34	
SP6XXX: Peripherals.....	4-57	
SP7XXX: Data Log	4-59	
SP8-xxx: Data Log2.....	4-66	
4.2.3	TEST PATTERN PRINTING (SP2902-3)	4-99
4.2.4	INPUT CHECK	4-100
Main Machine Input Check (SP5803)	4-100	
ARDF Input Check (SP6007).....	4-103	

Finisher Input Check (SP6117).....	4-104
4.2.5 OUTPUT CHECK	4-106
Main Machine Output Check (SP5804).....	4-106
ARDF Output Check (SP6008).....	4-108
Finisher Output Check (SP6118).....	4-108
4.2.6 SMC DATA LISTS (SP5990).....	4-109
4.2.7 MEMORY ALL CLEAR (SP5801).....	4-109
Using a Flash Memory Card	4-109
Without Using a Flash Memory Card	4-111
4.2.8 UPLOADING/DOWNLOADING NVRAM DATA.....	4-112
Uploading NVRAM Data (SP5824).....	4-112
Downloading NVRAM Data (SP5825).....	4-113
4.2.9 APS OUTPUT DISPLAY (SP4301).....	4-114
4.2.10 DF APS SENSOR OUTPUT DISPLAY (SP6901).....	4-115
4.2.11 NIP BAND WIDTH MEASUREMENT (SP1109).....	4-116
4.3 PROGRAM DOWNLOAD	4-117
4.4 SOFTWARE RESET	4-118
4.5 SYSTEM SETTINGS AND COPY SETTING RESET.....	4-119
4.5.1 SYSTEM SETTING RESET	4-119
4.5.2 COPIER SETTING RESET	4-120
4.6 USER TOOLS	4-121
4.6.1 HOW TO USE UP MODE.....	4-121
UP Mode Initial Screen: User Tools/Counter Display.....	4-121
System Settings.....	4-121
Copier/Document Server Features	4-121
Printer, Facsimile, Scanner Settings.....	4-122
Inquiry	4-122
Counter	4-123
4.7 LEADS	4-124
Controller	4-124
SBCU.....	4-124
IPU.....	4-124
4.8 DIP SWITCHES.....	4-124
Controller: DIP SW2.....	4-124
SBCU: DIP SW102	4-124
4.9 SPECIAL TOOLS AND LUBRICANTS	4-125
4.9.1 SPECIAL TOOLS	4-125
4.9.2 LUBRICANTS.....	4-125
4.10 USING THE DEBUG LOG.....	4-126
4.10.1 SWITCHING ON AND SETTING UP SAVE DEBUG LOG	4-126
4.10.2 RETRIEVING THE DEBUG LOG FROM THE HDD	4-129
4.10.3 RECORDING ERRORS MANUALLY	4-130

PREVENTIVE MAINTENANCE

5. PREVENTIVE MAINTENANCE.....	5-1
5.1 PM TABLE.....	5-1

REPLACEMENT AND ADJUSTMENT

6. REPLACEMENT AND ADJUSTMENT	6-1
6.1 SCANNER UNIT.....	6-1
6.1.1 EXPOSURE GLASS.....	6-1
6.1.2 SCANNER EXTERIOR/OPERATION PANEL.....	6-2
6.1.3 LENS BLOCK ASSEMBLY.....	6-3
6.1.4 ORIGINAL SIZE SENSORS.....	6-4
6.1.5 EXPOSURE LAMP.....	6-5
6.1.6 SCANNER MOTOR/LAMP STABILIZER.....	6-6
6.1.7 SCANNER WIRES.....	6-7
6.2 LASER UNIT.....	6-10
6.2.1 CAUTION DECAL LOCATIONS.....	6-10
6.2.2 LASER UNIT.....	6-11
6.2.3 POLYGON MIRROR MOTOR.....	6-12
6.2.4 LD UNIT.....	6-12
6.2.5 LASER SYNCHRONIZATION DETECTOR.....	6-13
6.3 PHOTOCONDUCTOR UNIT (PCU).....	6-14
6.3.1 PCU.....	6-14
6.4 TRANSFER UNIT.....	6-15
6.4.1 TRANSFER ROLLER UNIT.....	6-15
6.4.2 IMAGE DENSITY SENSOR.....	6-16
6.5 FUSING/EXIT.....	6-17
6.5.1 FUSING UNIT.....	6-17
6.5.2 THERMISTORS.....	6-17
6.5.3 THERMOFUSE.....	6-18
6.5.4 HOT ROLLER AND FUSING LAMP.....	6-20
6.5.5 PRESSURE ROLLER/CLEANING ROLLER.....	6-21
6.5.6 PAPER EXIT SENSOR/PAPER OVERFLOW SENSOR.....	6-22
6.6 PAPER FEED.....	6-23
6.6.1 FEED ROLLERS: TRAY 1.....	6-23
6.6.2 FEED ROLLER: TRAY 2.....	6-24
6.6.3 PAPER END SENSOR.....	6-25
6.6.4 PAPER TRAY LIFT MOTORS.....	6-26
6.6.5 REGISTRATION CLUTCH.....	6-27
6.6.6 PAPER FEED CLUTCHES.....	6-28
6.6.7 RELAY CLUTCHES.....	6-29
6.6.8 PAPER SIZE DETECTOR.....	6-30
6.6.9 REGISTRATION SENSOR.....	6-31
6.6.10 RELAY SENSORS.....	6-32
6.7 PCBS AND OTHER ITEMS.....	6-33
6.7.1 CONTROLLER BOARD.....	6-33
6.7.2 SBCU BOARD.....	6-34
6.7.3 POWER PACK.....	6-34
6.7.4 MAIN MOTOR.....	6-35
6.7.5 PSU.....	6-36
6.8 COPY ADJUSTMENTS: PRINTING/SCANNING.....	6-37
6.8.1 PRINTING.....	6-37

6.8.2 SCANNING.....	6-40
6.8.3 ADF IMAGE ADJUSTMENT	6-42
6.8.4 TOUCH SCREEN CALIBRATION	6-43
6.9 IDENTIFYING SKEWED, TRAPEZOID AND PARALLELOGRAM IMAGES	6-44
6.9.1 SKEWED IMAGES	6-44
6.9.2 TRAPEZOID IMAGES	6-44
6.9.3 PARALLELOGRAM IMAGES	6-45
6.10 CHECKING THE IMAGE WITH THE TRIMMING PATTERN	6-46
6.11 CORRECTING THE IMAGES	6-47
6.11.1 CORRECTING SKEWED IMAGES	6-47
6.11.2 CORRECTING TRAPEZOID IMAGES	6-50

TOUBLESHOOTING

7. TROUBLESHOOTING	7-1
7.1 SERVICE CALL CONDITIONS	7-1
7.1.1 SUMMARY	7-1
7.1.2 SC CODE DESCRIPTIONS	7-2
7.2 SELF-DIAGNOSTIC MODE	7-16
7.2.1 SELF-DIAGNOSTIC MODE AT POWER ON	7-16
7.2.2 DETAILED SELF-DIAGNOSTIC MODE	7-17
Executing Detailed Self-Diagnosis	7-17
7.3 PAPER FEED TROUBLESHOOTING	7-19
7.4 SKEWED IMAGE	7-20
7.5 ELECTRICAL COMPONENT DEFECTS	7-21
7.5.1 SENSORS	7-21
7.5.2 SWITCHES	7-23
7.6 BLOWN FUSE CONDITIONS	7-24

PAPER TRAY UNIT (A860/B390)

1. OVERALL MACHINE INFORMATION.....	8-1
1.1 SPECIFICATIONS.....	8-1
1.2 MECHANICAL COMPONENT LAYOUT	8-2
1.3 ELECTRICAL COMPONENT LAYOUT.....	8-3
1.4 ELECTRICAL COMPONENT DESCRIPTION.....	8-4
1.5 DRIVE LAYOUT	8-5
2. DETAILED DESCRIPTIONS	8-6
2.1 PAPER FEED AND SEPARATION MECHANISM	8-6
2.2 PAPER LIFT MECHANISM	8-7
2.3 PAPER END DETECTION	8-9
2.4 PAPER HEIGHT DETECTION	8-10
2.5 PAPER SIZE DETECTION.....	8-12

2.6	SIDE AND END FENCES	8-13
	Side Fences	8-13
	End Fence	8-13
3.	REPLACEMENT AND ADJUSTMENT	8-14
3.1	FEED ROLLER REPLACEMENT	8-14
3.2	TRAY MAIN BOARD REPLACEMENT	8-15
3.3	TRAY MOTOR REPLACEMENT	8-15
3.4	RELAY CLUTCH REPLACEMENT	8-16
3.5	UPPER PAPER FEED CLUTCH REPLACEMENT	8-17
3.6	LOWER PAPER FEED CLUTCH REPLACEMENT	8-18
3.7	LIFT MOTOR REPLACEMENT	8-19
3.8	PAPER END SENSOR REPLACEMENT	8-20
3.9	VERTICAL TRANSPORT SENSOR REPLACEMENT	8-20
3.10	PAPER SIZE SWITCH REPLACEMENT	8-21

LCT (A862/B391)

1.	OVERALL MACHINE INFORMATION	9-1
1.1	SPECIFICATIONS	9-1
1.2	MECHANICAL COMPONENT LAYOUT	9-2
1.3	ELECTRICAL COMPONENT LAYOUT	9-3
1.4	ELECTRICAL COMPONENT DESCRIPTIONS	9-4
2.	DETAILED SECTION DESCRIPTIONS	9-5
2.1	PAPER FEED	9-5
2.2	REVERSE ROLLER AND PICK-UP ROLLER RELEASE	9-6
2.3	TRAY LIFT	9-7
2.4	NEAR END/END DETECTION	9-8
2.5	RIGHT TRAY SIDE FENCE	9-9
2.6	LEFT TRAY REAR FENCE	9-9
2.7	RIGHT TRAY PAPER END DETECTION	9-10
3.	REPLACEMENT AND ADJUSTMENT	9-11
3.1	DETACHING THE TRAY FROM THE MAINFRAME	9-11
3.2	REAR FENCE HP SENSOR	9-11
3.3	CHANGING THE TRAY PAPER SIZE	9-12
3.4	LEFT TRAY PAPER END SENSOR	9-12
3.5	TRAY LIFT MOTOR	9-13
3.6	TRAY MOTOR	9-14
3.7	PAPER FEED CLUTCH AND RELAY CLUTCH	9-15
3.8	PAPER FEED UNIT	9-16
3.9	UPPER LIMIT, RIGHT TRAY PAPER END, AND RELAY SENSORS	9-17
3.10	REAR FENCE MOTOR	9-18
3.11	PICK-UP/PAPER FEED/REVERSE ROLLERS	9-19

AUTO REVERSE DOCUMENT FEEDER (B386)

1. OVERALL MACHINE INFORMATION.....	10-1
1.1 SPECIFICATIONS.....	10-1
1.2 MECHANICAL COMPONENT LAYOUT	10-2
1.3 ELECTRICAL COMPONENT LAYOUT.....	10-3
1.4 ELECTRICAL COMPONENT DESCRIPTION.....	10-4
1.5 DRIVE LAYOUT	10-5
2. DETAILED SECTION DESCRIPTIONS	10-6
2.1 ORIGINAL SIZE DETECTION.....	10-6
2.2 MIXED ORIGINAL SIZE MODE	10-9
2.3 PICK-UP AND SEPARATION	10-10
2.4 ORIGINAL TRANSPORT AND EXIT.....	10-11
2.4.1 SINGLE-SIDED ORIGINALS.....	10-11
2.4.2 DOUBLE-SIDED ORIGINALS	10-12
2.4.3 ORIGINAL TRAILING EDGE SENSOR.....	10-13
2.5 STAMP	10-14
2.6 TIMING CHART.....	10-15
2.7 CONDITION OF JAM DETECTION.....	10-16
2.8 OVERALL ELECTRICAL CIRCUIT	10-17
3. SERVICE TABLES.....	10-18
3.1 DIP SWITCHES.....	10-18
4. REPLACEMENT AND ADJUSTMENT	10-19
4.1 DF EXIT TABLE AND COVER	10-19
4.2 ORIGINAL FEED UNIT	10-20
4.3 LEFT COVER.....	10-21
4.4 PICK-UP ROLLER.....	10-22
4.5 FEED BELT	10-23
4.6 SEPARATION ROLLER.....	10-24
4.7 ORIGINAL SET/ORIGINAL REVERSE SENSOR	10-25
4.8 ORIGINAL SIZE SENSOR	10-26
4.9 ORIGINAL FEED DRIVE	10-27
DF Feed Clutch.....	10-27
Pick-up Solenoid	10-27
Transport Motor	10-27
DF Feed Motor.....	10-27
4.10 REGISTRATION SENSOR.....	10-28
4.11 STAMP SOLENOID AND ORIGINAL EXIT SENSOR.....	10-29

INTERCHANGE UNIT (B300/B416)

1. OVERALL MACHINE INFORMATION.....	11-1
1.1 SPECIFICATIONS.....	11-1
1.2 MECHANICAL COMPONENT LAYOUT	11-2

1.3 DRIVE LAYOUT	11-3
2. DETAILED DESCRIPTION	11-4
2.1 JUNCTION GATE MECHANISM.....	11-4
To the Exit Tray or Bridge Unit (for the Upper Tray on top of the Bridge Unit, or the Finisher).....	11-4
To the 1-bin Tray	11-4
To the Duplex Unit.....	11-4
3 REPLACEMENT AND ADJUSTMENT	11-5
3.1 EXIT SENSOR REPLACEMENT.....	11-5

1-BIN TRAY UNIT (A898/B413)

1. OVERALL INFORMATION	12-1
1.1 SPECIFICATIONS.....	12-1
1.2 MECHANICAL COMPONENT LAYOUT	12-2
1.3 ELECTRICAL COMPONENT LAYOUT.....	12-3
1.4 ELECTRICAL COMPONENT DESCRIPTION.....	12-3
2. DETAILED SECTION DESCRIPTIONS	12-4
2.1 BASIC OPERATION.....	12-4
3. REPLACEMENT AND ADJUSTMENT	12-5
3.1 PAPER SENSOR REMOVAL.....	12-5

SHIFT TRAY UNIT (B313/B459)

1. OVERALL MACHINE INFORMATION.....	13-1
1.1 SPECIFICATIONS.....	13-1
1.2 COMPONENT LAYOUT.....	13-2
2. DETAILED SECTION DESCRIPTIONS	13-3
2.1 BASIC OPERATION.....	13-3
2.2 PRIMARY MECHANISMS.....	13-4
2.2.1 TRAY SHIFT.....	13-4
2.2.2 HALF TURN DETECTION.....	13-5
3. REPLACEMENT AND ADJUSTMENT	13-6
3.1 TRAY COVER REPLACEMENT	13-6
3.1.1 TRAY COVER REMOVAL.....	13-6
3.1.2 TRAY COVER ATTACHMENT.....	13-6
3.2 TRAY MOTOR AND HALF TURN SENSOR REPLACEMENT	13-7
3.2.1 REPLACING THE TRAY MOTOR.....	13-7
3.2.2 REPLACING THE HALF TURN SENSOR:.....	13-7

BY-PASS (A899/B415)

1. OVERALL MACHINE INFORMATION.....	14-1
1.1 SPECIFICATIONS.....	14-1
1.2 MECHANICAL COMPONENT LAYOUT	14-1
1.3 ELECTRICAL COMPONENT LAYOUT.....	14-2
1.4 ELECTRICAL COMPONENT DESCRIPTION.....	14-2
2. DETAILED DESCRIPTIONS	14-3
2.1 BASIC OPERATION.....	14-3
2.2 PAPER SIZE DETECTION.....	14-4
3. REPLACEMENT AND ADJUSTMENT	14-5
3.1 PAPER FEED ROLLER/FRICTION PAD/PAPER END SENSOR.....	14-5
3.2 PAPER SIZE SENSOR BOARD.....	14-6
3.3 PAPER FEED CLUTCH	14-7

DUPLEX (A896/B414)

1. OVERALL MACHINE INFORMATION.....	15-1
1.1 SPECIFICATIONS.....	15-1
1.2 MECHANICAL COMPONENT LAYOUT	15-2
1.3 ELECTRICAL COMPONENT LAYOUT.....	15-3
1.4 ELECTRICAL COMPONENT DESCRIPTION.....	15-4
1.5 DRIVE LAYOUT	15-5
2. DETAILED DESCRIPTIONS	15-6
2.1 BASIC OPERATION.....	15-6
Longer than A4 sideways/LT sideways.....	15-6
Up to A4 sideways/LT sideways	15-7
2.2 FEED IN AND EXIT MECHANISM	15-8
When paper is fed into duplex unit:.....	15-8
Inversion and Exit:	15-8
3. REPLACEMENT AND ADJUSTMENT	15-9
3.1 COVER REMOVAL	15-9
3.2 ENTRANCE SENSOR REPLACEMENT	15-10
3.3 EXIT SENSOR REPLACEMENT.....	15-11

BRIDGE UNIT (A897/B417)

1. OVERALL MACHINE INFORMATION.....	16-1
1.1 SPECIFICATIONS.....	16-1
1.2 MECHANICAL COMPONENT LAYOUT	16-2
1.3 ELECTRICAL COMPONENT LAYOUT.....	16-3

1.4 ELECTRICAL COMPONENT DESCRIPTION.....	16-4
1.5 DRIVE LAYOUT	16-5
2. DETAILED DESCRIPTION	16-6
2.1 JUNCTION GATE MECHANISM.....	16-6
3. REPLACEMENT AND ADJUSTMENT	16-7
3.1 BRIDGE UNIT DRIVE MOTOR REPLACEMENT	16-7
3.2 TRAY EXIT SENSOR REPLACEMENT	16-8
3.3 RELAY SENSOR REPLACEMENT	16-8

1,000-SHEET FINISHER (B408)

1. REPLACEMENT AND ADJUSTMENT	17-1
1.1 MAIN PCB	17-1
1.2 STAPLER UNIT	17-2
1.3 MOTORS.....	17-3
1.3.1 SHIFT MOTOR.....	17-3
1.3.2 STAPLER MOTOR.....	17-3
1.3.3 UPPER TRANSPORT MOTOR AND EXIT MOTOR	17-3
1.3.4 LOWER TRANSPORT MOTOR.....	17-4
1.4 MOTORS AND SENSORS.....	17-5
1.4.1 PREPARATION.....	17-5
1.4.2 STACK HEIGHT SENSOR	17-6
1.4.3 STAPLER TRAY PAPER SENSOR.....	17-6
1.4.4 LOWER TRAY LIFT MOTOR	17-6
1.4.5 STACK FEED-OUT MOTOR.....	17-7
2. TROUBLESHOOTING	17-8
2.1 JAM DETECTION.....	17-8
3. SERVICE TABLES.....	17-9
3.1 DIP SWITCH SETTINGS	17-9
4. DETAILED DESCRIPTIONS	17-10
4.1 GENERAL LAYOUT	17-10
4.2 ELECTRICAL COMPONENT LAYOUT.....	17-11
4.3 ELECTRICAL COMPONENT DESCRIPTION.....	17-13
4.4 DRIVE LAYOUT	17-15
4.5 JUNCTION GATES	17-17
Upper tray mode	17-17
Sort/stack mode.....	17-17
Staple mode.....	17-17
4.6 UPPER TRAY.....	17-18
4.7 LOWER TRAY UP/DOWN MECHANISMS	17-19
4.8 PAPER SHIFT MECHANISM	17-20
4.9 JOGGER UNIT PAPER POSITIONING MECHANISM.....	17-21
4.10 EXIT GUIDE PLATE.....	17-22
4.11 STAPLER MECHANISM	17-23

4.12 STAPLER UNIT MOVEMENT MECHANISM	17-24
4.13 PAPER FEED-OUT MECHANISM	17-25
5. OVERALL MACHINE INFORMATION.....	17-26
5.1 SPECIFICATIONS.....	17-26
Upper Tray.....	17-26
Lower Tray.....	17-26

500-SHEET FINISHER (G302/B442)

1. REPLACEMENT AND ADJUSTMENT	18-1
1.1 EXTERIOR	18-1
1.2 ENTRANCE UPPER GUIDE / PAPER EXIT UNIT	18-4
1.3 ENTRANCE LOWER GUIDE	18-5
1.4 PAPER EXIT UNIT GEAR / PADDLE ROLLER SOLENOID	18-5
1.5 STAPLER UNIT	18-6
1.6 JOGGER TRAY UNIT	18-6
1.7 PAPER EXIT SENSOR FEELER	18-7
1.8 MAIN MOTOR	18-7
1.9 JOGGER MOTOR.....	18-8
1.10 CONTROL BOARD	18-8
1.11 OUTPUT TRAY UNIT.....	18-9
2. DETAILED DESCRIPTIONS	18-10
2.1 OVERALL MACHINE INFORMATION	18-10
2.1.1 COMPONENT LAYOUT	18-10
Mechanical component layout	18-10
Drive layout.....	18-11
2.1.2 ELECTRICAL COMPONENT DESCRIPTIONS	18-12
2.2 DETAILED SECTION DESCRIPTIONS	18-14
2.2.1 OUTPUT TRAY MECHANISM	18-14
Stack height detection.....	18-14
Output tray up/down mechanism	18-15
2.2.2 PAPER FEED	18-16
Overview.....	18-16
Straight feed out mode.....	18-16
Shift sorting mode.....	18-17
Stapling mode.....	18-19
2.2.3 JAM CONDITIONS	18-20
2.2.4 ERROR DETECTION.....	18-20
3. OVERALL MACHINE INFORMATION.....	18-21
3.1 SPECIFICATIONS.....	18-21

DataOverwriteSecurity Unit B692/B694

SEE SECTION B692/B694 FOR DETAILED TABLE OF CONTENTS

FAX OPTION B576

TABLE OF CONTENTS

INSTALLATION

1. INSTALLATION	1-1
1.1 CAUTIONS AND WARNINGS.....	1-1
1.2 FAX OPTION TYPE 2027 INSTALLATION	1-2
1.3 G3 INTERFACE UNIT TYPE 2027 INSTALLATION	1-5

TROUBLESHOOTING

2. TROUBLESHOOTING	2-1
2.1 ERROR CODES.....	2-1
2.2 FAX SC CODES.....	2-9

SERVICE TABLES

3. SERVICE TABLES	3-1
3.1 SERVICE PROGRAM MODE.....	3-1
3.1.1 SERVICE PROGRAM MODE OPERATION.....	3-1
Entering and Exiting SP mode	3-1
SP2-XXX (RAM Data).....	3-3
SP3-XXX (Machine Settings).....	3-3
SP4-XXX (ROM Versions).....	3-5
SP5-XXX (RAM Clear).....	3-5
SP6-XXX (Reports).....	3-6
SP7-XXX (Test)	3-8
3.2 BIT SWITCHES	3-9
3.2.1 SYSTEM SWITCHES.....	3-9
3.2.2 IFAX SWITCHES.....	3-21
3.2.3 PRINTER SWITCHES.....	3-21
3.2.4 COMMUNICATION SWITCHES.....	3-27
3.2.5 G3-1 SWITCHES.....	3-35
3.2.6 G3-2 SWITCHES.....	3-43
3.2.7 FAX SWITCHES.....	3-51
3.3 NCU PARAMETERS	3-55
3.4 DEDICATED TRANSMISSION PARAMETERS	3-65
3.4.1 PROGRAMMING PROCEDURE	3-65
3.4.2 PARAMETERS.....	3-66
3.5 SERVICE RAM ADDRESSES.....	3-69

DETAILED DESCRIPTIONS

4. DETAILED SECTION DESCRIPTIONS	4-1
4.1 OVERVIEW	4-1
4.2 BOARDS	4-2
4.2.1 FCU	4-2
4.2.2 MBU.....	4-3
4.2.3 NCU (US)	4-4
4.2.4 NCU (EUROPE/ASIA)	4-5
4.2.5 SG3-D BOARD	4-6
4.3 ADDRESS BOOK.....	4-7
4.3.1 ADDRESS BOOK BACKUP	4-7
Overview of Data Backup	4-7
SP Modes	4-9

SPECIFICATIONS

5. SPECIFICATIONS.....	5-1
1. GENERAL SPECIFICATIONS.....	5-1
2. CAPABILITIES OF PROGRAMMABLE ITEMS	5-2
3. MACHINE CONFIGURATION	5-3

INTERNET FAX (IFAX)

TABLE OF CONTENTS

INSTALLATION

1. INSTALLATION	1-1
1.1 IFAX INSTALLATION	1-1
1.2 INITIAL SETTINGS	1-1

TROUBLESHOOTING

2. TROUBLESHOOTING	2-1
2.1 ERROR CODES FOR LAN COMMUNICATION	2-1
2.2 TROUBLESHOOTING PROCEDURES	2-6

SERVICE TABLES

3. SERVICE TABLES AND PROCEDURES	3-1
3.1 ACCESSING IFAX BIT SWITCHES	3-1
3.2 SP1102 IFAX SWITCH.....	3-2
3.3 FIRMWARE UPDATE PROCEDURE.....	3-8
3.4 IFAX RAM ADDRESSES.....	3-9

DETAILED DESCRIPTIONS

4. DETAILED SECTION DESCRIPTIONS	4-1
4.1 INTERNET FAX.....	4-1
4.1.1 INTERNET FAX FEATURES.....	4-1
4.1.2 DNS SERVICE	4-2
4.2 INTERNET MAIL COMMUNICATION	4-3
4.2.1 MAIL TRANSMISSION.....	4-3
Procedure	4-3
Data Formats	4-3
Errors	4-3
Results.....	4-4
Selectable Options.....	4-4
Secure Internet Transmission	4-5
4.2.2 MAIL RECEPTION	4-6
POP3/IMAP4 Mail Reception Procedure	4-6
Characteristics of POP3/IMAP4 Reception	4-7
SMTP Reception.....	4-7
SMTP Reception Characteristics	4-8
Delivery: Transferring Mail Received With SMTP (Off Ramp Gateway).....	4-9
Overview	4-9
Handling Mail Reception Errors	4-12

Printing Received Mail	4-13
Multi-part Messages.....	4-13
Manual e-mail reception.....	4-13
Secure Internet Reception	4-13
4.2.3 MAIL BROADCASTING (E-MAIL AND G3 FAX ARE COMBINED)	4-14
4.2.4 TRANSFER REQUEST	4-15
Operation at the Transfer Requester	4-15
Operation at the Transfer Station.....	4-17
4.2.5 AUTOROUTING	4-19
4.2.6 TRANSFER BOX.....	4-19
4.3 E-MAIL OPTIONS (SUB TX MODE)	4-20
4.3.1 SUBJECT AND LEVEL OF IMPORTANCE	4-20
How the Subject Differs According to Mail Type	4-20
Subjects Displayed on the PC	4-20
4.3.2 E-MAIL MESSAGES.....	4-21
4.3.3 MESSAGE DISPOSITION NOTIFICATION (MDN)	4-22
Handling Mail	4-23
Handling Reports	4-24
Return Receipt Conditions	4-25

SPECIFICATIONS

5. SPECIFICATIONS.....	5-1
1. IFAX SPECIFICATIONS.....	5-1

PRINTER/SCANNER B577

TABLE OF CONTENTS

INSTALLATION

1. INSTALLATION.....	1-1
1.1 INSTALLATION REQUIREMENTS	1-1
1.2 PRINTER/SCANNER INSTALLATION.....	1-1

TROUBLESHOOTING

2. TROUBLESHOOTING	2-1
2.1 CONTROLLER ERRORS.....	2-1

SERVICE TABLES

3. SERVICE TABLES	3-1
3.1 PRINTER SERVICE MODE	3-1
Service Table Key.....	3-1
3.1.2 PRINTER SERVICE MODE TABLES.....	3-1
3.1.3 SP MODES RELATED TO THE PRINTER CONTROLLER.....	3-2
3.2 SCANNER SERVICE MODE.....	3-3
3.2.1 SCANNER PROGRAM MODE TABLE.....	3-3

DETAILED DESCRIPTIONS

4. DETAILS.....	4-1
4.1 ETHERNET BOARD	4-1
4.1.1 ETHERNET BOARD LAYOUT	4-1
4.1.2 ETHERNET BOARD OPERATION.....	4-2
4.2 IEEE1394 BOARD (FIREWIRE).....	4-3
4.2.1 OVERVIEW	4-3
4.3 USB	4-5
4.3.1 SPECIFICATIONS.....	4-5
4.3.2 USB 1.1/2.0	4-5
4.3.3 USB CONNECTORS.....	4-6
4.3.4 PIN ASSIGNMENT	4-6
4.3.5 REMARKS ABOUT USB	4-7
Related SP Mode.....	4-7
4.4 IEEE 802.11B (WIRELESS LAN)	4-8
4.4.1 SPECIFICATIONS.....	4-8
LED Indicators	4-8
4.4.2 TRANSMISSION MODES	4-9

Ad Hoc Mode	4-9
Infrastructure Mode.....	4-9
4.4.3 SECURITY FEATURES	4-10
Using the SSID in Ad hoc mode	4-10
4.4.4 WIRELESS LAN TROUBLESHOOTING NOTES	4-11
Communication Status.....	4-11
Channel Settings	4-11
Troubleshooting Procedure.....	4-12
4.5 BLUETOOTH.....	4-13
4.5.1 SPECIFICATIONS.....	4-13
4.5.2 BLUETOOTH PROFILES	4-14
4.5.3 BLUETOOTH SECURITY FEATURES.....	4-14
4.6 FILE FORMAT CONVERTER (MLB).....	4-15

SPECIFICATIONS

SPECIFICATIONS	5-1
1. SYSTEM COMPONENTS	5-1
2. LED INDICATORS	5-2
3. PRINTER SPECIFICATIONS	5-2
4. USB SPECIFICATIONS	5-4
5. IEEE 802.11B SPECIFICATIONS	5-4
6. IEEE 1394 SPECIFICATIONS.....	5-4
7. BLUETOOTH SPECIFICATIONS.....	5-3
8. SCANNER SPECIFICATIONS	5-4
9. SOFTWARE ACCESSORIES	5-5
9.1 PRINTER.....	5-5
9.2 SCANNER.....	5-6

IMPORTANT SAFETY NOTICES

PREVENTION OF PHYSICAL INJURY

1. Before disassembling or assembling parts of the copier and peripherals, make sure that the copier power cord is unplugged.
2. The wall outlet should be near the copier and easily accessible.
3. If any adjustment or operation check has to be made with exterior covers off or open while the main switch is turned on, keep hands away from electrified or mechanically driven components.
4. If a job has started before the copier completes the warm-up or initializing period, keep hands away from the mechanical and electrical components because the starts making copies as soon as the warm-up period is completed.
5. The inside and the metal parts of the fusing unit become extremely hot while the copier is operating. Be careful to avoid touching those components with your bare hands.

HEALTH SAFETY CONDITIONS

Toner is non-toxic, but if you get it in your eyes by accident, it may cause temporary eye discomfort. Try to remove with eye drops or flush with water as first aid. If unsuccessful, get medical attention.

SAFETY AND ECOLOGICAL NOTES FOR DISPOSAL

1. Do not incinerate the toner cassettes. Toner dust may ignite suddenly when exposed to an open flame.
2. Dispose of toner cassettes in accordance with local regulations. (This is a non-toxic unit.)
3. Dispose of replaced parts in accordance with local regulations.

OBSERVANCE OF ELECTRICAL SAFETY STANDARDS

1. The copier and its peripherals must be installed and maintained by a customer service representative who has completed the training course on those models.
2. The NVRAM on the Controller board has a lithium battery which can explode if replaced incorrectly. Replace the NVRAM only with an identical one. Do not recharge or burn this battery. Used NVRAM must be handled in accordance with local regulations.
3. The danger of explosion exists if batteries on the FCU, MBU and JBIG are incorrectly replaced. Replace only with the same or an equivalent type recommended by the manufacturer. Discard used batteries in accordance with the manufacturer's instructions.

LASER SAFETY

The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.

WARNING

Use of controls, or adjustment, or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

WARNING FOR LASER UNIT

WARNING: Turn off the main switch before attempting any of the procedures in the Laser Unit section. Laser beams can seriously damage your eyes.

CAUTION MARKING:



OVERALL INFORMATION B089/B093

LCT A862/B391

1,000-SHEET FINISHER B408

**TAB
POSITION 1**

DETAILED DESCRIPTIONS B089/B093

AUTO REVERSE DOCUMENT FEEDER B386

500-SHEET FINISHER G302/B422

**TAB
POSITION 2**

INSTALLATION B089/B093

INTERCHANGE UNIT B300/B416

FAX OPTION B576

**TAB
POSITION 3**

SERVICE TABLES B089/B093

1-BIN TRAY UNIT A898/B413

INTERNET FAX (IFAX)

**TAB
POSITION 4**

PREVENTIVE MAINTENANCE B089/B093

SHIFT TRAY UNIT B313/B459

PRINTER/SCANNER B577

**TAB
POSITION 5**

REPLACEMENT AND ADJUSTMENT B089/B093

BY-PASS A899/B415

**TAB
POSITION 6**

TROUBLESHOOTING B089/B093

DUPLEX A896/B414

**TAB
POSITION 7**

PAPER TRAY UNIT A860/B390

BRIDGE UNIT A897/B417

**DATAOVERWRITESECURITY UNIT
B692/B694**

**TAB
POSITION 8**

OVERALL INFORMATION

1. OVERALL MACHINE INFORMATION

1.1 SPECIFICATIONS

Configuration:	Desktop
Copy Process:	Dry electrostatic transfer system
Originals:	Sheet/Book
Original Size:	Maximum A3/11" x 17"
Copy Paper Size:	Maximum: A3/11" x 17" Minimum: A5/8 1/2" x 5 1/2" lengthwise Custom sizes 2nd paper tray Width: 100 ~ 297 mm (3.9" ~ 11.5") Length: 148 ~ 432 mm (5.8" ~ 17.0") By-pass tray (Option): Width: 90 ~ 305 mm (3.5" ~ 12.0") Length: 148 ~ 1,260 mm (5.8" ~ 49.6")
Copy Paper Weight:	Paper Tray: 60 ~ 105 g/m ² , 16 ~ 28 lb (1st paper tray) 52 ~ 157 g/m ² , 16 ~ 43 lb (2nd paper tray) By-pass (Option): 52 ~ 157 g/m ² , 16 ~ 42 lb
Reproduction Ratios:	5 Enlargement and 7 Reduction

	A4/A3 Version	LT/DLT Version
Enlargement	400%	400%
	200%	200%
	141%	155%
	122%	129%
	115%	121%
Full Size	100%	100%
Reduction	93%	93%
	87%	85%
	82%	78%
	71%	73%
	65%	65%
	50%	50%
	25%	25%

Zoom:	25% to 400% in 1% steps (Platen mode) 25% to 200% in 1% steps (ADF mode)
Power Source:	120 V, 60 Hz: More than 12 A (for North America) 220 ~ 240 V, 50/60 Hz: More than 7 A (for Europe/Asia) 110 V, 50/60 Hz: More than 13 A (for Taiwan)

SPECIFICATIONS

Power Consumption:

		Mainframe Only		Full System	
		120 V	220 ~ 240 V	120 V	220 ~ 240 V
Maximum (B089/B093/B097)		Less than 1.44 kW	Less than 1.5 kW	Less than 1.44 kW	Less than 1.5 kW
Copying	B089/B093	Approx. 650 W	Approx. 650 W	Approx. 680 W	Approx. 680 W
	B097	Approx. 770 W	Approx. 770 W	Approx. 800 W	Approx. 800 W
Warm-up (B089/B093/B097)		Approx. 1.44 kW	Approx. 1.5 kW	Approx. 1.44 kW	Approx. 1.5 kW
Stand-by (B089/B093/B097)		Approx. 150 W	Approx. 150 W	Approx. 160 W	Approx. 160 W
Energy Saver / Auto Off (B089/B093/B097)		Less than 10 W	Less than 10 W	Less than 10 W	Less than 10 W

- NOTE:** 1) Full system: Mainframe + ADF + 1-bin Sorter + Paper Tray Unit + Duplex Unit + Bridge Unit + Finisher
 2) Without the Option heaters, fax unit, and printer controller

Noise Emission (Sound Power Level):

- Stand-by (Mainframe only): B089/B093: 40 dB(A)
 B097: 40 dB(A)
- Operating (Mainframe only): B089/B093: 63 dB(A)
 B097: 66 dB(A)
- Operating (Full System): B089/B093 : 68.5 dB(A)
 B097: 70 dB(A)

- NOTE:** 1) The above measurements were made in accordance with ISO 7779.
 2) Full System: Mainframe + ADF + 1-bin Sorter + Paper Tray Unit + Duplex Unit + Bridge Unit + Finisher

Dimensions (W x D x H): 550 x 604 x 709 mm (21.7" x 23.8" x 28.0")

- NOTE:** Measurement Conditions
 1) With the paper tray unit or LCT
 2) Without the ADF

Weight: Less than 55 kg (121.3lb)

Copying Speed (copies/minute):

B089	A4, 11" x 8 1/2" LEF	A3/11" x 17"
Non-memory copy mode	22	13
Memory copy mode	22	13
B093	A4, 11" x 8 1/2" LEF	A3/11" x 17"
Non-memory copy mode	27	15
Memory copy mode	27	15
B097	A4, 11" x 8 1/2" LEF	A3/11" x 17"
Non-memory copy mode	32	18
Memory copy mode	32	18


NOTE: Measurement Conditions

- 1) Not APS mode
- 2) A4/LT copying
- 3) Full size

Warm-up Time:	Less than 10 seconds (20°C, 68°F) from when the operation switch is turned on. Less than 15 seconds (20°C, 68°F) from when the main switch is turned on.
First Copy Time:	B089/B0 93 Less than 4.9 sec. (A4), less than 5.0 sec. (LT) B097 Less than 4.5 sec. (A4/LT) Measured under the following conditions: <ul style="list-style-type: none"> • When the polygonal mirror motor is spinning. • From the 1st paper tray • Not APS mode • Full size
Copy Number Input:	Ten-key pad, 1 to 99 (count up or count down)
Manual Image Density:	7 steps
Paper Tray Capacity:	Paper Tray: 500 sheets x 2 (Special paper in the 2nd paper tray: 50 sheets) Paper Tray Unit (Option): 500 sheets x 2 LCT (Option): 1000 sheets x 2 By-pass Tray (Option): 100 sheets (A4, B5, A5, B6, 8 1/2" x 11", 5 1/2" x 8 1/2") 10 sheets (A3, B4, 11" x 17", 8 1/2" x 13") 1 sheet (non-standard sizes) NOTE: Copy paper weight: 80g/m ² (20 lb)
Toner Replenishment:	Cartridge exchange (360 g/cartridge)
Toner Yield:	11 k copies (A4 sideways, 6% full black, 1 to 1 copying, ADS mode)
Copy Tray Capacity:	Copy Tray: 500 sheets (without 1-bin tray) 250 sheets (with 1-bin tray)
Memory Capacity:	Standard 64 MB, Optional memory 128 MB

1.2 MACHINE CONFIGURATION

1.2.1 SYSTEM COMPONENTS



MACHINE CONFIGURATION

Overall Information

Version	Item	Code	No.	Comments
Copier	Copier (R-C3a)	B089	13	
	Copier (R-C3b)	B093	13	
	Copier (R-C3c)	B097	13	
	ARDF (Option)	B386	2	Common with B022/B027/B031
	Platen Cover (Option)	B406	1	
	Paper Tray Unit-2 tray (Option)	B390	8	
	LCT (Option)	B391	7	
	1-bin Tray (Option)	B413	3	
	Shift Tray (Option)	B459	12	
	Duplex Unit (Option)	B414	5	
	By-pass Tray (Option)	B415	6	
	Interchange Unit (Option)	B416	4	
	Bridge Unit (Option)	B417	11	
	1000-sheet finisher (Option)	B408	10	
	500-sheet finisher (Option)	B442	9	
	User Account Enhance Unit (Option)	B443		
	HDD (Option)	B592		
	Memory – 128 MB (Option)	G331		Common with B079
Key Counter Bracket (Option)	B452		Common with B022/B027/B031	
Fax	Fax Controller (Option)	B576		
	G3 Interface Unit (Option)	B593		
	Memory – 32 MB (Option)	G578		Common with B022/B027/B031
	Fax Function Expander (Option)	A892		
	Handset (Option)	B433		
Printer/ Scanner	Printer/Scanner Unit (Option)	B577		
	PS3 (Option)	B354		
	Bluetooth (Option)	G354		Common with B079
	IEEE1394 (FireWire - Option)	G336		
	USB 2.0 (Option)	B525		
	IEEE 802.11b (Wireless – LAN Option)	B515		
Others	NIB (Option)	G529		
	File Format Converter (Option)	B519		Common with B135

1.2.2 INSTALLABLE OPTIONAL TABLE

Copier options

No.	Option	B089/B093/ B097	Note
1	ARDF (Option)	○	Install either no. 1 or 2.
2	Platen Cover (Option)	○	Install either no. 1 or 2.
3	Paper Tray Unit – two-tray (Option)	○	Install either no. 3 or 4.
4	LCT (Option)	○	Install either no. 3 or 4.
5	1-bin Tray (Option)	△	Requires no.9.
6	Shift Tray (Option)	○	Install either no. 6 or 10.
7	Duplex Unit (Option)	△	Requires no.9.
8	By-pass Tray (Option)	○	
9	Interchange Unit (Option)	○	
10	Bridge Unit (Option)	△	No. 10 requires no.11 or 12. Install either no. 6 or 10.
11	1000-sheet Finisher (Option)	△	Install either no. 11 or 12 Requires no.10, and either no.3 or 4
12	500-sheet Finisher (Option)	△	Install either no. 11 or 12 Requires no.10, and either no.3 or 4
13	Memory 128 MB (Option)	○	
14	Key Counter Bracket	○	

○ = Available △ = Requires another option

Fax option


All options for the fax unit are available when the fax unit has been installed.

Printer/scanner options

1. The following boards cannot be installed together: USB 2.0, Bluetooth, File Format Converter, IEEE1394 (FireWire), IEEE 802.11b (Wireless LAN).
2. The printer/scanner option requires the 128 MB memory option.


1.3 PAPER PATH

Overall Information



1. Optional ADF
2. Optional 1-bin Tray
3. Optional Interchange Unit
4. Optional Duplex Unit
5. Optional By-pass Feed Tray
6. Optional Paper Tray Unit
7. Optional 1000-sheet Finisher
8. Optional Bridge Unit

1.4 MECHANICAL COMPONENT LAYOUT



MECHANICAL COMPONENT LAYOUT

1. 2nd scanner
2. Original width sensor
3. Exposure lamp
4. 1st scanner
5. Original length sensor
6. Lens
7. Scanner motor
8. SBU board
9. Exit roller
10. Fusing hot roller
11. Fusing pressure roller
12. Cleaning unit
13. OPC drum
14. Transfer roller
15. Development roller
16. ID sensor
17. Registration roller
18. Friction pad
19. Paper feed roller
20. Paper size sensor
21. Bottom plate
22. Tray heater
23. Polygon mirror motor
24. Laser unit
25. Toner supply bottle holder
26. Drum charge roller
27. Anti-condensation heater
28. Scanner home position sensor

1.5 ELECTRICAL COMPONENT DESCRIPTIONS

Refer to the electrical component layout on the reverse side of the point-to-point diagram for the location of the components.

Symbol	Name	Function
Motors		
M1	Scanner	Drives the 1st and 2nd scanners.
M2	Polygonal Mirror	Turns the polygonal mirror.
M3	Main	Drives the main unit components.
M4	Exhaust Fan	Removes heat from around the fusing unit.
M5	Upper Paper Lift	Raises the bottom plate in the 1st paper tray.
M6	Lower Paper Lift	Raises the bottom plate in the 2nd paper tray.
M7	Toner Supply	Rotates the toner bottle to supply toner to the development unit.
Magnetic Clutches		
MC1	Upper Paper Feed	Starts paper feed from the 1st paper tray.
MC2	Lower Paper Feed	Starts paper feed from the 2nd paper tray.
MC3	Upper Relay	Drives the upper relay rollers.
MC4	Lower Relay	Drives the lower relay rollers.
MC4	Registration	Drives the registration rollers.
Switches		
SW1	Main	Provides power to the machine. If this is off, there is no power supplied to the machine.
SW2	Right Upper Cover	Detects Whether the right upper cover is open or not.
SW3	Right Cover	Cuts the +5VLD and +24V dc power line and detects Whether the right cover is open or not.
SW4	Right Lower Cover	Detects Whether the right lower cover is open or not.
SW5	Upper Paper Size	Determines What size of paper is in the upper paper tray.
SW6	Lower Paper Size	Determines What size of paper is in the lower paper tray.
SW7	New PCU Detect	Detects When a new PCU is installed.
SW8	Front Cover Safety	Cuts the +5VLD and +24V dc power line and detects Whether the front cover is open or not.
SW9	Operation	Provides power for machine operation. The machine still has power if this switch is off.
Sensors		
S1	Scanner HP	Informs the CPU When the 1st and 2nd scanners are at home position.
S2	Platen Cover	Informs the CPU that the platen cover is in the up or down position (related to the APS/ARE functions).
S3	Original Width	Detects original width. This is one of the APS (Auto Paper Select) sensors.
S4	Original Length 1	Detects original length. This is one of the APS (Auto Paper Select) sensors.

ELECTRICAL COMPONENT DESCRIPTIONS


Symbol	Name	Function
S5	Original Length 2	Detects original length. This is one of the APS (Auto Paper Select) sensors.
S6	Toner Density (TD)	Detects the amount of toner inside the development unit.
S7	1st Paper End	Informs the CPU when the 1st paper tray runs out of paper.
S8	2nd Paper End	Informs the CPU when the 2nd paper tray runs out of paper.
S9	Image Density (ID)	Detects the density of various patterns and the reflectivity of the drum for process control.
S10	Paper Overflow	Detects paper overflow in the built-in copy tray.
S11	Paper Exit	Detects misfeeds.
S12	Upper Relay	Detects misfeeds.
S13	Lower Relay	Detects misfeeds.
S14	Registration	Detects misfeeds and controls registration clutch off-on timing.
S15	1st Paper Lift	Detects when the paper in the 1st paper tray is at the feed height.
S16	2nd Paper Lift	Detects when the paper in the 2nd paper tray is at the feed height.
S17	1st Paper Height – 1	Detects the amount of paper in the 1st paper tray.
S18	1st Paper Height – 2	Detects the amount of paper in the 1st paper tray.
S19	2nd Paper Height – 1	Detects the amount of paper in the 2nd paper tray.
S20	2nd Paper Height – 2	Detects the amount of paper in the 2nd paper tray.
PCBs		
PCB1	Controller	Controls all applications both directly and through other control boards.
PCB2	PSU (Power Supply Unit)	Provides dc power to the system and ac power to the fusing lamp and heaters.
PCB3	SBCU (Scanner & Base Engine Control Unit)	Controls the fusing lamp and the mechanical parts of the machine.
PCB4	SBU (Sensor Board Unit)	Contains the CCD, and outputs a video signal to the BICU board.
PCB5	Lamp Stabilizer	Stabilizes the power to the exposure lamp.
PCB6	LDD (Laser Diode Driver)	Controls the laser diode.
PCB7	Operation Panel	Controls the operation panel.
PCB8	High Voltage Supply	Supplies high voltage to the drum charge roller, development roller, and transfer roller.
PCB9	Memory (Option)	Expands the memory capacity for the copier, printer, and scanner features.
PCB10	IPU (Image Processing Unit)	Performs the image processing functions.
Solenoids		
SOL1	Fusing Drive Release	Releases the drive for the fusing unit.
Lamps		
L1	Exposure Lamp	Applies high intensity light to the original for exposure.

ELECTRICAL COMPONENT DESCRIPTIONS

Symbol	Name	Function
L2	Main Fusing Lamp	Heats the center of the hot roller.
L3	Secondary Fusing Lamp	Heats both ends of the hot roller.
L4	Quenching Lamp	Neutralizes any charge remaining on the drum surface after cleaning.
Heaters		
H1	Anti-condensation (Option)	Turns on when the main power switch is off to prevent moisture from forming on the optics.
H2	Tray (Option)	Turns on when the main power switch is off to prevent moisture from forming around the paper trays.
Others		
TS1	Fusing Thermostats	Opens the fusing lamp circuit if the fusing unit overheats.
TH1	Fusing Thermistors	Detects the temperature of the hot roller.
LSD 1	Laser Synchronization Detector	Detects the laser beam at the start of the main scan.
CO1	Mechanical Counter	Keeps track of the total number of prints made.
CO2	Key Counter (Option)	Used for control of authorized use. If this feature is enabled for copying, copying will be impossible until it is installed.

1.6 DRIVE LAYOUT


Overall Information



1. Scanner Drive Motor
2. Main Motor
3. Registration Clutch
4. Upper Paper Feed Clutch
5. Upper Transport Clutch
6. Lower Paper Feed Clutch
7. Lower Transport Clutch

1.7 COPY PROCESS

1.7.1 OVERVIEW



1. EXPOSURE

A xenon lamp exposes the original. Light reflected from the original passes to the CCD, where it is converted into an analog data signal. This data is converted to a digital signal, processed and stored in the memory. At the time of printing, the data is retrieved and sent to the laser diode. For multi-copy runs, the original is scanned once only and stored to the memory.

2. DRUM CHARGE

In the dark, the charge roller gives a negative charge to the organic photoconductive (OPC) drum. The charge remains on the surface of the drum because the OPC layer has a high electrical resistance in the dark.

3. LASER EXPOSURE

The processed data scanned from the original is retrieved from the memory and transferred to the drum by a laser beam, which forms an electrical latent image on the drum surface. The amount of charge remaining as a latent image on the drum depends on the laser beam intensity, which is controlled by the BICU board.

4. DEVELOPMENT

The magnetic developer brush on the development rollers comes in contact with the latent image on the drum surface. Toner particles are electrostatically attached to the areas of the drum surface where the laser reduced the negative charge on the drum.

5. ID SENSOR

The laser forms a sensor pattern on the drum surface. The ID sensor measures the reflectivity of the pattern. The output signal is one of the factors used for toner supply control. Also, the ID sensor measures the reflectivity of the drum surface. The output signal is used for charge roller voltage control.

6. IMAGE TRANSFER

Paper is fed to the area between the drum surface and the transfer roller at the proper time for aligning the copy paper and the developed image on the drum surface. Then, the transfer roller applies a high positive charge to the reverse side of the paper. This positive charge pulls the toner particles from the drum surface onto the paper. At the same time, the paper is electrostatically attracted to the transfer roller.

7. PAPER SEPARATION

Paper separates from the drum as a result of the electrostatic attraction between the paper and the transfer roller. The discharge plate helps separate the paper from the drum.

8. CLEANING

The cleaning blade removes any toner remaining on the drum surface after the image transfers to the paper.


9. QUENCHING

The light from the quenching lamp electrically neutralizes the charge on the drum surface.

BOARD STRUCTURE

1.8 BOARD STRUCTURE

1.8.1 OVERVIEW



This machine uses the RA2K architecture, Which allows the copier to be expanded as an MFP by installing simple modular components (ROM DIMMs) on the controller board.

Controller (Main Board):

Controls the memory and all peripheral devices.

SBCU (Scanner & Base Engine Control Unit):

This is the scanner and engine control board. It controls the following functions:

- Engine sequence
- Timing control for peripherals
- Operation control
- Drive control for the sensors, motors, and solenoids of the printer and scanner
- High voltage supply board control
- Serial interfaces with peripherals
- Fusing control

IPU (Image Processing Board):

This is the scanned image processing board. It controls the following functions.


- Image processing control
- Video control

SBU (Sensor Board Unit):

The SBU deals with the analog signals from the CCD and converts them into digital signals.

BOARD STRUCTURE

1.8.2 CONTROLLER



The controller employs RA2K architecture, which allows the board to control all applications, including copier, printer, scanner, and fax applications. To add the optional printer, scanner, or fax applications, ROM DIMMs must be installed on the controller. The fax option, however, requires FCU and NCU installation also.

The following systems and application software can be downloaded from the controller’s IC Card slot.

- Controller (System OS/Copier)
- Operation panel
- SBCU (engine control)
- Printer
- Scanner
- Fax
- PostScript 3
- NIB
- FCU

For details about how to download software from an IC card, see “Software Download” in 4.3. Program Download in the B022 Service Manual.

CPU:

RM5261. Clock frequency: 400 MHz.

MARIMBA ASIC:

This is a dedicated chip developed for use with RA2K. The CPU and memory I/F employ a 124 MHz bus (32 bit). These components perform CPU and I/F control and also control all of the following functions: memory, local bus, interrupts, PCI bus, video data, HDD, network, operation panel, IEEE1284, and image processing.

SDRAM:

This is a 64 MB RAM chip, expandable with a 128 MB or SDRAM.

System Flash ROM:

8 MB Flash ROM for the system OS and copier application.

Flash ROM DIMM Slots:

Two slots are provided for two ROM DIMMs (4 MB or 8MB). Expansion slots provided for the optional printer/scanner and PostScript 3 applications.

NVRAM:

32 KB of NVRAM are provided for the system. The NVRAM stores many settings, including OS system log information, copier calendar, current system settings, user accounts (max. 100) and all settings for the fax, printer, scanner, and network. The NVRAM also has an RTC (Real Time Clock) for time management.

NOTE: Optional NVRAM, Which can store up to 400 user accounts, can be installed on the controller.

HDD:

A 2.5" HDD (more than 20 GB) can be connected using an IDE I/F. The hard disk is partitioned as shown below.

Partition	Size	Function	Power OFF
File System 1	500 MB	Downloaded fonts, forms.	Remains
File System 2	500 MB	Job spooling area.	Erased
File System 3	2000 MB	Work data area	Remains *1
Image TMP	3780 MB	Collation, sample print, locked print.	Erased *3
Image LS *2	3055 MB	Document server, local storage archive	Remains *3
SAF Thumbnails	300 MB	Stores the SAF thumbnails	Remains
Job Log	10 MB	Job log.	Remains
Address Book	100 MB	Stores address book data	Remains
Mail RX	200 MB	Stores mail RX images	Remains
Image Transfer	1000 MB	Stores images for transfer	Remains
Capture	500 MB	Stores captured images	Remains
Others	1362 MB		Remains
Total	13.3 GB		

*1 Used for document server application.

*2 When an application uses an image page, first it uses the Image LS area. If this area is in use and not available, then it uses the Image TMP area.

*3 Commonly used area for applications. Stores copy, printer, fax, and scanner data. Storage capacity: About 9000 pages (3,000 files)

DETAILED SECTION DESCRIPTIONS

2. DETAILED SECTION DESCRIPTIONS

2.1 SUMMARY


This is a summary of the differences between the B022/B027/B031 and the B089/B093/B097.

- **2nd Feed Roller:**
The release lever and spring to stop the feed roller have been replaced by a release stopper. The shape of this mechanism has been simplified. The mechanical layout of the 1st feed roller has not changed.
- **Feed/Transport Clutch:**
The pawl attached to the clutch to stop it has been replaced with snap feet. This improves the operation of the clutch.
- **Quenching Lamp:**
The magnet that attaches the quenching lamp has been replaced with a hook. This change simplifies the configuration of the attachment mechanism.
- **Scanner Arm:**
A plate has been added to the scanner arm to strengthen it. This change reduces the degree of distortion in the shape of the scanner unit caused by the lowering of the front left side of the unit.
- **Controller Bracket:**
A plate has been added to controller bracket to strengthen it. This change increases the strength of the bracket that holds the controller unit in place.
- **Cap to Connect the Bridge Unit:**
The cap used to attach the Bridge Unit has been combined with the left rear cover (P/N:B0241304). The cap and cover have been combined to simplify the structure of this mechanism.
- **Magnet for the Front Cover of the Machine:**
The hook type mechanism has been replaced with a screw. This change simplifies the need for parts procurement.

SCANNING

2.2 SCANNING

2.2.1 OVERVIEW




The original is illuminated by the exposure lamp (a xenon lamp in this model) [A]. The image is reflected onto a CCD (charge coupled device) [B] via the 1st, 2nd, 3rd mirrors, and lens [C].

The 1st scanner [D] consists of the exposure lamp, a reflector [E], and the 1st mirror [F].

A lamp stabilizer energizes the exposure lamp. The light reflected by the reflector is of almost equal intensity, to reduce shadows on pasted originals.

An optics anti-condensation heater [G] is available as an option. It can be installed on the left side of the scanner. It turns on whenever the power cord is plugged in.

2.2.2 SCANNER DRIVE



A stepper motor drives the scanner. The 1st and 2nd scanners [A,B] are driven by the scanner drive motor [C] through the timing belt [D], scanner drive pulley [E], scanner drive shaft [F], and two scanner wires [G].

- Book mode -

The scanner drive board controls and operates the scanner drive motor. In full size mode, the 1st scanner speed is 150 mm/s during scanning. The 2nd scanner speed is half that of the 1st scanner.

In reduction or enlargement mode, the scanning speed depends on the magnification ratio. The returning speed is always the same, whether in full size or magnification mode. The image length change in the sub scan direction is done by changing the scanner drive motor speed, and in the main scan direction it is done by image processing on the IPU board.


Magnification in the sub-scan direction can be adjusted by changing the scanner drive motor speed using SP4009. Magnification in the main scan direction can be adjusted using SP4008.

- ADF mode -

The scanners are always kept at their home position (the scanner H.P sensor [H] detects the 1st scanner) to scan the original. The ADF motor feeds the original through the ADF. In reduction/enlargement mode, the image length change in the sub-scan direction is done by changing the ADF motor speed. Magnification in the main scan direction is done in the IPU board, like for book mode.

Magnification in the sub-scan direction can be adjusted by changing the ADF motor speed using SP6006. In the main scan direction, it can be adjusted with SP4008, like for book mode.


2.2.3 ORIGINAL SIZE DETECTION IN PLATEN MODE



In the optics cavity for original size detection, there are four reflective sensors in the 115V machines ([A] and [B]), and six reflective sensors in the 230V machines. The original width sensors [A] detect the original width, and the original length sensors [B] and [C] detect the original length. These are the APS (Auto Paper Select) sensors. Each APS sensor is a reflective photosensor.

While the main switch is on, these sensors are active and the original size data is always sent to the CPU. However, the CPU checks the data only when the platen cover sensor [D] is activated. This is when the platen is positioned about 15 cm above the exposure glass, for example while it is being closed. The CPU can recognize the original size from the combination of on/off signals from the APS sensors.

If the copy is made with the platen fully open, the CPU decides the original size from the sensor outputs when the Start key is pressed.



Original Size		Length Sensor				Width Sensor	
A4/A3 version	LT/DLT version	L4	L3	L2	L1	W2	W1
A3	11" x 17"	O	O	O	O	O	O
B4	10" x 14"	O	O	O	O	O	X
Foolscap	8.5" x 13"	O	O	O	X	X	X
A4-L	8.5" x 11"	O	O	X	X	X	X
B5-L		O	X	X	X	X	X
A4-S	11" x 8.5"	X	X	X	X	O	O
B5-S		X	X	X	X	O	X
A5-L, A5-S		X	X	X	X	X	X

NOTE: 1) L: Lengthwise, S: Sideways, O: High (paper present), X: Low
 2) The length sensors L3 and L4 are used only for 230V machines.

For other combinations, "CANNOT DETECT ORIG. SIZE" will be indicated on the operation panel display (if SP 4-303 is kept at the default setting).


The above table shows the outputs of the sensors for each original size. This original size detection method eliminates the necessity for a pre-scan and increases the machine's productivity.

However, if the by-pass feeder is used, note that the machine assumes that the copy paper is lengthwise. For example, if A4 sideways paper is placed on the by-pass tray, the machine assumes it is A3 paper and scans the full A3 area for the first copy of each page of the original, disregarding the original size sensors. However, for each page, the data signal to the laser diode is stopped to match the copy paper length detected by the registration sensor.

Original size detection using the ADF is described in the manual for the ADF.

2.3 IMAGE PROCESSING

2.3.1 OVERVIEW




The CCD generates an analog video signal. The SBU (Sensor Board Unit) converts the analog signal to an 8-bit digital signal, then it sends the digital signal to the IPU (Image Processing Unit) board.

The IPU board performs the image processing, such as auto shading, filtering, magnification, gradation processing.

The SIMAC on the controller board performs the image editing, such as image repeat, double copy.

Finally, the IPU board sends the video data to the LD drive board.

2.3.2 SBU (SENSOR BOARD UNIT)




The CCD converts the light reflected from the original into an analog signal. The CCD line has 7,450 pixels and the resolution is 600 dpi (23.6 lines/mm).

The CCD has two output lines, for odd and even pixels, to the analog processing IC. The analog processing IC performs the following operations on the signals from the CCD:

1. Z/C (Zero Clamp):
Adjusts the black level reference for even pixels to match the odd pixels.
2. Signal Amplification:
The analog signal is amplified by operational amplifiers in the AGC circuit.
3. Auto Gain Control
Adjusts the gain curve for the scanned image density.

After the above processing, the analog signals are converted to 8-bit signals by the A/D converter. This will give a value for each pixel on a scale of 256 grades. Then, the digitized image data goes to the IPU board.

2.3.3 AUTO IMAGE DENSITY



ADS prevents the background of an original from appearing on copies.


The copier scans the auto image density detection area [A] as shown in the diagram. This corresponds to a few mm at one end of the main scan line. As the scanner scans down the page, the SBU detects the peak white level for each scan line. The IPU performs the ADS function in accordance with the peak white level.

When an original with a gray background is scanned, the density of the gray area is the peak white level density. Therefore, the original background will not appear on copies. Because peak level data is taken for each scan line, ADS corrects for any changes in background density down the page.

As with previous digital copiers, the user can select manual image density when selecting auto image density mode, and the machine will use both settings when processing the original.

2.3.4 IPU (IMAGE PROCESSING UNIT)

Overview



The image data from the SBU goes to the IPU (Image Processing Unit) ICs on the SBCU board, which carry out the following processes on the image data.

IPU-A

- Auto shading
- Pre-filtering
- Magnification
- Test pattern generation

IPU-B

- Filtering (MTF and smoothing)
- ID gamma correction
- Grayscale processing
- Binary picture processing
- Error diffusion
- Dithering


Video Controller


- Video path control

The image data then goes to the LD driver (LDD).

Image Processing Modes

The user can select one of the following modes with the User Tools screen: Text, Text/Photo, Photo, Pale, Generation. Each of these modes has a range of different settings (e.g. Soft, Normal, Sharp, etc). For each mode, a Custom Setting option is also available. This Custom Setting holds the values selected with the SP modes, which can be adjusted to meet special requirements that cannot be covered by the standard settings.

To display this screen, press User Tools/Counter , press Copier/Document Server Settings, press the General Features tab, and then press Copy Quality.




Mode	Function
Text	Best reproduction of text and sharp lines. Ignores background texture. (☛ p.2-12 Text Mode)
Text/Photo	Good reproduction of mixed text and photographs with accurate grayscaling, better than that achieved in the Text mode. (☛ p.2-14 Text/Photo Mode)
Photo	Best possible reproduction of photographs. (☛ p.2-13 Photo Mode)
Pale	Reproduction similar to text mode, but of lower contrast. Ideal for copying thin originals. (☛ p.2-15 Pale Mode)
Generation Copy	Attempts to achieve the best reproduction of copied originals that are faded because they are copies of copies. (☛ p.2-16 Generation Copy)

In addition, there are two main image processing modes: grayscale processing and binary picture processing. When the optional hard disk has not been installed, the machine uses binary picture processing. However, when the optional hard disk has been installed, the machine uses grayscale processing. The user or technician cannot select the mode.

Image Processing Path

Overview

This diagram shows the various stages of the image process and where they are done.



Detailed Descriptions

SP Modes for Each Image Processing Step

The following tables show which settings and SP modes are used for each image processing step.

Text Mode

		Text Mode			
		Soft	Normal	Sharp	Custom Setting
ADS (SBU)		As selected at the operation panel			
Shading Correction	~34%	Enabled			
	35%~				
Small Smoothing Filter	~34%	Three-line filter			
	35%~	One-line filter			
Main Scan Magnification	~34%	Enabled			
	35%~				
Mirroring	~34%	Enabled only in the ADF mode			
	35%~				
Characteristic Detection	~34%	None			
	35%~	Weak	Middle	Strong	4-903-2 ~ 4
MTF/Smoothing Filter	~34%	MTF (Weak)	MTF (Medium)	MTF (Strong)	4-903-1
	35%~	Character (Weak)	Character (Medium)	Character (Strong)	4-903-2 ~ 4
Independent Dot Erase	~34%	None			4-904-1
	35%~	None			
Background Erase	~34%	None			4-904-6
	35%~	None			
γ Correction	~34%	Text			4-904-11
	35%~	Character (Text)			
Gradation	~34%	Normal error diffusion		Binary picture processing	4-903-1
	35%~	Character error diffusion		Binary picture processing	4-903-2 ~ 4
Line Width Correction	~34%	2-907-1			
	35%~				

Photo Mode

		Photo Mode			
		Coarse Print	Print Photo	Glossy Photo	Custom Setting
ADS (SBU)		As selected at the operation panel			
Shading Correction	~34%	Enabled			
	35%~				
Small Smoothing Filter	~34%	Three-line filter			
	35%~	One-line filter			
Main Scan Magnification	~34%	Enabled			
	35%~				
Mirroring	~34%	Enabled only in the ADF mode			
	35%~				
Characteristic Detection	~34%	None			
	35%~	None			4-903-6 ~ 8
MTF/Smoothing Filter	~34%	Character	Smoothing		4-903-5
	35%~	Smoothing		Character	4-903-6 ~ 8
Independent Dot Erase	~34%	None			4-904-2
	35%~	None			
Background Erase	~34%	None			4-904-7
	35%~	None			
γ Correction	~34%	Dither (16x16)	Dither (8x8)	Dither (Character)	4-904-12
	35%~				
Gradation	~34%	Dither (16x16)	Dither (8x8)	Normal error diffusion	4-903-5
	35%~			Character error diffusion	4-903-6 ~ 8
Line Width Correction	~34%	2-907-2			
	35%~				

Detailed Descriptions

Text/Photo Mode

		Text/Photo Mode			
		Photo Priority	Normal	Text Priority	Custom Setting
ADS (SBU)		As selected at the operation panel			
Shading Correction	~34%	Enabled			
	35%~				
Small Smoothing Filter	~34%	Three-line filter			
	35%~	One-line filter			
Main Scan Magnification	~34%	Enabled			
	35%~				
Mirroring	~34%	Enabled only in the ADF mode			
	35%~				
Characteristic Detection	~34%	None			
	35%~	Strong	Middle	Weak	4-903-10 ~ 12
MTF/Smoothing Filter	~34%	MTF (Weak)	MTF (Medium)	MTF (Strong)	4-903-9
	35%~	Character (Weak)	Character (Medium)	Character (Strong)	4-903-10 ~ 12
Independent Dot Erase	~34%	None			4-904-3
	35%~	None			
Background Erase	~34%	None			4-904-8
	35%~	None			
γ Correction	~34%	Text/Photo			4-904-13
	35%~	Character (Text/Photo)			
Gradation	~34%	Normal error diffusion			
	35%~	Character error diffusion			
Line Width Correction	~34%	2-907-3			
	35%~				

Pale Mode

		Pale Mode			
		Photo Priority	Normal	Text Priority	Custom Setting
ADS (SBU)		As selected at the operation panel			
Shading Correction	~34%	Enabled			
	35%~				
Small Smoothing Filter	~34%	Three-line filter			
	35%~	One-line filter			
Main Scan Magnification	~34%	Enabled			
	35%~				
Mirroring	~34%	Enabled only in the ADF mode			
	35%~				
Characteristic Detection	~34%	None			
	35%~	Weak	Middle	Strong	4-903-14 ~ 16
MTF/Smoothing Filter	~34%	MTF (Weak)	MTF (Medium)	MTF (Strong)	4-903-13
	35%~	Character (Weak)	Character (Medium)	Character (Strong)	4-903-14 ~ 16
Independent Dot Erase	~34%	None			4-904-4
	35%~	None			
Background Erase	~34%	None			4-904-9
	35%~	None			
γ Correction	~34%	Pale			4-904-14
	35%~	Character (Pale)			
Gradation	~34%	Normal error diffusion			
	35%~	Character error diffusion			
Line Width Correction	~34%	2-907-4			
	35%~				

Detailed Descriptions

Generation Copy

		Generation Copy Mode			
		Photo Priority	Normal	Text Priority	Custom Setting
ADS (SBU)		As selected at the operation panel			
Shading Correction	~34%	Enabled			
	35%~				
Small Smoothing Filter	~34%	Three-line filter			
	35%~	One-line filter			
Main Scan Magnification	~34%	Enabled			
	35%~				
Mirroring	~34%	Enabled only in the ADF mode			
	35%~				
Characteristic Detection	~34%	None			
	35%~	Weak	Middle	Strong	4-903-18 ~ 20
MTF/Smoothing Filter	~34%	MTF (Weak)	MTF (Medium)	MTF (Strong)	4-903-17
	35%~	Character (Weak)	Character (Medium)	Character (Strong)	4-903-18 ~ 20
Independent Dot Erase	~34%	Weak			4-904-5
	35%~	Weak			
Background Erase	~34%	Weak			4-904-10
	35%~	Weak			
γ Correction	~34%	Generation copy			4-904-15
	35%~	Character (Generation copy)			
Gradation	~34%	Normal error diffusion			
	35%~	Character error diffusion			
Line Width Correction	~34%	2-907-5			
	35%~				

Auto Shading

Auto shading does two things.

- Zeroes the black level for each scan line of data.
- Corrects for variations in white level across the main scan.


Pre-Filtering

Pre-filter smoothes mainly parallel lines in the main scan direction and extended lines in the sub-scan direction. This reduces moiré and spurious noise in images.

Main Scan Magnification/Reduction

Changing the scanner speed enables reduction and enlargement in the sub-scan direction. However, the IPU-A chip handles reduction and enlargement in the main scan direction. The processing for main scan magnification/reduction is the same as in the previous digital machines.

Mirroring for ADF Mode



When making a copy using the ADF, the magnification circuit creates a mirror image. This is because the scanning starting position in the main scan direction is at the other end of the scan line in ADF mode (compared with platen mode). In platen mode, the original is placed face down on the exposure glass, and the corner at [A] is at the start of the main scan. The scanner moves down the page. In ADF mode, the ADF feeds the leading edge of the original to the DF exposure glass, and the opposite top corner of the original is at the main scan start position.

To create the mirror image, the IPU-A stores each line in a LIFO (Last In First Out) memory.

Characteristic Detection

This function uses software filters to detect edge areas, non-edge areas, and areas of shaded dot patterns.

The result determines the image processing that will be applied to each pixel.

Filtering

Overview

There are some software filters for enhancing the desired image qualities of the selected original mode. These filters are the MTF filter, the smoothing filter, characteristic filter, and independent dot erase.

Depending on the original mode and the reproduction ratio, the machine will use either MTF/smoothing, or the filter determined by characteristic detection.

If MTF/smoothing is used, it is applied to all areas of the original, regardless of whether they are edge areas, non-edge areas, or independent dots.

- The MTF filter emphasizes sharpness and is used in all original types except Photo mode.
- The smoothing filter is used in Photo mode.

If the characteristic filter is used, the filter for each pixel depends on the image data type that was detected by characteristic detection.

MTF Filter

An MTF filter is used for all original types except Photo mode.

When the reproduction ratio is less than 35%, this filter is applied to all image data pixels, regardless of whether they are in an edge area or non-edge area.

When the reproduction ratio is 35% or more, the type of MTF filter used for each pixel depends on the results of characteristic detection.

Smoothing Filter

A smoothing filter is used in Photo mode instead of MTF. It is applied to all image data pixels, regardless of whether they are in an edge area or non-edge area.

With some combinations of reproduction ratio and image mode, the type of smoothing used for each pixel depends on the results of characteristic detection (see the Photo mode table in SP Modes for Each Processing Step).

Characteristic Filter

A characteristic filter is applied instead of MTF, smoothing, and ID gamma correction with some combinations of original type and reproduction ratio. See the 'SP Modes for Each Processing Step' section.

For example, In text mode, for the 'Normal' original type, if the reproduction ratio is less than 35%, MTF (medium) is used for all pixels in the image. However, if the reproduction ratio is 35% or more, the 'medium' characteristic filter is used, and the processing depends on whether the pixel was in an edge area, a non-edge area, or in an area shaded using a dot pattern.

Each characteristic filter consists of a combination of the following features: MTF, smoothing, error diffusion, dithering, ID gamma correction. For each of these features, the machine chooses from two types when making up a characteristic filter.

Independent Dot Erase

Independent dot erase removes unwanted dots from the image.

Independent dot erase is enabled only for Generation Copy mode (according to the default settings). However, for the “Custom Setting” original modes, independent dot detection can be enabled and adjusted with SP4-904-2~4. With a larger SP setting, more dots are detected as independent dots and erased, even if the dot density is high. However, dots in mesh-like images may be mistakenly detected as independent dots.

Background Erase

By default, this process is disabled in all original modes. However, it can be enabled with SP mode.

Usually, dirty background is erased using the Auto Image Density (ADS) function. However, sometimes, dirty background areas will still appear. These can be erased with this function.

The threshold level for erasing can be changed with SP4-904-6~10.

ID Gamma (γ) Correction

The machine automatically selects the most appropriate ID gamma correction based on the selected original type.

Also, for certain combinations of reproduction ratio and original type, characteristic detection is used. In this case, the machine can use one of two gamma correction tables. The one that is used is decided separately for each pixel, and depends on the results of characteristic detection.

Gradation Processing

Overview

There are four types of gradation processing:

- Grayscale processing: This has 4 output levels for each pixel.
- Binary picture processing: This has only two output levels (black and white).
- Error diffusion: There are two error diffusion processing types (normal and characteristic detection)
- Dithering: There are two dithering processing types (normal and characteristic detection).

Grayscale Processing

In this machine, the 8-bit image data is converted into 2-bit data. This produces up to 4 image density levels for each pixel.

To realize this, this machine uses a form of pulse width modulation. In this machine, pulse width modulation consists of the following processes:

- Laser diode pulse positioning
- Laser diode power/pulse width modulation

Laser diode power and pulse width modulation is done by the laser diode drive board (LDD). Briefly, the width of the laser pulse for a pixel depends on the output level (image density level: from 0 to 255) required for the pixel.

Note that although the LDD can create 256 levels per pixel, the machine only uses 8 of these, and only four are used for any one job. A gamma table determines which four output levels are used. The gamma table is different for each original type setting.

Binary Picture Processing

The 8-bit image data is converted into 1-bit data (black and white image data).

Error Diffusion

The error diffusion process reduces the difference in contrast between light and dark areas of a halftone image. Each pixel is corrected using the difference between it and the surrounding pixels. The corrected pixels are compared with an error diffusion matrix.

There are two types of error diffusion processing: One is 'normal'. The other is part of the characteristic detection process, in which the error diffusion method is determined separately for each pixel. The error diffusion type (normal or characteristic) depends on the reproduction ratio and the original type (refer to the SP Modes for Each Image Processing Step tables).

Dithering

Each pixel is compared with the pixel in the same position in a dither matrix. Several matrixes are available, to increase or decrease the detail on the copy.

Line width correction

This function is effective in all original modes.

Usually, lines will bulge in the main scan direction as a result of the negative/positive development system that is used in this model. So, pixels on edges between black and white areas are compared with adjacent pixels, and if the pixel is on a line, the line thickness will be reduced.


Line width correction is done in the VCU chip on the LDD board.

The line width correction type can be selected with SP2-907.

2.3.5 VIDEO CONTROL UNIT (VCU)

Fine Character and Image (FCI)

The FCI circuit performs image smoothing.



Detailed Descriptions


Usually, binary picture processing generates jagged edges on characters, as shown in the above illustration. These are reduced using edge smoothing. The FCI changes the laser pulse duration and position for certain pixels.

Fig. A shows the four possible pulse durations, and Fig. B shows how the laser pulse can be in one of three positions within the pixel. Fig. C shows an example of how edge smoothing is used.

This function only affects the received image for fax mode and for printer mode, even if copy mode is also using binary picture processing.

2.4 LASER EXPOSURE

2.4.1 OVERVIEW



The optical path from the laser diode to the drum is shown above.


The LD unit [A] outputs a laser beam to the polygon mirror [B] through the cylindrical lens [C]. The shield glass [D] prevents dust from reaching the polygon mirror.

Each surface of the polygon mirror reflects one full main scan line. The laser beam goes to the F-theta mirror [E], mirror [F], and BTL (barrel toroidal lens) [G]. Then the laser beam goes to the drum through the toner shield glass [H].

The laser synchronizing detector [I] determines the main scan starting position.

The speed of the polygon mirror motor is 28,818.9 rpm for 600 dpi.

2.4.2 AUTO POWER CONTROL (APC)




The LD driver IC drives the laser diode. To prevent the intensity of the laser beam from changing because of the temperature, the machine monitors the current passing through the laser diode (LD). The machine adjusts the current to the laser diode by comparing it with the reference level from the reference circuit. This auto power control is done just after the machine is turned on and during printing while the laser diode is active.

The laser diode power is adjusted on the production line.

NOTE: Do not touch the variable resistors on the LD unit in the field.

2.4.3 LD SAFETY SWITCH




To ensure technician and user safety and to prevent the laser beam from inadvertently switching on during servicing, safety switches are located at the front and right covers. The switches are installed on the +5VLD line coming from the power supply unit through the SBCU and IPU boards.

When the front cover or the right cover is opened, the power supply to the laser diode is interrupted.

2.5 PHOTOCONDUCTOR UNIT (PCU)

2.5.1 OVERVIEW



The PCU consists of the components shown in the above illustration. An organic photoconductor (OPC) drum (diameter: 30 mm) is used in this machine.

- | | |
|--------------------------|----------------------------------|
| 1. Cleaning Blade | 6. Development Roller |
| 2. Toner Collection Coil | 7. Development Unit |
| 3. Pick-off Pawl | 8. Charge Roller |
| 4. OPC Drum | 9. Charge Roller Cleaning Roller |
| 5. ID Sensor (see note) | 10. Quenching Lamp (see note) |


NOTE: These parts are not included in the PCU.

The machine informs the user when the PCU life has finished. However, the user can continue to make copies.

SP5-912 can be used to enable or disable this warning message, and to change the default replacement interval (the default is 60k).

PHOTOCONDUCTOR UNIT (PCU)


2.5.2 DRIVE



The main motor [A] drives the drum [B] through a series of gears, a timing belt [C], and the drum drive shaft [D]. The main motor assembly includes a drive controller, which outputs a motor lock signal when the rotation speed is out of the specified range.

The fly-wheel [E] on the end of the drum drive shaft stabilizes the rotation speed (this prevents banding and jitter from appearing on copies).

2.5.3 NEW PCU DETECTION



The new PCU detect switch [A] detects when a new PCU is installed. Each PCU has an actuator [B]. When a new PCU is installed in the machine, the actuator [B] pushes the new PCU detect switch. The actuator is a sector gear, and this gear engages with the drum gear [C]. When the drum rotates, the actuator is released from the drum gear. The actuator drops away from the new PCU detect switch and remains in this "down" position for the duration of the PCU's life.


The machine recognizes when a new PCU has been installed in the machine because the actuator of the new PCU contacts the new PCU detect switch. After the front cover and right cover are closed, the machine then performs the TD sensor initial setting procedure automatically (for about 45 seconds). During this time, the drum rotates and the actuator drops away from the sensor.

Also, while the machine performs the TD sensor initial setting, the machine makes a ID sensor pattern on the drum. This checks whether the developer has fallen into the development unit (in other words, it checks whether the technician remembered to remove the developer seal from the PCU at machine installation). If the machine does not detect the ID sensor pattern, SC 392 will be generated.

DRUM CHARGE

2.6 DRUM CHARGE

2.6.1 OVERVIEW




This copier uses a drum charge roller to charge the drum. The drum charge roller [A] always contacts the surface of the drum [B] to give it a negative charge of -900V.

The high voltage supply board gives a negative dc voltage to the drum charge roller through the spring [C] and terminal plate [D].

2.6.1 CHARGE ROLLER VOLTAGE CORRECTION

Correction for Environmental Conditions



Detailed Descriptions

With a drum charge roller system, the voltage transferred from roller to drum varies with the temperature and humidity around the drum charge roller. The lower the temperature or humidity is, the higher the applied voltage required.

To compensate, the machine uses the ID sensor to measure the effects of current environmental conditions. For this measurement, the process control parameters are balanced so that any small change in drum potential caused by environmental effects is reflected in a change in the amount of toner transferred to the drum.

This measurement is made immediately after the ID sensor pattern for toner density control. Immediately after making ID sensor pattern [A], the charge roller voltage stays on, but the development bias goes up to -650V; as a result the drum potential is reduced to -750V. The laser diode is not switched on, and the drum potential is now slightly higher than the development bias, so only a very small amount of toner transfers to the drum. The ID sensor measures the density of this pattern [B], and the output voltage is known as V_{sdp} . This voltage is compared with V_{sg} (read from the bare drum at the same time).

DRUM CHARGE

If the humidity drops, the drum potential goes up (to a higher –ve voltage) even if the charge roller voltage supply stays the same (efficiency of voltage transfer is higher with lower humidity). As a result, less toner is transferred to ID sensor pattern [B]. If the sensor output reaches a certain point, the drum charge voltage will be reduced.

To determine whether to change the drum charge roller voltage, the machine compares V_{sdp} with V_{sg} .


- $V_{sdp} / V_{sg} > 0.95$ = Reduce the magnitude of the drum charge voltage by 50 V
- $V_{sdp} / V_{sg} < 0.90$ = Increase the magnitude of the drum charge voltage by 50 V

2.6.2 ID SENSOR PATTERN PRODUCTION TIMING

The ID sensor pattern is made in the following conditions:

- During warming up at power on
- If the machine starts warming up after a certain time (default: 30 minutes) has passed since entering night mode or low power mode
The 30-minute interval can be changed using SP2995-1.
- At the end of a job, if an ID sensor pattern has not been made for a certain number of sheets (default: 0 sheets = disabled)
The number of sheets can be changed using SP2995-2.


2.6.3 DRUM CHARGE ROLLER CLEANING



Because the drum charge roller [A] always contacts the drum, it gets dirty easily. So, the charge roller cleaning roller [B] also contacts the drum charge roller all the time to clean the surface of the drum charge roller.

2.7 DEVELOPMENT

2.7.1 OVERVIEW




The development unit consists of the following parts.

- | | |
|-----------------------|-------------------|
| 1. Development roller | 4. Mixing auger 1 |
| 2. Mixing auger 2 | 5. Doctor blade |
| 3. TD sensor | |

This machine uses a single-roller development system. Two mixing augers mix the developer. The toner density (TD) sensor and image density (ID) sensor (see the illustration in the PCU section) are used to control toner density.

2.7.2 DRIVE




The main motor [A] drives the development roller [B] and mixing augers [C] through a train of gears and the development drive shaft [D]. When the PCU is pushed in, the development drive shaft engages the development roller gear.

The development drive gears (except for the gears in the development unit) are helical gears. These gears are quieter than normal gears.


DEVELOPMENT

2.7.3 DEVELOPER MIXING



This copier uses 2 mixing augers, [A] and [B], to keep the developer evenly mixed. Mixing auger 2 [A] transports excess developer, scraped off the development roller [C] by the doctor blade [D], towards the front of the machine. Mixing auger 1 [B] returns the excess developer, along with new toner, to the rear of the mixing assembly. Here the developer is reapplied to the development roller.

2.7.4 DEVELOPMENT BIAS




This machine uses a negative-positive development system, in which black areas of the latent image are at a low negative charge (about -150 ± 50 V) and white areas are at a high negative charge (about -950 V).

To attract negatively charged toner to the black areas of the latent image on the drum, the high voltage supply board applies a bias of -650 volts to the development rollers throughout the image development process. The bias is applied to the development roller shaft [A] through the drive shaft [B].

The development bias voltage (-650 V) can be adjusted with SP2-201-1.

2.7.5 TONER SUPPLY

Toner bottle replenishment mechanism




When a toner bottle is placed in the bottle holder unit [A] and the unit is pushed in completely, pin [B] moves against the side [C] of the PCU, and the toner shutter [D] is pulled out to open the bottle. When the toner bottle holder lever [E] is put back in the original position, the cap [F] on the toner bottle is pulled away and kept in place by the chuck [G].

The toner supply mechanism transports toner from the bottle to the development unit. The toner bottle has a spiral groove [H] that helps move toner to the development unit.

When the bottle holder unit is pulled out to add a new toner bottle, the following happens automatically to prevent toner from scattering.

- The chuck releases the toner bottle cap into its proper position.
- The toner shutter shuts to block the opening as a result of pressure from a spring.

Toner supply mechanismDetailed
Descriptions


The toner supply motor [A] drives the toner bottle [B] and the mylar blades [C]. First, the toner falls down into the toner bottle holder. The toner supply mylar blades transfer the toner to the slit [D]. When the PCU is installed in the machine, the shutter [E] above the PCU is opened by the machine frame. Then the toner falls down into the development unit through the slit and the shutter.

2.7.6 TONER DENSITY CONTROL

Overview

There are four modes for controlling toner supply as shown in the following tables. The mode can be changed with by SP2-921. The factory setting is sensor control 1 mode.

Basically, toner density is controlled using the standard TD sensor voltage (V_t), toner supply reference voltage (V_{ref}), actual TD sensor output voltage (V_t), and ID sensor output data (V_{sp}/V_{sg}).



There are four toner density control modes as follows.

Mode	Sensor control 1 (SP2-921, "0"): Normally use this setting only
Toner supply decision	Compare V_t with a reference voltage (V_{ts} or V_{ref})
Toner control process	Toner is supplied to the development unit when V_t is higher than the reference voltage (V_{ts} or V_{ref}). This mode keeps the V_{ref} value for use the next toner density control. V_{ts} is used for the first toner density control after a new PCU has been installed, until it has been corrected with the ID sensor output. V_{ref} is used after V_{ts} has been corrected with the ID sensor output voltage (corrected during the first toner density control for a new PCU).
Toner supply amount	Varies
Toner end detection	Performed

Mode	Sensor control 2 (SP2-921, "1"): For designer's use only; do not use in the field
Toner supply decision	Compare V_t with a reference voltage (V_{ts})
Toner control process	This toner control process is the same as sensor control 1 mode. However, the reference voltage used is always V_{ts} .
Toner supply amount	Varies
Toner end detection	Performed

Mode	Fixed control 1 (SP2-921, "2"): For designer's use only; do not use in the field
Toner supply decision	Compare V_t with a reference voltage (V_{ts} or V_{ref})
Toner control process	This toner control process is the same as sensor control 1 mode.
Toner supply amount	Fixed (SP2-925)
Toner end detection	Performed

Mode	Fixed control 2 (SP2-921, "3"): Use temporarily if the TD sensor needs to be replaced
Toner supply decision	None
Toner control process	Toner is supplied every printed page regardless of V_t .
Toner supply amount	Fixed (SP2-925)
Toner end detection	Not performed

Toner density sensor initial setting

The TD sensor initial setting procedure is performed automatically when the new PCU is installed in the machine. During TD sensor initial setting, the TD sensor is set so that the TD sensor output to the value of SP2-926 (default: 2.5V). This value will be used as the standard reference voltage (V_{ts}) of the TD sensor.

Toner density measurement

Toner density in the developer is detected once every copy cycle. The sensor output voltage (V_t) during the detection cycle is compared with the standard reference voltage (V_{ts}) or the toner supply reference voltage (V_{ref}).

V_{sp}/V_{sg} detection

The ID sensor detects the following voltages.

- V_{sg} : The ID sensor output when checking the drum surface
- V_{sp} : The ID sensor output when checking the ID sensor pattern
- At the end of a job, if an ID sensor pattern has not been made for a certain number of sheets (default: 0 sheets = disabled)
The number of sheets can be changed using SP2-995-2.

In this way, the reflectivity of both the drum surface and the pattern on the drum are checked. This compensates for any variations in the reflectivity of the pattern on the drum or the reflectivity of the drum surface.

The ID sensor pattern is made on the drum by charge roller and laser diode.

V_{sp}/V_{sg} is not detected every page or job; it is detected at the following times to decide V_{ref} .

- During warming up at power on
- If the machine starts warming up after a certain time (default: 30 minutes) has passed since entering night mode or low power mode

The 30-minute interval can be changed using SP2-995.

Toner supply reference voltage (V_{ref}) determination

The toner supply reference voltage (V_{ref}) is the threshold voltage for the toner supply determination. V_{ref} is determined using the following data:

- ID sensor output (V_{sp}/V_{sg})
- (V_{ts} or the current V_{ref}) - V_t

Toner supply determination

The reference voltage (V_{ts} or V_{ref}) is the threshold voltage for determining whether or not to supply toner. If V_t becomes greater than the reference voltage, the machine supplies additional toner.

Toner Supply Motor On Time Determinations

For fixed control mode, the toner supply motor on time is specified by the setting of SP2-925, and does not vary. The default setting is 200 ms for each copy. The toner supply motor on time for each value of SP2-925 is as follows.

Value of SP2-925	Motor On Time (t = 200 ms)
0	t
1	2t
2	4t
3	8t
4	12t
5	16t
6	Continuously
7	Not supplied

For sensor control modes 1 and 2, the toner supply motor on time is decided by the following factors.

- ΔVt (= $Vt - (Vref \text{ or } Vts)$)
- TD sensor sensitivity (coefficient: S, value is 0.3)

There are seven levels for toner supply motor on time as shown below.

Level	Decision	Motor On Time (seconds)
1	$0 < \Delta Vt \leq S/16$	t (0.6)
2	$S/16 < \Delta Vt \leq S/8$	t x 2 (1.2)
3	$S/8 < \Delta Vt \leq S/4$	t x 4 (2.4)
4	$S/4 < \Delta Vt \leq S/2$	t x 8 (4.8)
5	$S/2 < \Delta Vt \leq 4S/5$	t x 16 (9.6)
6	$4S/5 < \Delta Vt \leq S$ (near-end)	T (30); see note 3
7	$S < \Delta Vt$ (toner end)	T (30); see note 3

- NOTE:**
- 1) The value of "t" can be changed using SP2-922 (default: 0.6 second)
 - 2) The value of "T" can be changed using SP2-923 (default: 30 seconds)
 - 3) T (30) means that toner is supplied intermittently in a half duty cycle (1.5 s on, 1.5 s off) for 30 seconds

2.7.7 TONER SUPPLY IN ABNORMAL SENSOR CONDITIONS

ID sensor

Readings are abnormal if any of the following conditions occur:

- $V_{sg} \leq 2.5V$
- $V_{sg} < 3.5V$ when maximum power (254) is applied
- $V_{sp} \geq 2.5V$
- $(V_{sg} - V_{sp}) < 1.0V$
- ID sensor power required to make the standard output reaches the maximum value (254)

The above ID sensor values can be checked using SP2-220.

When this is detected, the machine changes the value of V_{ref} to the previous value then does the toner density control process (in a similar way to sensor control mode 2).

No SC code is generated if the ID sensor is defective.

TD Sensor

The TD sensor is checked every copy. If the readings from TD sensor become abnormal, the machine changes the toner density control mode to fixed supply mode 2, and the toner supply amount per page is always 200 ms, regardless of the value of SP2-925. Then at the end of a job (if the optional fax unit is installed), or 100 copies after the TD sensor error was detected (if no fax unit is installed), an SC code is generated (SC390) and the machine must be repaired. The 100-copy threshold can be adjusted with SP 2-992.

2.7.8 TONER NEAR END/END DETECTION AND RECOVERY

The toner near end and end conditions are detected using the V_t and V_{ref} values, in a similar way to toner density control.

This is done in all toner supply modes except for fixed mode 2, when toner end is not detected.

Toner Near End Detection

If V_t is at level 6 (see the table on the previous page) five times consecutively, the machine enters the toner near end condition and the toner end indicator starts blinking. Then the machine supplies toner for a certain time, which depends on the setting of SP 2-923 (see the previous page).

Toner Near End Recovery

If the machine detects " $S/2 < \Delta Vt \leq 4S/5$ " twice consecutively when in one of the following situations, the machine leaves the toner near end condition.

- While in the toner recovery cycle (supplying toner on and off for 30 s – see the previous page) after the machine has detected a toner near end condition.
- During copying in the toner near end condition.
- If the front cover is opened and closed for more than 10 seconds while a toner near end condition exists.

Toner End Detection

There are two situations for entering the toner end condition.


- When Vt is level 7 three times consecutively, the machine enters the toner end condition.
- When " $4S/5 < \Delta Vt \leq S$ " is detected in the toner near end condition, then 50 copies can be made after this condition (the number of copies between this condition and toner end can be changed using SP2-213).

Toner End Recovery

If the front cover is opened and closed for 10 seconds while a toner end condition exists and the toner bottle is replaced, the machine attempts to recover using the same procedure as for toner near end/end detection.

2.8 DRUM CLEANING AND TONER RECYCLING

2.8.1 DRUM CLEANING




The cleaning blade [A] removes any toner remaining on the drum after the image is transferred to the paper. This model uses a counter blade system.

The cleaning blade scrapes off toner remaining on the drum. When toner builds up in the cleaning unit, toner at the top of the pile is removed by the toner collection coil [B].

To remove the toner and other particles that are accumulated at the edge of the cleaning blade, the drum turns in reverse for about 5 mm at the end of every copy job. This feature is controlled with SP 2-998.

In addition, cleaning is done in the middle of a job if 100 sheets have been made since the previous cleaning. This feature is controlled with SP 2-211.

2.8.2 TONER RECYCLING




Detailed Descriptions

Toner picked up by the toner collection coil [A], is transported to the opening [B] in the side of the PCU. Then, this toner falls into the development unit with new toner coming from the toner bottle and it is all mixed together by mixing auger 1 [C] and used again.

2.9 PAPER FEED

2.9.1 OVERVIEW



There are two paper trays, each of which can hold 500 sheets.


The paper tray feed stations use a friction pad system.

The two relay sensors are used for paper jam detection.

The components of the paper feed station are as follows.

- | | |
|---------------------------|--------------------------|
| 1. Paper Lift Sensor | 7. Upper Relay Sensor |
| 2. Paper Height –1 Sensor | 8. Upper Relay Roller |
| 3. Paper Height –2 Sensor | 9. Lower Relay Roller |
| 4. Paper End Sensor | 10. Lower Relay Sensor |
| 5. Paper Feed Roller | 11. Friction Pad |
| 6. Paper Size Sensor | 12. Tray Heater (Option) |

2.9.2 PAPER FEED DRIVE MECHANISM




The main motor [A] drives the pick-up and feed mechanism of both the first and second paper trays. The paper feed clutches [B] transfer drive from this motor to the paper feed rollers [C].

When the paper feed clutch turns on, the feed rollers start to feed the paper. The paper feed clutch stays on until shortly after the registration sensor [D] has been activated.

PAPER FEED


2.9.3 PAPER FEED AND SEPARATION MECHANISM



The paper feed roller [A] drives the top sheet of paper from the paper tray to the copier. The friction pad [B] allows only one sheet to feed at a time. The friction pad applies pressure to the feed roller with a spring [C].

The friction pad pressure cannot be adjusted.

2.9.4 PAPER LIFT MECHANISM



The paper size switch detects when the tray is pushed in.

When the paper tray is pushed into the machine, the pin [A] for the lift motor pressure shaft engages the lift motor coupling [B] and the pin [C] for the bottom plate lift shaft in the tray engages the bottom plate pressure lever coupling [D]. The pin [E] on the rear of the tray pushes the lock lever so that the lift motor can lift the bottom plate pressure lever.

The lift motor turns on, and turns clockwise as shown in the diagram. The main pressure spring [K] pulls the bottom plate pressure lever, and this lifts the tray bottom plate.

When the top of the stack touches the feed roller, the motor cannot pull up the plate any more, so it pulls the actuator [G] into the lift sensor [F]. Then the lift motor stops. The pressure of the feed roller on the paper is now too high, so the lift motor reverses a certain time (200 ms or 600 ms), depending on the paper size, to reduce this pressure. For smaller paper, it reverses the larger amount (600 ms) to reduce the pressure more.


NOTE: The relationship between the bottom plate pressure adjustment, paper size thresholds, and the related SP modes is explained in “Bottom Plate Pressure Adjustment for Paper Size”.

PAPER FEED

For A4-width paper or wider, a projection [H] on the side fence engages the secondary pressure spring [J] through a lever [I]. Then, the secondary pressure spring [J] applies paper feed pressure in addition to the main pressure spring [K], to ensure that extra pressure is applied to wider paper.

When the paper tray is pulled out, the pins [A, C] disengage from the couplings [B, D], and the bottom plate drops. To make it easier to push the tray in, the lift motor rotates backwards 1.7 seconds to return the bottom plate pressure lever coupling [D] to the original position. The amount of reverse can be adjusted with SP 1-912.

2.9.5 PAPER END DETECTION




If there is some paper in the paper tray, the paper stack raises the paper end feeler [A] and the paper end sensor [B] is deactivated.

When the paper tray runs out of paper, the paper end feeler drops into the cutout [C] in the tray bottom plate and the paper end sensor is activated.

When the paper tray is drawn out with no paper in the tray, the shape of the paper end feeler causes it to lift up.

2.9.6 PAPER HEIGHT DETECTION



The amount of paper in the tray is detected by the combination of on/off signals from two paper height sensors [A] and [B]. The paper amount is displayed on the LCD.

When the amount of paper decreases, the bottom plate pressure lever [C] moves the actuator up.

The following combination of sensor signals is sent to the copier.

Amount of Paper	Paper Height Sensor 1	Paper Height Sensor 2
Near End	OFF	ON
30%	ON	ON
70%	ON	OFF
100%	OFF	OFF

When the tray contains paper of a small width, the paper feed pressure may become too low when the thickness of the remaining stack of paper has decreased. The lift motor rotates forward 400 ms after the sensor detects a certain amount of paper remaining in the tray to increase paper feed pressure, simulating the pressure generated by a full tray.

NOTE: The relationship between the bottom plate re-adjustment timing, paper size threshold, and the related SP modes is explained in “Bottom Plate Pressure Adjustment for Paper Size”.

2.9.7 FEED PRESSURE ADJUSTMENT FOR PAPER SIZE

Overview

For the friction pad system, the pressure from the top of the stack against the feed roller is very important for paper feed quality from the paper tray. If the pressure is high, double feed may occur. On the other hand, if the pressure is low, non-feed may occur. Because of this, the pressure must be varied depending on the paper size, paper weight, and amount of paper remaining in the tray. To achieve this, the pressure for each paper tray can be adjusted using SP mode.

Paper Size Thresholds

The upward pressure from the bottom plate spring is always the same. However, downward pressure from the stack on the bottom plate depends on the paper size. Because of this, for a smaller paper size, the pressure of the top of the stack against the feed roller is more than normal (because of the smaller downward pressure from the stack), so adjustment may be necessary.

Using the following SP modes, either two or three paper size ranges can be specified. Using other SP modes (explained later), the pressure can be adjusted separately for each of these ranges to deal with any feed problems that have been occurring.

Paper Size	Normal	Small Size	Middle Size
	Greater than HLT/A5 (default setting)	HLT/A5 or smaller (default setting)	None (default setting)
1st paper tray	---	SP1908-8	SP1908-9
2nd paper tray	---	SP1909-8	SP1909-9
3rd paper tray	---	SP1910-8	SP1910-9
4th paper tray	---	SP1911-8	SP1911-9

Paper Size Ranges

For Three Size Ranges

Small paper size range: Paper sizes equal to the 'Small' SP mode value, or smaller.

Middle paper size range: Paper sizes greater than the small paper size, up to and including the middle paper size specified by the 'Middle' SP mode.

Normal paper size range: Paper sizes greater than the 'Middle' SP mode.

For Two Size Ranges


Small paper size range: Paper sizes equal to the 'Small' SP mode value, or smaller.

Normal paper size range: Paper sizes greater than the 'Small' SP mode.

Feed Pressure Adjustment

The pressure can be adjusted to solve a paper feed problem. This adjusts the amount of lift motor reverse just after the lift sensor is activated when lifting the stack to the paper feed position. To apply less pressure to the top of the stack, the amount of reverse should be increased.

Effect of the Amount of Remaining Paper



Detailed Descriptions

From tray full to paper near-end

The pressure between the top of the stack and the fed roller also depends on the amount of remaining paper, especially for small paper sizes, as shown in the above graph. The pressure for A5 changes significantly between stack heights of 500 sheets and 50 sheets, but not much for A4 or A3 paper.

For 500 sheets of A5, the pressure is too high. To counter this, the lift motor reverses 600 ms (① in the graph), as explained in the previous section. The SP modes in the following table are for solving feed problems that occur when the tray is between full and near-end.

Paper Size	Normal	Small Size	Middle Size
	Greater than HLT/A5 (default setting)	HLT/A5 or smaller (default setting)	None (default setting)
1st paper tray	SP1908-1	SP1908-2	SP1908-3
2nd paper tray	SP1909-1	SP1909-2	SP1909-3
3rd paper tray	SP1910-1	SP1910-2	SP1910-3
4th paper tray	SP1911-1	SP1911-2	SP1911-3
Default (all trays)	200 ms	600 ms	200 ms (default: not used)

PAPER FEED

From paper near end to paper end

When paper is used up, the pressure on the bottom plate reduces, so the upward pressure increases, causing the pressure of the feed roller against the top of the stack to increase.

However, for small paper sizes, because of the previous correction (600 ms reverse rotation of the lift motor), the pressure between the feed roller and the top of the stack becomes too small at some point as paper is used up, and this could cause paper feed problems. This condition is more significant for smaller paper sizes, such as A5, as shown in the diagram.

If a paper feed problem occurs when the stack is partly used up, the pressure can be re-adjusted (② in the graph) using the following SP modes. The default is set for 50 sheets (at the near-end point)

The lift motor rotates forward for the time specified by the SP mode to increase the pressure.

Paper Size	Small Size	Middle Size
	HLT/A5 or smaller (default setting)	None (default setting)
1st paper tray	SP1908-4	SP1908-5
2nd paper tray	SP1909-4	SP1909-5
3rd paper tray	SP1910-4	SP1910-5
4th paper tray	SP1911-4	SP1911-5
Default (all trays)	400 ms	300 ms (default: not used)


Also, the point at which this adjustment is applied (near-end [50 sheets], 25% full, 75% full) can be selected (③ in the graph) using the following SP modes.

Paper Size	Small Size	Middle Size
	HLT/A5 or smaller (default setting)	None (default setting)
1st paper tray	SP1908-6	SP1908-7
2nd paper tray	SP1909-6	SP1909-7
3rd paper tray	SP1910-6	SP1910-7
4th paper tray	SP1911-6	SP1911-7
Default (all trays)	Near-end	Near-end (default: not used)

2.9.8 PAPER SIZE DETECTION

Size \ SW	1	2	3	4
A3	○	○	○	○
A4 Sideways	●	●	○	●
A4 Lengthwise	●	●	○	○
A5 Lengthwise, 8 1/2" x 14"	○	○	●	●
B4, 11" x 17"	●	○	●	○
B5 Sideways, 11" x 8 1/2"	●	○	○	○
B5 Lengthwise, 8 1/2" x 11"	○	●	●	●
* (Asterisk)	○	●	○	●

●: ON (Not pushed)
○: OFF (Pushed)



Detailed Descriptions

There are four paper size microswitches [A] on the front right plate of the paper tray unit. The switches are actuated by a paper size actuator [B] behind the paper size indicator plate, which is on the front right of the tray.

Each paper size has its own actuator, with a unique combination of notches. To determine which size has been installed, the CPU reads which microswitches the actuator has switched off.


The CPU disables paper feed from a tray if the paper size cannot be detected. If the paper size actuator is broken, or if there is no tray installed, the Add Paper indicator will light.

When the paper size actuator is at the "*" mark, the paper tray can be set up to accommodate one of a wider range of paper sizes by using user tools. If the paper size for this position is changed without changing the user tool setting, a paper jam will result.

2.9.9 SPECIAL PAPER SETTING

Only the 2nd tray can feed special paper such as thick paper or envelopes. The special paper type can be selected either by using the UP mode or with the following operation.

- Select the 2nd tray then press the \# key.




After selecting the special paper type, the fusing temperature and transfer roller current will be changed as follows.

1. Fusing temperature (when thick paper is selected):
Current operation temperature + 15 °C
2. Transfer roller current:
A3 width (11"): 14 μA
B4 width (10"): 15 μA
A4 width (8.5"): 17 μA
A5 width (5.5"): 20 μA

Note that for the by-pass tray, the fusing and transfer conditions for special paper are also applied if the user uses thick (non-standard) mode.

2.9.10 SIDE AND END FENCES




Side Fences

If the tray is full of paper and it is pushed in strongly, the fences may deform or bend. This may cause the paper to skew or the side-to-side registration to be incorrect. To correct this, each side fence has a stopper [A] attached to it. Each side fence can be secured with a screw [B], for customers who do not want to change the paper size.

End Fence

As the amount of paper in the tray decreases, the bottom plate [C] lifts up gradually. The end fence [D] is connected to the bottom plate. When the tray bottom plate rises, the end fence moves forward and pushes the back of the paper stack to keep it squared up.

2.9.11 PAPER REGISTRATION



The drive from the main motor [A] is transmitted to the registration roller through the registration clutch gear [B].

The registration sensor [C] is used for correcting paper skew and for detecting paper misfeeds.


The cleaning mylar [D] contacts the registration roller. It removes paper dust from the registration roller so that this dust will not transfer into the development unit through the drum cleaning unit.

The amount of paper buckle at the registration roller to correct skew can be adjusted with SP 1003.

If jams frequently occur after registration, the paper feed clutch can be re-energized so that the feed roller can assist the registration roller to re-start paper feed. This may be needed when feeding thicker paper. This adjustment is made with SP 1903; it can be adjusted separately for tray 1 and the by-pass feeder, so place the problem paper type in one of these and adjust SP 1-903 for that tray only.

2.10 IMAGE TRANSFER AND PAPER SEPARATION

2.10.1 OVERVIEW



Detailed
Descriptions

The machine uses a transfer roller [A], which touches the surface of the drum [B]. The high voltage supply board supplies a positive current to the transfer roller, which attracts the toner from the drum onto the paper. The current depends on the paper width, paper type, and paper feed tray.

The curvature of the drum and the discharge plate [C] help the paper to separate from the drum. The high voltage supply board also supplies a negative dc voltage to the discharge plate.

Drive from the drum through a gear [D] turns the transfer roller

2.10.2 IMAGE TRANSFER CURRENT TIMING

There are two transfer current levels: low transfer current level and high transfer current level. The image transfer procedure is as follows:

1. When the CPU receives the image writing start signal, the CPU instructs the high voltage supply board to supply +10 μ A (low transfer current level) to the roller. This prevents any positively charged toner on the drum surface from transferring to the transfer roller.
2. At a certain time after the low transfer current has been supplied to the roller, an appropriate current is applied to the roller to transfer the toner to the paper.
3. After the trailing edge of the paper has passed through the roller, transfer current turns off. In multiple copy mode, the transfer current shifts again to the low transfer current.

The transfer current (high transfer current level) depends on the paper feed station, paper width, and the temperature in the machine.

Example: Temperature = 15°C ~ 24°C

Paper Width	Paper Tray / By-pass Tray (Normal)	Duplex (2nd Side)	By-pass Tray (Thick) / 2nd Paper Tray (Special Paper)
A3/11" x 17", A4/8 1/2 x 11"sideways	14 μ A	10 μ A	14 μ A
B4	13 μ A	12 μ A	15 μ A
A4/11" x 8 1/2 lengthwise, A5/5 1/2 x 8 1/2 sidewise	13 μ A	16 μ A	17 μ A
A5/8 1/2 x 5 1/2 lengthwise and less	16 μ A	16 μ A	20 μ A

The transfer current can be adjusted using SP2301, except for the low transfer current.

Be careful when increasing the transfer current. This might cause a ghosting effect, in which part of the image at the top of the page is repeated lower down the page at a lower density. It may also damage the OPC drum in the worst case.

2.10.3 TRANSFER ROLLER CLEANING

If the paper size is smaller than the image, or if a paper jam occurs during printing, toner may be transferred to the roller surface. To prevent the toner from transferring to the back side of the printouts, the transfer roller requires cleaning before the next printing run.

During transfer roller cleaning, the high voltage supply unit supplies a negative cleaning current ($-4 \mu\text{A}$) to the transfer roller. Any negatively charged toner on the transfer roller is then transferred back to the drum. Then a positive cleaning current ($+10 \mu\text{A}$) is applied to the transfer roller to push back to the drum any positively charged toner on the transfer roller.


The machine goes through the cleaning mode in the following conditions:

- Before starting the printing job (only if enabled with SP2-996; note that the default setting is off)
- Just after the power is switched on.
- After a copy jam has been cleared

The transfer roller cleaning function is done.

Also, the transfer roller cleaning current can be adjusted using SP2-301-4.

2.10.4 PAPER SEPARATION MECHANISM




The discharge plate [A] and the drum curvature of the drum help the paper to separate away from the drum. The high voltage supply board applies a constant dc voltage, -1.8 kV (when feeding from a paper tray) or -2.1 kV (from the duplex unit) to the discharge plate.

The discharge plate voltage can be adjusted using SP2-901.

2.11 IMAGE FUSING AND PAPER EXIT


2.11.1 OVERVIEW



The fusing unit and paper exit area consist of the following parts.

- | | |
|-------------------------|---------------------------|
| 1. Paper exit roller | 7. Two fusing lamps |
| 2. Fusing exit sensor | 8. Two thermistors |
| 3. Hot roller strippers | 9. Four thermostats |
| 4. Pressure spring | 10. Hot roller |
| 5. Pressure roller | 11. Paper overflow sensor |
| 6. Cleaning roller | |

2.11.2 FUSING DRIVE AND RELEASE MECHANISM




The main motor [A] drives the fusing unit through a gear train and drives the paper exit rollers [B] through a timing belt [C].

The fusing unit release mechanism automatically disengages the fusing unit drive gear [D] when the right cover [E] is opened. This allows the fusing unit drive gear to rotate freely so that misfed paper can easily be removed.

Also, the fusing drive is released by the fusing drive release solenoid [F]. To reduce the warming up time, the machine cuts the drive to the fusing unit during warming up. Just after the main switch is turned on, this solenoid is energized and the fusing unit drive gear [D] is disengaged.

However, the fusing unit drive is not released when the temperature is lower than 15°C.


2.11.3 FUSING ENTRANCE GUIDE SHIFT MECHANISM



The entrance guide [A] is adjustable for paper thickness to prevent creasing. The left screw holes [B] on each side are used as the default setting.

If creasing occurs frequently in the fusing unit, adjust the entrance guide to the right, by securing it with the other holes [C]. This allows more direct access to the gap between the hot roller and the pressure roller.

2.11.4 PRESSURE ROLLER




The pressure springs [A] constantly apply pressure between the hot roller [B] and the pressure roller [C].

Applied pressure can be changed by adjusting the position of the pressure springs. The spring is positioned at the top [D] as the default setting.


The user moves lever [E] when using thicker copy paper or envelopes, to reduce the pressure between the hot and pressure rollers.

2.11.5 CLEANING MECHANISM



The cleaning roller [A] is always in contact with the pressure roller [B]. It collects toner and paper dust adhered to the surface of the pressure roller.

2.11.6 FUSING TEMPERATURE CONTROL



Temperature Control

Just after the main power switch is turned on, the CPU turns on the fusing lamp to obtain a fusing temperature of 175°C (Main fusing lamp), 165°C (Sub fusing lamp) for the first 60s, or for the first three consecutive pages of printing, whichever comes first. After that, the machine keeps the fusing temperature at 175°C for the first 20 consecutive pages of printing. Then the fusing temperature is kept at 165°C.

The three-page and 60-second limits can be adjusted with SP1-105-8 and -9.

Note that the fusing temperature is higher if the user uses special paper in the 2nd tray or thick paper mode from the bypass tray (☛ 2.8.9).

Fusing Lamp Control

Turning on and off the fusing lamp power causes fluorescent light in the room to flicker. To reduce the flickering, use the following SP modes.

Fusing temperature detection cycle (SP mode 1-108)


The CPU checks the output from the fusing thermistor once a second (default setting). The CPU compares the current and previous temperatures. Based on the result, it then decides how long the fusing lamp power should be on during the next one-second interval (also, if the current temperature is too high, the power will not be needed).

Starting and stopping the fusing lamp power every second causes fluorescent lighting in the room to flicker. To reduce this flickering, use SP1-108 to change the cycle from 1 second to 3 seconds.

Fusing soft-start

In addition, whenever the fusing lamp power switches on, full power is applied to the fusing lamp gradually, not all at once. This prevents the power in the room from dropping suddenly. This feature is known as "Soft Start". The machine does this by gradually allowing more power to the fusing lamp over a number of zero-cross cycles of the ac supply. The diagram below shows full power being applied gradually over the duration of 3 zero-cross cycles. Soft start occurs every time the fusing lamp power switches on (i.e., at some time during every second), not just at the start of the print job.

NOTE: This feature is effective to counter flickering lights. However, generated noise increases if the setting is changed from the default. If a radio or a TV is close by the machine, the noise may have some effect on the image or sound.




2.11.7 OVERHEAT PROTECTION

If the hot roller temperature becomes higher than 231°C, the CPU cuts off the power to the fusing lamp. At the same time, SC543 is generated.

Even if the thermistor overheat protection fails, there are four thermostats in series with the common ground line of the fusing lamp. If the temperature of the thermostat reaches 210°C, one of the thermostats opens, removing power from the fusing lamp. At the same time, SC 542 is generated and the machine stops operating.


2.11.8 PAPER EXIT



The paper overflow detection sensor [A] is located at the paper exit section of the fusing unit. When this sensor is activated, the machine detects that the paper stack height exceeded a certain limit and stops printing.

2.12 ENERGY SAVER MODES

2.12.1 OVERVIEW



When the machine is not being used, the energy saver function reduces power consumption by decreasing the fusing temperature.

This machine has two types of energy saver mode as follows.

- 1) Energy saver mode
- 2) Auto Off mode

These modes are controlled by the following UP and SP modes.

- Panel off timer (energy saver mode timer) : User Tools – System Settings – Timer Setting – Panel Off Timer
- Auto off timer: User Tools – System Settings – Timer Setting – Auto Off Timer
- Auto off disabling (SP mode): Set SP 5-305 to 1. This allows the user to disable auto off mode by setting the auto off timer to 0.

2.12.2 ENERGY SAVER MODE

Entering the energy saver mode

The operation manual uses the term 'panel off mode' for the timer.

The machine enters energy saver mode when one of the following is done.

- The panel off timer runs out
- The Clear Mode/Energy Saver Key is held down for one second

Note that the default setting of the panel off timer is 60 s, which is the same as the auto off timer. In this condition, if the machine is not touched for 60 s, it will go straight to auto off mode. If the user wants an energy saver mode and an auto off mode, the panel off timer must be set to a shorter value than the auto off timer,

What happens in energy saver mode

When the machine enters energy saver mode, the fusing lamp drops to a certain temperature, and the operation panel indicators are turned off except for the Energy Saver LED and the Power LED.

If the CPU receives an image print out command from an application (e. g. to print incoming fax data or to print data from a PC), the fusing temperature rises to print the data.

Return to stand-by mode

If one of the following is done, the machine returns to stand-by mode:

- The Clear Mode/Energy Saver Mode key is pressed
- Any key on the operation panel or touch panel screen is pressed
- An original is placed in the ADF
- The ADF is lifted
- A sheet of paper is placed in the by-pass feed table

The recovery time from energy saver mode is about 3 s.

Mode	Operation Switch	Energy Saver LED	Fusing Temp.	+24V	System +5V
Energy Saver	On	On	150°C	On	On

2.12.3 AUTO OFF MODE

There are two Auto Off modes: Off Stand-by mode and Off mode. The difference between Off Stand-by mode and Off mode is the machine's condition when it enters Auto Off mode.

Entering off stand-by and off modes

The machine enters the Off Stand-by mode or Off mode when one of the following is done.

- The auto off timer runs out
- The operation switch is pressed to turn the power off

If one or more of the following conditions exists, the machine enters Off Stand-by mode. If none of these conditions exist, the machine enters Off Mode.

- Error or SC condition
- An optional G4 unit is installed
- Image data is stored in the memory
- During memory TX or polling RX
- The handset is off hook
- An original is in the ADF
- The ADF is open

Off Stand-by mode

The system +5V is still supplied to all components. When the machine detects a ringing signal or receives a stream of data for a print job, the +24V supply is activated and the machine automatically prints the incoming message or executes the print job.

Off Mode

The system +5V supply also turns off. However, +5VE (+5V for energy saver mode) is still activated. When the machine detects a ringing signal, off-hook signal, or receives a print job, the machine returns to the Off Stand-by mode and the system +5V and +24V supplies are activated.

Returning to stand-by mode

The machine returns to stand-by mode when the operation switch is pressed. The recovery time is about 10 s.

Mode	Operation Switch	Energy Saver Mode	Fusing Lamp	+24V	System +5V	Note
Off Stand-by	Off	Off	Off (On when printing)	On	On	
Off	Off	Off	Off	Off	Off	+5VE is supplied

INSTALLATION

3. INSTALLATION PROCEDURE

3.1 INSTALLATION REQUIREMENTS

3.1.1 ENVIRONMENT

1. Temperature Range: 10°C to 32°C (50°F to 89.6°F)
2. Humidity Range: 15% to 80% RH
3. Ambient Illumination: Less than 1,500 lux (do not expose to direct sunlight.)
4. Ventilation: Room air should turn over at least 30 m³/hr/person
5. Ambient Dust: Less than 0.10 mg/m³ (2.7 x 10⁻⁶ oz/yd³)
6. Avoid an area which is exposed to sudden temperature changes. This includes:
 - 1) Areas directly exposed to cool air from an air conditioner.
 - 2) Areas directly exposed to heat from a heater.
7. Do not place the machine in an area where it will be exposed to corrosive gases.
8. Do not install the machine at any location over 2,000 m (6,500 ft.) above sea level.
9. Place the copier on a strong and level base. (Inclination on any side should be no more than 5 mm.)
10. Do not place the machine where it may be subjected to strong vibrations.

3.1.2 MACHINE LEVEL


Front to back: Within 5 mm (0.2") of level

Right to left: With in 5 mm (0.2") of level


INSTALLATION REQUIREMENTS

3.1.3 MINIMUM SPACE REQUIREMENTS

Place the copier near the power source, providing clearance as shown:



- A: In Front: Over 750 mm (29.6")
- B: Left: Over 10 mm (4")
- C: To Rear: Over 10 mm (4")
- D: Right: Over 10 mm (4")



- E: 620 mm (24.4")
- F: 640 mm (25.2")
- G: 550 mm (21.7")
- H: 1137 mm (44.8")

NOTE: The 750 mm recommended for the space at the front is only for pulling out the paper tray. If an operator stands at the front of the copier, more space is required.

3.1.4 POWER REQUIREMENTS


⚠ CAUTION

- 1. Make sure that the wall outlet is near the copier and easily accessible. Make sure the plug is firmly inserted in the outlet.**
- 2. Avoid multi-wiring.**
- 3. Be sure to ground the machine.**

1. Input voltage level: 120 V, 60 Hz: More than 12 A
220 V ~ 240 V, 50 Hz/60 Hz: More than 7 A
110V, 50 Hz/60 Hz: More than 13 A
2. Permissible voltage fluctuation: $\pm 10\%$
3. Do not set anything on the power cord.


3.2 COPIER INSTALLATION

3.2.1 POWER SOCKETS FOR PERIPHERALS



3.2.2 INSTALLATION FLOW CHART

The following flow chart shows how to install the optional units more efficiently.




Installation

3.2.3 ACCESSORY CHECK

Check the quantity and condition of the accessories in the box against the following list:

Description	Q'ty
1. Paper Tray Decal.....	1
2. Emblem	1
3. Model Name Decal	1
4. NECR	1
5. End Fence	1
6. HDD Caution Decal (-17, -57 only)	1
7. Operating Instructions – System Setting.....	1
8. Operating Instructions – Copy Reference.....	1

3.2.4 INSTALLATION PROCEDURE



Installation

⚠ CAUTION


Unplug the machine power cord before starting the following procedure.

If the optional paper tray or the optional LCT is going to be installed now, put the copier on the paper tray unit or the LCT first, then install these options, then install the copier.


NOTE: Keep the shipping retainers after installing the machine. They will be reused if the machine is moved to another location in the future.

1. Remove the tapes and the shipping retainer [A] on the exterior of the copier.
2. Install the end fence [B].

COPIER INSTALLATION




3. Open the front cover [A].
4. Remove the red tag [B] and toner seal [C], then peel the sealing tape [D] off to install the developer.
5. Raise the toner bottle holder lever [E], push lever [F] down, and pull the toner bottle holder [G] out.
6. Shake the toner bottle [H] well.
NOTE: Do not remove the toner bottle cap [I] until after shaking.
7. Unscrew the bottle cap [I] and insert the bottle into the holder.
NOTE: Do not touch the inner bottle cap [J].
8. Reposition the holder and press down the holder lever to secure the bottle.
9. Open the right cover.
10. Rotate the green fusing pressure lever [K] to the up position.



11. Attach the appropriate emblem [A] to the front cover if the emblem is not attached to the front cover.
12. Pull the paper tray out and turn the paper size dial to select the appropriate size. Adjust the side guides and end guide to match the paper size.
NOTE: To move the side guides, first pull out the tray fully, then push down the green lock at the rear of the tray.
13. Attach the appropriate paper tray number decal [B] to each paper tray.
NOTE: Paper tray number decals are also used for the optional paper tray or the optional LCT. Keep any remaining decals for use with these optional units.

COPIER INSTALLATION



14. **If the optional bridge unit will not be installed:** Swing the sensor feeler [A] out.
15. Install the optional ARDF or the optional platen cover (see ARDF Installation or Platen Cover Installation).
16. Plug in the machine and turn the main power switch on. The machine automatically performs TD sensor initial setting (approximately 15 seconds).
17. Check the copy quality and copying functions.

HDD Caution Decal (for only -17, -57 models)

18. When installing the optional HDD, attach the HDD caution decal [B] to the front cover.


3.3 PAPER TRAY UNIT INSTALLATION

3.3.1 ACCESSORY CHECK

Check the quantity and condition of the accessories against the following list.

Description	Q'ty
1. Securing Bracket	2
2. Screw – M4 x 10	4

3.3.2 INSTALLATION PROCEDURE




Installation


⚠ CAUTION
Unplug the machine power cord before starting the following procedure.

1. Remove the strips of tape.
2. Set the copier [A] on the paper tray unit [B].
NOTE: When installing the copier, be careful not to pinch the cable [C].

PAPER TRAY UNIT INSTALLATION



3. Remove the connector cover [A] (⚙️ x 1).
4. Connect the cable [B] to the copier, as shown.
5. Attach a securing bracket [C] to each side of the paper tray unit, as shown (⚙️ x 1 each).
6. Re-install the connector cover.
7. Remove the 2nd paper tray [D] and secure the paper tray unit [E] (⚙️ x 2).



Installation

8. Reinstall the 2nd paper tray and attach the appropriate paper tray number decal [A] to the paper tray.
NOTE: The paper tray number decal is in the accessory box for the main copier.
9. Rotate the adjuster [B] until the machine cannot be pushed across the floor.
10. Load paper into the paper trays and select the proper paper size.
11. Turn on the main switch.
12. Check the machine's operation and copy quality.


3.4 LCT INSTALLATION

3.4.1 ACCESSORY CHECK

Check the quantity and condition of the accessories against the following list.

Description	Q'ty
1. Securing Bracket	2
2. Screw – M4 x 10	4
3. Paper Size Decal	1



3.4.2 INSTALLATION PROCEDURE



⚠ CAUTION


Unplug the machine power cord before starting the following procedure.

1. Remove the strips of tape.
2. Set the copier [A] on the LCT [B].
NOTE: When installing the copier, be careful not to pinch the cable [C].



3. Remove the connector cover [A] (⚙️ x 1).
4. Connect the cable [B] to the copier, as shown.
5. Attach a securing bracket [C] to each side of the LCT, as shown (⚙️ x 1 each).
6. Re-install the connector cover.
7. Remove the 2nd paper tray and secure the LCT [D] (⚙️ x 2).

LCT INSTALLATION




8. Load paper into the LCT.
9. Reinstall the 2nd paper tray and attach the appropriate paper tray number decal [A] and paper size decal [B] to the LCT.
NOTE: The paper tray number decal is in the accessory box for the main copier.
10. Rotate the adjuster [C] until the machine cannot be pushed across the floor.
11. Load paper into the paper tray and turn on the main switch.
12. Check the machine's operation and copy quality.

3.5 AUTO REVERSE DOCUMENT FEEDER INSTALLATION

3.5.1 ACCESSORY CHECK

Check the quantity and condition of the accessories against the following list.


Description	Q'ty
1. Scale Guide	1
2. DF Exposure Glass.....	1
3. Stud Screw	2
4. Knob Screw	2
5. Original Size Decal	2
6. Screwdriver Tool.....	1
7. Cloth Holder.....	1
8. Cloth	1
9. Attention Decal – Top Cover.....	1
10. Attention Decal – Scanner	1



Installation

AUTO REVERSE DOCUMENT FEEDER INSTALLATION

3.5.2 INSTALLATION PROCEDURE




⚠ CAUTION

Unplug the copier power cord before starting the following procedure.


1. Remove the strips of tape.

AUTO REVERSE DOCUMENT FEEDER INSTALLATION




2. Remove the left scale [A] ($\times 2$).
3. Peel off the backing [B] of the double-sided tape attached to the glass holder.
4. Place the DF exposure glass [C] on the glass holder.
NOTE: When installing the DF exposure glass, make sure that the white point [D] is on the lower front side of the glass, as shown.
5. Peel off the backing [E] of the double-sided tape attached to the rear side of the scale guide [F], then install it ($\times 2$ removed in step 2).
6. Install the two stud screws [G].
7. Mount the DF on the copier, then slide the DF to the front as shown.
8. Secure the DF unit with two screws [H].
9. Connect the cable [I] to the copier.

AUTO REVERSE DOCUMENT FEEDER INSTALLATION



10. Peel off the platen sheet [A] and place it on the exposure glass.
11. Line up the rear left corner of the platen sheet flush against corner [B] on the exposure glass.
12. Close the ARDF.
13. Attach the appropriate scale decal [C] as shown.

AUTO REVERSE DOCUMENT FEEDER INSTALLATION



Installation


14. Attach the decal [A] to the top cover as shown, choosing the language most suitable for the machine installed.
15. Line up arrow on the decal [B] with the center of the ADF exposure glass as shown, and attach it to the cover. As with step 14, choose the language most suitable for the machine installed.
16. Attach the cloth holder [C] to the left side of the scanner as shown.
17. Insert the cloth [D] in the cloth holder.
18. Turn the main power switch on. Then check if the document feeder works properly.
19. Make a full size copy. Then check to make sure the registrations (side-to-side and leading edge) and image skew are correct. If they are not, adjust the registrations and image skew (refer to the service manual).

3.6 INTERCHANGE UNIT INSTALLATION


3.6.1 COMPONENT CHECK

Check the quantity and condition of the components against the following list.

Description	Q'ty
1. Interchange Unit	1
2. Connector Cover.....	1
3. Tapping Screw M3 x 8	1



3.6.2 INSTALLATION PROCEDURE



⚠ CAUTION


Unplug the copier power cord before starting the following procedure.

1. Remove all tapes.
2. Open the right cover [A] of the copier.
3. Open cover [B]
4. Remove the metal clip [C].
NOTE: To remove the clip, push the small tab [D] on the clip into the slot [E], then the clip can be removed.
5. Remove the cover [B].

If the optional 1-bin tray unit (B413) will be installed, do steps 6 and 7.

6. Loosen the screw, push down tab [F] with a screwdriver, and remove the front right cover [G].
7. Slide out the exit cover [H].

INTERCHANGE UNIT INSTALLATION




8. Open the cover [A] of the interchange unit.
9. Install the interchange unit (2 connectors) [B].
10. Secure the interchange unit with the knob screws [C].
11. Attach the connector cover [D] (1 x 1).

3.7 1-BIN TRAY UNIT INSTALLATION

3.7.1 COMPONENT CHECK

Check the quantity and condition of the components against the following list.


Description	Q'ty
1. 1-Bin Tray Unit.....	1
2. Tray	1
3. Sub-Tray.....	1
4. Tray Guide.....	1
5. Paper Guide	1
6. Tapping Screw M3 x 8.....	1



Installation

1-BIN TRAY UNIT INSTALLATION

3.7.2 INSTALLATION PROCEDURE




⚠ CAUTION

Unplug the copier power cord before starting the following procedure.

NOTE: Before installing this 1-bin tray unit, the optional interchange unit (B416) must be installed.

1. Remove all tapes.
2. If the optional bridge unit has been installed, open the right jam removal cover [A] of the bridge unit.
If the optional bridge unit is not installed, skip this step.


1-BIN TRAY UNIT INSTALLATION



Installation

3. If the front right cover [A] is installed, remove it.
4. Install the 1-bin tray unit [B] (1 x 1).
5. Connect the connector [C].
6. Reinstall the front right cover.
7. Peel off the backing [D] of the double-sided tape attached to the paper guide [E]. Then attach the paper guide to the underside of the scanner unit as shown.

1-BIN TRAY UNIT INSTALLATION




8. Install the tray guide [A].
9. Install the tray [B].
10. Install the sub-tray [C].
11. Turn on the main power switch and check the 1-bin tray unit operation.

3.8 SHIFT TRAY

3.8.1 COMPONENT CHECK


Check the quantity and condition of the components against the following list.

Description	Q'ty
1. Shift Tray Unit.....	1
2. Paper Guide - Large	1
3. Paper Guide - Small	2
4. Stepped Screw	1



SHIFT TRAY


3.8.2 INSTALLATION PROCEDURE



⚠ CAUTION

Unplug the copier power cord before starting the following procedure.

1. Remove all tapes.
2. Remove the plate [A].
3. Install the large paper guide [B] and two small paper guides [C], as shown.




4. Install the stepped screw [A].
5. Install the shift tray unit [B], as shown.
NOTE: 1) Set the shift tray on the stepped screw.
2) The shift tray must be installed under the paper guide [C] installed in step 3.
6. Connect the cable [D] to the copier.
7. Turn on the main power switch.
8. Check the shift tray operation.

3.9 BY-PASS FEED UNIT INSTALLATION


3.9.1 COMPONENTS CHECK

Check the quantity and condition of the components against the following list.

Description	Q'ty
1. By-pass Tray Unit	1
2. Unit Holder	1
3. Tapping Screw	2
4. Allen Key	1



3.9.2 INSTALLATION PROCEDURE




Installation

⚠ CAUTION

Unplug the copier power cord before starting the following procedure.

1. Remove all tapes.
2. Remove the entrance cover [A] (⚙ x 2) and two screws [B].

BY-PASS FEED UNIT INSTALLATION



3. Install the unit holder [A] using the Allen key (⌘ x 4).
NOTE: 1) Make sure that the four screws are tightened in the proper order, as shown above. Otherwise, when the optional duplex unit (B414) is installed, it will not properly lock in place.
2) After securing the unit, store the Allen key in the inner cover [B] for future use.
4. **If the optional duplex unit (B414) will be installed:** Remove the indicated parts [C] of the by-pass tray unit [D].
5. Install the by-pass tray unit (⌘ x 2, ⌘ x 1).
6. Turn the main power switch on and check the by-pass tray function.
7. Make a copy from the by-pass tray. Then check the registration.


3.10 DUPLEX UNIT INSTALLATION

3.10.1 ACCESSORY CHECK


Check the quantity and condition of the accessories against the following list.

Description	Q'ty
1. Duplex Unit	1
2. Connector Cover	1
3. Bracket	1
4. Clip	1
5. Unit Holder	1
6. Unit Holder Cover	1
7. Allen Key	1
8. Tapping Screw - M3 x 8	4

Installation



3.10.2 INSTALLATION PROCEDURE



CAUTION


Unplug the copier power cord before starting the following procedure.

NOTE: Before installing the duplex unit, the optional interchange unit (B416) must be installed.

1. Remove all tapes.
2. Remove three covers [A].
3. Remove the connector cover [B] (⌀ x 1), the entrance cover [C] (2 screws if the by-pass tray has not been installed), and two screws [D].
4. Install the bracket [E] (⌀ x 1).
5. **If the by-pass tray has already been installed, skip this step:** Install the unit holder [F] using the Allen key (⌀ x 4).

NOTE: 1) Make sure that the four screws are tightened in the proper order, as shown above. Otherwise, the duplex unit will not properly lock in place.
2) After securing the unit, store the Allen key in the inner cover [G] for future use.

DUPLEX UNIT INSTALLATION



Installation


6. Set the duplex unit [A] on the unit holder [B] or on the by-pass tray unit if it has already been installed.
7. Attach the link [C] to the shaft [D] and secure it with the clip.
8. Connect the cable [E] and install the connector cover [F] (1 x 1).
9. **If the by-pass tray has already been installed, skip this step:** Install the unit holder cover [G] (1 x 2).
10. Turn on the main power switch and check the duplex unit function.

3.11 BRIDGE UNIT INSTALLATION


3.11.1 ACCESSORY CHECK

Check the quantity and condition of the accessories against the following list.

Description	Q'ty
1. Bridge Unit.....	1
2. Securing Plate	1
3. Shoulder Screw	1
4. Knob Screw	1




3.11.2 INSTALLATION PROCEDURE

**⚠ CAUTION**

Unplug the copier power cord before starting the following procedure.

1. Remove all tapes.
2. Loosen the screw [A] and remove the front right cover [B].
3. If the sensor feeler [C] is out, fold it away into the machine.

BRIDGE UNIT INSTALLATION




4. Remove the cover [A].
5. Install the bridge unit [B] (⚙ x 1 shoulder, ⚙ x 1 knob).
6. Reinstall the front right cover [C].
7. Connect the cable [D] to the main machine.
8. Attach the securing plate [E], as shown.
NOTE: Do not attach it with a screw; this is done when securing the front stand for the optional finisher.
9. Install the optional finisher (refer to the finisher installation procedure).

3.12 1000-SHEET FINISHER INSTALLATION

3.12.1 ACCESSORY CHECK

Check the quantity and condition of the accessories against the following list.




Installation

No.	Description	Q'ty	For B022/B027/B031/ B089/B093/B097	For B051/B052	For B079/B082/ B135/B138
1	Front Joint Bracket	1	✓	---	✓
2	Rear Joint Bracket	1	✓	---	---
3	Rear Joint Bracket	1	---	---	✓
4	Grounding Plate	1	✓	---	✓
5	Copy Tray	1	✓	✓	✓
6	Staple Position Decal	1	✓	✓	✓
7	Screw - M4 x 14	4	✓ (Use 3)	---	✓ (Use 4)
8	Knob Screw - M4 x 10	1	✓	✓	✓
9	Screw - M3 x 8	1	✓	---	✓
10	Knob Screw - M3 x 8	1	✓	✓	✓

✓ = Necessary, --- = Not necessary

3.12.2 INSTALLATION PROCEDURE




⚠ CAUTION

Unplug the main machine power cord before starting the following procedure.

NOTE: The following options must be installed before installing this finisher:
Bridge Unit (B417)
Paper Tray Unit (B390) or LCT (B391)


1. Unpack the finisher and remove the tapes.

NOTE: Be sure to keep screw [A]. It will be needed to secure the grounding plate in step 4.



2. Install the front joint bracket [A] (⌘ x 2 M4 x 17) and rear joint bracket [B] (⌘ x 1 M4 x 17).
3. Remove the left stand [C] (⌘ x 3)
4. Install the lower grounding plate [D] on the finisher (⌘ x 2 M3 x 8).
NOTE: Use the screw removed in step 1 and the screw from the accessory box.
5. Open the front door [E]. Then pull the locking lever [F].
6. Align the finisher on the joint brackets, and lock it in place by pushing the locking lever.
7. Secure the locking lever (⌘ x 1 knob M3 x 8) and close the front door.
8. Install the copy tray [G] (⌘ x 1 knob M4 x 10).
9. Connect the finisher cable [H] to the main machine.

1000-SHEET FINISHER INSTALLATION




10. Attach the staple position decal [A] to the ARDF as shown.
11. Turn on the ac switch and check the finisher operation.

3.13 500-SHEET FINISHER INSTALLATION

3.13.1 ACCESSORY CHECK


Check the quantity and condition of the accessories against the following list.

Description	Q'ty
1. Unit Holder.....	1
2. Entrance Guide.....	1
3. Output Tray.....	1
4. Snap Ring.....	2
5. Knob Screw	2



Installation

3.13.2 INSTALLATION PROCEDURE




⚠ CAUTION

Unplug the main machine power cord before starting the following procedure.

NOTE: Before installing the 500-sheet finisher, the optional bridge unit (B417) must be installed.


1. Unpack the finisher and remove the tapes.
2. Install the entrance guide [A].
3. Install the unit holder [B] (⚙ x 2).
4. Install the 500-sheet finisher [C].

500-SHEET FINISHER INSTALLATION




5. Install the output tray [A] as shown (2 snap rings).
6. Connect the finisher cable [B].
7. Turn on the main power switch and check the finisher operation.

3.14 PLATEN COVER INSTALLATION



1. Install the platen cover [A] (🔩 x 2).

3.15 KEY COUNTER INSTALLATION




Installation

⚠ CAUTION

Unplug the machine power cord before starting the following procedure.


1. Remove two caps [A].
2. Connect the key counter cable [B].
3. Install the stepped screw [C].
4. Hold the key counter plate nuts [D] on the inside of the key counter bracket [E] and insert the key counter holder [F].
5. Secure the key counter holder to the bracket (⚙ x 2).
6. Install the key counter cover [G] (⚙ x 2).

KEY COUNTER INSTALLATION



7. Connect the cable [A].
8. Hook the key counter holder assembly [B] onto the stepped screw [C].
9. Secure the key counter holder assembly with a screw [D].
10. Use the User Tools to enable the counter function for the following modes:
 - Copy mode
 - Document server mode
 - Fax mode
 - Scanner mode
 - Printer mode

3.16 OPTICS ANTI-CONDENSATION HEATER




Installation

⚠ CAUTION

Unplug the machine power cord before starting the following procedure.

1. Remove the rear scale [A] (⚙ x 3), left scale [B] (⚙ x 2), and exposure glass [C].
NOTE: When reinstalling the exposure glass, make sure that the mark [D] is positioned at the rear left corner, as shown.
2. Move the 1st and 2nd scanners to the right.
3. Install the cable clamp [E].
4. Install the anti-condensation heater [F] (⚙ x 2).
5. Join the connectors [G]
6. Attach the cable cover [H], as shown.



3.17 TRAY HEATER



⚠ CAUTION


Unplug the machine power cord before starting the following procedure.

1. Remove the connector cover [A] and rear cover [B] (⚙ x 4).
2. Slide out the 1st and 2nd paper trays.
3. Pass the connector [C] through the opening [D].
4. Install the tray heater assembly [E] (⚙ x 1).



5. Remove the 2nd paper lift motor [A] (⚙ x 2, 🛠 x 1).
6. Route the heater cable [B] to the side of rivet [C] and under bracket [D].
7. Clamp the heater cable [B] as shown.
8. Joint the heater cable and the ac cable [E].
9. Reinstall the paper lift motor [A] and reassemble the machine.

3.18 TRAY HEATER (OPTIONAL PAPER TRAY UNIT)




⚠ CAUTION

Unplug the machine power cord before starting the following procedure.

1. Remove the joint brackets [A] (⚙ x 1 each).
2. Remove the rear cover [B] for the optional paper tray unit (⚙ x 2).
3. Remove the cable guide [C] (⚙ x 1).
4. Install the clamps [D].



TRAY HEATER (OPTIONAL PAPER TRAY UNIT)



Installation


5. Slide out the two paper trays from the optional paper tray unit.
6. Pass the connector [A] through the opening [B].
7. Install the tray heater assembly [C] (⌀ x 1).
8. Clamp the cables [D], as shown.
9. Join the connectors [E].
10. Reinstall the cable guide.

TRAY HEATER (OPTIONAL PAPER TRAY UNIT)



11. Remove two screws [A] from the rear side of the paper feed unit.
12. Reinstall the rear cover for the optional paper tray unit.
13. Reinstall the two paper trays into the optional paper tray unit.
14. Remove the 2nd paper tray of the copier.
15. Remove two screws [B] and install the screws [C] which were removed in step 12.
16. Reinstall the 2nd paper tray of the copier.

3.19 TRAY HEATER (OPTIONAL LCT)




Installation

⚠ CAUTION
Unplug the machine power cord before starting the following procedure.


1. Remove two joint brackets [A] (⚙ x 1 each).
2. Remove the rear cover for the LCT [B] (⚙ x 2).
3. Slide out the paper tray [C].
4. Push the stopper [D] on both slide rails and remove the paper tray.
5. Pass the connector [E] through the opening [F].
6. Install the tray heater [G] (⚙ x 1).

TRAY HEATER (OPTIONAL LCT)



7. Install five clamps [A].
8. Connect the cable [B] to the tray heater cable [C].
9. Route the cable and clamp it.
10. Remove the connector cover of the copier [D].
11. Join the connectors [E].
12. Reinstall the connector cover of the copier.

TRAY HEATER (OPTIONAL LCT)




Installation

13. Remove two screws [A] from the rear side of the LCT.
14. Reinstall the rear cover of the LCT.
15. Reinstall the paper tray.
16. Remove the 2nd paper tray of the copier.
17. Remove two screws [B] and install the screws [C] which were removed in step 13.
18. Reinstall the 2nd paper tray of the copier.

3.20 OPTIONAL BOARDS AND DIMMS

3.20.1 REMOVING THE COVERS



⚠ CAUTION

Unplug the main machine power cord before starting the following procedure.

1. If the paper tray unit or LCT is installed, remove the connector cover [A] (⚙ x 1) and disconnect the cable to prevent the cover from damage.
2. Remove the rear cover [B] (⚙ x 4).
3. Remove the controller board cover [C] (⚙ x 8).
4. Remove the knockouts [D] as required.

Top: NIB, marked "LAN"

Middle: File Format Converter, IEEE 1394, IEEE 802.11b, USB 2.0, or Bluetooth. (Only one of these can be installed.)

Bottom: IEEE 1284. (The connector is provided on the controller board.)

3.20.2 PRINTER/SCANNER MODULE (B577)


Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. HDD.....	1
2. NIB.....	1
3. Keytop - Copy	1
4. Keytop – Document Server.....	1
5. Keytop - Printer.....	1
6. Keytop – Scanner	1
7. CD-ROM: Printer	1
8. CD-ROM: Scanner.....	1
9. CD-ROM: Operation Manual.....	1
10. Operating Instructions.....	1
11. FCC Label (USA only)	1



Printer/Scanner Module ROM DIMM Installation



⚠ CAUTION


Unplug the main machine power cord before starting the following procedure.

1. Remove the machine rear cover and controller board cover. (☛3.20.1)
2. Install the scanner/printer ROM DIMM [A] into the lower slot [B] on the controller board.
3. Install the 128 MB Memory DIMM G331. (☛3.20.3)
4. Install the HDD unit. (☛3.20.4)
5. Install the NIB. (☛3.20.5)
6. Install the interface option.

NOTE: Only one slot is available for an interface option. You can install only one printer interface option at a time: File Format Converter (B519), IEEE 1394 (G336), IEEE 802.11b (B515), USB 2.0 (B525-01), or Bluetooth (G354). Refer to the sections below for details about how to install each optional interface.

7. Before using the printer/scanner features, connect the copier to a power source, switch it on then execute SP5801 9 Memory Clear – Scanner Applications.
8. Do not connect the parallel cable now. Turn the machine on and check Copier SP mode SP5-907: Plug & Play Name
9. Print out the configuration page to confirm correct installation of the printer controller (User Tools> Printer Settings> List Test Print> Config. Page)
10. To connect the parallel cable, switch the machine off, connect the cable, then switch the machine on again.
11. Execute SP5801 10 (Net File Memory Clear).

3.20.3 128 MB MEMORY (G331)



Installation

⚠ CAUTION
Unplug the main machine power cord before starting the following procedure.

1. Remove the machine rear cover and controller board cover. (☛3.20.1)
2. Install the memory DIMM [A] on the controller board.


3.20.4 HDD (B592)

Accessories


Check the accessories and their quantities against the following list:

Description	Q'ty
1. HDD.....	1
2. Bracket	1
3. Shoulder Screws	4
4. Screws	3
5. Connector Cable	1

⚠ CAUTION
Unplug the main machine power cord before starting the following procedure.



1. Remove the machine rear cover and controller board cover. (☛3.20.1)
2. Attach the HDD [A] to the bracket [B] (⚙ x 4 shoulder screws).
3. Attach one end of the connector cable [C] to the HDD.
4. Attach the other end of the connector to CN516 [D] on the controller board.
5. Fasten the bracket with the HDD attached to the controller board [E] (⚙ x 3).



Installation

6. Remove the blank keys [A]
7. Replace the blank with the keytops [B] for the appropriate units to be installed in this order from top to bottom:


Copy	If you are installing the HDD without the Printer/Scanner DIMM, attach only the Copy and Document Server Keytops.
Document Server	
Printer	If you are installing the HDD with the Printer/Scanner DIMM, attach all the keytops.
Scanner	
8. Install the stamp data on the hard disk using SP5853.

3.20.5 NIB (B525-17)

Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. NIB Board	1
2. Screw	1



⚠ CAUTION
Unplug the main machine power cord before starting the following procedure.


1. Remove the machine rear cover, controller board cover, and remove the top knockout. (☛3.20.1)
2. Attach the NIB [A] to the controller board (🔩 x 1).

3.20.6 IEEE 1394 INTERFACE KIT (G336)

Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. IEEE 1394 Board	1
2. 6-pin/6-pin Cable	1
3. 6-pin/4-pin Cable	1
4. Screws.....	2



Installation

⚠ CAUTION
Unplug the main machine power cord before starting the following procedure.

NOTE: To install this option, the Printer/Scanner Option must be installed first. (☛3.20.2) Only one slot is available for the interface option. You can install only one printer interface option at a time: File Format Converter (B519), IEEE 1394 (G336), IEEE 802.11b (B515), USB 2.0 (B525-01), or Bluetooth (G354).

1. Remove the machine rear, controller board cover, and middle knockout. (☛3.20.1)
2. Remove the slot cover [A] (⚙ x 2).
3. Attach the IEEE 1394 board [B] to the controller board.
NOTE: Make sure that the jumper on the board is set to TB2.
4. Fasten the board with the screws [C] (⚙ x 2).
5. Use the appropriate cable provided to connect the machine to the computer.

UP Mode Settings for IEEE 1394

Enter the UP mode and follow the procedure below to perform the initial interface settings for IEEE 1394. These settings take effect every time the machine is powered on.

1. Press User Tools/Counter.
2. On the touch panel, press System Settings.
3. Press Interface Settings/IEEE1394.
4. Press the key and enter the following settings:
 - IP Address
 - Subnet Mask
 - IP Over 1394. Enable or disable this setting as required. This setting enables IP Over 1394 as the default setting for the printing method.
 - SCSI Print. Enable or disable this setting as required. This setting enables SCSI Print as the default setting for the printing method.
 - SCSI Print Bi-directional. Switch bi-directional printing on or off for SCSI print.

SP Mode Settings for IEEE 1394

The following SP commands can be set for IEEE 1394.


SP No.	Name	Function
5839 004	Host Name	Sets the names for all the physical devices connected of the IEEE 1394 firewire network.
5839 007	Cycle Master	Enables or disables cycle master function of the IEEE 1394 standard bus.
5839 008	BCR Mode	Sets the BCR (Broadcast Channel Register) setting for the Auto Node operation for the standard IEEE1394 bus for when IRM is not in use. Three settings are available: 00, 01, 11.
5839 009	IRM 1394a Check	Determines whether an IRM check for IEEE 1394 is conducted for the Auto Node when IRM is not used.
5839 010	Unique ID	Enables the "Node_Unique_Id" setting for enumeration on the standard IEEE 1394 bus.
5839 011	Logout	Determines how successive initiator login in requests are handled during login in for SBP-2.
5839 012	Login	Enables or disables exclusive login for SBP-2.
5839 013	Login MAX	Sets the limit for the number of logins for SBP-2. Range: 1 ~ 62.

3.20.7 IEEE 802.11B INTERFACE KIT (B515)

Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. IEEE 802.11b Board	1
2. PCI Card.....	1
3. Antennas	2
4. Velcro pads	2





Installation

⚠ CAUTION
Unplug the main machine power cord before starting the following procedure.

NOTE: To install this option, the Printer/Scanner Option must be installed first. (☛3.20.2) Only one slot is available for the interface option. You can install only one printer interface option at a time: File Format Converter (B519), IEEE 1394 (G336), IEEE 802.11b (B515), USB 2.0 (B525-01), or Bluetooth (G354).

1. Remove the machine rear, controller board cover, and middle knockout. (☛3.20.1)
2. Remove the slot cover [A] (⚙ x 2). Save these screws
3. Attach the IEEE 802.11b Board [B] to the controller board.
NOTE: Make sure that the jumper at TB1 is set on the left at 3, 4.
4. Fasten the board with the screws [C] removed in Step 2.





5. Pull off the edge connector protector [A] off the card and discard it.
- ⇒ 6. With the card label facing the front, insert the card [B] into the PCI slot.
7. Use the Velcro pads to install the antennas [C] on the left rear corner of the machine.
NOTE: The antennas should be separated by at least 40 ~ 60 mm (1.5~2.5"). Always detach the antennas from the corners of the machine and disconnect them before moving the machine.
8. Connect the antennas to the terminals [D].
9. Coil the cables [E] and hang them over the antennas as shown.
10. Attach the cover [F] (⚙ x 2).
11. If reception is poor, you may need to move the machine:
 - Make sure that the machine is not located near an appliance or any type of equipment that can generate a strong magnetic field.
 - Position the machine as close as possible to the access point.

UP Mode Settings for Wireless LAN

Enter the UP mode and follow the procedure below to perform the initial interface settings for IEEE 802.11b. These settings take effect every time the machine is powered on.

NOTE: The wireless LAN cannot be used if Ethernet is being used.

1. Press the User Tools/Counter key.
2. On the touch panel, press System Settings.
NOTE: The Network I/F (default: Ethernet) must be set for either Ethernet or wireless LAN.
3. Select Interface Settings → Network (tab)
4. Press IEEE 802.11b. The wireless LAN options are displayed.
5. **Transmission Mode.** Select either “Ad Hoc Mode” or “Infrastructure Mode”.
6. **SSID Setting.** Enter the SSID setting. (The setting is case sensitive.)
7. **Channel.** This setting is required when Ad Hoc Mode is selected.
Range: 1 ~ 14 (default: 11)
NOTE: The allowed range for the channel settings may vary for different countries.
8. **WEP (Privacy) Setting.** The WEP (Wired Equivalent Privacy) setting is designed to protect wireless data transmission. In order to unlock encoded data, the same WEP key is required on the receiving side. There are 64 bit and 128 bit WEP keys.

Range of Allowed Settings:

64 bit	10 characters
128 bit	26 characters

9. **Bandwidth Status.** This setting is enabled only for the Infrastructure Mode. Press here to display the current status of the bandwidth. One of the following is displayed to reflect the reception status of the wireless LAN:

Good	76 ~ 100%
Fair	41 ~ 75%
Poor	21 ~ 40%
Unavailable	0 ~ 20%

OPTIONAL BOARDS AND DIMMS

10. **Transmission Speed.** Press the Next button to display more settings, then select the transmission speed for the mode: Auto, 11 Mbps, 5.5 Mbps, 2 Mbps, 1 Mbps (default: Auto). This setting should match the distance between the closest machine or access point, depending on which mode is selected.

NOTE: For the Ad Hoc Mode, this is the distance between the machine and the closest PC in the network. For the Infrastructure Mode, this is the distance between the machine and the closest access point.

11 Mbps	140 m (153 yd.)
5.5 Mbps	200 m (219 yd.)
2 Mbps	270 m (295 yd.)
1 Mbps	400 m (437 yd.)

11. To initialize the wireless LAN settings, use page 2/2. Press Execute to initialize the following settings:

- Transmission mode
- Channel
- Transmission Speed
- WEP
- SSID
- WEP Key

SP Mode Settings for IEEE 802.11b Wireless LAN

The following SP commands can be set for IEEE 802.11b


SP No.	Name	Function
5840 4	SSID	Used to confirm the current SSID setting.
5840 6	Channel MAX	Sets the maximum range of the channel settings for the country.
5840 7	Channel MIN	Sets the minimum range of the channels settings allowed for your country.
5840 10	WEP Key	Used to confirm the current WEP key setting.
5840 11	WEP Key Select	Used to select the WEP key (Default: 00).
5840 20	WEP Key Select	Used to display the maximum length of the string that can be used for the WEP Key entry.

3.20.8 USB 2.0 BOARD (B525-01)

Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. USB 2.0 Board.....	1



Installation

⚠ CAUTION
Unplug the main machine power cord before starting the following procedure.

NOTE: To install this option, the Printer/Scanner Option must be installed first. (☛3.20.2) Only one slot is available for the interface option. You can install only one printer interface option at a time: File Format Converter (B519), IEEE 1394 (G336), IEEE 802.11b (B515), USB 2.0 (B525-01), or Bluetooth (G354).

1. Remove the machine rear, controller board cover, and middle knockout. (☛3.20.1)
2. Remove the slot cover [A] (☛ x 2). Save these screws
3. Attach the USB 2.0 board [B] to the controller board.
4. Fasten the board with the screws [C] removed in Step 2.
5. Execute SP5990 5 to print a Self-Diagnostic Report with the system settings and confirm that the machine correctly recognizes the interface.

OPTIONAL BOARDS AND DIMMS

USB SP Settings

The following SP commands are available. However, only one setting may require adjustment and this setting should be performed only if the customer is experiencing USB data transmission errors.

NOTE: Do not change the settings marked “DFU”. These settings are for design and factory use only.


SP No.	Name	Function
5844 1	Transfer Rate	Adjusts the USB transfer rate. Do not change the setting unless there is a data transfer error using the USB high speed mode.
		HS/FS: High speed/Full speed auto adjust (480Mbps/12Mbps)
		FS: Full speed (12Mbps fixed)
5844 2	Vendor ID	Displays the vendor ID. DFU
5844 3	Product ID	Displays the product ID. DFU
5844 4	Dev. Release Number	Displays the development release version number. DFU

3.20.9 BLUETOOTH UNIT 2045 (G354)

Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. PCI Card.....	1
2. Bluetooth Board.....	1
3. Cap.....	1





Installation

⚠ CAUTION
Unplug the main machine power cord before starting the following procedure.

NOTE: To install this option, the Printer/Scanner Option must be installed first. (☛3.20.2) Only one slot is available for the interface option. You can install only one printer interface option at a time: File Format Converter (B519), IEEE 1394 (G336), IEEE 802.11b (B515), USB 2.0 (B525-01), or Bluetooth (G354).

1. Remove the machine rear, controller board cover, and middle knockout. (☛3.20.1)
2. Remove the slot cover [A] (⚙ x 2). Save these screws
3. Attach the Bluetooth Board [B] to the controller board.
NOTE: Make sure that the jumper at TB1 is set on the left at 3, 4.
4. Fasten the board with the screws [C] removed in Step 2.






- ⇒ 5. With the Bluetooth PCI card label facing the front of the machine, insert the card [A] into the PCI slot.
6. Press the antenna [B] to extend it.
7. Attach the antenna cap [C].

3.20.10 POSTSCRIPT 3 UNIT (G354-05)

Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. PostScript 3 Emulation SD Card.....	1
2. Decal	1



Installation

⚠ CAUTION
Unplug the main machine power cord before starting the following procedure.

NOTE: To install this DIMM, the Printer/Scanner option must be installed first. (☛3.20.2)


1. Remove the machine rear, controller board cover. (☛3.20.1)
2. Install the Postscript 3 DIMM [A] in the upper slot [B] of the controller board.

3.20.11 FILE FORMAT CONVERTER (B519)

Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. File Format Converter Board	1



CAUTION
Unplug the main machine power cord before starting the following procedure.

NOTE: Only one slot is available for the interface option. You can install only one printer interface option at a time: File Format Converter (B519), IEEE 1394 (G336), IEEE 802.11b (B515), USB 2.0 (B525-01), or Bluetooth (G354).

1. Remove the machine rear, controller board cover, and middle knockout. (☛3.20.1)
2. Remove the slot cover [A] (☛ x 2). Save these screws
3. Attach the File Format Converter board [B] to the controller board.
4. Fasten the board with the screws [C] removed in Step 2.

3.20.12 CHECK ALL CONNECTIONS

1. Plug in the power cord and turn on the main switch.
2. Enter the printer user mode and print the configuration page.

User Tools> Printer Settings> List Test Print> Config. Page

NOTE: The same data can also be printed by executing SP1-004 – Print Summary. All installed options are listed in the “System Reference” column.


⇒ 3.20.13 USER ACCOUNT ENHANCEMENT UNIT (B443)

Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. User Account Enhancement Unit.....	1

⚠ CAUTION
Unplug the main machine power cord before starting the following procedure.



1. Remove the machine rear cover and controller board cover. (☛3.20.1)
2. Install the user account enhancement NVRAM [A] in optional socket (IC 37).
3. Replace the controller board cover, rear cover, and plug in cord and turn on the main switch.

SERVICE TABLES

4. SERVICE TABLES

4.1 GENERAL CAUTION

⚠ CAUTION

Never turn off the main power switch when the power LED is lit or flashing. To avoid damaging the hard disk or memory, press the operation power switch to switch the power off, wait for the power LED to go off, and then switch the main power switch off.

NOTE: The main power LED (Ⓜ) lights or flashes while the platen cover or ARDF is open, while the main machine is communicating with a fax machine or the network server, or while the machine is accessing the hard disk or memory for reading or writing data.

Do not turn off the main switch while any of the electrical components are active. Doing so might cause damage to units, such as the PCU, when they are pulled out of or put back into the copier.

4.1.1 PCU (PHOTOCONDUCTOR UNIT)

The PCU consists of the OPC drum, development unit, charge roller, and cleaning unit. Follow the cautions below when handling a PCU.

1. Never touch the drum surface with bare hands. When the drum surface is touched or becomes dirty, wipe it with a dry cloth or clean it with wet cotton. Wipe with a dry cloth after cleaning with the cotton.
2. Never used alcohol to clean the drum; alcohol dissolves the drum surface.
3. Store the PCU in a cool, dry place away from heat.
4. Never expose the drum to corrosive gases such as ammonia gas.
5. Never shake the used PCU. Doing so may cause toner and/or developer to spill out.
6. Dispose of used PCUs in accordance with local regulations.

4.1.2 TRANSFER ROLLER UNIT

1. Never touch the transfer roller surface with bare hands.
2. Take care not to scratch the transfer roller as the surface is easily damaged.

4.1.3 SCANNER UNIT

1. Clean the exposure glass with alcohol or with glass cleaner to reduce the amount of static electricity on the surface of the glass.
2. Use a blower brush or a cotton pad with water to clean the mirrors and lens.

GENERAL CAUTION

3. Do not bend or crease the exposure lamp flat cable.
4. Do not disassemble the lens unit. Doing so will throw the lens and the copy image out of focus.
5. Do not turn any of the CCD positioning screws. Doing so will throw the CCD out of position.

4.1.4 LASER UNIT

1. Do not loosen the screws that secure the LD drive board to the laser diode casing. Doing so will throw the LD unit out of adjustment.
2. Do not adjust the variable resistors on the LD unit, as they are adjusted in the factory.
3. The polygon mirror and F-theta mirror are very sensitive to dust.
4. Do not touch the glass surface of the polygon mirror motor unit with bare hands.

4.1.5 FUSING UNIT

1. After installing the fusing thermistor, make sure that it is in contact with the hot roller and that the hot roller can rotate freely.
2. Be careful not to damage the edges of the hot roller strippers or their tension springs.
3. Do not touch the fusing lamp and rollers with bare hands.
4. Make sure that the fusing lamp is positioned correctly and that it does not touch the inner surface of the hot roller.

4.1.6 PAPER FEED

1. Do not touch the surface of the paper feed roller.
2. To avoid paper misfeeds, the side fences and end fences of the paper tray must be positioned correctly to align with the actual paper size.

4.1.7 OTHERS

1. The TD sensor initial setting is performed automatically after installing the new PCU and closing the front cover. Never open the front cover or turn off the main switch during this time. The main motor stops when the initial setting has finished.
2. The toner bottle should be replaced while the main switch is on.
3. If the optional tray, drum, and optics anti-condensation heaters have been installed, keep the copier power cord plugged in, even when the copier main switch is turned off. This keeps the heaters energized.

4.2 SERVICE PROGRAM MODE

4.2.1 SERVICE PROGRAM MODE OPERATION

The service program mode is used to check electrical data, change modes, and adjust values. Two service program modes are provided:

- **SP Mode (Service)**. Includes all the options in the SP displays for normal maintenance and adjustments.
- **SSP Mode (Special Service)**. Includes the normal SP modes and *some additional options in the SP displays not required for normal settings and adjustments*. (Most are marked “DFU” in the following tables.) Do not change these important settings needlessly. For details, contact your supervisor.

Entering and Exiting SP mode



1. Press the Clear Mode key.



2. Use the keypad to enter “107”.



3. Hold down Clear/Stop for at least 3 seconds.

4. Enter the Service Mode.

To enter the Normal Service Mode:

Copy SP

On the touch-panel, press Copy SP.

To enter the Special Service Mode:

Copy SP

Hold down # and then press Copy SP.

Exit


5. Press Exit twice to return to the copy window.

NOTE: Use SP2902 to perform test pattern printing. (☛ 4.2.3)

SERVICE PROGRAM MODE

SP Mode Button Summary

Here is a short summary of the touch-panel buttons.



- ① Opens all SP groups and sublevels.
- ② Closes all open groups and sublevels and restores the initial SP mode display.
- ③ Opens the copy window (copy mode) so you can make test copies. To return to the SP mode screen, press SP Mode (highlighted) in the copy window.
- ④ Enter the SP code directly with the number keys if you know the SP number and then press $\#$. (SP Mode must be highlighted before you can enter the number. Just press SP Mode if it is not highlighted.)
- ⑤ Press twice to leave the SP mode and return to the copy window to resume normal operation.
- ⑥ Press any Group number to open a list of SP codes and titles for that group. For example, to open the SP code list for SP1nnn, press Group1. If an SP has sublevels, touch the appropriate button to expand the list.
- ⑦ Press to scroll the display to the previous or next group.
- ⑧ Press to scroll to the previous or next display in segments the size of the screen display (page).
- ⑨ Press to scroll the display to the previous or next line, line by line.
- ⑩ Press to move the highlight on the left to the previous or next selection in the list.


Switching Between SP Mode and Copy Mode for Test Printing

- 1) In the SP mode, select the test print and then press Copy Window.
- 2) Use the copy window (copier mode), to select the appropriate settings (paper size, etc.) for the test print.
- 3) Press Start (Ⓢ) to execute the test print.
- 4) Press SP Mode (highlighted) to return to the SP mode screen and repeat from step 1.

Selecting the Program Number

Program numbers have two or three levels.

1. Before you begin, refer to the Service Tables to find the SP that you want to adjust. (☞ 4.2.2)
2. Press the Group number on the left side SP Mode window that contains the SP that you want to adjust.
3. Use the scrolling buttons in the center of the SP mode window to display the SP number that you want to open, and then press that number to expand the list.
4. Use the center touch-panel buttons to scroll to the number and title of the item that you want to set and press. The small entry box on the right is activated and displays the default or the current setting below.



NOTE: Refer to the Service Tables for the range of allowed settings. (☞ 4.2.2)


1. To enter a setting
 - Press (⊕/⊖) to toggle between plus and minus and then use the keypad to enter the appropriate number. The number you enter writes over the previous setting.
 - Press (#) to enter the setting. (If you enter a number that is out of range, the key press is ignored.)
 - When you are prompted to complete the selection, press Yes.
2. If you need to perform a test print, press Copy Window to open the copy window and select the settings for the test print. Press Start (Ⓢ) twice, and then press SP Mode (highlighted) in the copy window to return to the SP mode display.
3. When you are finished, press Exit twice to return to the copy window.


4.2.2 SERVICE PROGRAM MODE TABLES

Service Table Key

Notation	What it means
[range / default / step]	Example: [-9 ~ +9 / +3.0 / 0.1 mm step]. The setting can be adjusted in the range ± 9 , the setting is reset to +3.0 after an NVRAM reset, and the value can be changed in 0.1 mm steps with each key press.
<i>italics</i>	Comments added for reference.
*	Value stored in NVRAM. After a RAM reset, this default value (factory setting) is restored.
<i>1111</i>	An SP number set in bold-italic denotes a "Special Service Program" mode setting that appears only after entering the SP mode by pressing $\text{\textcircled{\#}}$ and Copy SP together. (☛ 4.2.1)
DFU	Denotes "Design or Factory Use". Do not change this value.
Japan only	The feature or item is for Japan only. Do not change this value.
(S)	Sideways feed direction
(L)	Lengthwise feed direction

SP1XXX: Feed

1001*	Leading Edge Registration	[+9.0 ~ -9.0 / +0.0 / 0.1 mm/step]
1001 1	Paper Tray Feed	Adjusts the printing leading edge registration from each paper feed station using the Trimming Area Pattern (SP4417, No.15). Use the  key to toggle between + and - before entering the value. The specification is 3 ± 2 mm. See "Replacement and Adjustment - Copy Adjustment" for details.
1001 2	By-pass Feed	
1001 3	Duplex, Side2	

1002*	Side-to-Side Registration	[+9.0 ~ -9.0 / +0.0 / 0.1 mm/step]
1002 1	Tray 1	Adjusts the printing side-to-side registration from each paper feed station using the Trimming Area Pattern (SP4417, No.15). Use the  key to toggle between + and - before entering the value. The specification is 2 ± 1.5 mm. See "Replacement and Adjustment - Copy Adjustment" for details.
1002 2	Tray 2	
1002 3	Tray 3 (Optional PFU Tray 1, or LCT)	
1002 4	Tray 4 (Optional PFU Tray 2)	
1002 5	By-pass	
1002 6	Duplex Side 2	

1003*	Paper Feed Timing	
1003 1	Tray 1	Adjusts the paper feed clutch timing at registration. The paper feed clutch timing determines the amount of paper buckle at registration. (A larger setting leads to more buckling.) [0 ~ 10 / 5 / 1 mm/step]
1003 2	Tray 2/3/4 By-pass	
1003 3	Duplex Side 2	[0 ~ 20 / 6 / 1 mm/step]

1007	By-pass Paper Size Display	Displays the by-pass paper width sensor output.
------	----------------------------	---

1103	Fusing Idling	[0 = Off / 1 = On / 2 = Off plus machine temperature check]
Switches fusing idling on/off. Switch on if fusing on the 1st and 2nd copies is incomplete (this may occur if the room is cold.)		

Service Tables

SERVICE PROGRAM MODE

1105*	Fusing Temperature Adjustment	
1105 1	Roller Center	Adjusts the fusing temperature at the center and both ends of the hot roller for normal printing. [120 ~ 200 / 165 / 1°C/step]
1105 2	Roller Ends	
1105 3	Energy Saver	Adjusts the fusing temperature at the center and both ends of the hot roller for energy saver mode. [0 ~ 160 / 150 / 1°C/step]
1105 4	Thick Paper - Center	Adjusts the additional fusing temperature for thick paper for the 2nd paper tray and for the bypass tray. [0 ~ 30 / 15 / 1°C/step]
1105 5	Thick Paper - Ends	
1105 6	After Warming-up - Center	Adjusts the fusing temperature at the center of the hot roller after the machine has warmed up. [120 ~ 200 / 165 / 1°C/step]
1105 7	After Warming-up - Ends	Adjusts the fusing temperature at both ends of the hot roller after the machine has warmed up. [120 ~ 200 / 175 / 1°C/step]
1105 8	After Warming-up - No. of Pages	In this machine, fusing temperature is kept 10°C higher than the normal temperature for a number of pages after the machine has warmed up. This SP selects the number of pages made at this temperature. See Detailed Section Descriptions – Fusing for more details. [0 ~ 10 / 3 / 1 page/step]
1105 9	After Warming-up - Times	In this machine, fusing temperature is kept 10°C higher than the normal temperature for a short while after the machine been warmed up. This SP selects the length of time that this temperature is used. See Detailed Section Descriptions – Fusing for more details. [0 ~ 180 / 60 / 1s/step]

1106	Fusing Temp. Display	
1106 1	Roller Center	Displays the fusing temperature for the center or both ends of the hot roller.
1106 2	Roller Ends	
1106 3	In the Machine at Power On	Displays the temperature in the machine at power on. <i>This temperature is monitored by the thermistor on the SBCU board.</i>

1108*	Fusing Soft Start Setting	
	Selects whether the fusing temperature control cycle is 1 or 3 seconds. <i>If this is "1 (3 s)", the power supply fluctuation caused by the fusing lamp turning on is less often.</i> [0 = 1 s / 1 = 3 s] Default: 0 = N. America, 1 = Europe/Asia	

1109	Fusing Nip Band Check	
	Checks the fusing nip band (☛ 4.2.11) [1 = Start / 0 = Stop]	

1903*	Feed Clutch Re-energize	
	Adjusts the paper feed amount allowed by the clutch after correcting the skew at registration. When paper jams occur after restarting paper feed after registration, increase the value to help the registration roller feed the paper.	
1903 1	By-pass Feed	[0 ~ 10 / 6 / 1 mm/step]
1903 2	Tray 1 Feed	[0 ~ 10 / 0 / 1 mm/step]
1903 3	Other Trays	

1905*	Tray Paper Full Detection	[0 = No / 1 = Yes]
	Determines whether or not to detect if the built-in copy tray is full.	

1906*	Tray Paper Full Timer	[100 ~ 5000 / 500 / 10 ms/step]
	Adjusts the time that the paper overflow sensor must remain on before a message appears on the LCD. The sensor may be switched on and off again if the paper is curled, giving a false tray full detection. This SP prevents this problem. <i>This SP mode is used when SP1905 is set to 1.</i>	

1908*	1st Bottom Plate Pressure Adjustment	
1908 1	Normal Size	
	<p>If a middle size threshold is not stored with SP1908-9, this SP adjusts the upper paper lift motor reverse time for paper sizes larger than the small size threshold set with SP1908-8.</p> <p>If a middle size threshold is stored with SP1908-9, then this SP adjusts the motor reverse time for sizes larger than the middle size.</p> <p>Do not input a value greater than 1200.</p> <p><i>Use this SP when a paper feed problem occurs from the 1st paper tray.</i></p> <p><i>See "Paper Lift Mechanism" for details on SP1908.</i></p> <p>[0 ~ 2000 / 200 / 1 ms/step]</p>	
1908 2	Small Size	
	<p>Adjusts the upper paper lift motor reverse time for paper of the same size as or smaller than the small size threshold set with SP1908-8.</p> <p>Do not input a value greater than 1200.</p> <p><i>Use this SP when a paper feed problem occurs from the 1st paper tray.</i></p> <p><i>See "Paper Lift Mechanism" for details on SP1908.</i></p> <p>[0 ~ 2000 / 600 / 1 ms/step]</p>	
1908 3	Middle Size	
	<p>Adjusts the upper paper lift motor reverse time for paper sizes larger than the small size threshold set with SP1908-8, up to and including the middle size threshold set with SP1908-9. If a middle size threshold is not stored with SP1908-9, this SP is not used.</p> <p>Do not input a value greater than 1200.</p> <p><i>Use this SP when a paper feed problem occurs from the 1st paper tray.</i></p> <p><i>See "Paper Lift Mechanism" for details on SP1908.</i></p> <p>[0 ~ 2000 / 200 / 1 ms/step]</p>	

SERVICE PROGRAM MODE

1908	1st Bottom Plate Pressure Re-adjustment
1908 4	Small Size
	Adjusts the upper paper lift motor forward rotation time for paper of the same size as or smaller than the small size threshold set with SP1908-8. The motor rotates forward when the remaining paper amount is lower than the value of SP1908-6. <i>Use this SP when a paper feed problem occurs when paper in the 1st paper tray is running low.</i> <i>See "Paper Lift Mechanism" for details on SP1908.</i> [0 ~ 2000 / 400 / 1 ms/step]
1908 5	Middle Size
	Adjusts the upper paper lift motor forward rotation time for paper sizes larger than the small size threshold set with SP1908-8, up to and including the middle size threshold set with SP1908-9. The motor rotates forward when the amount of remaining paper is lower than the value of SP1908-7. If a middle size threshold is not stored with SP1908-9, this SP is not used. <i>Use this SP when a paper feed problem occurs when paper in the 1st paper tray is running low.</i> <i>See "Paper Lift Mechanism" for details on SP1908.</i> [0 ~ 2000 / 300 / 1 ms/step]
	1st Paper Amount
1908 6	Small Size
	Selects the remaining paper amount limit for use with SP1908-4. <i>Set this SP to 2 or 3 when a paper feed problem occurs before near-end.</i> <i>See "Paper Lift Mechanism" for details on SP1908.</i> [0 = None (Empty) / 1 = Near End / 2 = 25% / 3 = 75%]
1908 7	Middle Size
	Selects the remaining paper amount limit for use with SP1908-5. <i>Set this SP to 2 or 3 when a paper feed problem occurs before near-end.</i> <i>See "Paper Lift Mechanism" for details on SP1908.</i> [0 = None (Empty) / 1 = Near End / 2 = 25% / 3 = 75%]
	1st Paper Size
1908 8	1st Small Paper Size Setting
	Selects the small size threshold for the 1st paper tray. "0" means that this setting is not used. <i>The size used by SP1908 is determined by paper width. See "Paper Lift Mechanism" for details on SP1908.</i> [0 = None (Not used) / 1 = HLT/A5 / 2 = A4 / 3 = LT / 4 = DLT / 5 = A3]
1908 9	1st Middle Paper Size Setting
	Selects the middle size threshold for the upper tray. "0" means that this setting is not used. <i>The value must be larger than the small size threshold (SP1908-8). The size used by SP1908 is determined by paper width. See "Paper Lift Mechanism" for details on SP1908.</i> [0 = None (Not used) / 1 = HLT/A5 / 2 = A4 / 3 = LT / 4 = DLT / 5 = A3]

1909*	2nd Bottom Plate Pressure Adjustment
1909 1	Normal Size
	<p>If a middle size threshold is not stored with SP1909-9, this SP adjusts the upper paper lift motor reverse time for paper sizes larger than the small size threshold set with SP1909-8.</p> <p>If a middle size threshold is stored with SP1909-9, then this SP adjusts the motor reverse time for sizes larger than the middle size.</p> <p>Do not input a value greater than 1,200.</p> <p><i>Use this SP when a paper feed problem occurs from the 2nd paper tray.</i></p> <p><i>See "Paper Lift Mechanism" for details on SP1909.</i></p> <p>[0 ~ 2000 / 200 / 1 ms/step]</p>
1909 2	Small Size
	<p>Adjusts the upper paper lift motor reverse time for paper of the same size as or smaller than the small size threshold set with SP1909-8.</p> <p>Do not input a value greater than 1,200.</p> <p><i>Use this SP when a paper feed problem occurs from the 2nd paper tray.</i></p> <p><i>See "Paper Lift Mechanism" for details on SP1909.</i></p> <p>[0 ~ 2000 / 600 / 1 ms/step]</p>
1909 3	Middle Size
	<p>Adjusts the upper paper lift motor reverse time for paper sizes larger than the small size threshold set with SP1909-8, up to and including the middle size threshold set with SP1909-9. If a middle size threshold is not stored with SP1909-9, this SP is not used.</p> <p>Do not input a value greater than 1200.</p> <p><i>Use this SP when a paper feed problem occurs from the 2nd paper tray.</i></p> <p><i>See "Paper Lift Mechanism" for details on SP1909.</i></p> <p>[0 ~ 2000 / 200 / 1 ms/step]</p>
	2nd Bottom Plate Pressure Re-adjustment
1909 4	Small Size
	<p>Adjusts the upper paper lift motor forward rotation time for paper of the same size as or smaller than the small size threshold set with SP1909-8. The motor rotates forward when the remaining paper amount is lower than the value of SP1909-6.</p> <p><i>Use this SP when a paper feed problem occurs when paper in the 2nd paper tray is running low.</i></p> <p><i>See "Paper Lift Mechanism" for details on SP1909.</i></p> <p>[0 ~ 2000 / 400 / 1 ms/step]</p>
1909 5	Middle Size
	<p>Adjusts the upper paper lift motor forward rotation time for paper sizes larger than the small size threshold set with SP1909-8, up to and including the middle size threshold set with SP1909-9.</p> <p>The motor rotates forward when the remaining paper amount is lower than the value of SP1909-7.</p> <p>If a middle size threshold is not stored with SP1909-9, this SP is not used.</p> <p><i>Use this SP when a paper feed problem occurs when paper in the 2nd paper tray is running low.</i></p> <p><i>See "Paper Lift Mechanism" for details on SP1909.</i></p> <p>[0 ~ 2000 / 300 / 1 ms/step]</p>

SERVICE PROGRAM MODE

	2nd Paper Amount
1909 6	Small Size
	Selects the remaining paper amount limit for use with SP1909-4. <i>Set this SP to 2 or 3 when a paper feed problem occurs before near-end. See "Paper Lift Mechanism" for details on SP1909.</i> [0 = None (Empty) / 1 = Near End / 2 = 25% / 3 = 75%]
1909 7	Middle Size
	<i>Set this SP to 2 or 3 when a paper feed problem occurs before near-end. See "Paper Lift Mechanism" for details on SP1909.</i>
	2nd Paper Size
1909 8	2nd Small Paper Size Setting
	Selects the small size threshold for the 2nd paper tray. "0" means that this setting is not used. <i>The size used by SP1909 is determined by paper width. See "Paper Lift Mechanism" for details on SP1909.</i> [0 = None (Not used) / 1 = HLT/A5 / 2 = A4 / 3 = LT / 4 = DLT / 5 = A3]
1909 9	2nd Middle Paper Size Setting
	Selects the middle size threshold for the upper tray. "0" means that this setting is not used. <i>The value must be larger than the small size threshold (SP1909-8). The size used by SP1909 is determined by paper width. See "Paper Lift Mechanism" for details on SP1909.</i> [0 = None (Not used) / 1 = HLT/A5 / 2 = A4 / 3 = LT / 4 = DLT / 5 = A3]

1910*	3rd Bottom Plate Pressure Adjustment
1910 1	Normal Size (Optional PFU)
	If a middle size threshold is not stored with SP1910-9, this SP adjusts the upper paper lift motor reverse time for paper sizes larger than the small size threshold set with SP1910-8. If a middle size threshold is stored with SP1910-9, then this SP adjusts the motor reverse time for sizes larger than the middle size. Do not input a value greater than 1200. <i>Use this SP when a paper feed problem occurs from the 3rd paper tray. See "Optional Paper Tray Unit – Paper Lift Mechanism" for details on SP1910.</i> [0 ~ 2000 / 200 / 1 ms/step]
1910 2	Small Size (Optional PFU)
	Adjusts the upper paper lift motor reverse time for paper of the same size as or smaller than the small size threshold set with SP1910-8. Do not input a value greater than 1200. <i>Use this SP when a paper feed problem occurs from the 3rd paper tray. See "Optional Paper Tray Unit – Paper Lift Mechanism" for details on SP1910.</i> [0 ~ 2000 / 600 / 1 ms/step]
1910 3	Middle Size (Optional PFU)
	Adjusts the upper paper lift motor reverse time for paper sizes larger than the small size threshold set with SP1910-8, up to and including the middle size threshold set with SP1910-9. If a middle size threshold is not stored with SP1910-9, this SP is not used. Do not input a value greater than 1200. <i>Use this SP when a paper feed problem occurs from the 3rd paper tray. See "Optional Paper Tray Unit – Paper Lift Mechanism" for details on SP1910.</i> [0 ~ 2000 / 200 / 1 ms/step]

	3rd Bottom Plate Pressure Re-adjustment
1910 4	Small Size (Optional PFU)
	Adjusts the upper paper lift motor forward rotation time for paper of the same size as or smaller than the small size threshold set with SP1910-8. The motor rotates forward when the remaining paper amount is lower than the value of SP1910-6. <i>Use this SP when a paper feed problem occurs when paper in the 3rd paper tray is running low.</i> See "Optional Paper Tray Unit – Paper Lift Mechanism" for details on SP1910. [0 ~ 2000 / 400 / 1 ms/step]
1910 5	Middle Size (Optional PFU)
	Adjusts the upper paper lift motor forward rotation time for paper sizes larger than the small size threshold set with SP1910-8, up to and including the middle size threshold set with SP1910-9. The motor rotates forward when the remaining paper is lower than the value of SP1910-7. If a middle size threshold is not stored with SP1910-9, this SP is not used. <i>Use this SP when a paper feed problem occurs when paper in the 3rd paper tray is running low.</i> See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1910. [0 ~ 2000 / 300 / 1 ms/step]
	3rd Paper Amount
1910 6	Small Size (Optional PFU)
	Selects the remaining paper amount limit for use with SP1910-4. <i>Set this SP to 2 or 3 when a paper feed problem occurs before near-end.</i> See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1910. [0 = None (Empty) / 1 = Near End / 2 = 25% / 3 = 75%]
1910 7	Middle Size (Optional PFU)
	Selects the remaining paper amount limit for use with SP1910-5. <i>Set this SP to 2 or 3 when a paper feed problem occurs before near-end.</i> See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1910. [0 = None (Empty) / 1 = Near End / 2 = 25% / 3 = 75%]
	3rd Paper Size
1910 8	3rd Small Paper Size Setting (Optional PFU)
	Selects the small size threshold for the 3rd paper tray. "0" means that this setting is not used. <i>The size used by SP1910 is determined by paper width. See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1910.</i> [0 = None (Not used) / 1 = HLT/A5 / 2 = A4 / 3 = LT / 4 = DLT / 5 = A3]
1910 9	3rd Middle Paper Size Setting (Optional PFU)
	Selects the middle size threshold for the upper tray. "0" means that this setting is not used. <i>The value must be larger than the small size threshold (SP1910-8). The size used by SP1910 is determined by paper width. See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1910.</i> [0 = None (Not used) / 1 = HLT/A5 / 2 = A4 / 3 = LT / 4 = DLT / 5 = A3]

SERVICE PROGRAM MODE

1911*	4th Bottom Plate Pressure Adjustment
1911 1	Normal Size (Optional PFU)
	<p>If a middle size threshold is not stored with SP19119, this SP adjusts the upper paper lift motor reverse time for paper sizes larger than the small size threshold set with SP19118.</p> <p>If a middle size threshold is stored with SP19119, then this SP adjusts the motor reverse time for sizes larger than the middle size.</p> <p>Do not input a value greater than 1200.</p> <p><i>Use this SP when a paper feed problem occurs from the 4th paper tray.</i></p> <p><i>See "Optional Paper Tray Unit – Paper Lift Mechanism" for details on SP1911.</i></p> <p>[0 ~ 2000 / 200 / 1 ms/step]</p>
1911 2	Small Size (Optional PFU)
	<p>Adjusts the upper paper lift motor reverse time for paper of the same size as or smaller than the small size threshold set with SP19118.</p> <p>Do not input a value greater than 1200.</p> <p><i>Use this SP when a paper feed problem occurs from the 4th paper tray.</i></p> <p><i>See "Optional Paper Tray Unit – Paper Lift Mechanism" for details on SP1911.</i></p> <p>[0 ~ 2000 / 600 / 1 ms/step]</p>
1911 3	Middle Size (Optional PFU)
	<p>Adjusts the upper paper lift motor reverse time for paper sizes larger than the small size threshold set with SP19118, up to and including the middle size threshold set with SP19119. If a middle size threshold is not stored with SP19119, this SP is not used.</p> <p>Do not input a value greater than 1200.</p> <p><i>Use this SP when a paper feed problem occurs from the 4th paper tray.</i></p> <p><i>See "Optional Paper Tray Unit – Paper Lift Mechanism" for details on SP1911.</i></p> <p>[0 ~ 2000 / 200 / 1 ms/step]</p>
	4th Bottom Plate Pressure Re-adjustment
1911 4	Small Size (Optional PFU)
	<p>Adjusts the upper paper lift motor forward rotation time for paper of the same size as or smaller than the small size threshold set with SP19118. The motor rotates forward when the remaining paper amount is lower than the value of SP19116.</p> <p><i>Use this SP when a paper feed problem occurs when paper in the 4th paper tray is running low.</i></p> <p><i>See "Optional Paper Tray Unit – Paper Lift Mechanism" for details on SP1911.</i></p> <p>[0 ~ 2000 / 400 / 1 ms/step]</p>
1911 5	Middle Size (Optional PFU)
	<p>Adjusts the upper paper lift motor forward rotation time for paper sizes larger than the small size threshold set with SP19118, up to and including the middle size threshold set with SP19119.</p> <p>The motor rotates forward when the remaining paper amount is lower than the value of SP19117.</p> <p>If a middle size threshold is not stored with SP19119, this SP is not used.</p> <p><i>Use this SP when a paper feed problem occurs when paper in the 4th paper tray is running low.</i></p> <p><i>See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1911.</i></p> <p>[0 ~ 2000 / 300 / 1 ms/step]</p>
	4th Paper Amount
1911 6	Small Size (Optional PFU)
	<p>Selects the remaining paper amount limit for use with SP19114.</p> <p><i>Set this SP to 2 or 3 when a paper feed problem occurs before near-end.</i></p> <p><i>See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1911.</i></p> <p>[0 = None (Empty) / 1 = Near End / 2 = 25% / 3 = 75%]</p>

1911 7	Middle Size (Optional PFU)
	Selects the remaining paper amount limit for use with SP19115. <i>Set this SP to 2 or 3 when a paper feed problem occurs before near-end.</i> <i>See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1911.</i> [0 = None (Empty) / 1 = Near End / 2 = 25% / 3 = 75%]
	4th Paper Size
1911 8	4th Small Paper Size Setting (Optional PFU)
	Selects the small size threshold for the 4th paper tray. "0" means that this setting is not used. <i>The size used by SP1911 is determined by paper width. See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1911.</i> [0 = None (Not used) / 1 = HLT/A5 / 2 = A4 / 3 = LT / 4 = DLT / 5 = A3]
1911 9	4th Middle Paper Size Setting (Optional PFU)
	Selects the middle size threshold for the upper tray. "0" means that this setting is not used. <i>The value must be larger than the small size threshold (SP19118). The size used by SP1911 is determined by paper width. See "Optional Paper Tray Unit - Paper Lift Mechanism" for details on SP1911.</i> [0 = None (Not used) / 1 = HLT/A5 / 2 = A4 / 3 = LT / 4 = DLT / 5 = A3]

1912*	Tray Motor Reverse Time
	Adjusts the tray motor reverse time. <i>The tray motor reverses when the tray is pulled out. The tray can be put back in the machine without damage while the motor reverses.</i> [0 ~ 9000 / 1700 / 1 ms/step]

1994	Punch Hole Detection
	When using paper that has punch holes, the registration sensor may detect the hole and a paper jam will be detected. If you select "1", the machine ignores the registration sensor off signal within 50 mm from the trailing edge of the paper. [0 = No 1 = Yes] DFU

1995	Paper Height Sensor Check DFU
	These sensors display the status of the paper height sensors for the 1st and 2nd Paper Trays.
1995 1	1st Paper Tray 1:OK 0:NG
1995 2	2nd Tray 1:OK 0:NG

1997	Jam Detect for Manual Tray	[0 ~ 1/ 0 / 1]
	Sets the jam detection method for the bypass tray. 0: Normal Detection. Detects a jam if the size of the paper fed is shorter or longer than the size selected for the bypass tray. 1: Simple Detection. Detects a jam if the size of the paper fed is longer than the size set for the bypass tray.	

Service Tables

SERVICE PROGRAM MODE

SP2XXX: Drum

2001*	Charge Roller Bias Adjustment
2001 1*	Printing
	Adjusts the voltage applied to the charge roller during printing. <i>This value will be changed automatically when the charge roller bias correction is performed.</i> <i>Note that if this value is changed, the charge roller voltage will be corrected based on the new voltage.</i> [2100 ~ 1500 / -1700 / 1 V/step]
2001 2*	ID Sensor Pattern
	Adjusts the voltage applied to the charge roller when making the Vsdp ID sensor pattern (for charge roller bias correction). <i>The actual charge roller voltage is this value plus the value of SP20011.</i> [0 ~ 400 / 200 / 1 V/step]
2001 3	Temporary Input
	Inputs the charge roller voltage temporarily for test purposes. Do not change the value. [0 ~ -2500 / 0 / 1 V/step]

2005*	Charge Roller Bias Correction
2005 1	Vsdp Min
	Adjusts the lower threshold value for the charge roller correction. <i>When the value of Vsdp/Vsg is less than this value, the charge roller voltage increases by 50V (e.g. from -500 to -550). The size of the increase depends on SP2005 3.</i> [0 ~ 100 / 90 / 1%/step]
2005 2	Vsdp Max
	Adjusts the upper threshold value for the charge roller correction. <i>When the value of Vsdp/Vsg is greater than this value, the charge roller voltage decreases by 50V (e.g. from -550 to -500). The size of the decrease depends on SP2005 3.</i> [0 ~ 100 / 95 / 1 %/step]
2005 3	Charge Roller Bias Correction
	Adjusts the size of the charge roller voltage correction. [0 ~ 200 / 50 / 1 V/step]

2101*	Erase Margin Adjustment	
2101 1	Leading Edge	
		Adjusts the leading edge erase margin. <i>The specification is 3 ± 2 mm. See "Replacement and Adjustment - Copy Adjustment" for details.</i> [0.0 ~ 9.0 / 3.0 / 0.1 mm/step]
2101 2	Trailing Edge – Small Paper	
	Adjusts the trailing edge erase margin for paper of length 216 mm or less. <i>The specification is 3 ± 2 mm. See "Replacement and Adjustment - Copy Adjustment" for details.</i> [0.0 ~ 9.0 / 2.0 / 0.1 mm/step]	
2101 3	Trailing Edge – Middle Paper	
	Adjusts the trailing edge erase margin for paper of length 216.1 ~ 297 mm. <i>The specification is 3 ± 2 mm. See "Replacement and Adjustment - Copy Adjustment" for details.</i> [0.0 ~ 9.0 / 3.0 / 0.1 mm/step]	
2101 4	Trailing Edge – Large Paper	
	Adjusts the trailing edge erase margin for paper longer than 297 mm. <i>The specification is 3 ± 2 mm. See "Replacement and Adjustment - Copy Adjustment" for details.</i> [0.0 ~ 9.0 / 4.0 / 0.1 mm/step]	
2101 5	Left Side	
	Adjusts the left edge erase margin. <i>The specification is 2 ± 1.5 mm. See "Replacement and Adjustment - Copy Adjustment" for details.</i> [0.0 ~ 9.0 / 2.0 / 0.1 mm/step]	
2101 6	Right Side	
	Adjusts the right edge erase margin. <i>The specification is $2 + 2.5/-1.5$ mm. See "Replacement and Adjustment - Copy Adjustment" for details.</i> [0.0 ~ 9.0 / 2.0 / 0.1 mm/step]	
2101 7	Rear – Trailing Edge (Duplex 2nd Side)	
	Adjusts the trailing edge erase margin on the reverse side of duplex copies. The actual trailing edge erase margin on the reverse side is this value plus the value of SP21012 or 3 or 4. <i>The specification is 3 ± 2 mm. See "Replacement and Adjustment - Copy Adjustment" for details.</i> [0.0 ~ 9.0 / 1.2 / 0.1 mm/step]	
2101 8	Rear – Left Side (Duplex 2nd Side)	
	Adjusts the left side erase margin on the reverse side of duplex copies. The actual left side erase margin on the reverse side is this value plus the value of SP21015. <i>The specification is 2 ± 1.5 mm. See "Replacement and Adjustment - Copy Adjustment" for details.</i> [0.0 ~ 9.0 / 0.3 / 0.1 mm/step]	
2101 9	Rear – Right Side (Duplex 2nd Side)	
	Adjusts the right side erase margin on the reverse side of duplex copies. The actual right side erase margin on the reverse side is this value plus the value of SP21016. <i>The specification is $2 + 2.5/-1.5$ mm. See "Replacement and Adjustment - Copy Adjustment" for details.</i> [0.0 ~ 9.0 / 0.3 / 0.1 mm/step]	

SERVICE PROGRAM MODE

2101 10	Printer - Rear Trailing Edge
	<p>In printer mode, adjusts the trailing edge erase margin on the reverse side of duplex copies.</p> <p>The actual trailing edge erase margin on the reverse side is this value plus the value of SP21017.</p> <p><i>The specification is 3 ± 2 mm. See "Replacement and Adjustment - Copy Adjustment" for details</i></p> <p>[0.0 ~ 9.0 / 0.0 / 0.1 mm/step]</p>

2103*	LD Power Adjustment	[50 ~ 170 / 129 / 1/step]
	<p>Adjusts the LD power. DFU</p> <p>Do not change the value.</p>	

2110*	Test Mode dpi										
	<p>Sets the scanning resolution (dpi). DFU</p> <p>[See below / 8 / 0~18]</p> <table> <tr> <td>0: 400x400 dpi</td> <td>1: 391x406 dpi</td> </tr> <tr> <td>2: 406x391 dpi</td> <td>4: 300x300 dpi</td> </tr> <tr> <td>8: 600x600 dpi</td> <td>15: 439x430 dpi</td> </tr> <tr> <td>16: 476x476 dpi</td> <td>17: 483x465 dpi</td> </tr> <tr> <td>18: 465x483 dpi</td> <td></td> </tr> </table>	0: 400x400 dpi	1: 391x406 dpi	2: 406x391 dpi	4: 300x300 dpi	8: 600x600 dpi	15: 439x430 dpi	16: 476x476 dpi	17: 483x465 dpi	18: 465x483 dpi	
0: 400x400 dpi	1: 391x406 dpi										
2: 406x391 dpi	4: 300x300 dpi										
8: 600x600 dpi	15: 439x430 dpi										
16: 476x476 dpi	17: 483x465 dpi										
18: 465x483 dpi											

2201*	Development Bias Adjustment
2201 1	Printing
	<p>Adjusts the development bias during printing.</p> <p><i>This can be adjusted as a temporary measure if faint copies appear due to an aging drum.</i></p> <p>[-1500 ~ 2000 / -650 / 1 V/step]</p>
2201 2	ID Sensor Pattern
	<p>Adjusts the development bias for making the ID sensor pattern.</p> <p>The actual development voltage for the ID sensor pattern is this value plus the value of SP22011.</p> <p><i>This should not be used in the field, because it affects ID sensor pattern density, which affects toner supply.</i></p> <p>[0 = N (200V) / 1 = H (240V) / 2 = L (160V) / 3 = HH (280V) / 4 = LL (120V)]</p>

2210*	Bias Off Time
2210 1	Charge Bias
	<p>Adjusts the charge voltage (-1200V) application time.</p> <p>DFU</p> <p><i>When the charge voltage and development bias are turned off at the same time, toner or carrier will be attracted to the drum. To reduce the toner or carrier attraction, the machine applies -1200V to the charge roller before the development bias is turned off. This SP adjusts the time for applying the charge.</i></p> <p>[0 ~ 150 / 80 / 1 ms /step]</p>
2210 2	Development Bias
	<p>Adjusts the development bias off time.</p> <p>DFU</p> <p>[-120 ~ 120 / 0 / 1ms/step]</p>

2211*	PCU Reverse Interval	[0 ~ 999 / 100 / 1 sheet/step] 0: Never cleans during job
	Adjusts the PCU reverse interval for cleaning during a job. When the machine has made this number of copies in the middle of a job, the machine reverses to clean the edge of the cleaning blade. After cleaning, the machine resumes the job. Set to a shorter interval if thin white lines appear on printouts.	

2213*	Copies after Near End	[0 = 50 pages / 1 = 20 pages]
	Selects the number of copies that can be made after toner near-end has been detected. <i>If the user normally makes copies with a high proportion of black, reduce the interval.</i>	

2220*	Vt/Vsg/Vsp/Vsdp/Vts Display	
2220 1	Vsp	Displays the individual Vt, Vsg, Vsp, Vsdp, and Vts values.
2220 2	Vsg	
2220 3	Vsdp	
2220 4	Vt	
2220 5	Vts	
2220 6	Vsp/Vsg/Vsdp/Vt/Vts	Displays all the data used in process control, separated by slashes (/).

2301*	Transfer Current Adjust	
2301 1*	Normal Paper	Adjusts the current applied to the transfer roller during copying from a paper tray when the user uses the "Normal" paper setting. <i>If the user normally feeds thicker paper from a paper tray, use a higher setting.</i> [0 = -2 μA / 1 = 0 μA / 2 = +2 μA / 3 = +4 μA]
2301 2*	Thick/Thin Paper	
	Adjusts the current applied to the transfer roller during copying from the by-pass tray. These settings are also used if the 2nd tray is used and special paper is selected. <i>If the user normally feeds thicker paper from the by-pass tray/2nd tray (special paper), use a higher setting. If waste toner is re-attracted from the drum (this can occur when using an OHP sheet), use a higher setting.</i> [0 = -2 μA / 1 = 0 μA / 2 = +2 μA / 3 = +4 μA]	
2301 3*	Duplex, Side2	Adjusts the current applied to the transfer roller during copying from the duplex unit when the user uses the "Normal" paper setting. <i>Use this SP when the image on the rear side of the paper has a problem caused by poor image transfer.</i> [0 = -2 μA / 1 = 0 μA / 2 = +2 μA / 3 = +4 μA]
2301 4*	Cleaning	
	Adjusts the current applied to the transfer roller during roller cleaning. <i>If toner remains on the roller after cleaning (dirty background appears on the rear side of the paper), increase the current.</i> [0 ~ 10 / -4 / 1 μA/step]	
2301 5	Input – Front DFU	
2301 6	Input – Rear DFU	

Service Tables

SERVICE PROGRAM MODE

2301 7	Temp Inside the Machine
	Displays the temperature measured inside the machine just after power-on (by the thermistor on the SBCU board) the last time that the fusing unit was less than 40°C just after the machine was switched on. <i>The transfer current is corrected in accordance with this value.</i>

2801	Developer Initialization
	Initializes the developer and resets the TD and ID sensor outputs to their defaults. <i>Use this if the machine did not detect the new PCU when it was installed, and the TD/ID sensors were not initialized.</i>

2802	Developer Mixing
	Mixes the developer and checks Vt. The machine mixes the developer for 2 minutes and while doing this, it reads the TD sensor output (Vt). It does not initialize the TD sensor output. <i>If the machine has not been used for a long time, prints may have a dirty background. In this case, use this SP mode to mix the developer.</i>

2803*	Developer Initialization Data
2803 1	Vts
	When the machine detects a new PCU (photoconductor unit) in the machine, it checks the heat seals at the creation of the first ID sensor pattern. After the agitator is rotated for 30 sec., the machine creates the second ID sensor pattern and corrects the reference value of the TD sensor. The corrected reference value for the TD sensor is recorded here.
2803 2	ID Sensor PWM Value
	Displays the PWM value of the ID sensor after performing the developer initialization. This value is added to the value of SP2934 4 (PWM Start Value for Vsg Auto Adjust).
2803 3	Flag DFU

SERVICE PROGRAM MODE

2901*	Separation Voltage Adj	
2901 1	Front – Leading Edge	
	Adjusts the voltage that is applied to the separation plate during printing at the leading edge of the paper on the front side. <i>If the copies have pawl marks at the leading edge, increase this voltage.</i> [-1000 ~ 4000 / -1800 / 1 V/step]	
2901 2	Front – Image Area	
	Adjusts the voltage that is applied to the separation plate during printing on the image area of the paper on the front side. <i>If the copies have pawl marks in the image area, increase this voltage.</i> [-1000 ~ 4000 / -1800 / 1 V/step]	
2901 3	Rear – Leading Edge	
	Adjusts the voltage applied to the separation plate, during printing at the leading edge of the paper on the rear side. <i>See SP29011.</i> [-1000 ~ 4000 / -2100 / 1 V/step]	
2901 4	Rear – Image Area	
	Adjusts the voltage applied to the separation plate, during printing at the image area of the paper on the rear side. <i>See SP29012.</i> [-1000 ~ 4000 / -2100 / 1 V/step]	

2902*	Test Pattern	
2902 2	IPU Test Pattern	Prints the test patterns. Select the number of the test pattern that you want to print 2902-2: Not used; to print the IPU Test Pattern – SP 4417 2902-3: (● 4.2.3) <i>When adjusting the printing registration, select no. 15 (Trimming Area Pattern).</i> [0 ~ 41 / 0 / 1 step]
2902 3	Test Pattern Printing	

2906*	Tailing Correction	
2906 1	Shift Value	
	Shifts the image across the page at the interval specified by SP2906 2. <i>When making many copies of an original that contains vertical lines (such as a table), separation may not work correctly, then a tailing image will occur (ghosts of the vertical lines will continue past the bottom of the table). This SP prevents this problem.</i> [0.0 ~ 1.0 / 0.0 / 1 mm/step]	
2906 2	Interval	
	Changes the interval for the image shift specified by SP2906 1. [1 ~ 10 / 0 / 1 page/step]	

Service
Tables

SERVICE PROGRAM MODE

2907*	Line Width Correction	
	Adjusts the line width for the copy mode. The default setting disables this function. A number smaller than the default makes lines thinner, a number larger than the default makes lines thicker.	
2907 1	Text Mode	[0 ~ 10 / 5 / 1 step]
2907 2	Photo Mode	[0 ~ 10 / 6 / 1 step]
2907 3	Text/Photo Mode	[0 ~ 10 / 5 / 1 step]
2907 4	Pale Mode	
2907 5	Generation Mode	

2908	Forced Toner Supply	
	Forces the toner bottle to supply toner to the toner supply unit. Press Execute on the touch panel to start. <i>During this process, the machine supplies toner until the toner concentration in the development unit reaches a standard level. However, if the toner concentration does not reach a standard level, the machine supplies toner for 2 minutes maximum.</i>	

2909*	Main Scan Magnification	[-0.5 ~ 0.5 / 0.0 / 0.1%/step]
2909 1	Copy (Short Edge Feed)	
	Adjusts the main scan magnification in copy mode when the machine feeds the paper in the short edge feed orientation.	
2909 2	Printer (Short Edge Feed)	
	Adjusts the main scan magnification in printer mode when the machine feeds the paper in the short edge feed orientation.	
2909 3	Copy –(Long Edge Feed)	
	Adjusts the main scan magnification in copy mode when the machine feeds the paper in the long edge feed orientation.	
2909 4	Printer (Long Edge Feed)	
	Adjusts the main scan magnification in printer mode when the machine feeds the paper in the long edge feed orientation.	

2910*	Margin Adjustment for By-pass	
	Adjusts the blank margin at the trailing edge of paper fed from the by-pass table. [-9.0 ~ +9.0 / 0.1 mm / 1mm/step]	

2913*	ID Adjustment for Test Pattern	[0 ~ 15 / 15 / 1/step]
	Adjusts the image density level for black pixels on test pattern printouts (patterns are made with SP2902) <i>This SP affects all test patterns except for the grayscale test patterns.</i>	

2915*	Polygon Motor Idling Time	[0 = None / 1 = 15 s / 2 = 25 s]
<p>Selects the polygon motor idling time. <i>If the user sets an original, touches a key, or opens the platen cover/DF, the polygon motor starts idling to make a faster first copy. However, with the default (15 s), the motor stops if the user does nothing for 15 s, and stops 15 s after the end of a job.</i> <i>If set at "0", the polygon motor never turns off during stand-by. However, when the machine goes into energy saver mode, the polygon motor turns off regardless of this timer.</i></p>		

2921*	Toner Supply Mode	[0 = Sensor 1 / 1 = Sensor 2 / 2 = Fixed 1 / 3 = Fixed 2]
<p>Selects the toner supply mode. <i>Normally, only use setting 0. Change to 3 temporarily if the TD sensor is defective. Do not use settings 1 and 2; these are for designer's use only.</i></p>		

2922*	Toner Supply Time	[0.1 ~ 5.0 / 0.6 / 0.1 s/step]
<p>Adjusts the toner supply motor on time for sensor supply mode. This SP is effective only when SP2921 is "0" or "1". <i>Increasing this value increases the toner supply motor on time. So, use a high value if the user tends to make lots of copies that have a high proportion of black.</i></p>		

2923*	Toner Recovery Time	[3 ~ 60 / 30 / 1 s/step]
<p>Adjusts the toner supply motor on time during recovery from toner near-end/end. This SP is effective only when SP2921 is "0", "1", or "2". <i>Note that toner recovery is done in a 3-second cycle. So, the input value should be a multiple of 3 (e.g. 3, 6, 9). See "Toner Density Control" for more details.</i></p>		

2925*	Toner Supply Ratio									
<p>Adjusts the toner supply rate for fixed toner supply mode. This SP is effective only when SP2921 is "2" or "3". <i>Increasing this value increases the toner supply motor on time. So, use a high value if the user tends to make lots of copies that have a high proportion of black. See "Toner Density Control" for more details.</i></p>										
[0 ~ 7 / 0 / 1/step]										
<table> <tr> <td>0: t</td> <td>4: 12t</td> </tr> <tr> <td>1: 2t</td> <td>5: 16t</td> </tr> <tr> <td>2: 4t</td> <td>6: On continuously</td> </tr> <tr> <td>3: 8t</td> <td>7: 0 s</td> </tr> </table>			0: t	4: 12t	1: 2t	5: 16t	2: 4t	6: On continuously	3: 8t	7: 0 s
0: t	4: 12t									
1: 2t	5: 16t									
2: 4t	6: On continuously									
3: 8t	7: 0 s									
t: 200 ms										

2926*	Standard Vt	[0.00 ~ 5.00 / 2.50 / 0.01 V/step] DFU
<p>Adjusts Vts (Vt for a new PCU). The TD sensor output is adjusted to this value during the TD sensor initial setting process. This SP is effective only when SP2921 is "0", "1", or "2". DFU. Do not change this value.</p>		

Service Tables

SERVICE PROGRAM MODE

2927*	ID Sensor Control	[0 = No / 1 = Yes]
	Selects whether the ID sensor is used or not for toner density control. <i>If this value is "0", dirty background may occur after the machine has not been used for a long time.</i>	

2928*	Toner End Clear
	Clears the toner end condition. Press Execute on the touch panel to clear the toner end condition without adding new toner. When you press Execute, the following are cleared: <ul style="list-style-type: none"> • Toner end indicator (goes out) • Toner near-end counter • Toner near-end level When making a lot of copies after changing this setting to "1", the carrier may be attracted to the drum when the toner runs out, which may damage the drum.

2929*	Vref Adjustment
2929 1	Upper Limit
	Adjusts the upper limit for Vref. [0.00 ~ 5.00 / 3.10 / 0.01 V/step]
2921 2	Lower Limit
	Adjusts the lower limit for Vref. [0.00 ~ 5.00 / 1.40 / 0.01 V/step]

2930*	TD Sensor Manual Setting
	Adjusts the TD sensor output. DFU [0 ~ 5 / 0.0V / 0.05V/step]

2931*	TD (V/wt%) Setting
	Adjusts the TD sensor sensitivity (coefficient: S) for toner density control. DFU [0.01 ~ 1.50 / 0.4 / 0.01/step]

2932*	Toner Density Control Level
	Adjusts the toner density control threshold level. [0 = Normal / 1 = Dark / 2 = Light / 3 = Darker / 4 = Lighter] <i>Use this SP when you want to adjust the image density.</i>

2933*	ID Sensor Control Correction
	Adjusts the ID sensor control coefficient. DFU [0.5 ~ 3 / 1 / 0.1/step]

2934*	ID Sensor PWM Setting	
2934 1	Display	Displays the PWM of the ID Sensor LED.
2934 2	Upper Limit	
	Adjusts the upper limit of the PWM for the ID sensor LED. DFU [0 ~ 999 / 0 / 1/step]	
2934 3	Upper Limit Correction	
	Corrects the upper limit of the PWM for the ID sensor LED. DFU [0 ~ 999 / 0 / 1/step]	

2935	ID Sensor Initialization	
	Performs the ID sensor initial setting. <i>Press Execute on the touch panel to start. Perform this setting after replacing or cleaning the ID sensor.</i>	

2936*	ID Sensor Pattern Size	
	Selects the ID sensor pattern size in the main scan direction. <i>Set to 1 if white spots or black spots appear on prints. The ID sensor pattern is 290 mm wide, and when this is cleaned off, dirt is removed also.</i> [0 = 20 mm / 1 = 290 mm]	

2990	Original Toner ID	
	Displays the ISSUER CODE of the loaded toner. The history of the toner ID codes are stored in NVRAM for display. South Korea only	
2990 1	Latest	Most current code (in use).
2990 2	Last 1	Up to four issuer codes of toner lots in the same series can be stored. If toner with a new series code is set, then the new code replaces the history of the previous toner.
2990 3	Last 2	
2990 4	Last 3	
2990 5	Last 4	

2991	Original Toner Counter	[0~65535 / 0 / 1]
	Displays the page counts for the ISSUER CODE history. South Korea only	
2991 1	Latest	This SP displays the page counts for each successive issuer code. See SP2990 above.
2991 2	Last 1	
2991 3	Last 2	
2991 4	Last 3	
2991 5	Last 4	

2992*	Copies After TD Sensor Error	[0 = 100 copies / 1 = 200 copies]
	Selects the number of copies that can be made after a TD sensor error has been detected. When the machine copies this amount, an SC condition will occur. If the optional fax unit is installed, the SC condition occurs immediately regardless of the number of prints (this is because the sender of the fax cannot check the image quality of the printout).	

2993*	ISSUER CODE Ref	[0~9999 / 0 / 1]
	Sets the standard issuer code, once it has been determined. South Korea Only.	

2994*	Vts Limitation - Factory	
2994 1	Upper Limit - Factory Only	DFU
2994 2	Lower Limit - Factory Only	DFU

Service Tables

SERVICE PROGRAM MODE

2995*	ID Sensor Detection Interval
2995 1	Warming-up
	If the machine starts warming-up after this time has passed since entering energy saver mode or auto off mode, the machine makes an ID sensor pattern. <i>If this value is greater, there is a greater chance that background will become dirty.</i> [0 ~ 999 / 30 / 1 minute/step]
2995 2	Number of Page
	The machine makes an ID sensor pattern after the specified number of prints has been made. 0 = this feature is disabled. [0 ~ 999 / 0 / 1 page/step]






2996*	Transfer Roller Cleaning
	Selects whether the transfer roller is cleaned before each copy job. <i>Set this to '1' when dirty background appears on the reverse side of the first page of a copy job. However, the first copy time will be longer.</i> <i>If this SP is at 0, the transfer roller is never cleaned.</i> <i>See 'Detailed Section Descriptions – Transfer Roller Cleaning' for more details.</i> [0 = No / 1 = Yes]

2997*	Standard Vt (Factory Only)	DFU
-------	----------------------------	------------

2998*	PCU Reverse Rotation Time
2998 1	Wait Time
	Adjusts the waiting time for starting to rotate the drum in reverse after the end of each job. The wait time calculation formula is as follows. This value x 30 ms. 0: Reverses immediately after the end of the job (no waiting) [0 ~ 99 / 10 / 1/step]
2998 2	Reverse Time
	Adjusts the drum reverse rotation time. The reverse rotation time calculation formula is as follows. This value x 30 ms. 0: No reverse at end of job [0 ~ 99 / 1 / 1/step]

2999*	Toner Control Data Display
	Displays the toner density control data on the debug monitor. DFU [0 = No / 1 = Yes]


SP4-XXX: Scanner

4008*	Scanner Sub Scan Mag	[−0.9 ~ +0.9 / 0.0 / 0.1% step]
	Adjusts the magnification in the sub scan direction. Use the  key to toggle between + and – before entering the value. The specification is ± 1%. See “Replacement and Adjustment - Copy Adjustment” for details.	
4009*	Scanner Main Scan Mag	[−0.9 ~ +0.9 / 0.0 / 0.1% step]
	Adjusts the magnification in the main scan direction for scanning. Use the  key to toggle between + and – before entering the value. The specification is ± 1%. See “Replacement and Adjustment – Copy Adjustment” for details.	
4010*	Scanner Leading Edge Registration	[−0.9 ~ +0.9 / 0.0 / 0.1 mm step]
	Adjusts the leading edge registration for scanning in platen mode. (−): The image moves in the direction of the leading edge. Use the  key to toggle between + and – before entering the value. The specification is 2 ± 1.5 mm. See “Replacement and Adjustment – Copy Adjustment” for details.	
4011*	Scanner Side-to-side Registration	[−4.6 ~ +4.6 / 0.0 / 0.1 mm step]
	Adjusts the side-to-side registration for scanning in platen mode. (−): The image disappears at the left side. (+): The image appears. Use the  key to toggle between + and – before entering the value. The specification is 2 ± 1.5 mm. See “Replacement and Adjustment – Copy Adjustment” for details.	
4012*	Scanner Erase Margin	
4012 1	Leading Edge	Adjusts the erase margin at each side for scanning. Do not adjust this unless the user wishes to have a scanner margin that is greater than the printer margin. [0 ~ 9.0 / 0.5 / 0.1 mm/step]
4012 2	Trailing Edge	
4012 3	Right Side	
4012 4	Left Side	
4013	Scanner Free Run	
	Performs a scanner free run with the exposure lamp on. Press ON on the touch panel to start this feature. Press the  (Clear/Stop) key to stop.	

Service Tables

SERVICE PROGRAM MODE

4015*	White Plate Scanning
4015 1	Start Position
	Adjusts the scanning start position on the white plate for auto shading. <i>The default is 10.5 mm from the leading edge. The setting specifies how far scanning starts from the default position.</i> [-5.0 ~ +5.0 / 0.0 / 0.1 mm/step]
4015 2	Scanning Area
	Adjusts the width of the area on the white plate (in the sub scan direction) that is scanned for auto shading. <i>The default is 4.76 mm. The current setting specifies the difference from this default.</i> [-5.0 ~ +5.0 / 0.0 / 0.1 mm/step]
4301	APS Data Display
	Displays the status of the APS sensors and platen/DF cover sensor (☛ 4.2.9).
4303*	APS Small Size Original
	Selects whether the copier determines that the original is A5 size when the APS sensor cannot detect the size. <i>If "A5 lengthwise" is selected, paper sizes that cannot be detected by the APS sensors are regarded as A5 lengthwise. If "Not detected" is selected, "Cannot detect original size" will be displayed.</i> [0 = No (Not detected) / 1 = Yes (A5 lengthways)]
4305*	Original Size Detection
	Selects whether the machine determines that the original is A4/LT, or 8K/16K. 8K/16K is not available for USA models. [0 = Normal (LT for USA models, A4 for Europe/Asia models) 1 = Reversed [A4 for USA models, LT for Europe/Asia models] 2 = 8K/16K]

4417	<p>IPU Test Pattern</p> <p>Prints test patterns from the IPU video data outputs.</p> <p>0. No Print</p> <ol style="list-style-type: none"> 1. Vertical Line – 1 dot 2. Vertical Line – 2 dot 3. Horizontal Line – 1 dot 4. Horizontal Line – 2 dot 5. Alternating Dot Pattern 6. Grid Pattern – 1 dot 7. Vertical Bands 8. Grayscale – Horizontal (8 level) 9. Grayscale – Vertical (8 level) 10. Grayscale – 16 level 11. Cross Pattern 12. Slant Pattern 13. Patch Pattern (256 level) 14. Patch Pattern (64 level) 15. Trimming Area 16. Frequency characteristics – Vertical 15. Frequency characteristics – Horizontal <p><i>Change to the copy mode display by pressing the  (Interrupt) key, then print the test pattern.</i></p>
------	--

4428	<p>SBU Auto Adjustment</p> <p>Performs the auto scanner adjustment.</p> <p><i>Using this SP mode after replacing the white plate or erasing the memory on the controller board. See “Replacement and Adjustment – Copy Image Adjustments - Standard White Density Adjustment” for details on how to do this.</i></p> <p><i>Press Execute on the touch panel to start.</i></p>
------	---

Service Tables

SERVICE PROGRAM MODE

4901	SBU Adjustment
4901 1	Gain – Even DFU
	Checks the difference value of the black level for the EVEN channel after adjusting the black level at power-up. <i>However, after doing a memory all clear (SP5801), use it to re-input the previous value.</i> [0 ~ 255 / 40 / 1/step]
4901 2	Gain – Odd DFU
	Checks the difference value of the black level for the ODD channel after adjusting the black level at power-up.. <i>However, after doing a memory all clear (SP5801), use it to re-input the previous value.</i> [0 ~ 255 / 40 / 1/step]
4901 3	DC Cont – Even DFU
	Adjusts the coefficient of the D/A converter for the AGC gain curve for DC cont for the EVEN channel. <i>However, after doing a memory all clear (SP5801), use it to re-input the previous value.</i> [0 ~255 / 25 / 1/step]
4901 4	DC Cont – Odd DFU
	Adjusts the coefficient of the D/A converter for the AGC gain curve for DC cont for the ODD channel. <i>However, after doing a memory all clear (SP5801), use it to re-input the previous value.</i> [0 ~255 / 25 / 1/step]
4901 7	Ref. Cont DFU
	Adjusts the coefficient of the D/A converter for the AGC gain curve for scanning the white plate. [0 ~255 / 147 / 1/step]
4902	Exposure Lamp ON
	Turns on the exposure lamp. <i>Press ON on the touch panel to turn on the lamp. Press OFF to turn off the lamp.</i>

4903*	Image Quality Adjustment - All	Note: These adjustments are effective only for the "Custom Setting" Original type.
4903 1	Text: 25% ~ 34%	Adjusts the image quality in Text mode. <i>A larger number increases contrast and sharpens the image but moiré may appear.</i> <i>A smaller number reduces contrast and moiré but the line may become narrower.</i> [0 ~ 10 / 4 / 1 step]
4903 2	Text: 35% ~ 66%	[0 ~ 10 / 3 / 1 step]
4903 3	Text: 67% ~ 141%	[0 ~ 10 / 4 / 1/step]
4903 4	Text: 142% ~ 400%	
4903 5	Photo: 25% ~ 34%	Adjusts the image quality in Photo mode. <i>0 ~ 6 are for a glossy photo image (error diffusion)</i> <i>7 ~ 20 are for a printed photo image (dithering)</i> <i>If copy quality is not satisfactory, try another setting (trial and error)</i> [0 ~ 20 / 11 / 1/step]
4903 6	Photo: 35% ~ 66%	
4903 7	Photo: 67% ~ 141%	
4903 8	Photo: 142% ~ 400%	
4903 9	Text/Photo: 25% ~ 34%	Adjusts the image quality in Text/Photo mode. <i>A larger number increases contrast and sharpens the image but moiré may appear.</i> <i>A smaller number reduces contrast and moiré but the line may become narrower.</i> [0 ~ 10 / 3 / 1 step]
4903 10	Text/Photo: 35% ~ 66%	[0 ~ 10 / 5 / 1 step]
4903 11	Text/Photo: 67% ~ 141%	
4903 12	Text/Photo: 142% ~ 400%	
4903 13	Pale: 25% ~ 34%	Adjusts the image quality in Pale mode. <i>A larger number increase the number of gradations in low contrast areas.</i> [0 ~ 10 / 3 / 1 step]
4903 14	Pale: 35% ~ 66%	
4903 15	Pale: 67% ~ 141%	
4903 16	Pale: 142% ~ 400%	
4903 17	Generation: 25% ~ 34%	Adjusts the image quality in Generation mode. <i>A larger number increases contrast and sharpens the image but moiré may appear.</i> <i>A smaller number reduces contrast and moiré but the line may become narrower.</i> [0 ~ 10 / 3 / 1 step]
4903 18	Generation: 35% ~ 66%	[0 ~ 10 / 5 / 1 step]
4903 19	Generation: 67% ~ 141%	
4903 20	Generation: 142% ~ 400%	

SERVICE PROGRAM MODE

4904*	Independent Dot Erase	
4904 1	Text	<p>This adjustment is only effective for the "Custom Setting" original type.</p> <p><i>With a larger SP setting, more dots are detected as independent dots and erased. However, dots in mesh-like images may be detected as independent dots mistakenly. If "0" is selected, independent dot erase is disabled.</i></p> <p>[0 ~ 10 / 0 / 1 step]</p>
4904 2	Photo	
4904 3	Text/Photo	
4904 4	Pale	
4904 5	Generation	
	Background Erase -	
4904 6	Text	<p>This adjustment is only effective for the "Custom Setting" original type.</p> <p><i>A larger number reduces dirty background. If "0" is selected, background erase is disabled.</i></p> <p>[0 ~ 255 / 0 / 1 step]</p>
4904 7	Photo	
4904 8	Text/Photo	
4904 9	Pale	
4904 10	Generation	
	Gamma Selection	
4904 11	Text	<p>This adjustment is only effective for the "Custom Setting" original type.</p> <p>Selects the gamma table for each original type.</p> <p>[0 ~ 2 / 0 / 1/step]</p> <p>0: Standard gamma table 1: This gamma table reduces the background of the original and gives sharp characters. 2: The gamma table increases the number of gradations in high-density areas.</p>
4904 12	Photo	
4904 13	Text/Photo	
4904 14	Pale	
4904 15	Generation	

4905*	Image Data Path
	<p>Selects one of the following video data outputs which will be used for printing. DFU</p> <p>[0 ~ 3 / 0 / 1 step]</p> <p>0: Normal 1: After black level correction 2: After shading correction without black level correction 3: Shading data</p>

4907*	Gash Adj: Others
4907 1*	Fax 25%, 50% Reduction
	<p>Determines whether 25% and 50% reduction is available in fax mode.</p> <p>[0 = No, 1 = Yes]</p>
4907 2	Outline Level DFU

4909*	IPU Image Data Path	
	Selects one of the following image data outputs, which will be used for printing. DFU [0 ~ 255 / 0 / 1 step] Bit 7: Shading Bit 6: Scanner gamma Bit 5: Pre-filtering Bit 4: Magnification Bit 3: Scanner/Printer Mask Bit 2: Gradation Bit 1: Filtering Bit 0: Printer gamma	

4920	Scanning (Factory Only) DFU	
------	------------------------------------	--

4930*	Sensor Condition	
4930 1	Platen Cover sensor	Checks the following sensors in the scanner unit. [0 = Opened, 1 = Closed]
4930 2	Scanner HP Sensor	[0 = Opened, 1 = Closed]

4999	ADF Scan Glass Dust Check	
	This function checks the narrow scanning glass of the ADF for dust that can cause black lines in copies. If dust is detected a system banner message is displayed, but processing does not stop.	
4999 1	Check On/Off Change	
	Issues a warning if there is dust on the narrow scanning glass of the ADF when the original size is detected before a job starts. This function can detect dust on the white plate above the scanning glass, as well as dust on the glass. Sensitivity of the level of detection is adjusted with SP4999 2. [0 ~ 1 / 0 / 1] 0: Off. No dust warning. 1: On. Dust warning. This warning does not stop the job. Note: Before switching this setting on, clean the ADF scanning glass and the white plate above the scanning glass.	
4999 2	Detect Level	
	Adjusts the sensitivity for dust detection on the ADF scanning glass. This SP is available only after SP49991 is switched on. [0~8 / 4/ 1] If you see black streaks in copies when no warning has been issued, raise the setting to increase the level of sensitivity. If warnings are issued when you see not black streaks in copies, lower the setting. Note: Dust that triggers a warning could be removed from the glass by the originals in the feed path. If the dust is removed by passing originals, this is not detected and the warning remains on.	

Service Tables

SERVICE PROGRAM MODE

SP5XXX: Mode

5024*	mm/inch Selection
	Selects whether mm or inches are used in the display. Note: After selecting the number, you must turn the main power switch off and on. Europe/Asia model: [0 = mm / 1 = inch] American model: [0 = mm / 1 = inch]

5044	Operation Panel Bit SW
5044 1	SW1 DFU
5044 2	SW2 DFU

5104*	A3/DLT Double Count
	Specifies whether the counter is doubled for A3/11" x 17" paper. <i>If "Yes" is selected, the total counter (mechanical counter) and the current user code counter counts up twice when A3/11" x 17" paper is used.</i> [0 = No / 1 = Yes]

5106*	ADS Level Selection
	Selects the image density level that is used in ADS mode. [1 ~ 7 / 4 / 1 notch/step]

5113*	Option Counter Type
	Selects the optional counter type. 0 = No 1 = Key Card1 2 = Key Card2 3 = Pre-paid Card 4 = Coin lock 5 = MF key card 11: MF key card (Increment) 12: MF key card (Decrement)

5118*	Disable Copying	DFU
-------	-----------------	------------

5120*	Mode Clear Opt. Counter Removal
	This SP is for Japan only. Do not change the value. [0 = Yes / 1 = Stand-by / 2 = None]

5121*	Counter Up Timing
	Determines whether the total counter counts up at paper feed-in or at paper exit. [0 = Feed In / 1 = Exit]

5127*	APS Off Mode
	Selects whether APS mode is selected as the power-up default. [0 = Enable / 1 = Disabled]

5129*	F Paper Size Selection
	<p>Selects the "F" paper size. [0 ~ 2 / 0 / 1 step] 0: 8" x 13" 1: 8.5" x 13" 2: 8.25" x 13"</p>

5131*	Paper Size Type Selection
	<p>Selects the paper size (type) for both originals and copy paper. [0~2 / DIP SW setting / 1 step] 0: Japan 1: North America 2: Europe <i>After changing the setting, turn the copier off and on. If the paper size of the archive files stored on the HDD is different, abnormal copies could result. Ask the customer to restore the archive files.</i></p>

5150*	By-Pass Length Setting
	<p>Determines whether long paper can be fed from the by-pass tray. [0 = Off, 1 = On] <i>Normally the paper length from the by-pass tray is limited to 600 mm, but this can be extended with this SP to 1260 mm. Note that, with either setting, the image quality can only be guaranteed for 432 mm.</i></p>

5162*	Application Switch Method	0: HW, 1: SW
	<p>Determines whether the application screen is switched with a hardware switch or software switch. 0: Soft Key Set 1: Hard Key Set</p>	

5212*	Page Numbering
5212 3	Duplex Printout Right/Left Position
	<p>Determines how horizontal printing is executed during duplex printing. Set the upper right corner of the front side and the upper left corner of the back side so the starting points for horizontal printing are the same on both sides DFU. [-10~+10 / 0 / 1 mm step] -10: Extreme right +10: Extreme left</p>
5212 4	Duplex Printout High/Low Position
	<p>Determines how vertical printing is executed during duplex printing. Set the upper right corner of the front side and the upper left corner of the back side so the starting points for vertical printing are the same on both sides. DFU [-10~+10 / 0 / 1 mm step] -10: Extreme top +10: Extreme bottom</p>

Service Tables

SERVICE PROGRAM MODE

5302 2*	Set Time
	Adjusts the RTC (real time clock) time setting for the local time zone. [-1440~+1440 / see below / 1 min./step] NA: -300 (New York) EU: +60 (Paris) Asia: +480 (Hong Kong) <i>Example: For Japan (+9 GMT), enter 540 (9 hours x 60 min.)</i>


5404	User Code Count Clear
	Clears the counts for the user codes assigned by the key operator to restrict the use of the machine.

5501*	PM Alarm
5501 1	PM Alarm Interval
	Sets the PM interval. <i>The value stored in this SP is used when the value of SP55012 is "1".</i> [0 ~ 255 / 0 / 1 k copies/step]
5501 2	Original Count Alarm DFU
	Selects whether the PM alarm for the number of scans is enabled or not. <i>If this is "1", the PM alarm function is enabled.</i> [0 = No / 1 = Yes]

5504*	Jam Alarm
	Sets the alarm to sound for the specified jam level (document misfeeds are not included). RSS use only [0~3 / 3 / 1 step] 0: Zero (Off) 1: Low (2.5K jams) 2: Medium (3K jams) 3: High (6K jams)

5505*	Error Alarm Setting
	Sets the error alarm level. Japan only DFU [0~255 / 50 / 100 copies per step]

5507*	Supply Alarm	
5507 1	Paper	Switches the control call on/off for the paper supply. DFU 0: Off, 1: On 0: No alarm. 1: Sets the alarm to sound for the specified number transfer sheets for each paper size (A3, A4, B4, B5, DLT, LG, LT, HLT)
5507 2	Staple	Switches the control call on/off for the stapler installed in the finisher. DFU 0: Off, 1: On 0: No alarm 1: Alarm goes off for every 1K of staples used.
5507 3	Toner	Switches the control call on/off for the toner end. DFU 0: Off, 1: On If you select "1" the alarm will sound when the copier detects toner end.
5507 128*	Others	The "Paper Supply Call Level: nn" SPs specify the paper control call interval for the referenced paper sizes. DFU [00250 ~ 10000 / 1000 / 1 Step]
5507 132*	A3	
5507 133*	A4	
5507 134*	A5	
5507 141*	B4	
5507 142*	B5	
5507 160*	DLT	
5507 164*	LG	
5507 166*	LT	
5507 172*	HLT	



SERVICE PROGRAM MODE

5508*	CC Call
5508 1	Jam Remains
	Switches the control call on/off for an unattended jam. Japan Only 0: Off, 1: On If you select "1", the alarm sound if a jam is left unattended for 15 minutes.
5508 2	Continuous Jams
	Switches the control call on/off for the occurrence of consecutive jams. Japan Only 0: Off, 1: On If you select "1", the alarm will sound if 5 consecutive jams occur in the copier.
5508 3	Continuous Door Open
	Switches the control call on/off for the cover open alarm. Japan Only 0: Off, 1: On If you select "1", the alarm will sound if the door remains open for 15 minutes.
5508 4	Low Call Mode
	Selects whether or not the new CC call. Japan Only 0: Previous Mode, 1: New Mode
5508 11	Jam Details: Time Length
	This SP is effective when the value of SP5508-4 is "1". Japan Only [3 ~ 30 / 10 / 1 min/step]
5508 12	Jam Details: Continuous Count
	This SP is effective when the value of SP5508-4 is "1". Japan Only [2 ~ 10 / 5 / 1 time/step]
5508 13	Door Open: Time Length
	This SP is effective when the value of SP5508-4 is "1". Japan Only [3 ~ 30 / 10 / 1 min/step]
5508 21	Jam Operation: Time Length
	This SP is effective when the value of SP5508-4 is "1". Japan Only 0: Auto Call, 1: Alarm
5508 22	Jam Operation: Continuous Count
	This SP is effective when the value of SP5508-4 is "1". Japan Only 0: Auto Call, 1: Alarm
5508 23	Door Operation: Time Length
	This SP is effective when the value of SP5508-4 is "1". Japan Only 0: Auto Call, 1: Alarm

5801	Memory Clear	Resets all correction data for process control and all software counters, and returns all modes and adjustments to their default values. (☛ 4.2.7). <i>To execute, hold down Ⓢ for over 3 seconds, and then turn the copier off and on again.</i> <i>Use this SP only after replacing the NVRAM, or after the copier has malfunctioned due to a damaged NVRAM.</i>
5801 1	All Clear	Initializes items 2 ~ 12 below.
5801 2	Engine	Initializes all registration settings for the engine and processing settings.
5801 3	SCS	System Control Service. Initializes default system settings, CSS settings, operation display coordinates, and ROM update information. SCS: System Control Service
5801 4	IMH Memory Clr	Image Memory Handler. Initializes the registration setting for the image memory handler.
5801 5	MCS	Memory Control Service. Initializes the automatic delete time setting for stored documents.
5801 6	Copier application	Initializes all copier application settings.
5801 7	Fax application	Initializes the fax reset time, job login ID, all TX/RX settings, local storage file numbers, and the off-hook timer.
5801 8	Printer application	Initializes the printer defaults, programs registered, the printer SP bit switches, and printer CSS counter.
5801 9	Scanner application	Initializes the scanner defaults for the scanner and all the scanner SP modes.
5801 10	Web Service/Network Application	Deletes the network file application management files and thumbnails, and initializes the job login ID.
5801 11	NCS	Network Control Service. Initializes the system defaults and interface settings (IP addresses also), Smart Net Monitor for Admin, Web Status Monitor settings, and the TELNET settings.
5801 12	R-FAX	Initializes the job login ID, SmartNetMonitor for Admin, job history, and local storage file numbers.
5801 14	Clear DCS Settings	Initializes: SP5845 (All), SP5860 (All), SP5861 (All), SP5863, registered scanner documents and subjects.
5801 15	Clear UCS Settings	Initializes: SP5846 (All), SP5801 15

5802	Printer Free Run
	Performs a free run for both the scanner and the printer. <i>After selecting "1", press "OK" or the Ⓢ key twice to start this feature. Press the Ⓢ (Clear/Stop) key to stop.</i> [0 = No / 1 = Yes]

5803	Input Check
	Displays signals received from sensors and switches. Press the Ⓢ (Clear Modes) key to exit the program. (☛ 4.2.4)

Service Tables







SERVICE PROGRAM MODE

5804	Output Check
	Turns on electrical components individually for test purposes. (▶ 4.2.5)

5807*	Option Connection Check	
5807 1	ARDF	Checks the connectors to the optional peripheral devices. Execution will return either a "1" or "0" on the display. 1: Device connected correctly. 0: Device not connected correctly.
5807 2	Paper Tray Unit	
5807 3	LCT	
5807 4	Finisher (1000-sheet, Two-Tray finisher)	

5810	SC Code Reset DFU
	Resets all level A service call conditions, such as fusing errors. To clear the service call, touch "Execute" on the LCD, then turn the main power switch off/on.

5811	Machine No. Setting	Use to input the machine serial number. (Normally done at the factory.) DFU
		<i>This serial number will be printed on the SMC report</i>

5812*	Service Tel. No. Setting	
5812 1	Service	Use this to input the telephone number of the service representative (this is displayed when a service call condition occurs). <i>Press the  key if you need to input a pause (-). Press the  (Clear/Stop) key to delete the telephone number.</i>
5812 2	Facsimile	
5812 3	Supply	Use this to input the telephone number that the customer uses to order toner (this is displayed in the inquiry menu of UP mode). <i>Press the  key if you need to input a pause (-). Press the  (Clear/Stop) key to delete the telephone number.</i>
5812 4	Operation	
		Use this to input the telephone number of the sales representative (this is displayed in the inquiry menu of UP mode). <i>Press the  key if you need to input a pause (-). Press the  (Clear/Stop) key to delete the telephone number.</i>

SERVICE PROGRAM MODE

5816*	Remote Service	
5816 1	I/F Setting	Switches the remote diagnostics function off and on. [0~2 / 2 / 1] 0: Remote diagnostics off. 1: Serial (CSS or NRS) remote diagnostics on. 2: Network remote diagnostics.
5816 2	CE Call	Allows the customer engineer to start or end the remote machine check using CSS or NRS by pressing the center report key.
5816 3	Function Flag	Enables and disables remote diagnosis via the NRS network. [0~1 / 0 / 1] 0: Disables remote diagnosis via network. 1: Enables remote diagnosis via network.
5816 4	Communication Test Call	Executes a transmission test call for NRS. The test returns a value in the range 0 to 99. 0: Normal end (center operating) 1: Normal end (center not operating) Other: Abnormal
5816 5	Device Information Call	Executes a call to determine whether the machine is operating. The test returns a value in the range 0 to 99. 0: Normal end (center operating) 1: Normal end (center not operating) Other: Abnormal
5816 6	Device Information Call Display	Determines whether the item for initial setting of the screen for the NRS device information notification call is displayed. 0: Enabled. Item initial setting not displayed. 1: Disable. Item for initial setting is displayed.
5816 7	SSL Disable	Determines whether RCG (Remote Communication Gate) confirmation is done by SSL during an RCG send for the NRS via a network interface. 0: Yes. SSL not used. 1: No. SSL used.
5816 8	RCG Connect Timeout	Sets the length of time (seconds) for the timeout when the RCG (Remote Communication Gate) connects during a call via the NRS network. [1~90 / 10 / 1 sec.]
5816 9	RCG Write to Timeout	Sets the length of time (seconds) for the timeout when send data is written to the RCG during a call via the NRS network. [0~100 / 30 / 1 sec.]
5816 10	RCG Read Timeout	Sets the length of time (seconds) for the timeout when send data is written from the RCG during a call via the NRS network. [0~100 / 30 / 1 sec.]

Service Tables

SERVICE PROGRAM MODE

5816 11	Port 80 Enable	Determines whether permission is granted for access to the SOAP method via Port 80 on the NRS network. 0 : No. Access denied 1 : Yes. Access granted.
---------	----------------	---

5821	Remote Service Address	
5821 1	CSS PI Device Code DFU. Japan Only	
	Sets the PI device code. After changing this setting, you must switch the machine off and on.	
5821 2	RCG IP Address DFU. Japan Only	
	Sets the IP address of the RCG (Remote Communication Gate) destination for call processing at the remote service center. [00000000h ~ FFFFFFFFh/ 00000000h /	

5824	NVRAM Data Upload
	Uploads the UP and SP mode data (except for counters and the serial number) from the NVRAM on the control board to a flash memory card. (☛ 4.2.8) <i>While using this SP mode, always keep the front cover open. This prevents a software module accessing the NVRAM during the upload.</i>

5825	NVRAM Data Download
	Downloads the content of a flash memory card to the NVRAM on the control board. (☛ 4.2.8) <i>While using this SP mode, always keep the front cover open. This prevents a software module accessing the NVRAM during the download. After executing this SP, switch the copier off and on.</i>

5828*	Network Setting																												
5828 66	Job Spooling Clear: Start Time	Determines whether unprinted jobs on the HDD are printed then next time the machine is switched on. Available only the job spooling feature. [0~1 / 1 / 1] 0: Clear spooled jobs from HDD at power on. 1: Print spooled jobs on HDD at power on.																											
5828 69	Job Spooling: Protocol	Disables and enables protocols used for job spooling. The settings are done by entering a "0" (Off) or a "1" for each bit switch. Defaults: 1 (all enabled).																											
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Protocol</th> <th>Comments</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>LPR</td> <td></td> </tr> <tr> <td>1</td> <td>FTP</td> <td>Not used</td> </tr> <tr> <td>2</td> <td>IPP</td> <td></td> </tr> <tr> <td>3</td> <td>SMB</td> <td></td> </tr> <tr> <td>4</td> <td>BM Links</td> <td>Japan Only</td> </tr> <tr> <td>5</td> <td>Reserved</td> <td>Not used</td> </tr> <tr> <td>6</td> <td>Reserved</td> <td>Not used</td> </tr> <tr> <td>7</td> <td>Reserved</td> <td>Not used</td> </tr> </tbody> </table>	Bit	Protocol	Comments	0	LPR		1	FTP	Not used	2	IPP		3	SMB		4	BM Links	Japan Only	5	Reserved	Not used	6	Reserved	Not used	7	Reserved	Not used
		Bit	Protocol	Comments																									
		0	LPR																										
		1	FTP	Not used																									
		2	IPP																										
		3	SMB																										
		4	BM Links	Japan Only																									
		5	Reserved	Not used																									
6	Reserved	Not used																											
7	Reserved	Not used																											
5828 74	Delete Password	Deletes the NCS password. Sets the Telnet, WSM, and remote ROM update passwords to NULL (empty)																											
5828 84	Print Settings List	Prints a list of the NCS parameter settings.																											
5828 90	TELNETs	Disables or enables Telnet operation. If this SP is disabled the Telnet port is closed. [0~1/ 1 / 1] 0: Disable 1: Enable																											
5828 91	Web	Disables or enables the Web operation. [0~1/ 1 / 1] 0: Disable 1: Enable																											

Service Tables

SERVICE PROGRAM MODE

5832	HDD Formatting	
	Enter the SP number for the partition to initialize, then press #. When execution ends, cycle the machine off and on.	
5832 1	ALL	Initializes entire content of the HDD.
5832 2	IMH	Initializes 1) documents stored on the document server, 2) stamp print data, 3) scanner delivery images, 4) fax delivery images.
5832 3	Thumbnail	Initializes MCS thumbnail images.
5832 4	Job Log	Initializes job data used by the Poplar server. Japan Only
5832 5	Printer Fonts	Initializes printer fonts, overlay forms.
5832 6	User Info.	Initializes user information (UCS)
5832 7	Mail RX Data	Initializes mail receive data (DCS)
5832 8	Mail TX data	Initializes mail send data (DCS)
5832 9	Data for Design	Designer use only.
5832 10	Fax	Initializes the logs (fax history and debug log)
5832 11	Ridoc I / F	Initializes the NetFile management area.

5833*	Job Log Transfer On/Off Setting	
	Switches the job log transfer on/off for Poplar server. DFU 0: Off (disable), 1: On (enable)	

5834	Operation Panel Image Exposure
	Enables and disables the operation panel read (dump) feature. After powering on the machine, set this option to 1 to enable this feature. 0: Off (disable), 1: On (enable) DFU <i>To reset the machine to 0, the machine must be turned off and on again. Selecting 0 for this option without cycling the power off and on does not restore the default setting (0).</i>

5836*	Capture Settings	
5836 1*	Capture Function (0:Off 1:On)	0: Disable, 1: Enable
	With this function disabled, the settings related to the capture feature cannot be initialized, displayed, or selected.	
5836 2*	Panel Setting	0: Disable, 1: Enable
	Determines whether each capture related setting can be selected or updated from the initial system screen. The setting for SP58361 has priority	
5836 71 to 5836 76, Copier and Printer Document Reduction The following 6 SP modes set the default reduction for stored documents sent to the document management server via the MLB. [0~2 / 2 / 1] <i>Enabled only when optional MLB (Media Link Board) is installed</i>		
5836 71*	Reduction for Copy Color	0: 1to-1, 1: 1/2, 2: 1/4
5836 72*	Reduction for Copy B&W Text	0: 1to-1, 1: 1/2, 0: 1/4
5836 73*	Reduction for Copy B&W Other	0: 1to-1, 1: 1/2, 0: 1/4
5836 74*	Reduction for Printer Color	0: 1to-1, 1: 1/2, 2: 1/4
5836 75*	Reduction for Printer B&W	0: 1to-1, 1: 1/2, 0: 1/4
5836 76*	Reduction for Printer B&W HQ	0: 1to-1, 1: 1/2, 0: 1/4
5836 81 to 5836 86, Stored document format The following 6 SP modes set Sets the default format for stored documents sent to the document management server via the MLB. <i>Enabled only when optional MLB (Media Link Board) is installed</i>		
5836 81*	Format for Copy Color	0: JFIF/JPEG, 1: TIFF/MMR, 2: TIFF/MH, 3: TIFF/MR
5836 82*	Format for Copy B&W Text	0: JFIF/JPEG, 1: TIFF/MMR, 2: TIFF/MH, 3: TIFF/MR
5836 83*	Format Copy B&W Other	0: JFIF/JPEG, 1: TIFF/MMR, 2: TIFF/MH, 3: TIFF/MR
5836 84*	Format for Printer Color	0: JFIF/JPEG, 1: TIFF/MMR, 2: TIFF/MH, 3: TIFF/MR
5836 85*	Format for Printer B&W	0: JFIF/JPEG, 1: TIFF/MMR, 2: TIFF/MH, 3: TIFF/MR
5836 86*	Format for Printer B&W HQ	0: JFIF/JPEG, 1: TIFF/MMR, 2: TIFF/MH, 3: TIFF/MR
5836 91*	Default for JPEG	[5~95 / 50 / 1]
	Sets the JPEG format default for documents sent to the document management server via the MLB with JPEG selected as the format. <i>Enabled only when optional MLB (Media Link Board) is installed.</i>	

Service Tables

SERVICE PROGRAM MODE

5839*	IEEE 1394	
5839 4	Host Name	Enter name
	Enter the name of the device used on the network. Example: RNP0000000000	
5839 7*	Cycle Master	0: Disable (Off), 1: Enable (On)
	Enables or disables the cycle master function for the 1394 bus standard.	
5839 8*	BCR mode	(Binary 0~3) 00: Off. Writes from the IRM. 01: Copies BCR of the IRM after no data is written from the IRM after the prescribed time has elapsed. 10: Reserved. Not used. 11:BCR normally enabled.
	Determines how BCR (Broadcast Channel Register) operates on the 1394 standard bus when the independent node is in any mode other than IRM. (NVRAM: 2bits)	
5839 9*	IRM 1394a Check	0: Checks whether IRM conforms to 1394a 1: After IRM is checked, if IRM does not conform then independent node switches to IRM.
	Conducts a 1394a check of IRM when the independent node is in any mode other than IRM.	
5839 10*	Unique ID	0: Does not list the Node_Unique_ID assigned by the system administrator. Instead, the Source_ID of the GASP header in the ARP is used. 1: The Node_Unique_ID assigned by the system administrator is used, and the Source_ID of the GASP header in the ARP is ignored. Also, when the serial bus is reset, extra bus transactions are opened for enumeration.
	Lists the ID (Node_Unique_ID) assigned to the device by the system administrator.	
5839 11*	Logout	0: Disable (refuse login) Initiator retry during login Login refusal on arrival of login request (standard operation) 1: Enable (force logout) Initiator retry during login Login refusal on arrival of login request, and the initiator forces the login.
	Handles the login request of the login initiator for SBP-2. (1bit)	
5839 12*	Login	0: Disables. The exclusive login (LOGIN ORB exClusvie it) is ignored. 1: Enables. Exclusive login is in effect.
	Enables or disables the exclusive login feature (SBP-2 related).	
5839 13*	Login MAX	[0~63 / 8 / 1], (0 and 63: Reserved)
	Sets the maximum number of logins from the initiator (6-bits)	

5840	IEEE 802.11b	
5840 4	SSID	Enter ID
	Enters a unique ID (up to 32 characters long) to identify the device when it is operating in an area with another wireless LAN network.	
5840 6	Channel MAX	JA [1~14 / 14 / 1] NA [1~11 / 11 / 1] EU [1~13 / 13 / 1] China, Taiwan (Same as NA)
	Sets the maximum number of channels available for data transmission via the wireless LAN. The number of channels available varies according to location. The default settings are set for the maximum end of the range for each area. Adjust the upper 4 bits to set the maximum number of channels. <i>Displayed only when the option 802.11b for wireless LAN is installed.</i>	
5840 7	Channel MIN	JA [1~14 / 1 / 1] NA [1~11 / 1 / 1] EU [1~13 / 1 / 1] China, Taiwan (Same as NA)
	Sets the minimum number of channels available for data transmission via the wireless LAN. The number of channels available varies according to location. The default settings are set for the minimum end of the range for each area. Adjust the lower 4 bits to set the minimum number of channels. <i>Displayed only when the option 802.11b for wireless LAN is installed.</i>	
5840 11	WEP Key Select	00 : Key #1 01: Key #2 (Reserved) 10: Key #3 (Reserved) 11: Key #4 (Reserved)
	Selects the WEP key. [00~11 / 00 / 1 binary]	
5840 18*	SSID Key Check	
	Execute to determine whether the value entered for the SSID setting is correct. If the execution returns "2" the setting is correct. If the returned value is "3", the setting is not correct.	
5840 20	WEP Mode	0 : Max. 64-bit (10 characters) 1: Max. 128-bit (10, 26 characters)
	Determines the operation mode of the WEP key. <i>Displayed only when the option 801.11b for wireless LAN is installed.</i>	

Service Tables

SERVICE PROGRAM MODE

5841	Supply Name Setting	
	Allows setting the following items with the Soft Keyboard after pressing the "Soft Keyboard" button displayed for this SP code. The items you enter are displayed after pressing "User Tools" and then pressing the "Inquiry" button on the touch-panel display. The items stored in SP 5841-12, 13, and 14 do not appear on the Inquiry screen.	
5841 1	Toner Name Setting: Black	Enter the name of the toner in use.
5841 5	Staple Std	Enter the name of the staples in use for normal stapling (not booklet stapling)
5841 7	Org Stamp	Enter the name of the original stamp that is installed in the document feeder. (This is stamped on originals to indicate that they have scanned.)
5841 11	Staple Std 1	Enter the names of the staples used in the finisher.
5841 12	Staple Std 2	
5841 13	Staple Std 3	
5841 14	Staple Std 4	

5842	Net File Analysis Mode Setting	[8 bits / 0011 1111 / Bit SW]
	Selects each debug output mode for NetFile processing <i>Bit 8 is reserved. Bit 7 is the debug output switch for each mode. Net files are jobs to be printed from the document server using a PC and the DeskTopBinder software</i>	

5844	USB	
5844 1	Transfer Rate	[0x01~0x04 / 0x04 / 0]
	Sets the speed for USB data transmission. 0x01: Full Speed (12 Mbps fixed) 0x04: High Speed/Full Speed (480 Mbps/12 Mbps auto adjust)	
5844 2	Vendor ID	[0x0000~0xFFFF/ 0x05CA /1], DFU
	Sets the vendor ID: Initial Setting: 0x05A Ricoh Company.	
5844 3	Product ID	[0x0000~0xFFFF/0x0403/1], DFU
	Sets the product ID.	
5844 4	Device Release Number	[0000~9999/0100/1], DFU
	Sets the device release number of the BCD (binary coded decimal) display. <i>Enter as a decimal number. NCS converts the number to hexadecimal number recognized as the BCD.</i>	

5845	Delivery Server Setting	
	Provides items for delivery server settings.	
5845 1	FTP Port No.	[0~65535 / 3670 / 1]
	Sets the FTP port number used when image files to the Scan Router Server.	
5845 2	IP Address	[0~0xFFFFFFFF / 0x00]
	Use this SP to set the Scan Router Server address. The IP address under the transfer tab can be referenced by the initial system setting.	
5845 6*	Delivery Error Display Time Netfiles:	[0~999 / 300 / 1]
	Use this setting to determine the length of time the prompt message is displayed when a test error occurs during document transfer with the NetFile application and an external device.	
5845 8*	IP Address Secondary	Range: 000.000.000.000 ~ 255.255.255.255
	Specifies the IP address assigned to the computer designated to function as the secondary delivery server of Scan Router. This SP allows only the setting of the IP address without reference to the DNS setting.	
5845 9*	Delivery Server Model	[0~4/ 0 / 1]
	Allows changing the model of the delivery server registered by the I/O device. 0: Unknown 1: SG1 Provided 2: SG1 Package 3: SG2 Provided 4: SG2 Package	
5845 10*	Delivery Svr Capability	[0~255 / 0 / 1]
	Changes the capability of the registered that the I/O device registered. Bit7 = 1 Comment information exists Bit6 = 1 Direct specification of mail address possible Bit5 = 1 Mail RX confirmation setting possible Bit4 = 1 Address book automatic update function exists Bit3 = 1 Fax RX delivery function exists Bit2 = 1 Sender password function exists Bit1 = 1 Function to link MK-1 user and Sender exists Bit0 = 1 Sender specification required (if set to 1, Bit6 is set to "0")	

SERVICE PROGRAM MODE

5846	UCS Settings	
5846 1	Machine ID (For Delivery Server)	Displays ID
	Displays the unique device ID in use by the delivery server directory. The value is only displayed and cannot be changed. This ID is created from the NIC MAC or IEEE 1394 EUI. The ID is displayed as either 6-byte or 8-byte binary.	
5846 2	Machine ID Clear (For Delivery Server)	Clears ID
	Clears the unique ID of the device used as the name in the file transfer directory. Execute this SP if the connection of the device to the delivery server is unstable. After clearing the ID, the ID will be established again automatically by cycling the machine off and on.	
5846 3	Maximum Entries	[2000~50000/2000/1]
	Changes the maximum number of entries that UCS can handle. If a value smaller than the present value is set, the UCS managed data is cleared, and the data (excluding user code information) is displayed.	
5846 4	Delivery Server Model	0: Not used, 1:SG1 Provided, 2: SG1 Package, 3: SG2 Provided 4: SG2 Package
	Changes the model of the transfer server registered for the I/O device.	
5846 5	Delivery Server Capability	Bit 7 = 1 Comment information Bit 6 = 1 Address direct entry possible Bit 5 = 1 Mail Rx confirmation possible Bit 4 = 1 Address book auto update Bit 3 = 1 Fax Rx function [0~255 / 0 / 2]
	Changes the capability of the server registered for the I/O device.	
5846 6	Delivery Server Retry Timer	[0~255/ 0 /1]
	Sets the interval for retry attempts when the delivery server fails to acquire the delivery server address book.	
5846 7	Delivery Server Retry Times	[0~255/ 0 /1]
	Sets the number of retry attempts when the delivery server fails to acquire the delivery server address book.	
5846 8	Delivery Server Maximum Entries	[2000~50000 / 2000 / 1]
	Sets the maximum number account entries of the delivery server user information managed by UCS.	
5846 10	LDAP Search Timeout	[1~255 / 60 / 1]
	Sets the length of the timeout for the search of the LDAP server.	
5846 50	Initialize All Directory Info.	Clears all directory information managed by UCS, including all user codes.
5846 51	Upload All Directory Info.	Uploads all directory information to the IC card.
5846 52	Download All Directory Info.	Downloads all directory information from the IC card.
5846 70	LDAP Attribute (Name)	Allows you to enter a search attribute other than the default mail (cn) for the LDAP server search.
5846 71	LDAP Attribute (Mail)	Allows you to enter a search attribute other than the default mail address (mail) for the LDAP server search.
5846 72	LDAP Attribute (Fax)	Allows you to enter a search attribute other than the default facsimile telephone number (FacsimileTelephoneNumber) for the LDAP server search.
5846 73	LDAP Attribute (Organization)	Allows you to enter a search attribute other than the default organization name (o) for the LDAP server search.

SERVICE PROGRAM MODE

5846	UCS Settings	
5846 74	LDAP Attribute (Organizational Unit)	Allows you to enter a search attribute other than the default organization unit name (ou) for the LDAP server search.
5846 80	Backup FCU	Backs up all directory information on the HDD to the FCU ROM.
5846 90	Plain Data Forbidden	Allows you to prevent the address from plain data. This is a security function that prevents unauthorized access to address book data. 0: No check. Address book data not protected. 1: Check. Allows operation of UCS without data from HDD or SC card and without creating address book information with plain data.
5846 99	Bit Switches	Sets UCS debug output. DFU

5847	Net File Resolution Reduction	
	5847 1 through 5847 6 changes the default settings of image data transferred externally by the Net File page reference function. [0~2 / 2 / 1] 5847 21 sets the default for JPEG image quality of image files handled by NetFile. <i>"Net files" are jobs to be printed from the document server using a PC and the DeskTopBinder software.</i>	
	5847 2	Rate for Copy B&W Text
	5847 3	Rate for Copy B&W Other
	5847 5	Rate for Printer B&W
5847 6	Rate for Printer B&W HQ	0: 1x 1: 1/2x 2: 1/3x 3: 1/4x
5847 21	Network Quality Default for JPEG Sets the default value for the quality of JPEG images sent as NetFile pages. This function is available only with the MLB (Media Link Board) option installed. [5~95 / 50 / 1]	

5848	Web Service (Access Control)	
	5847 2 sets the 4-bit switch assignment for the access control setting. Setting of 0001 has no effect on access and delivery from Scan Router. 5847 100 sets the maximum size allowed for downloaded images. The default is equal to 1 gigabyte.	
5848 1	NetFile (Lower 4 Bits Only)	Bit switch settings.
	0000: No access control 0001: Denies access to DeskTop Binder. Access and deliveries from Scan Router have no effect on capture.	
5848 2	Repository (Lower 4 Bits)	0000: No access control 0001: Denies access to DeskTop Binder.
5848 3	Doc. Svr. Print (Lower 4 Bits)	Switches access control on and off. 0000: OFF
5848 4	User Directory (Lower 4 Bits)	
5848 5	Delivery Input (Lower 4 Bits)	
5848 6	Fax Control (Lower 4 Bits)	
5848 7	Comm. Log Fax (Lower 4 Bits)	No information available.
5848 100	Repository: Max. Size of Download Image	[1~1024 / 1024 / 1K]

Service Tables

SERVICE PROGRAM MODE

5849	Installation Date	
5849 1	Display	DFU
5849 2	Switch to Print	DFU

5850	Address Book Function	
5850 1	User Info. Management Module Setting (Address Book Function)	
5850 3	Circuit Conversion	
	<p>The machine is sold ready to use with a G3 line. This SP allows you to switch all at once to convert the address book for use with ISDN option. Conversely, if for some reason the ISDN line becomes unusable, you can easily switch back to G3.</p> <p>Japan only</p>	

5853	Stamp Data Download
	<p>Use this SP to download the fixed stamp data stored in the firmware of the ROM and copy it to the HDD. This SP can be executed as many times as required. This SP must be executed after replacing or formatting the hard disk.</p> <p>Note: This SP can be executed only with the hard disk installed.</p>

5856	Remote ROM Update
	<p>When set to "1" allows reception of firmware data via the local port (IEEE 1284) during a remote ROM update. This setting is reset to zero after the machine is cycled off and on.</p> <p>[0~1 / 0 / 1] DFU</p> <p>0: Not allowed 1: Allowed</p>

5857	Debug Log Save Function	
5857 1	On/Off (1:ON 0:OFF)	0: OFF, 1: ON
	Switches the debug log feature on and off. The debug log cannot be captured until this feature is switched on.	
5857 2	Target (1:IC Card 2:HDD)	1:IC Card, 2:HDD
	Select "1" (IC Card) if an HDD unit is not installed in the machine, or if the HDD unit is temporarily out of service. The IC card can store only 4 MB so use the HDD selection.	
5857 3	Initialize IC Card	DFU
	Initializes the IC card inserted into the controller slot. Initializing erases all data on the IC card. Use to initialize a new card.	
5857 4	Save to IC Card	DFU
	Saves the debug log in memory to the IC card.	
5857 5	Save to HDD	DFU
	Saves the debug log in memory to the HDD. <i>A unique file name is generated to avoid overwriting existing file names on the IC card. Up to 4MB can be copied to an IC card. 4 MB segments can be copied one by one to each IC card.</i>	
5857 7	HDD to IC Card (Latest 4MB)	
	Copies the latest 4 MB of the debug log on the HDD to the IC card. This function erases all data from the IC card as it copies.	
5857 8	HDD to IC Card (Latest 4MB Any Key)	
	Copies the latest 4 MB of the debug log on the HDD to the IC card, but only those portions of the log specified with a key specified with SP5859 (Debug Save Key No.) This function erases all data from the IC card as it copies. <i>To enable this SP, the machine must be cycled off and on.</i>	
5857 11	Erase Debug Data From HDD	DFU.
	Erases all debug log data from the IC card.	

5858	Debug Log Save Function	
	These SPs select the content of the debugging information to be saved to the destination selected by SP5857 2. SP5858 3 stores one SC specified by number. <i>Refer to Section 4 for a list of SC error codes.</i>	
5858 1	Engine SC Error	Stores SC codes generated by copier engine errors.
5858 2	Controller SC Error	Stores SC codes generated by RA2K controller errors.
5858 3	Any SC Error	[0~65535 / 0 / 1]
5858 4	Jam	Stores jam errors.

5859	Debug Log Save Function	
5859 1	Key 1	These SPs allow you to set up to 10 keys for log files for functions that use common memory on the controller board. (●5.3.1) [-9999999~9999999 / 0 / 1]
5859 2	Key 2	
5859 3	Key 3	
5859 4	Key 4	
5859 5	Key 5	
5859 6	Key 6	
5859 7	Key 7	
5859 8	Key 8	
5859 9	Key 9	
5859 10	Key 10	

5860	SMTP/POP3/IMAP4	
5860 20	Partial Mail Receive Timeout	[1~168 / 72 / 1]
	Sets the amount of time to wait before saving a mail that breaks up during reception. The received mail is discarded if the remaining portion of the mail is not received during this prescribed time.	
5860 21	MDN Response RFC2298 Compliance	[0~1 / 0 / 1]
	Determines whether RFC2298 compliance is switched on for MDN reply mail. 0: No compliance. 1: Compliance. The MAIL FROM (SMTP command) is sent open (< >).	
5860 22	SMTP Auth. From Field Replacement	[0~1 / 1 / 1]
	Determines whether the FROM item of the mail header is switched to the validated account after the SMTP server is authorized.	

⇒

5870	Common Key Info Writing	
	Writes to flash ROM the common proof for validating the device for NRS specifications.	

⇒

5871	HDD Function Disable DFU	[0~1 / 0 / 1] (0: OFF, 1: ON)
	Disables the HDD functions by suppressing all functions that write data to the HDD. After this SP is executed, the machine must be switched off and on to enable the setting. Note: This SP is intended for use during the installation of the security DIMM, an option that is not yet available.	

⇒

5872	HDD Overwrite Status Check DFU	
------	---------------------------------------	--

5907*	Plug & Play Setting
	Sets the brand name and the production name for Windows Plug & Play. This information is stored in NVRAM. If the NVRAM is defective or has been replaced, these names should be registered again. Allows input of the maker and model on a two-line display. After replacing the NVRAM, the settings can be selected from available maker and model names. To select and enable the maker & model name: 1 Press and hold down (#). 2 Enter the number that corresponds to the correct name on the list.

5908*	LCT Paper Size
	Selects the paper size for the LCT. Use this SP after changing the paper size in the optional LCT (i.e., after changing the side plate position for the LCT). [0~1 / 1 / 1] North America 0: A4 1: LT [0~1 / 0 / 1] Other Areas (Europe/Asia) 0: A4 1: LT

5912*	PCU Alarm Setting	
5912 1	Display	Selects whether the PCU alarm message (Change Photoconductor Unit) blinks when the PCU alarm interval expires. <i>When installing the machine, if the customer requires that the PCU alarm message blink, select "1". If set to "0", there will be no message.</i> [0 = No / 1 = Yes]
5912 2	Interval	Sets the PCU alarm interval. <i>When the machine reaches this value, the PCU alarm will be displayed on the LCD to inform the user. Only used if SP59121 is at "1".</i> [1 ~ 255 / 60 / 1 k copies/step]

5913	Switchover Permission Time	
	Sets the amount of time to elapse while the machine is in standby mode (and the operation panel keys have not been used) before another application can gain control of the display. [3~30 / 3 / 1 s]	

5914*	Application Counter Display	[0 = No / 1 = Yes]
5914 1	Printer Counter (0:OFF 1:ON)	Selects whether the total counters for printer mode and/or copy mode are displayed in user tool mode.
5914 2	Fax Counter (0:OFF 1:ON)	
5914 3	Copy Count (0:OFF 1:ON)	

5915*	Mechanical Counter Detection	
	Checks whether the mechanical counter inside the inner cover is connected or not. Display: 0: Not detected 1: Detected 2: Unknown	

5918*	A3/DLT Counter Display	
	Displays the counter, which counts A3/DLT as double. 0 = No, 1 = Yes <i>The A3/DLT counter counts up twice when an A3 or DLT sheet is fed out.</i>	

5920	Low Power Mode Recovery time DFU	
------	---	--

5921*	Exhaust Fan Control	
	Sets the timing for slowing the exhaust fan motor speed or shutting the motor off for normal operation, depending on the following conditions: 1. After the machine has entered energy saver mode or stand-by mode, the machine slows the fan speed after this time runs out. 2. After the machine has entered the auto off mode or an error occurs, the machine stops the fan after this time runs out. [30 ~ 120 / 30 s / 1 s]	

Service Tables

5923*	Border Remove Area Switching
	<p>Toggles between two settings that affect the appearance of the pages for border removal and printed facing pages: (1) Using the original area as the allotted area, or (2) Using only the copy paper as the allotted area. [0 = Original base, 1 = Copy base] 0: Original area used as base 1: Copy used as the base</p>

5967	Copy Server: Set Function
	<p>Enables the document server function. This is a security feature. If you set this SP to 1, the machine disables the use of the document server and removes all image data from the temporary area on the HDD. [0~1 / 0 / 1] 0: Enables. Document server can be used. 1: Disables. Document server cannot be used.</p>

5974*	Cherry Server Selection
	<p>Switches writing between the Scan Router V2 Lite application provided and the optional full version. 0: Lite, 1: Full</p>

5990	SMC Printout (SMC Report)	
5990 1	All (Data List)	Prints all of the system parameter lists for the item selected. (☛ 4.2.6) Input the number for the item that you want to print, then press “Execute” on the touch panel.
5990 2	SP (Mode Data List)	
5990 3	User Program	
5990 4	Logging Data	
5990 5	Diagnosis Report	
5990 7	NIB Summary	
5990 8	Capture Log	
5990 21	Copier User Program	
5990 22	Scanner SP	
5990 23	Scanner User Program	

5995	Factory Mode	DFU
------	--------------	------------

5996	Machine State DFU	
5996 1	Destination	Shows intended destination of the engine board. 0: Japan 1: North America 2: Europe 3: Mainland China 4: Taiwan
5996 2	SBCU ID	Displays the CPM information for the engine board. For example, 22 (22 cpm), 27 (27 cpm), and so on.
5996 3	IPU ID	Displays the IPU ID (presently fixed at “32”).

SP6XXX: Peripherals

6006*	DF Adjustment	
	These settings adjust the registration and other settings for the ADF mode. Use the \odot key to toggle between + and - before entering a value. For more details, see "Replacement and Adjustment - Copy Adjustment" for details.	
6006 1	Side-to-Side (For Simplex)	[-5.0 ~ +5.0 / 0.0 / 0.1 mm/step]
6006 2	Leading Edge	
6006 3	Trailing Edge Erase	Adjusts the trailing edge erase margin. [-5.0 ~ +5.0 / 1.0 / 0.1 mm/step]
6006 4	Side-to-Side/Rear (For Duplex)	Adjusts the side-to-side registration on the rear side of the original. [-5.0 ~ +5.0 / 0.0 / 0.1 mm/step]
6006 5	Sub Scan Magnification	Adjusts the sub scan magnification. [-5.0 ~ +5.0 / 0.0 / 0.1 % step]
6006 6	Skew Correction	Selects whether skew correction is done. 0 = Off, 1 = On
6006 7	Original Buckle Adjustment	Adjusts the amount of original buckle at the ARDF registration roller when the ARDF feeds the back side of the original. [-5.0 ~ +5.0 / 0.0 / 0.1 mm/step]

6007	ADF Input Check	
	Displays the signals received from sensors and switches of the ARDF. (☛ 4.2.4)	

6008	ADF Output Check	
	Switches on each electrical component (ARDF motor, solenoid, etc.) of the ARDF for testing. (☛ 4.2.5) Press $\textcircled{1}$ to switch on or $\textcircled{0}$ to switch off.	

6009	ADF Free Run	
	Performs an ARDF free run in duplex mode. Press $\textcircled{1}$ to start. 1: To Start, 0: To cancel This is a general free run controlled from the copier. For more detailed free run modes, see the ARDF manual.	

6010*	Stamp Position Adjustment	
	Adjusts the stamp position in the sub-scan direction in fax mode. [-5.0 ~ +5.0 / 0 / 1 mm/step]	

6016*	ADF Original Size Detection	
	Selects whether the machine determines that the original is A4/LT, or 8K/16K when the APS sensor in the ADF does not detect the original size. 8K/16K is not available for 115V machines. [0 = Normal (LT for USA models, A4 for Europe/Asia models) 1 = Reversed [A4 for USA models, LT for Europe/Asia models] 2 = 8K/16K]	

SERVICE PROGRAM MODE

6105*	Staple Position Adjustment	[−3.5~+3.5 / 0.0 / 0.5 mm step]
	Adjusts the staple position in the main scan direction when using the two-tray finisher. <i>Press \odot to toggle \pm. A larger value shifts the staple toward the edge of the paper.</i>	

6117	Finisher Input Check
	Displays the signals received from sensors and switches in the finisher. (☛ 4.2.4)

6118	Finisher Output Check
	Switches on each electrical component of the finisher for testing. (☛ 4.2.5) Press \odot to switch on or \ominus to switch off.

6901	ADF APS Data Display
	Displays the status of the original size sensors in the ADF. (☛ 4.2.10)

6910*	ADF Shading Interval Time
	Adjusts the interval for shading processing in DF mode. <i>Light and heat may affect the scanner response. If copy quality indicates that white level is drifting during a DF copy job, reduce this setting.</i> [0 ~ 120 / 20s / 1s/step]

6920	DF Check	
6920 1	DF GATE	DFU 0 = Gate, 1 = Asart
6920 2	DF TXD Break	DFU 0 = Off, 1 = On
6920 3	Serial Communication	DFU 0 = NG, 1 = OK
6920 4	Original Set	DFU 0 = Off, 1 = On
6920 5	Serial Check	DFU

6925	Bridge/Duplex/By-Pass/Loop Back	DFU
6925 1	Practice	DFU
6925 2	Result	DFU

SP7XXX: Data Log

7001*	Main Motor Operation Time	
	The number of prints and drive time for drum revolutions can be obtained by counting the main motor revolution time. If the amount of the time required for the drum to revolve to print 1 copy increases, this data combined with the number of copies can be used to analyze problems and could be useful for future product development.	
	Display: 00000000~99999999 min.	

7002*	Total Original Counter	
7002 1	Total	Select a number to display the total original count (number of originals fed) for the selected item.
7002 2	Copy	
7002 3	Fax	
7002 4	Document Svr Applications	
7002 5	Scanner	
7002 6	Others	

7003*	Print Counter	
7003 1	Total Count	Select a number to display the total print count for the selected item.
7003 2	Copy	
7003 3	Fax	
7003 4	Printer	Select a number to display the total print count for the selected item.
7003 5	Others	

7006*	C/O, P/O Counters	
7006 1	C/O	Displays the number of copies per original when making more than 10 copies. (Range: 0 ~ 9,999,999) <i>For example, if you make 15 copies of a 3 page original document, for a total of 45 sheets, then the counter would be 15 (5 copies counted from 11 to 15 x 3 originals). No count will be returned for 1~10 copies of an original.</i>
7006 2	P/O	

7007*	Other Counter	
7007 1	Duplex Counter	Displays the count total for the selected item.
7007 2	A3/DLT Counter	
7007 3	Staple Counter	
7007 4	Scan Counter	

Service Tables

SERVICE PROGRAM MODE

7101*	Copy Counter – Paper Size	
7 101 5	A4 LEF	Displays the total number of copies by paper size.
7 101 6	A5 LEF	
7 101 14	B5 LEF	
7 101 38	LT LEF	
7 101 44	HLT LEF	
7 101 132	A3 SEF	
7 101 133	A4 SEF	
7 101 134	A5 SEF	
7 101 141	B4 SEF	
7 101 142	B5 SEF	
7 101 160	DLT SEF	
7 101 164	LG SEF	
7 101 166	LT SEF	
7 101 172	HLT SEF	
7 101 255	Others	

7105	P type Counter	
7105 1	Normal	Displays the count for each type of special paper, up to 99,999,999.
7105 2	Recycled	
7105 3	Special	
7105 4	Colour	
7105 5	(Not used)	
7105 6	Letterhead	
7105 7	Label	
7105 8	Thick	
7105 9	OHP	
7105 10	Used	
7105 11	Index	
7105 255	Others	

7 201*	Total Scan Counter
	Displays the total number of scanned originals.

7 204*	Copy Counter – Paper Tray	
7 204 1	Bypass	Displays the total number of copies fed from each paper feed station.
7 204 2	Tray 1	
7 204 3	Tray 2	
7 204 4	Tray 3	
7 204 5	Tray 4	

7 205*	Total ADF Counter
	Displays the total number of originals fed by the ADF.

SERVICE PROGRAM MODE

7206*	Staple Counter
	Displays the total number of staples fired.

7209*	Punch Counter
	Displays the total times the punch has fired. DFU

7 401*	Total SC Counter
	Displays the total number of service calls that have occurred.

7 403*	SC History	
7 403 1	Latest	Displays the most recent 10 service calls.
7 403 2	Latest 1	
7 403 3	Latest 2	
7 403 4	Latest 3	
7 403 5	Latest 4	
7 403 6	Latest 5	
7 403 7	Latest 6	
7 403 8	Latest 7	
7 403 9	Latest 8	
7 403 10	Latest 9	

7 502*	Total Paper Jam Counter
	Displays the total number of paper jams.

7 503*	Total Original Jam Counter
	Displays the total number of original jams.

Service
Tables

SERVICE PROGRAM MODE

7 504*	Total Jams by Location These SPs display the total number of paper jams by location. A "Check-in" (paper late) error occurs when the paper fails to activate the sensor at the precise time. A "Check-out" ("paper lag") paper jam occurs when the paper remains at the sensor for longer than the prescribed time.
7 504 1	At power on
7 504 3	Upper relay sensor (Lag)
7 504 4	Lower relay sensor (Lag)
7 504 5	Vertical transport sensor (Late) (optional bank)
7 504 6	Relay sensor (Late) (optional LCT)
7504 7	By-pass Non-Feed
7504 10	Duplex Non-Feed
7 504 11	Registration sensor (Late)
7 504 12	Paper exit sensor (Late)
7 504 13	Bridge relay sensor (Late)
7 504 14	Bridge exit sensor (Late)
7 504 15	Duplex entrance sensor (Late)
7 504 16	Duplex exit sensor (Late)
7 504 17	1 bin tray exit sensor (Late)
7 504 20	Finisher entrance sensor
7 504 21	Finisher shift tray exit sensor
7 504 23	Finisher staple tray paper sensor
7 504 24	Finisher stack feed-out belt HP sensor
7 504 26	Finisher paper taking out
7 504 27	Finisher drive error
7 504 28	Finisher tray lift error
7 504 29	Finisher jogger drive error
7 504 30	Finisher tray shift drive error
7 504 31	Finisher stapler error
7 504 32	Finisher stack-feed out error
7 504 33	Finisher feed out error
7 504 34	Finisher no response
7 504 53	Transport Sensor 1 (Off Check)
7 504 54	Transport Sensor 2 (Off Check)
7 504 55	Transport Sensor 3 (Off Check)
7 504 56	LCT Relay Sensor (Off Check)
7 504 57	U Relay Sn (Lag) from Bypass
7 504 61	Registration sensor (Lag)
7 504 62	Paper exit sensor (Lag)
7 504 63	Bridge relay sensor (Lag)
7 504 64	Bridge exit sensor (Lag)
7 504 65	Duplex entrance sensor (Lag)
7 504 66	Duplex exit sensor (Lag)
7 504 67	1 bin tray exit sensor (Lag)

7 505	Total Original Jam by Location
	Displays the total number of original jams by location. These jams occur when the original does not activate the sensors. A Check-in (“paper late”) error occurs when the paper fails to activate the sensor at the precise time. a Check-out (“paper lag”) paper jam occurs when the paper remains at the sensor for longer than the prescribed time.
7505 1	At Power On
7505 5	Registration Sensor (On Check)
7505 6	Exit Sensor (On Check)
7505 7	Inverter Sensor (On Check)
7505 55	Registration Sensor (Off Check)
7505 56	Exit Sensor (Off Check)
7505 57	Inverter Sensor (Off Check)

7 506*	Jam Count by Copy Size	
7 506 5	A4 LEF	Displays the total number of copy jams by paper size.
7 506 6	A5 LEF	
7 506 14	B5 LEF	
7 506 038	LT LEF	
7 506 044	HLT LEF	
7 506 132	A3 SEF	
7 506 133	A4 SEF	
7 506 134	A5 SEF	
7 506 141	B4 SEF	
7 506 142	B5 SEF	
7 506 160	DLT SEF	
7 506 164	LG SEF	
7 506 166	LT SEF	
7 506 172	HLT SEF	
7 506 255	Others	

7 507*	Plotter (Copy) Jam History					
7507 1	Last	Displays the copy jam history (the most recent 10 jams) Sample Display: CODE: 007 SIZE: 05h TOTAL: 0000334 DATE: Mon Mar 15 11:44:50 2000 where: CODE is the SP7504-*** number (see above). SIZE is the ASAP paper size code in hex. TOTAL is the total jam error count (SP7003) DATE is the date the jams occurred.				
7507 2	Latest 1					
7507 3	Latest 2					
7507 4	Latest 3					
7507 5	Latest 4					
7507 6	Latest 5					
7507 7	Latest 6					
7507 8	Latest 7					
7507 9	Latest 8					
7507 10	Latest 9					
	Size	Code	Size	Code	Size	Code
	A4 (S)	05	A3 (L)	84	DLT (L)	A0
	A5 (S)	06	A4 (L)	85	LG (L)	A4
	B5 (S)	0E	A5 (L)	86	LT (L)	A6
	LT (S)	26	B4 (L)	8D	HLT (L)	AC
	HLT (S)	2C	B5 (L)	8E	Others	FF

Service Tables

SERVICE PROGRAM MODE

7508*	Original Jam History	
7508 1	Last	Displays the original jam history (the most recent 10 jams. Sample Display: CODE: 007 SIZE: 05h TOTAL: 0000334 DATE: Mon Mar 15 11:44:50 2000 where: CODE is the SP7505*** number (see above). SIZE is the ASAP paper size code in hex. TOTAL is the total error count (SP7002001) DATE is the date the jams occurred.
7508 2	Last 1	
7508 3	Last 2	
7508 4	Last 3	
7508 5	Last 4	
7508 6	Last 5	
7508 7	Last 6	
7508 8	Last 7	
7508 9	Last 8	
7508 10	Last 9	
7801	ROM No./Firmware Version	
	Displays the ROM number and firmware version numbers.	
7803*	PM Counter Display	
	Displays the PM counter since the last PM.	
7804	PM Counter Resets	
	Resets the PM counter. To reset, press Execute on the touch panel.	
7807	SC/Jam Counter Reset	
	Resets the SC and jam counters. To reset, press Execute on the touch panel. This SP does not reset the jam history counters: SP7507, SP7508.	
7808	Resets Counters	
	Resets all counters except SP7002***, SP7006*** and SP7007***. To reset, press Execute on the touch panel.	
7810	Access Code Clear	
	Use to clear the key operator code if the key operator forgets the code. After clearing the code is reset for Null and the password entry display does not open. To clear, press Execute on the touch panel.	
7811	Original Counter Clear	
	Clears the original total display, displayed with SP7002***. To clear, press Execute on the touch panel.	
7816	Print Counter Reset by Tray	
7816 1	By-pass	Resets the total copy count by paper tray. To reset, press Execute on the touch panel. Use these SP modes when replacing the pick-up, feed, and separation rollers.
7816 2	Tray 1	
7816 3	Tray 2	
7816 4	Tray 3	
7816 5	Tray 4	
7816 6	LCT	

SERVICE PROGRAM MODE

7825	Total Counter Reset	
	Resets all electronic counters. To reset, press Execute on the touch panel. DFU	

7826	MF Error Counter	
7826 1	Error Total	Japan only DFU
7826 2	Error Staple	Japan only DFU

7827	MF Device Error Counter Clear	Japan only DFU
------	-------------------------------	-----------------------

7832	Self-Diagnosis Result Display	
	Execute to open the “Self-Diagnostics Result Display” to view details about errors. Use the keys in the display on the touch-panel to scroll through all the information. If no errors have occurred, you will see the “No Error” message on the screen.	

7836	Total Memory Size	
	Displays the memory capacity of the controller system.	

7852	ADF Scan Glass Dust Check Counter	
	Counts the number of occurrences (0 ~ 65,535) when dust was detected on the scanning glass of the ADF. Counting is done only if SP4991 1 (ADF Scan Glass Dust Check) is switched on. Memory All Clear (SP5801) resets this counter to zero	

7901*	Assert Info. DFU	
	These SP numbers display the results of the occurrence of the most recent SC code generated by the machine.	
7991 1*	Source File Name	Module name
7991 2*	Line Number	Number of lines
7991 3*	Result	Value

7909	PCU Counter Display	
	Displays the value of the PCU counter (number of copies since the last PCU change).	

7999	Engine Debug Log Switch	
	DFU	

Service Tables

SERVICE PROGRAM MODE

SP8-xxx: Data Log2

Many of these counters are provided for features that are currently not available, such as sending color faxes, and so on. However, here are some Group 8 codes that when used in combination with others, can provide useful information.

SP Numbers	What They Do
SP8 211~SP8 216	The number of pages scanned to the document server.
SP8 401~SP8 406	The number of pages printed from the document server
SP8 691~SP8 696	The number of pages sent from the document server

Specifically, the following questions can be answered:

- How is the document server actually being used?
- What application is using the document server most frequently?
- What data in the document server is being reused?

Most of the SPs in this group are prefixed with a letter that indicates the mode of operation (the mode of operation is referred to as an 'application'). Before reading the Group 8 Service Table, make sure that you understand what these prefixes mean.

PREFIXES	WHAT IT MEANS	
T:	Total: (Grand Total).	Grand total of the items counted for all applications (C, F, P, etc.)..
C:	Copy application.	Totals (pages, jobs, etc.) executed for each application when the job was <i>not</i> stored on the document server.
F:	Fax application.	
P:	Print application.	
S:	Scan application.	
L:	Local storage (document server)	Totals (jobs, pages, etc.) for the document server. The L: counters work differently case by case. Sometimes, they count jobs/pages stored on the document server; this can be in document server mode (from the document server window), or from another mode, such as from a printer driver or by pressing the Store File button in the Copy mode window. Sometimes, they include occasions when the user uses a file that is already on the document server. Each counter will be discussed case by case.
O:	Other applications (external network applications, for example)	Refers to network applications such as Web Image Monitor. Utilities developed with the SDK (Software Development Kit) will also be counted with this group in the future.

The Group 8 SP codes are limited to 17 characters, forced by the necessity of displaying them on the small LCDs of printers and faxes that also use these SPs. Read over the list of abbreviations below and refer to it again if you see the name of an SP that you do not understand.

Key for Abbreviations

ABBREVIATION	WHAT IT MEANS
/	"By", e.g. "T:Jobs/Apl" = Total Jobs "by" Application
>	More (2> "2 or more", 4> "4 or more")
AddBook	Address Book
Apl	Application
B/W	Black & White
Bk	Black
C	Cyan
ColCr	Color Create
ColMode	Color Mode
Comb	Combine
Comp	Compression
Deliv	Delivery
DesApl	Designated Application. The application (Copy, Fax, Scan, Print) used to store the job on the document server, for example.
Dev Counter	Development Count, no. of pages developed.
Dup, Duplex	Duplex, printing on both sides
Emul	Emulation
FC	Full Color
FIN	Post-print processing, i.e. finishing (punching, stapling, etc.)
Full Bleed	No Margins
GenCopy	Generation Copy Mode
GPC	Get Print Counter. For jobs 10 pages or less, this counter does not count up. For jobs larger than 10 pages, this counter counts up by the number that is in excess of 10 (e.g., for an 11-page job, the counter counts up 11-10 =1)
IFax	Internet Fax
ImgEdt	Image Edit performed on the original with the copier GUI, e.g. border removal, adding stamps, page numbers, etc.
K	Black (YMCK)
LS	Local Storage. Refers to the document server.
LSize	Large (paper) Size
Mag	Magnification
MC	One color (monochrome)
NRS	New Remote Service, which allows a service center to monitor machines remotely. "NRS" is used overseas, "CSS" is used in Japan.
Org	Original for scanning
OrgJam	Original Jam
Palm 2	Print Job Manager/Desk Top Editor: A pair of utilities that allows print jobs to be distributed evenly among the printers on the network, and allows files to moved around, combined, and converted to different formats. Currently not available.
PC	Personal Computer
PGS	Pages. A page is the total scanned surface of the original. Duplex pages count as two pages, and A3 simplex count as two pages if the A3/DLT counter SP is switched ON.

SERVICE PROGRAM MODE

ABBREVIATION	WHAT IT MEANS
PJob	Print Jobs
Ppr	Paper
PrtJam	Printer (plotter) Jam
PrtPGS	Print Pages
R	Red (Toner Remaining). Applies to the wide format model A2 only. This machine is under development and currently not available.
Rez	Resolution
SC	Service Code (Error SC code displayed)
Scn	Scan
Sim, Simplex	Simplex, printing on 1 side.
S-to-Email	Scan-to-E-mail
SMC	SMC report printed with SP5990. All of the Group 8 counters are recorded in the SMC report.
Svr	Server
TonEnd	Toner End
TonSave	Toner Save
TXJob	Send, Transmission
YMC	Yellow, Magenta, Cyan
YMCK	Yellow, Magenta, Cyan, Black

NOTE: All of the Group 8 SPs are reset with SP5 801 1 Memory All Clear, or the Counter Reset SP7 808.

8 001	T:Total Jobs	These SPs count the number of times each application is used to do a job. [0~9999999/ 0 / 1] Note: The L: counter is the total number of times the other applications are used to send a job to the document server, plus the number of times a file already on the document server is used.
8 002	C:Total Jobs	
8 003	F:Total Jobs	
8 004	P:Total Jobs	
8 005	S:Total Jobs	
8 006	L:Total Jobs	
8 007	O:Total Jobs	

- These SPs reveal the number of times an application is used, not the number of pages processed.
- When an application is opened for image input or output, this counts as one job.
- Interrupted jobs (paper jams, etc.) are counted, even though they do not finish.
- Only jobs executed by the customer are counted. Jobs executed by the customer engineer using the SP modes are not counted.
- When using secure printing (when a password is required to start the print job), the job is counted at the time when either “Delete Data” or “Specify Output” is specified.
- A job is counted as a fax job when the job is stored for sending.
- When a fax is received to fax memory, the F: counter increments but the L: counter does not (the document server is not used).
- A fax broadcast counts as one job for the F: counter (the fax destinations in the broadcast are not counted separately).
- A fax broadcast is counted only after all the faxes have been sent to their destinations. If one transmission generates an error, then the broadcast will not be counted until the transmission has been completed.
- A printed fax report counts as one job for the F: counter.
- The F: counter does not distinguish between fax sending or receiving.
- When a copy job on the document server is printed, SP8022 also increments, and when a print job stored on the document server is printed, SP8024 also increments.
- When an original is both copied and stored on the document server, the C: and L: counters both increment.
- When a print job is stored on the document server, only the L: counter increments.
- When the user presses the Document Server button to store the job on the document server, only the L: counter increments.
- When the user enters document server mode and prints data stored on the document server, only the L: counter increments.
- When an image received from Palm 2 is received and stored, the L: counter increments.
- When the customer prints a report (user code list, for example), the O: counter increments. However, for fax reports and reports executed from the fax application, the F: counter increments.

Service Tables

SERVICE PROGRAM MODE

8 011	T:Jobs/LS	These SPs count the number of jobs stored to the document server by each application, to reveal how local storage is being used for input. [0~9999999/ 0 / 1] The L: counter counts the number of jobs stored from within the document server mode screen at the operation panel.
8 012	C:Jobs/LS	
8 013	F:Jobs/LS	
8 014	P:Jobs/LS	
8 015	S:Jobs/LS	
8 016	L:Jobs/LS	
8 017	O:Jobs/LS	

- When a scan job is sent to the document server, the S: counter increments. When you enter document server mode and then scan an original, the L: counter increments.
- When a print job is sent to the document server, the P: counter increments.
- When a network application sends data to the document server, the O: counter increments.
- When an image from Palm 2 is stored on the document server, the O: counter increments.
- When a fax is sent to the document server, the F: counter increments.

8 021	T:Pjob/LS	These SPs reveal how files printed from the document server were stored on the document server originally. [0~9999999/ 0 / 1] The L: counter counts the number of jobs stored from within the document server mode screen at the operation panel.
8 022	C:Pjob/LS	
8 023	F:Pjob/LS	
8 024	P:Pjob/LS	
8 025	S:Pjob/LS	
8 026	L:Pjob/LS	
8 027	O:Pjob/LS	

- When a copy job stored on the document server is printed with another application, the C: counter increments.
- When an application like DeskTopBinder merges a copy job that was stored on the document server with a print job that was stored on the document server, the C: and P: counters both increment.
- When a job already on the document server is printed with another application, the L: counter increments.
- When a scanner job stored on the document server is printed with another application, the S: counter increments. If the original was scanned from within document server mode, then the L: counter increments.
- When images stored on the document server by a network application (including Palm 2), are printed with another application, the O: counter increments.
- When a copy job stored on the document server is printed with a network application (Web Image Monitor, for example), the C: counter increments.
- When a fax on the document server is printed, the F: counter increments.

8 031	T:Pjob/DesApl	These SPs reveal what applications were used to output documents from the document server. [0~9999999/ 0 / 1] The L: counter counts the number of jobs printed from within the document server mode screen at the operation panel.
8 032	C:Pjob/DesApl	
8 033	F:Pjob/DesApl	
8 034	P:Pjob/DesApl	
8 035	S:Pjob/DesApl	
8 036	L:Pjob/DesApl	
8 037	O:Pjob/DesApl	

- When documents already stored on the document server are printed, the count for the application that started the print job is incremented.
- When the print job is started from a network application (Desk Top Binder, Web Image Monitor, etc.) the L: counter increments.

8 041	T:TX Jobs/LS	These SPs count the applications that stored files on the document server that were later accessed for transmission over the telephone line or over a network (attached to an e-mail, or as a fax image by I-Fax). [0~9999999/ 0 / 1] Note: Jobs merged for sending are counted separately. The L: counter counts the number of jobs scanned from within the document server mode screen at the operation panel.
8 042	C:TX Jobs/LS	
8 043	F:TX Jobs/LS	
8 044	P:TX Jobs/LS	
8 045	S:TX Jobs/LS	
8 046	L:TX Jobs/LS	
8 047	O:TX Jobs/LS	

- When a stored copy job is sent from the document server, the C: counter increments.
- When images stored on the document server by a network application or Palm2 are sent as an e-mail, the O: counter increments.

8 051	T:TX Jobs/DesApl	These SPs count the applications used to send files from the document server over the telephone line or over a network (attached to an e-mail, or as a fax image by I-Fax). Jobs merged for sending are counted separately. [0~9999999/ 0 / 1] The L: counter counts the number of jobs sent from within the document server mode screen at the operation panel.
8 052	C:TX Jobs/DesApl	
8 053	F:TX Jobs/DesApl	
8 054	P:TX Jobs/DesApl	
8 055	S:TX Jobs/DesApl	
8 056	L:TX Jobs/DesApl	
8 057	O:TX Jobs/DesApl	

- If the send is started from Desk Top Binder or Web Image Monitor, for example, then the O: counter increments.

Service Tables

SERVICE PROGRAM MODE

8 061	T:FIN Jobs		[0~9999999/ 0 / 1]
	These SPs total the finishing methods. The finishing method is specified by the application.		
8 062	C:FIN Jobs		[0~9999999/ 0 / 1]
	These SPs total finishing methods for copy jobs only. The finishing method is specified by the application.		
8 063	F:FIN Jobs		[0~9999999/ 0 / 1]
	These SPs total finishing methods for fax jobs only. The finishing method is specified by the application. Note: Finishing features for fax jobs are not available at this time.		
8 064	P:FIN Jobs		[0~9999999/ 0 / 1]
	These SPs total finishing methods for print jobs only. The finishing method is specified by the application.		
8 065	S:FIN Jobs		[0~9999999/ 0 / 1]
	These SPs total finishing methods for scan jobs only. The finishing method is specified by the application. Note: Finishing features for scan jobs are not available at this time.		
8 066	L:FIN Jobs		[0~9999999/ 0 / 1]
	These SPs total finishing methods for jobs output from within the document server mode screen at the operation panel. The finishing method is specified from the print window within document server mode.		
8 067	O:FIN Jobs		[0~9999999/ 0 / 1]
	These SPs total finishing methods for jobs executed by an external application, over the network. The finishing method is specified by the application.		
8 06x 1	Sort	Number of jobs started in Sort mode. When a stored copy job is set for Sort and then stored on the document server, the L: counter increments. (See SP8 066 1)	
8 06x 2	Stack	Number of jobs started out of Sort mode.	
8 06x 3	Staple	Number of jobs started in Staple mode.	
8 06x 4	Booklet	Number of jobs started in Booklet mode. If the machine is in staple mode, the Staple counter also increments.	
8 06x 5	Z-Fold	Number of jobs started In any mode other than the Booklet mode and set for folding (Z-fold).	
8 06x 6	Punch	Number of jobs started in Punch mode. When Punch is set for a print job, the P: counter increments. (See SP8 064 6.)	
8 06x 7	Other	Reserved. Not used.	

8 071	T:Jobs/PGS	[0~9999999/ 0 / 1]	
	These SPs count the number of jobs broken down by the number of pages in the job, regardless of which application was used.		
8 072	C:Jobs/PGS	[0~9999999/ 0 / 1]	
	These SPs count and calculate the number of copy jobs by size based on the number of pages in the job.		
8 073	F:Jobs/PGS	[0~9999999/ 0 / 1]	
	These SPs count and calculate the number of fax jobs by size based on the number of pages in the job.		
8 074	P:Jobs/PGS	[0~9999999/ 0 / 1]	
	These SPs count and calculate the number of print jobs by size based on the number of pages in the job.		
8 075	S:Jobs/PGS	[0~9999999/ 0 / 1]	
	These SPs count and calculate the number of scan jobs by size based on the number of pages in the job.		
8 076	L:Jobs/PGS	[0~9999999/ 0 / 1]	
	These SPs count and calculate the number of jobs printed from within the document server mode window at the operation panel, by the number of pages in the job.		
8 077	O:Jobs/PGS	[0~9999999/ 0 / 1]	
	These SPs count and calculate the number of "Other" application jobs (Web Image Monitor, Palm 2, etc.) by size based on the number of pages in the job.		
8 07x 1	1 Page	8 07x 8	21~50 Pages
8 07x 2	2 Pages	8 07x 9	51~100 Pages
8 07x 3	3 Pages	8 07x 10	101~300 Pages
8 07x 4	4 Pages	8 07x 11	301~500 Pages
8 07x 5	5 Pages	8 07x 12	501~700 Pages
8 07x 6	6~10 Pages	8 07x 13	701~1000 Pages
8 07x 7	11~20 Pages	8 07x 14	1001~ Pages

- For example: When a copy job stored on the document server is printed in document server mode, the appropriate L: counter (SP8076 0xx) increments.
- Printing a fax report counts as a job and increments the F: counter (SP 8073).
- Interrupted jobs (paper jam, etc.) are counted, even though they do not finish.
- If a job is paused and re-started, it counts as one job.
- If the finisher runs out of staples during a print and staple job, then the job is counted at the time the error occurs.
- For copy jobs (SP 8072) and scan jobs (SP 8075), the total is calculated by multiplying the number of sets of copies by the number of pages scanned. (One duplex page counts as 2.)
- The first test print and subsequent test prints to adjust settings are added to the number of pages of the copy job (SP 8072).
- When printing the first page of a job from within the document server screen, the page is counted.

SERVICE PROGRAM MODE

8 111	T:FAX TX Jobs	[0~9999999/ 0 / 1]
	These SPs count the total number of jobs (color or black-and-white) sent by fax, either directly or using a file stored on the document server, on a telephone line. Note: Color fax sending is not available at this time.	
8 113	F:FAX TX Jobs	[0~9999999/ 0 / 1]
	These SPs count the total number of jobs (color or black-and-white) sent by fax directly on a telephone line. Note: Color fax sending is not available at this time.	
8 116	L:FAX TX Jobs	[0~9999999/ 0 / 1]
	These SPs count the total number of jobs (color or black-and-white) sent by fax on a telephone line using a file stored on the document server. Documents sent from fax memory are not counted. Note: Color fax sending is not available at this time.	

- These counters count jobs, not pages.
- This SP counts fax jobs sent over a telephone line with a fax application, including documents stored on the document server.
- If the mode is changed during the job, the job will count with the mode set when the job started.
- If the same document is faxed to both a public fax line and an I-Fax at a destination where both are available, then this counter increments, and the I-Fax counter (8 12x) also increments.
- The fax job is counted when the job is scanned for sending, not when the job is sent.

8 121	T:IFAX TX Jobs	[0~9999999/ 0 / 1]
	These SPs count the total number of jobs (color or black-and-white) sent, either directly or using a file stored on the document server, as fax images using I-Fax. Note: Color fax sending is not available at this time.	
8 123	F:IFAX TX Jobs	[0~9999999/ 0 / 1]
	These SPs count the number of jobs (color or black-and-white) sent (not stored on the document server), as fax images using I-Fax. Note: Color fax sending is not available at this time.	
8 126	L:IFAX TX Jobs	[0~9999999/ 0 / 1]
	These SPs count the number of jobs (color or black-and-white) sent using a file stored on the document server, as fax images using I-Fax. Note: Color fax sending is not available at this time.	

- These counters count jobs, not pages.
- The counters for color are provided for future use; the color fax feature is not available at this time.
- The fax job is counted when the job is scanned for sending, not when the job is sent.

8 131	T:S-to-Email Jobs	[0~9999999/ 0 / 1]
	These SPs count the total number of jobs scanned and attached to an e-mail, regardless of whether the document server was used or not.	
8 135	S:S-to-Email Jobs	
	These SPs count the number of jobs scanned and attached to an e-mail, without storing the original on the document server.	
8 136	L:S-to-Email Jobs	
	These SPs count the number of jobs using a file stored on stored on the document server, and attaching it to an e-mail.	

- These counters count jobs, not pages.
- If the job is stored on the document server, after the job is stored it is determined to be color or black-and-white then counted.
- If the job is cancelled during scanning, or if the job is cancelled while the document is waiting to be sent, the job is not counted.
- If the job is cancelled during sending, it may or may not be counted, depending on what stage of the process had been reached when the job was cancelled.
- If several jobs are combined for sending to the Scan Router, Scan-to-Email, or Scan-to-PC, or if one job is sent to more than one destination. each send is counted separately. For example, if the same document is sent by Scan-to-Email as well as Scan-to-PC, then it is counted twice (once for Scan-to-Email and once for Scan-to-PC).

Service Tables

8 141	T:Deliv Jobs/Svr	[0~9999999/ 0 / 1]
	These SPs count the total number of jobs scanned and sent to a Scan Router server.	
8 143	F:Deliv Jobs/Svr	
	These SPs count the number of jobs scanned in fax mode and sent to a Scan Router server.	
8 145	S:Deliv Jobs/Svr	
	These SPs count the number of jobs scanned in scanner mode and sent to a Scan Router server.	

- These counters count jobs, not pages.
- The jobs are counted even though the arrival and reception of the jobs at the Scan Router server cannot be confirmed.
- If even one color image is mixed with black-and-white images, then the job is counted as a “Color” job.
- If the job is cancelled during scanning, or if the job is cancelled while the document is waiting to be delivered, the job is not counted.
- If the job is cancelled during sending, it may or may not be counted, depending on what stage of the process had been reached when the job was cancelled.
- Even if several files are combined for sending, the transmission counts as one job.

SERVICE PROGRAM MODE

8 151	T:Deliv Jobs/PC	[0~9999999/ 0 / 1]
These SPs count the total number of jobs scanned and sent to a folder on a PC (Scan-to-PC). Note: At the present time, 8 151 and 8 155 perform identical counts.		
8 155	S:Deliv Jobs/PC	
These SPs count the total number of jobs scanned and sent with Scan-to-PC.		

- These counters count jobs, not pages.
- If the job is cancelled during scanning, it is not counted.
- If the job is cancelled while it is waiting to be sent, the job is not counted.
- If the job is cancelled during sending, it may or may not be counted, depending on what stage of the process had been reached when the job was cancelled.
- Even if several files are combined for sending, the transmission counts as one job.

8 161	T:PCFAX TX Jobs	These SPs count the number of PC Fax transmission jobs. A job is counted from when it is registered for sending, not when it is sent. [0~9999999/ 0 / 1] Note: At the present time, these counters perform identical counts.
8 163	F:PCFAX TX Jobs	

- This counts fax jobs started from a PC using a PC fax application, and sending the data out to the destination from the PC through the copier.

8 191	T:Total Scan PGS	These SPs count the pages scanned by each application that uses the scanner to scan images. [0~9999999/ 0 / 1]
8 192	C:Total Scan PGS	
8 193	F:Total Scan PGS	
8 195	S:Total Scan PGS	
8 196	L:Total Scan PGS	

- SP 8 191 to 8 196 count the number of scanned sides of pages, not the number of physical pages.
- These counters do not count reading user stamp data, or reading color charts to adjust color.
- Previews done with a scanner driver are not counted.
- A count is done only after all images of a job have been scanned.
- Scans made in SP mode are not counted.

Examples:

- If 3 B5 pages and 1 A3 page are scanned with the scanner application but not stored, the S: count is 4.
- If both sides of 3 A4 sheets are copied and stored to the document server using the Store File button in the Copy mode window, the C: count is 6 and the L: count is 6.
- If both sides of 3 A4 sheets are copied but not stored, the C: count is 6.
- If you enter document server mode then scan 6 pages, the L: count is 6.

Service Tables

8 201	T:LSize Scan PGS	[0~9999999/ 0 / 1]
	These SPs count the total number of large pages input with the scanner for scan and copy jobs. Large size paper (A3/DLT) scanned for fax transmission are not counted. Note: These counters are displayed in the SMC Report, and in the User Tools display.	
8 205	S:LSize Scan PGS	[0~9999999/ 0 / 1]
	These SPs count the total number of large pages input with the scanner for scan jobs only. Large size paper (A3/DLT) scanned for fax transmission are not counted. Note: These counters are displayed in the SMC Report, and in the User Tools display..	

SERVICE PROGRAM MODE

8 211	T:Scan PGS/LS	These SPs count the number of pages scanned into the document server . [0~9999999/ 0 / 1] The L: counter counts the number of pages stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen
8 212	C:Scan PGS/LS	
8 213	F:Scan PGS/LS	
8 215	S:Scan PGS/LS	
8 216	L:Scan PGS/LS	

- Reading user stamp data is not counted.
- If a job is cancelled, the pages output as far as the cancellation are counted.
- If the scanner application scans and stores 3 B5 sheets and 1 A4 sheet, the S: count is 4.
- If pages are copied but not stored on the document server, these counters do not change.
- If both sides of 3 A4 sheets are copied and stored to the document server, the C: count is 6 and the L: count is 6.
- If you enter document server mode then scan 6 pages, the L: count is 6.

8 221	ADF Org Feeds	[0~9999999/ 0 / 1]
	These SPs count the number of pages fed through the ADF for front and back side scanning.	
8 221 1	Front	Number of front sides fed for scanning: With an ADF that can scan both sides simultaneously, the Front side count is the same as the number of pages fed for either simplex or duplex scanning. With an ADF that cannot scan both sides simultaneously, the Front side count is the same as the number of pages fed for duplex front side scanning. (The front side is determined by which side the user loads face up.)
8 221 2	Back	Number of rear sides fed for scanning: With an ADF that can scan both sides simultaneously, the Back count is the same as the number of pages fed for duplex scanning. With an ADF that cannot scan both sides simultaneously, the Back count is the same as the number of pages fed for duplex rear-side scanning.

- When 1 sheet is fed for duplex scanning the Front count is 1 and the Back count is 1.
- If a jam occurs during the job, recovery processing is not counted to avoid double counting. Also, the pages are not counted if the jam occurs before the first sheet is output.

8 231	Scan PGS/Mode	[0~9999999/ 0 / 1]
	These SPs count the number of pages scanned by each ADF mode to determine the work load on the ADF.	
8 231 1	Large Volume	Selectable. Large copy jobs that cannot be loaded in the ADF at one time.
8 231 2	SADF	Selectable. Feeding pages one by one through the ADF.
8 231 3	Mixed Size	Selectable. Select "Mixed Sizes" on the operation panel.
8 231 4	Custom Size	Selectable. Originals of non-standard size.
8 231 5	Platen	Book mode. Raising the ADF and placing the original directly on the platen.

- If the scan mode is changed during the job, for example, if the user switches from ADF to Platen mode, the count is done for the last selected mode.
- The user cannot select mixed sizes or non-standard sizes with the fax application so if the original's page sizes are mixed or non-standard, these are not counted.
- If the user selects "Mixed Sizes" for copying in the platen mode, the Mixed Size count is enabled.
- In the SADF mode if the user copies 1 page in platen mode and then copies 2 pages with SADF, the Platen count is 1 and the SADF count is 3.

Service Tables

SERVICE PROGRAM MODE

8 241	T:Scan PGS/Org	[0~9999999/ 0 / 1]					
	These SPs count the total number of scanned pages by original type for all jobs, regardless of which application was used.						
8 242	C:Scan PGS/Org	[0~9999999/ 0 / 1]					
	These SPs count the number of pages scanned by original type for Copy jobs.						
8 243	F:Scan PGS/Org	[0~9999999/ 0 / 1]					
	These SPs count the number of pages scanned by original type for Fax jobs.						
8 245	S:Scan PGS/Org	[0~9999999/ 0 / 1]					
	These SPs count the number of pages scanned by original type for Scan jobs.						
8 246	L:Scan PGS/Org	[0~9999999/ 0 / 1]					
	These SPs count the number of pages scanned and stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen						
8 247	O:Scan PGS/Org	[0~9999999/ 0 / 1]					
	These SPs count the number of pages scanned by original type by Other applications.						
		8 241	8 242	8 243	8 245	8 246	8 247
8 24x 1: Text		Yes	Yes	Yes	Yes	Yes	Yes
8 24x 2: Text/Photo		Yes	Yes	Yes	Yes	Yes	Yes
8 24x 3: Photo		Yes	Yes	Yes	Yes	Yes	Yes
8 24x 4: GenCopy, Pale		Yes	Yes	No	Yes	Yes	Yes
8 24x 5: Map		Yes	Yes	No	Yes	Yes	Yes
8 24x 6: Normal/Detail		Yes	No	Yes	No	No	No
8 24x 7: Fine/Super Fine		Yes	No	Yes	No	No	No
8 24x 8: Binary		Yes	No	No	Yes	No	No
8 24x 9: Grayscale		Yes	No	No	Yes	No	No

- If the scan mode is changed during the job, for example, if the user switches from ADF to Platen mode, the count is done for the last selected mode.

SERVICE PROGRAM MODE

8 251	T:Scan PGS/ImgEdt	<p>These SPs show how many times Image Edit features have been selected at the operation panel for each application. Some examples of these editing features are:</p> <ul style="list-style-type: none"> • Erase> Border • Erase> Center • Image Repeat • Centering • Positive/Negative <p>[0~9999999/ 0 / 1] Note: The count totals the number of times the edit features have been used. A detailed breakdown of exactly which features have been used is not given.</p>
8 252	C:Scan PGS/ImgEdt	
8 254	P:Scan PGS/ImgEdt	
8 256	L:Scan PGS/ImgEdt	
8 257	O:Scan PGS/ImgEdt	

The L: counter counts the number of pages stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen.

8 281	T:Scan PGS/TWAIN	<p>These SPs count the number of pages scanned using a TWAIN driver. These counters reveal how the TWAIN driver is used for delivery functions.</p> <p>[0~9999999/ 0 / 1] Note: At the present time, these counters perform identical counts.</p>
8 285	S:Scan PGS/TWAIN	

8 291	T:Scan PGS/Stamp	<p>These SPs count the number of pages stamped with the stamp in the ADF unit.</p> <p>[0~9999999/ 0 / 1] The L: counter counts the number of pages stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen</p>
8 293	F:Scan PGS/Stamp	
8 295	S:Scan PGS/Stamp	
8 296	L:Scan PGS/Stamp	

Service Tables

SERVICE PROGRAM MODE

8 301	T:Scan PGS/Size	[0~9999999/ 0 / 1]
	These SPs count by size the total number of pages scanned by all applications. Use these totals to compare original page size (scanning) and output (printing) page size [SP 8-441].	
8 302	C:Scan PGS/Size	[0~9999999/ 0 / 1]
	These SPs count by size the total number of pages scanned by the Copy application. Use these totals to compare original page size (scanning) and output (printing) page size [SP 8-442].	
8 303	F:Scan PGS/Size	[0~9999999/ 0 / 1]
	These SPs count by size the total number of pages scanned by the Fax application. Use these totals to compare original page size (scanning) and output page size [SP 8-443].	
8 305	S:Scan PGS/Size	[0~9999999/ 0 / 1]
	These SPs count by size the total number of pages scanned by the Scan application. Use these totals to compare original page size (scanning) and output page size [SP 8-445].	
8 306	L:Scan PGS/Size	[0~9999999/ 0 / 1]
	These SPs count by size the total number of pages scanned and stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen. Use these totals to compare original page size (scanning) and output page size [SP 8-446].	
8 30x 1	A3	
8 30x 2	A4	
8 30x 3	A5	
8 30x 4	B4	
8 30x 5	B5	
8 30x 6	DLT	
8 30x 7	LG	
8 30x 8	LT	
8 30x 9	HLT	
8 30x 10	Full Bleed	
8 30x 254	Other (Standard)	
8 30x 255	Other (Custom)	

8 311	T:Scan PGS/Rez	[0~9999999/ 0 / 1]
	These SPs count by resolution setting the total number of pages scanned by applications that can specify resolution settings.	
8 315	S:Scan PGS/Rez	[0~9999999/ 0 / 1]
	These SPs count by resolution setting the total number of pages scanned by applications that can specify resolution settings. Note: At the present time, 8 311 and 8 315 perform identical counts.	
8 31x 1	1200dpi ~	
8 31x 2	600dpi~1199dpi	
8 31x 3	400dpi~599dpi	
8 31x 4	200dpi~399dpi	
8 31x 5	~199dpi	

- Copy resolution settings are fixed so they are not counted.
- The Fax application does not allow finely-adjusted resolution settings so no count is done for the Fax application.

8 321	T:Scan PGS/Comp	[0~9999999/ 0 / 1]
	These SPs count by compression method the total number of pages scanned.	
8 325	S:Scan PGS/Comp	[0~9999999/ 0 / 1]
	These SPs count by compression method the total number of pages scanned by the Scan application. Note: At the present time, 8 321 and 8 325 perform identical counts.	
8 32x 1	JPEG	
8 32x 2	JPEG2000	
8 32x 3	TIFF (Comp OFF)	
8 32x 4	TIFF (Comp ON)	
8 32x 5	PDF	
8 32x 6	Other	

Service Tables

SERVICE PROGRAM MODE

8 381	T:Total PrtPGS	<p>These SPs count the number of pages printed by the customer. The counter for the application used for storing the pages increments.</p> <p>[0~9999999/ 0 / 1]</p> <p>The L: counter counts the number of pages stored from within the document server mode screen at the operation panel. Pages stored with the Store File button from within the Copy mode screen go to the C: counter.</p>
8 382	C:Total PrtPGS	
8 383	F:Total PrtPGS	
8 384	P:Total PrtPGS	
8 385	S:Total PrtPGS	
8 386	L:Total PrtPGS	
8 387	O:Total PrtPGS	

- When the A3/DLT double count function is switched on with SP5104, 1 A3/DLT page is counted as 2.
- When several documents are merged for a print job, the number of pages stored are counted for the application that stored them.
- These counters are used primarily to calculate charges on use of the machine, so the following pages are not counted as printed pages:
 - Blank pages in a duplex printing job.
 - Blank pages inserted as document covers, chapter title sheets, and slip sheets.
 - Reports printed to confirm counts.
 - All reports done in the service mode (service summaries, engine maintenance reports, etc.)
 - Test prints for machine image adjustment.
 - Error notification reports.
 - Partially printed pages as the result of a copier jam.

8 391	LSize PrtPGS	[0~9999999/ 0 / 1]
	<p>These SPs count pages printed on paper sizes A3/DLT and larger.</p> <p>Note: In addition to being displayed in the SMC Report, these counters are also displayed in the User Tools display on the copy machine.</p>	

8 401	T:PrtPGS/LS	<p>These SPs count the number of pages printed from the document server. The counter for the application used to print the pages is incremented.</p> <p>The L: counter counts the number of jobs stored from within the document server mode screen at the operation panel.</p> <p>[0~9999999/ 0 / 1]</p>
8 402	C:PrtPGS/LS	
8 403	F:PrtPGS/LS	
8 404	P:PrtPGS/LS	
8 405	S:PrtPGS/LS	
8 406	L:PrtPGS/LS	

- Print jobs done with Web Image Monitor and Desk Top Binder are added to the L: count.
- Fax jobs done with Web Image Monitor and Desk Top Binder are added to the F: count.

8 411	Prints/Duplex	This SP counts the amount of paper (front/back counted as 1 page) used for duplex printing. Last pages printed only on one side are not counted. [0~9999999/ 0 / 1]
-------	---------------	--

8 421	T:PrtPGS/Dup Comb	[0~9999999/ 0 / 1]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing. This is the total for all applications.	
8 422	C:PrtPGS/Dup Comb	[0~9999999/ 0 / 1]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by the copier application.	
8 423	F:PrtPGS/Dup Comb	[0~9999999/ 0 / 1]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by the fax application.	
8 424	P:PrtPGS/Dup Comb	[0~9999999/ 0 / 1]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by the printer application.	
8 425	S:PrtPGS/Dup Comb	[0~9999999/ 0 / 1]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by the scanner application.	
8 426	L:PrtPGS/Dup Comb	[0~9999999/ 0 / 1]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing from within the document server mode window at the operation panel.	
8 427	O:PrtPGS/Dup Comb	[0~9999999/ 0 / 1]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by Other applications	
8 42x 1	Simplex> Duplex	
8 42x 2	Duplex> Duplex	
8 42x 3	Book> Duplex	
8 42x 4	Simplex Combine	
8 42x 5	Duplex Combine	
8 42x 6	2>	2 pages on 1 side (2-Up)
8 42x 7	4>	4 pages on 1 side (4-Up)
8 42x 8	6>	6 pages on 1 side (6-Up)
8 42x 9	8>	8 pages on 1 side (8-Up)
8 42x 10	9>	9 pages on 1 side (9-Up)
8 42x 11	16>	16 pages on 1 side (16-Up)
8 42x 12	Booklet	
8 42x 13	Magazine	

Service Tables

- These counts (SP8 421 to SP8 427) are especially useful for customers who need to improve their compliance with ISO standards for the reduction of paper consumption.
- Pages that are only partially printed with the n-Up functions are counted as 1 page.
- Here is a summary of how the counters work for Booklet and Magazine modes:

SERVICE PROGRAM MODE

Booklet	
Original Pages	Count
1	1
2	2
3	2
4	2
5	3
6	4
7	4
8	4

Magazine	
Original Pages	Count
1	1
2	2
3	2
4	2
5	4
6	4
7	4
8	4

8 431	T:PrtPGS/ImgEdt	[0~9999999/ 0 / 1]
	These SPs count the total number of pages output with the three features below, regardless of which application was used.	
8 432	C:PrtPGS/ImgEdt	[0~9999999/ 0 / 1]
	These SPs count the total number of pages output with the three features below with the copy application.	
8 434	P:PrtPGS/ImgEdt	[0~9999999/ 0 / 1]
	These SPs count the total number of pages output with the three features below with the print application.	
8 436	L:PrtPGS/ImgEdt	[0~9999999/ 0 / 1]
	These SPs count the total number of pages output from within the document server mode window at the operation panel with the three features below.	
8 437	O:PrtPGS/ImgEdt	[0~9999999/ 0 / 1]
	These SPs count the total number of pages output with the three features below with Other applications.	
8 43x 1	Cover/Slip Sheet	Total number of covers or slip sheets inserted. The count for a cover printed on both sides counts 2.
8 43x 2	Series/Book	The number of pages printed in series (one side) or printed as a book with booklet right/left pagination.
8 43x 3	User Stamp	The number of pages printed where stamps were applied, including page numbering and date stamping.

8 441	T:PrtPGS/Ppr Size	[0~9999999/ 0 / 1]
	These SPs count by print paper size the number of pages printed by all applications.	
8 442	C:PrtPGS/Ppr Size	[0~9999999/ 0 / 1]
	These SPs count by print paper size the number of pages printed by the copy application.	
8 443	F:PrtPGS/Ppr Size	[0~9999999/ 0 / 1]
	These SPs count by print paper size the number of pages printed by the fax application.	
8 444	P:PrtPGS/Ppr Size	[0~9999999/ 0 / 1]
	These SPs count by print paper size the number of pages printed by the printer application.	
8 445	S:PrtPGS/Ppr Size	[0~9999999/ 0 / 1]
	These SPs count by print paper size the number of pages printed by the scanner application.	
8 446	L:PrtPGS/Ppr Size	[0~9999999/ 0 / 1]
	These SPs count by print paper size the number of pages printed from within the document server mode window at the operation panel.	
8 447	O:PrtPGS/Ppr Size	[0~9999999/ 0 / 1]
	These SPs count by print paper size the number of pages printed by Other applications.	
8 44x 1	A3	
8 44x 2	A4	
8 44x 3	A5	
8 44x 4	B4	
8 44x 5	B5	
8 44x 6	DLT	
8 44x 7	LG	
8 44x 8	LT	
8 44x 9	HLT	
8 44x 10	Full Bleed	
8 44x 254	Other (Standard)	
8 44x 255	Other (Custom)	

Service Tables

- These counters do not distinguish between LEF and SEF.

SERVICE PROGRAM MODE

8 451	PrtPGS/Ppr Tray		[0~9999999/ 0 / 1]
	These SPs count the number of sheets fed from each paper feed station.		
8 451 1	Bypass	Bypass Tray	
8 451 2	Tray 1	Copier	
8 451 3	Tray 2	Copier	
8 451 4	Tray 3	Paper Tray Unit (Option)	
8 451 5	Tray 4	Paper Tray Unit (Option)	
8 451 6	Tray 5	LCT (Option)	
8 451 7	Tray 6	Currently not used.	
8 451 8	Tray 7	Currently not used.	
8 451 9	Tray 8	Currently not used.	
8 451 10	Tray 9	Currently not used.	

8 461	T:PrtPGS/Ppr Type		[0~9999999/ 0 / 1]
	<p>These SPs count by paper type the number pages printed by all applications.</p> <ul style="list-style-type: none"> • These counters are not the same as the PM counter. The PM counter is based on feed timing to accurately measure the service life of the feed rollers. However, these counts are based on output timing. • Blank sheets (covers, chapter covers, slip sheets) are also counted. • During duplex printing, pages printed on both sides count as 1, and a page printed on one side counts as 1. 		
8 462	C:PrtPGS/Ppr Type		[0~9999999/ 0 / 1]
	These SPs count by paper type the number pages printed by the copy application.		
8 463	F:PrtPGS/Ppr Type		[0~9999999/ 0 / 1]
	These SPs count by paper type the number pages printed by the fax application.		
8 464	P:PrtPGS/Ppr Type		[0~9999999/ 0 / 1]
	These SPs count by paper type the number pages printed by the printer application.		
8 466	L:PrtPGS/Ppr Type		[0~9999999/ 0 / 1]
	These SPs count by paper type the number pages printed from within the document server mode window at the operation panel.		
8 46x 1	Normal		
8 46x 2	Recycled		
8 46x 3	Special		
8 46x 4	Thick		
8 46x 5	Normal (Back)		
8 46x 6	Thick (Back)		
8 46x 7	OHP		
8 46x 8	Other		

8 471	PrtPGS/Mag	[0~9999999/ 0 / 1]
	These SPs count by magnification rate the number of pages printed.	
8 471 1	~49%	
8 471 2	50%~99%	
8 471 3	100%	
8 471 4	101%~200%	
8 471 5	201% ~	

- Counts are done for magnification adjusted for pages, not only on the operation panel but performed remotely with an external network application capable of performing magnification adjustment as well.
- Magnification adjustments done with printer drivers with PC applications such as Excel are also counted.
- Magnification adjustments done for adjustments after they have been stored on the document server are not counted.
- Magnification adjustments performed automatically during Auto Reduce/Enlarge copying are counted.
- The magnification rates of blank cover sheets, slip sheets, etc. are automatically assigned a rate of 100%.

8 481	T:PrtPGS/TonSave
8 484	P:PrtPGS/TonSave
	These SPs count the number of pages printed with the Toner Save feature switched on. Note: These SPs return the same results as this SP is limited to the Print application. [0~9999999/ 0 / 1]

Service
Tables

SERVICE PROGRAM MODE

8 511	T:PrtPGS/Emul	[0~9999999/ 0 / 1]
	These SPs count by printer emulation mode the total number of pages printed.	
8 514	P:PrtPGS/Emul	[0~9999999/ 0 / 1]
	These SPs count by printer emulation mode the total number of pages printed.	
8 514 1	RPCS	
8 514 2	RPDL	
8 514 3	PS3	
8 514 4	R98	
8 514 5	R16	
8 514 6	GL/GL2	
8 514 7	R55	
8 514 8	RTIFF	
8 514 9	PDF	
8 514 10	PCL5e/5c	
8 514 11	PCL XL	
8 514 12	IPDL-C	
8 514 13	BM-Links	
8 514 14	Other	

- SP8 511 and SP8 514 return the same results as they are both limited to the Print application.
- Print jobs output to the document server are not counted.

8 521	T:PrtPGS/FIN	[0~9999999/ 0 / 1]
	These SPs count by finishing mode the total number of pages printed by all applications.	
8 522	C:PrtPGS/FIN	[0~9999999/ 0 / 1]
	These SPs count by finishing mode the total number of pages printed by the Copy application.	
8 523	F:PrtPGS/FIN	[0~9999999/ 0 / 1]
	These SPs count by finishing mode the total number of pages printed by the Fax application. Note: <ul style="list-style-type: none"> Print finishing options for received faxes are currently not available. 	
8 524	P:PrtPGS/FIN	[0~9999999/ 0 / 1]
	These SPs count by finishing mode the total number of pages printed by the Print application.	
8 525	S:PrtPGS/FIN	[0~9999999/ 0 / 1]
	These SPs count by finishing mode the total number of pages printed by the Scanner application.	
8 526	L:PrtPGS/FIN	[0~9999999/ 0 / 1]
	These SPs count by finishing mode the total number of pages printed from within the document server mode window at the operation panel.	
8 52x 1	Sort	
8 52x 2	Stack	
8 52x 3	Staple	
8 52x 4	Booklet	
8 52x 5	Z-Fold	
8 52x 6	Punch	
8 52x 7	Other	

Service Tables

- NOTE:** 1) If stapling is selected for finishing and the stack is too large for stapling, the unstapled pages are still counted.
 2) The counts for staple finishing are based on output to the staple tray, so jam recoveries are counted.

8 531	Staples	This SP counts the amount of staples used by the machine. [0~9999999/ 0 / 1]
-------	---------	---

SERVICE PROGRAM MODE

8 581	T:Counter	[0~9999999/ 0 / 1]
	<p>These SPs count the total output broken down by color output, regardless of the application used. In addition to being displayed in the SMC Report, these counters are also displayed in the User Tools display on the copy machine.</p> <p>Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.</p>	

8 591	O:Counter	[0~9999999/ 0 / 1]
	<p>These SPs count the totals for A3/DLT paper use, number of duplex pages printed, and the number of staples used. These totals are for Other (O:) applications only.</p>	
8 591 1	A3/DLT	
8 591 2	Duplex	
8 591 3	Staple	

8 631	T:FAX TX PGS	[0~9999999/ 0 / 1]
	<p>These SPs count by color mode the number of pages sent by fax to a telephone number.</p> <p>Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.</p>	
8 633	F:FAX TX PGS	[0~9999999/ 0 / 1]
	<p>These SPs count by color mode the number of pages sent by fax to a telephone number.</p> <p>Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.</p>	

- If a document has color and black-and-white pages mixed, the pages are counted separately as B/W or Color.
- At the present time, this feature is provided for the Fax application only so SP8631 and SP8633 are the same.
- The counts include error pages.
- If a document is sent to more than one destination with a Group transmission, the count is done for each destination.
- Polling transmissions are counted but polling RX are not.
- Relay, memory, and confidential mailbox transmissions and are counted for each destination.

8 641	T:FAX TX PGS	[0~9999999/ 0 / 1]
	These SPs count by color mode the number of pages sent by fax to as fax images using I-Fax. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	
8 643	F:FAX TX PGS	[0~9999999/ 0 / 1]
	These SPs count by color mode the number of pages sent by Fax as fax images using I-Fax. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	

- If a document has color and black-and-white pages mixed, the pages are counted separately as B/W or Color.
- At the present time, this feature is provided for the Fax application only so SP8641 and SP8643 are the same.
- The counts include error pages.
- If a document is sent to more than one destination with a Group transmission, the count is done for each destination.
- Polling transmissions are counted but polling RX are not.
- Relay, memory, and confidential mailbox transmissions and are counted for each destination.

Service Tables

8 651	T:S-to-Email PGS	[0~9999999/ 0 / 1]
	These SPs count by color mode the total number of pages attached to an e-mail for both the Scan and document server applications. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	
8 655	S:S-to-Email PGS	[0~9999999/ 0 / 1]
	These SPs count by color mode the total number of pages attached to an e-mail for the Scan application only. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	
8 656	L:S-to-Email PGS	[0~9999999/ 0 / 1]
	These SPs count by color mode the total number of pages attached to an e-mail for LS applications only. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	

SERVICE PROGRAM MODE

- NOTE:** 1) The count for B/W and Color pages is done after the document is stored on the HDD. If the job is cancelled before it is stored, the pages are not counted.
- 2) If Scan-to-Email is used to send a 10-page document to 5 addresses, the count is 10 (the pages are sent to the same SMTP server together).
- 3) If Scan-to-PC is used to send a 10-page document to 5 folders, the count is 50 (the document is sent to each destination of the SMB/FTP server).
- 4) Due to restrictions on some devices, if Scan-to-Email is used to send a 10-page document to a large number of destinations, the count may be divided and counted separately. For example, if a 10-page document is sent to 200 addresses, the count is 10 for the first 100 destinations and the count is also 10 for the second 100 destinations, for a total of 20.).

8 661	T:Deliv PGS/Svr	[0~9999999/ 0 / 1]
	These SPs count by color mode the total number of pages sent to a Scan Router server by both Scan and LS applications. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	
8 665	S:Deliv PGS/Svr	[0~9999999/ 0 / 1]
	These SPs count by color mode the total number of pages sent to a Scan Router server by the Scan application. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	
8 666	L:Deliv PGS/Svr	[0~9999999/ 0 / 1]
	These SPs count by color mode the total number of pages sent to a Scan Router server by LS applications. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	

- NOTE:** 1) The B/W and Color counts are done after the document is stored on the HDD of the Scan Router server.
- 2) If the job is canceled before storage on the Scan Router server finishes, the counts are not done.
- 3) The count is executed even if regardless of confirmation of the arrival at the Scan Router server.

8 671	T:Deliv PGS/PC	[0~9999999/ 0 / 1]
	These SPs count by color mode the total number of pages sent to a folder on a PC (Scan-to-PC) with the Scan and LS applications. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	
8 675	S:Deliv PGS/PC	[0~9999999/ 0 / 1]
	These SPs count by color mode the total number of pages sent with Scan-to-PC with the Scan application. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	
8 676	L:Deliv PGS/PC	[0~9999999/ 0 / 1]
	These SPs count by color mode the total number of pages sent with Scan-to-PC function with the LS applications. Note: This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only.	

8 681	T:PCFAX TXPGS	These SPs count the number of pages sent by PC Fax. These SPs are provided for the Fax application only, so the counts for SP8 681 and SP8 683 are the same. [0~9999999/ 0 / 1]
8 683	F:PCFAX TXPGS	

- This counts pages sent from a PC using a PC fax application, from the PC through the copier to the destination.
- When sending the same message to more than one place using broadcasting, the pages are only counted once. (For example, a 10-page fax is sent to location A and location B. The counter goes up by 10, not 20.)

8 691	T:TX PGS/LS	These SPs count the number of pages sent from the document server. The counter for the application that was used to store the pages is incremented. [0~9999999/ 0 / 1] The L: counter counts the number of pages stored from within the document server mode screen at the operation panel. Pages stored with the Store File button from within the Copy mode screen go to the C: counter.
8 692	C:TX PGS/LS	
8 693	F:TX PGS/LS	
8 694	P:TX PGS/LS	
8 695	S:TX PGS/LS	
8 696	L:TX PGS/LS	

- NOTE:**
- 1) Print jobs done with Web Image Monitor and Desk Top Binder are added to the count.
 - 2) If several documents are merged for sending, the number of pages stored are counted for the application that stored them.
 - 3) When several documents are sent by a Fax broadcast, the F: count is done for the number of pages sent to each destination.

Service Tables

SERVICE PROGRAM MODE

8 701	TX PGS/Port	[0~99999999/ 0 / 1]
	These SPs count the number of pages sent by the physical port used to send them. For example, if a 3-page original is sent to 4 destinations via ISDN G4, the count for ISDN (G3, G4) is 12.	
8 701 1	PSTN-1	
8 701 2	PSTN-2	
8 701 3	PSTN-3	
8 701 4	ISDN (G3,G4)	
8 701 5	Network	

8 741	RX PGS/Port	[0~99999999/ 0 / 1]
	These SPs count the number of pages received by the physical port used to receive them.	
8 741 1	PSTN-1	
8 741 2	PSTN-2	
8 741 3	PSTN-3	
8 741 4	ISDN (G3,G4)	
8 741 5	Network	

8 771	Dev Counter	[0~99999999/ 0 / 1]
	These SPs count the frequency of use (number of rotations of the development rollers) for black and other color toners. Note: For machines that do not support color, the Black toner count is the same as the Total count.	

8 791	LS Memory Remain	This SP displays the percent of space available on the document server for storing documents. [0~100/ 0 / 1]
-------	------------------	---

8 801	Toner Remain	[0~100/ 0 / 1]
	This SP displays the percent of toner remaining for each color. This SP allows the user to check the toner supply at any time. Note: <ul style="list-style-type: none"> • This precise method of measuring remaining toner supply (1% steps) is better than other machines in the market that can only measure in increments of 10 (10% steps). • This SP is expanded for color MFP and color LP machines. For this machine, the count is done for black only. 	

8 781	Pixel Coverage Ratio DFU
8 831	Pixel Coverage Ratio DFU
8 841	Pixel Coverage Ratio DFU
8 851	DFU
8 861	DFU
8 871	DFU
8 881	DFU
8 901	Pixel Coverage Ratio DFU
8 911	Pixel Coverage Ratio DFU

8 941	Machine Status	[0~99999999/ 0 / 1]
	These SPs count the amount of time the machine spends in each operation mode. These SPs are useful for customers who need to investigate machine operation for improvement in their compliance with ISO Standards.	
8 941 1	Operation Time	Engine operation time. Does not include time while controller is saving data to HDD (while engine is not operating).
8 941 2	Standby Time	Engine not operating. Includes time while controller saves data to HDD. Does not include time spent in Energy Save, Low Power, or Off modes.
8 941 3	Energy Save Time	Includes time while the machine is performing background printing.
8 941 4	Low Power Time	Includes time in Energy Save mode with Engine on. Includes time while machine is performing background printing.
8 941 5	Off Mode Time	Includes time while machine is performing background printing. Does not include time machine remains powered off with the power switches.
8 941 6	Down Time/SC	Total down time due to SC errors.
8 941 7	Down Time/PrtJam	Total down time due to paper jams during printing.
8 941 8	Down Time/OrgJam	Total down time due to original jams during scanning.
8 941 9	Down Time/TonEnd	Total down time due to toner end.

Service Tables

SERVICE PROGRAM MODE

8 951	AddBook Register		
	These SPs count the number of events when the machine manages data registration.		
8 951 1	User Code	User code registrations.	[0~9999999/ 0 / 1]
8 951 2	Mail Address	Mail address registrations.	
8 951 3	Fax Destination	Fax destination registrations.	
8 951 4	Group	Group destination registrations.	
8 951 5	Transfer Request	Fax relay destination registrations for relay TX.	
8 951 6	F-Code	F-Code box registrations.	
8 951 7	Copy Program	Copy application registrations with the Program (job settings) feature.	[0~255 / 0 / 255]
8 951 8	Fax Program	Fax application registrations with the Program (job settings) feature.	
8 951 9	Printer Program	Printer application registrations with the Program (job settings) feature.	
8 951 10	Scanner Program	Scanner application registrations with the Program (job settings) feature.	

4.2.3 TEST PATTERN PRINTING (SP2902-3)

NOTE: Always print a test pattern to confirm correct operation of the machine.

1. Enter the SP mode and select SP2902.
2. Press $\text{\textcircled{3}}$.
3. Enter the number for the test pattern that you want to print and press $\text{\textcircled{\#}}$. (See the tables below.)
4. Press Copy Window to open the copy window and then select the settings for the test print (paper size, etc.)
5. Press Start $\text{\textcircled{\textcircled{S}}}$ twice. (Ignore the "Place Original" messages) to start the test print.
6. Press SP Mode (highlighted) to return to the SP mode display.

No.	Test Pattern	No.	Test Pattern
0	None	15	Grayscale (Grid)
1	Vertical Line (1dot)	16	Grayscale with White Line (Horizontal)
2	Horizontal Line (1dot)	17	Grayscale with White Line (Vertical)
3	Vertical Line (2dot)	18	Grayscale with White Line (Vertical /Horizontal)
4	Horizontal Line (2 dot)	23	P Pattern
5	Grid Pattern (1dot)	31	Grayscale (Horizontal, 8bit, Odd)
6	Grid Pattern (1dot pair)	32	Grayscale (Vertical, 8bit, Odd)
7	Alternating Dot Pattern	33	Grayscale with White Line (Horizontal 8bit, Odd)
8	Full Dot Pattern	34	Grayscale with White Line (Vertical 8bit, Odd)
9	Black band	35	Grayscale (Horizontal, 8bit, Even)
10	Trimming Area	36	Grayscale (Vertical, 8bit, Even)
11	Argyle Pattern	37	Grayscale with White Line (Horizontal 8bit, Even)
12	Grayscale (Horizontal)	38	Grayscale with White Line (Vertical 8bit, Even)
13	Grayscale (Vertical)	40	Grid (1dot pair) (OR Outside Data 1)
14	Grayscale (Vertical/Horizontal)	41	Trimming Area (OR Outside Data)

Also see SP 4417 in the SP table for a different set of test patterns.

4.2.4 INPUT CHECK

Main Machine Input Check (SP5803)

1. Enter the SP mode and select SP5803.
2. Enter the number (1 – 11) for the item that you want to check. A small box will be displayed on the SP mode screen with a series of 0's and 1's. The meaning of the display is as follows.

0 0 0 0 0 0 0 0

Bit 7 6 5 4 3 2 1 0

3. Check the status of each item against the corresponding bit numbers listed in the table below.

Number	Bit	Description	Reading	
			0	1
1	7	Paper Height Sensor 2 (2nd Tray)	Activated	Deactivated
	6	Paper Height Sensor 1 (2nd Tray)	Activated	Deactivated
	5	Paper Height Sensor 2 (1st Tray)	Activated	Deactivated
	4	Paper Height Sensor 1 (1st Tray)	Activated	Deactivated
	3	Paper End Sensor (2nd Tray)	Paper End	Paper is present
	2	Upper Relay Sensor	Activated	Deactivated
	1	Lower Right Cover Open	Closed	Open
	0	Not used		
2	7	Paper Exit Sensor	Activated	Deactivated
	6	Fusing Unit	Unit Set	Unit not set
	5	PCU Set	Activated	Deactivated
	4	New PCU Sensor	Activated	Deactivated
	3	Interchange Exit Sensor	Activated	Deactivated
	2	1 bin Tray Unit Set	Unit Set	Unit not set
	1	1 bin Tray Paper Sensor	Activated	Deactivated
	0	Interchange Unit Set	Unit Set	Unit not set
3	7	Bridge Exit Sensor	Activated	Deactivated
	6	Not used		
	5	Bridge Paper Sensor	Activated	Deactivated
	4	Bridge Right Guide Switch	Activated	Deactivated
	3	Bridge Left Guide Switch	Activated	Deactivated
	2	Bridge Unit Set	Unit Set	Unit not set
	1	Bridge Fan Motor Lock	Locked	Unlocked
	0	Shift Tray Unit Set	Unit Set	Unit not set

SERVICE PROGRAM MODE

Number	Bit	Description	Reading	
			0	1
4	7	Wake up Signal	Not detected	Detected
	6	Lower Relay Sensor	Activated	Deactivated
	5	Vertical Transport Sensor (Optional paper tray unit)	Activated	Deactivated
	4	3rd Tray Paper Size	Activated	Deactivated
	3	4th Tray Paper Size	Activated	Deactivated
	2	Motor Lock (Optional paper tray unit)	Not locked	Locked
	1	Height Sensor (Optional paper tray unit)	Activated	Deactivated
	0	Unit Set (Optional paper tray unit)	Unit set	Unit not set
5	7	Fusing Drive Release Solenoid	Activated	Deactivated
	6	Main Motor Brake Signal	Not active	Active
	5	Main Motor On Signal	Activated	Deactivated
	4	Main Motor Rotation Direction Signal	Not active	Active
	3	3rd Paper End Sensor	Paper End	Paper is present
	2	4th Paper End Sensor	Paper End	Paper is present
	1	3rd Paper Height Sensor	Deactivated	Activated
	0	4th Paper Height Sensor	Deactivated	Activated
6	7	Duplex Unit Set	Unit set	Unit not set
	6	Total Counter	Not detected	Detected
	5	By-pass Tray Unit Set	Detected	Not detected
	4	By-pass Paper End Sensor	Paper End	Paper is present
	3	By-pass Paper Size 2	Activated	Deactivated
	2	By-pass Paper Size 1	Activated	Deactivated
	1	By-pass Paper Size 4	Activated	Deactivated
	0	By-pass Paper Size 3	Activated	Deactivated
7	7	Not Used		
	6	Not Used		
	5	Not Used		
	4	Not Used		
	3	Key Counter Set	Detected	Not detected
	2	Key Card Set	Detected	Not detected
	1	Polygon Motor Ready Signal	Ready	Not ready
	0	Not Used		

Service Tables

SERVICE PROGRAM MODE

Number	Bit	Description	Reading	
			0	1
8	7	Dip Switch - 4	On	Off
	6	Dip Switch - 3	Off	On
	5	Dip Switch - 2	Off	On
	4	Dip Switch - 1	Off	On
	3	Not Used		
	2	Front Safety Sw – 5V	On	Off
	1	Front Safety Sw – 24V	Off	On
	0	Main Motor Ready Signal	Ready	Not ready
9	7	Not used		
	6	Relay Off Signal	Not detected	Detected
	5	Toner Bottle Motor Lock	Locked	Not locked
	4	Right Cover Open	Closed	Open
	3	Registration Sensor	Activated	Deactivated
	2	Exhaust Fan Lock	Not locked	Locked
	1	Interchange Cover Open	Closed	Open
	0	Paper Overflow Sensor	Activated	Deactivated
10	7	Not Used		
	8	Not Used		
	5	Not Used		
	4	Upper Relay Sensor	Activated	Deactivated
	3	1st Paper End	Paper End	Paper is present
	2	2nd Paper Lift Sensor	Activated	Deactivated
	1	1st Paper Lift Sensor	Activated	Deactivated
	0	Not Used		
11	7	2nd Paper Size 1	Activated	Deactivated
	6	2nd Paper Size 2	Activated	Deactivated
	5	2nd Paper Size 3	Activated	Deactivated
	4	2nd Paper Size 4	Activated	Deactivated
	3	1st Paper Size 1	Activated	Deactivated
	2	1st Paper Size 2	Activated	Deactivated
	1	1st Paper Size 3	Activated	Deactivated
	0	1st Paper Size 4	Activated	Deactivated

NOTE: Numbers 12 to 14 are not used for this machine.


ARDF Input Check (SP6007)

1. Enter the SP mode and select SP6007.
2. Enter the number (1 – 11) for the item that you want to check. A small box will be displayed on the SP mode screen with a series of 0's and 1's, as shown below. However, only bit 0 at the right side of the screen is valid.

0 0 0 0 0 0 0 0

Bit 7 6 5 4 3 2 1 0

3. Check the status of bit 0 for the required item listed in the table below.



Service Tables

No..	Description	Reading	
		0	1
1	Original set sensor	Paper not detected	Paper detected
2	Original width sensor 1 (W1)	Paper not detected	Paper detected
3	Original width sensor 2 (W2)	Paper not detected	Paper detected
4	Original length sensor 1 (L1)	Paper not detected	Paper detected
5	Original length sensor 2 (L2)	Paper not detected	Paper detected
6	Original trailing edge sensor	Paper not detected	Paper detected
7	ADF cover sensor	Cover closed	Cover opened
8	DF position sensor	ADF closed	ADF opened
9	Registration sensor	Paper not detected	Paper detected
10	Exit sensor	Paper not detected	Paper detected
11	Inverter sensor	Paper not detected	Paper detected

SERVICE PROGRAM MODE

Finisher Input Check (SP6117)

1. Enter the SP mode and select SP6117.
2. Enter the number (1 – 4) for the item that you want to check. A small box will be displayed on the SP mode screen with a series of 0's and 1's.
The meaning of the display is as follows.

0 0 0 0 0 0 0

Bit 7 6 5 4 3 2 1 0

3. Check the status of each item against the corresponding bit numbers listed in the table below.

For 1000-sheet Finisher

Number	Bit	Description	Reading	
			0	1
1	7	Stack Feed-out Belt HP Sensor	Activated	Deactivated
	6	Not Used		
	5	Jogger Fence HP Sensor	Activated	Deactivated
	4	Stapler HP Sensor	Activated	Deactivated
	3	Stapler Tray Entrance Sensor	Activated	Deactivated
	2	Not Used		
	1	Lower Tray Exit Sensor	Activated	Deactivated
	0	Entrance Sensor	Activated	Deactivated
2	7	Not Used		
	6	Not Used		
	5	Stapler Ready Signal	Activated	Deactivated
	4	Not Used		
	3	Not Used		
	2	Staple Sensor	Activated	Deactivated
	1	Staple Hammer HP Sensor	Activated	Deactivated
	0	Stapler Tray Paper Sensor	Activated	Deactivated
3	7	Not Used		
	6	Lower Tray Lower Limit Sensor	Activated	Deactivated
	5	Not used		
	4	Stack Height Sensor	Activated	Deactivated
	3	Not Used		
	2	Not Used		
	1	Shift HP Sensor	Activated	Deactivated
	0	Exit Guide HP Sensor	Activated	Deactivated

SERVICE PROGRAM MODE

Number	Bit	Description	Reading	
			0	1
3	7	Not Used		
	6	Not Used		
	5	Not Used		
	4	Not Used		
	3	Upper Tray Paper Limit Sensor	Activated	Deactivated
	2	Not Used		
	1	Not Used		
	0	Not Used		

For 500-sheet Finisher

Number	Bit	Description	Reading	
			0	1
1	7	Stack Near-limit Sensor	Activated	Deactivated
	6	Tray Upper Limit Sensor	Activated	Deactivated
	5	Lever Sensor	Activated	Deactivated
	4	Stack Height Sensor	Activated	Deactivated
	3	Top Cover Sensor	Closed	Opened
	2	Jogger HP Sensor	Activated	Deactivated
	1	Exit Sensor	Activated	Deactivated
	0	Entrance Sensor	Activated	Deactivated
2	7	Not Used		
	6	Not Used		
	5	Not Used		
	4	Staple Unit Lock	Locked	Not Locked
	3	Staple Cartridge Sensor	Activated	Deactivated
	2	Staple End Sensor	Activated	Deactivated
	1	Staple Hammer HP Sensor	Activated	Deactivated
	0	Staple Unit Cover Switch	Closed	Opened

Service
Tables

SERVICE PROGRAM MODE


4.2.5 OUTPUT CHECK

NOTE: Motors keep turning in this mode regardless of upper or lower limit sensor signals. To prevent mechanical or electrical damage, do not keep an electrical component on for a long time.

Main Machine Output Check (SP5804)

1. Open SP mode 5804.
2. Select the SP number that corresponds to the component you wish to check. (Refer to the table on the next page.)
3. Press On then press Off to test the selected item.

NOTE: You cannot exit and close this display until you press off to switch off the output check currently executing. Do not keep an electrical component switched on for a long time.



Output Check Table

NOTE: Pull out the tray before performing the output checks 25, 26, 29, and 30.

Number	On Screen	Service Manual Part Name
1	Main Motor (Fwd)	Main motor (forward)
2	Main Motor (Rev)	Main motor (Reverse) Do not use
3	Registration CL	Registration clutch
4	Development CL	Not used
5	Toner Bottle Motor	Toner supply motor
6	Exhaust Fan Motor (High Speed)	Exhaust fan (High Speed)
7	Exhaust Fan Motor (Low Speed)	Exhaust fan (Low Speed)
8	By-pass Feed CL	By-pass feed clutch
9	1st Paper Feed CL	Upper paper feed clutch
10	2nd Paper Feed CL	Lower paper feed clutch
11	1st Paper Tray Up	Upper paper lift motor (Up)
12	1st Paper Tray Down	Upper paper lift motor (Down)
13	2nd Paper Tray Up	Lower paper lift motor (Up)
14	2nd Paper Tray Down	Lower paper lift motor (Down)
15	Paper Transport CL	Upper relay clutch
16	Paper Transport CL2	Lower relay clutch
17	Fuser Drive Cancel SOL	Fusing drive release solenoid

Number	On Screen	Service Manual Part Name
21	Paper Transport CL3	Relay clutch (Optional paper tray unit)
22	3rd Paper Feed CL	Upper paper feed clutch (Optional paper tray unit)
23	4th Paper Feed CL	Lower paper feed clutch (Optional paper tray unit)
24	Paper Bank Motor	Tray motor (Optional paper tray unit)
25	3rd/LCT Tray Up	Upper Paper lift motor (Up) (Optional paper tray unit or LCT)
26	3rd/LCT Tray Down	Upper paper lift motor (Down) (Optional paper tray unit or LCT)
27	4th Tray Up	Lower paper lift motor (Up) (Optional paper tray unit)
28	4th Tray Down	Lower paper lift motor (Down) (Optional paper tray unit)
29	Tandem Rear Fence Drive Motor – Fwd	Rear fence motor (forward) (Optional LCT)
30	Tandem Rear Fence Drive Motor – Rev	Rear fence motor (reverse) (Optional LCT)
31	Tandem Fence SOL	Side fence solenoid (Optional LCT)
32	Exit Tray Shift Motor	Shift tray motor (Optional shift tray)
33	Exit Junction Gate SOL (Upper Unit)	Exit junction gate (Optional interchange unit)
34	Exit Junction Gate SOL (Lower Unit)	Duplex junction gate (Optional interchange unit)
41	Duplex Inverter Motor (Rev)	Duplex inverter motor (Reverse) (Optional duplex unit)
42	Duplex Inverter Motor (Fwd)	Duplex inverter motor (Forward) (Optional duplex unit)
43	Duplex Transport Motor	Duplex transport motor (Optional duplex unit)
44	Duplex SOL	Inverter gate solenoid (Optional duplex unit)
51	Relay Fan Motor	Bridge cooling fan motor (Optional bridge unit)
52	Relay Transport Motor	Bridge unit drive motor (Optional bridge unit)
53	Relay SOL	Junction gate solenoid (Optional bridge unit)
54	Total Counter	Total counter
60	Polygon Motor	Polygonal mirror motor
61	Polygon Motor/LD	Polygonal mirror motor and laser diode
62	LD ON	Laser diode - Do not use
81	Duplex Unit Free Run 1	Duplex unit free run (without paper)
82	Duplex Unit Free Run 2	Duplex unit free run (with paper)

SERVICE PROGRAM MODE

ARDF Output Check (SP6008)

1. Open SP mode SP6008.
2. Select the SP number that corresponds to the component you wish to check. (Refer to the table below.)
3. Press On then press Off to test the selected item. You cannot exit and close this display until you click Off to switch off the output check currently executing.

No.	Description
1	Feed Motor (Fwd)
2	Feed-in Motor (Rev)
3	Transport Motor (Fwd)
4	Feed Clutch
5	Pick-up Solenoid
6	Junction Gate Solenoid
7	Stamp Solenoid

Finisher Output Check (SP6118)

1. Open SP mode SP6118.
2. Select the SP number that corresponds to the component you wish to check. (Refer to the table below.)
3. Press On then press Off to test the selected item. You cannot exit and close this display until you click Off to switch off the output check currently executing.

No.	Description	
	1000-sheet finisher	500-sheet finisher
1	Upper Transport Motor	Main Motor
2	Shift Tray Lift Motor	Output Tray Motor
3	Staple Hammer Motor	Stapler Motor
4	Shift Motor	Jogger Motor
5	Lower Transport Motor	Not Used
6	Shift Tray Exit Motor	Not Used
7	Tray Junction Gate Solenoid	Not Used
8	Jogger Motor	Not Used
9	Stapler Motor	Not Used
10	Stapler Junction Gate Solenoid	Not Used
11	Positioning Roller Solenoid	Not Used
12	Stack Feed-out Motor	Not Used
13	Exit Guide Plate Motor	Not Used
14	Not Used	Paddle Roller Solenoid
15	Not Used	Exit Unit Gear Solenoid
16	Not Used	Stack Height Lever Solenoid
17		

4.2.6 SMC DATA LISTS (SP5990)

1. Open SP mode 5990 and select the number corresponding to the list that you wish to print.

SMC (System Parameter and Data Lists)	
1	All Data List
2	SP Mode Data List
3	UP Mode Data List
4	Logging Data List
5	Self-Diagnostics Results List
7	NIB Summary
8	Capture Log
21	Copy UP Mode List
22	Scanner SP Mode List
23	Scanner UP Mode List

2. Touch "Execute" on the touch panel
3. Select. "Single Face" or "Both Face" then touch "Execute" to start printing.
4. After printing the list, press Exit twice to close the SP Mode screen and return to copy mode.

4.2.7 MEMORY ALL CLEAR (SP5801)

Executing Memory All Clear resets all the settings stored in the NVRAM to their default settings except the following:

SP70021:	Electrical total counter value
SP58111:	Machine serial number
SP5907:	Plug & Play Brand Name and Production Name Setting

Normally, this SP mode should not be used. This procedure is necessary only after replacing the NVRAM, or when the copier malfunctions because the NVRAM is damaged.

Using a Flash Memory Card

1. Upload the NVRAM data to a flash memory card (☛ NVRAM Data Upload).
2. Print out all SMC data lists (SP mode 5990).
NOTE: Be sure to print out all the lists. If the NVRAM data upload was not completed, it is necessary to change the SP mode settings by hand.
3. Open SP mode 5801.

SERVICE PROGRAM MODE

- Press the number for the item that you want to initialize. The number you select determines which application is initialized. For example, press 1 if you want to initialize all modules, or select the appropriate number from the table below.

No.	What It Initializes	Comments
1	All modules	Initializes items 2 ~ 12 below.
2	Engine	Initializes all registration settings for the engine and process settings.
3	SCS (System Control Service)/SRAM	Initializes default system settings, CSS settings, operation display coordinates, and ROM update information.
5	MCS (Memory Control Service)	Initializes the automatic delete time setting for stored documents.
6	Copier application	Initializes all copier application settings.
7	Fax application	Initializes the fax reset time, job login ID, all TX/RX settings, local storage file numbers, and off-hook timer.
8	Printer application	Initializes the printer defaults, programs registered, the printer SP bit switches, and the printer CSS counter.
9	Scanner application	Initializes the scanner defaults for the scanner and all the scanner SP modes.
10	Network application	Deletes the network file application management files and thumbnails, and initializes the job login ID.
11	NCS (Network Control Service)	Initializes the system defaults and interface settings (IP addresses also), SmartNetMonitor for Admin, WebStatusMonitor settings, and the TELNET settings.
12	R-FAX	Initializes the job login ID, SmartNetMonitor for Admin, job history, and local storage file numbers.
14	Clear DCS Settings	Initializes: SP5845 (All), SP5860 (All), SP5861 (All), SP5863, registered scanner documents and subjects.
15	Clear UCS Settings	Initializes: SP5846 (All), SP5801 15

- Press Execute and turn the main switch off and back on.
- Download the NVRAM data from a flash memory card (☛ NVRAM Data Download).

Without Using a Flash Memory Card

If there is no flash memory card, follow the steps below.


1. Execute SP5990 to print out all SMC Data Lists.
2. Open SP mode 5801.
3. Press the number for the item that you want to initialize.
4. Press Execute and turn the main switch off and back on.
5. Make sure that you do the following:
 - Do the printer and scanner registration and magnification adjustments (☛ 3 Replacement and Adjustment, “Copy Adjustments”).
 - Do the touch screen calibration (☛ 3 Replacement and Adjustment, “touch screen calibration”).
 - Referring to the SMC data lists, re-enter any values, which had been changed from their factory settings.
 - Do SP 20012 (ID Sensor Initial Setting) and SP49111 (HDD media check).
 - Do the white level adjustment (☛ Section 6.8.2 Standard White Density Adjustment)
6. Check the copy quality and the paper path, and do any necessary adjustments.

4.2.8 UPLOADING/DOWNLOADING NVRAM DATA

The content of the NVRAM can be uploaded to and downloaded from a flash memory card.

Uploading NVRAM Data (SP5824)

The contents of the NVRAM in the machine can be uploaded to a flash memory card.




1. Turn off the main switch.
2. Remove the application cover [A].
3. Plug the flash memory card [B] into the card slot.
4. Turn on the main switch.
5. Open SP5824.
6. Touch “Execute” to start uploading the NVRAM data.
7. Turn off the main switch, then remove the IC card.

Downloading NVRAM Data (SP5825)

This downloads data from a flash card to the NVRAM inside the machine.

The following data are not downloaded from the flash card:

- Total count categories (SP7002*** Copy Counter)
- C/O, P/O Counter (SP7006*** C/O, P/O Count Display)
- Duplex, A3/DLT/Over 420 mm, Staple and Scanner application scanning counters (system settings).



1. Turn off the main switch.
2. Remove the application cover [A].
3. Plug the flash memory card [B] into the card slot.
4. Turn on the main switch.
8. Open SP5825.
5. Touch “Execute” to start download the NVRAM data.
6. Turn off the main switch, then remove the IC card.

Note that the following errors could occur during downloading:

- If a card is not installed in the card slot and a message tells you that downloading cannot proceed, you cannot execute downloading, even by pressing “Execute”
- If the correct card for the NVRAM data is not inserted in the card slot, after you press “Execute” a message will tell you that downloading cannot proceed because the card is abnormal and the execution will halt.


4.2.9 APS OUTPUT DISPLAY (SP4301)

When open this SP, a small box will be displayed on the SP mode screen with a series of 0's and 1's. The meaning of the display is as follows.

0 0 0 0 0 0 0 0

Bit 7 6 5 4 3 2 1 0

1 = Paper detected



Bit	Description
7	L1
6	L2
5	L3
4	L4
3	W2
2	W1
1	Not Used
0	Not Used

4.2.10 DF APS SENSOR OUTPUT DISPLAY (SP6901)


When open this SP, a small box will be displayed on the SP mode screen with a series of 0's and 1's. The meaning of the display is as follows.

0 0 0 0 0 0 0 0

Bit 7 6 5 4 3 2 1 0

1 = Paper detected

illustration to be changed




	Large	\longleftrightarrow		Small
W1	0	0	1	1
W2	0	1	0	1

Bit	Description
7	Not Used
6	Not Used
5	W1
4	W2
3	L1
2	L2
1	L3
0	Not Used

Service Tables

4.2.11 NIP BAND WIDTH MEASUREMENT (SP1109)



When paper wrinkling or image off-set occurs, the pressure from the pressure roller can be adjusted by changing the position of the pressure springs. At this time, the nip band width can also be checked with SP1109, as follows.


1. Do a free run (SP5802) for about 50 sheets.
2. Access SP1109 and press the “1” key.
3. Press Copy Window to return to the copy window.
4. Place an OHP sheet (A4/8.5”x11” sideways) on the by-pass tray or in the 2nd paper tray.
5. Press the “Start” key.
The OHP sheet is stopped in the fusing unit for about 20 seconds, then it will be fed automatically.
6. Check the nip band width [A]. The relationship between the position of the pressure spring and the band width is as follows.

NOTE: Check the nip band width around the center of the OHP.

1. Pressure spring position	Nip band width
Upper (default position)	5.2 ± 0.5 mm
Lower	5.3 ± 0.5 mm
2. Envelope feed mode (green lever down) at the default pressure spring position	4.7 ± 0.5 mm

If the width is out of the above specification, the pressure spring should be replaced.

4.3 PROGRAM DOWNLOAD



1. Turn off the main power switch.
2. Remove the application cover [A].
3. Insert the IC card [B] containing the software you wish to download into the card slot of the controller.
4. Turn on the main power.
5. Follow the instructions displayed on the LCD panel
6. Monitor the downloading status on the operation panel.
 - While downloading is in progress, the LCD will display “Writing”. When downloading has been completed, the panel will display “OK”.
 - For operation panel software, the Start key lights red while downloading is in progress, and then lights green again after downloading is completed.

CAUTION

Never switch off the power while downloading. Switching off the power while the new software is being downloading will damage the boot files in the controller.

7. After confirming that downloading is completed, turn off the main power and remove the IC card.
8. If more software needs to be downloaded, repeat steps 1 to 7.
9. Turn the main power on and confirm that the new software loads and that the machine starts normally.

NOTE: If the download failed, an error message will appear on the panel. Then, download the firmware again using the IC card as usual.



SOFTWARE RESET

4.4 SOFTWARE RESET

The software can be rebooted when the machine hangs up. Use the following procedure.

Turn the main power switch off and on.

-or-

Press and hold down   together for over 10 seconds. When the machine beeps once release both buttons. After “Now loading. Please wait” is displayed for a few seconds the copy window will open. The machine is ready for normal operation.


4.5 SYSTEM SETTINGS AND COPY SETTING RESET

4.5.1 SYSTEM SETTING RESET

The system settings in the UP mode can be reset to their defaults. Use the following procedure.

1. Press User Tools/Counter.
2. Hold down **#** and then press System Settings.

NOTE: You must press **#** first.




3. When the message prompts you to confirm that you want to reset the system settings, press Yes.
4. When the message tells you that the settings have been reset, press Exit.

4.5.2 COPIER SETTING RESET

The copy settings in the UP mode can be reset to their defaults. Use the following procedure.

1. Press User Tools/Counter.
2. Hold down **#** and then press Copier/Document Server Settings.
NOTE: You must press **#** first.



3. When the message prompts you to confirm that you want to reset the Copier Document Server settings, press Yes.
4. When the message tells you that the settings have been reset, press Exit.


4.6 USER TOOLS

The user program (UP) mode can be accessed by users and operators, and by sales and service staff. UP mode is used to input the copier's default settings. The user can reset the default settings at any time. (☛ 4.5)

4.6.1 HOW TO USE UP MODE

UP Mode Initial Screen: User Tools/Counter Display


To enter the UP mode, press User Tools/Counter.



System Settings

In the User Tools/Counter display, press System Settings.

Click a tab to display the settings. If the Next button is lit in the lower right corner, press it to display more options. Perform the settings, press Exit to return to the User Tools/Counter display, and then press Exit to return to the copy window.



B089S915.WMF

Copier/Document Server Features

In the User/Tools Counter display, press Copy/Document Server Settings.

Click a tab to display the settings. If the Next button is lit in the lower right corner, press it to display more options. Perform the settings, press Exit to return to the User Tools/Counter display, and then press Exit to return to the copy window.

Service Tables

USER TOOLS

Printer, Facsimile, Scanner Settings

In the User/Tools Counter display, press Printer Settings, Facsimile, or Scanner Settings to open the appropriate screen and then click the tab to display more settings. The screen below shows the Printer Features screen.

Copier/Document Server Features		Exit
Select items to set.		
General Features	Reproduction Ratio	Edit
Stamp	Input/Output	
Auto Paper Select Priority	ON	Auto Image Density Priority
Auto Tray Switching	With image rotation	Copy Quality
Paper Display	Display	Image Density
Original Type Priority	Text	
Original Type Display	Display	
1/4		Previous Next

Inquiry

In the User/Tools Counter display, press Inquiry.


The following SP mode settings will be displayed.

- Service Telephone Number (SP58121)
- Sales Telephone Number (SP8124)
- Consumable Telephone Number (SP8123)
- Toner Name (SP-841)

Inquiry		Exit
Consumables		
Telephone No. to order	012345678	
Machine Maintenance/Repair		
Telephone No.	12345678	
Serial No. of Machine	00000010156	
Sales Representative		
Telephone No.	01234568	
Print Inquiry List		

Counter

In the User/Tools Counter display, press Counter.



The screenshot shows a terminal window titled "Counter" with a timestamp "AUG 9, 2001 2:28PM" in the top right corner. The window contains the following data:

Category	Count
Total	9998160
Copier	9998021
Printer	9998139
A3/DLT	9998000

Buttons for "Exit" and "Print Counter List" are visible in the interface.

The following SP mode counters will be displayed.

- Copy Counter (SP59142)
- A3/DLT Counter (SP5918)
- Printer Counter (SP59141)

View the settings, press Print Counter Exit to return to the User Tools/Counter display, and then press Exit to return to the copy window.

LEDS

4.7 LEDS

Controller

Number	Normal	Controller Software Download	Error
LED 1	Off	Blinking	Off
LED 2	Blinking	Blinking	Lit or Off
LED 3 (+5V line)	Lit	Lit	Lit

SBCU

Number	Normal	SBCU Software Download	Error
LED 1	Lit	Lit	Off or Blinking
LED 2	Blinking	Lit	Lit (except downloading) or Off

IPU

Number	Normal	Error
LED 1	Lit	Off or Blinking

4.8 DIP SWITCHES

Controller: DIP SW2

DIP SW No.	ON	OFF
1	IC Card Boot	System ROM Boot
2	Keep at "OFF"	
3		
4		

SBCU: DIP SW102

DIP SW No.	DESTINATION					
	JPN	NA	EU	CHINA	TAIWAN	KOREA
1	OFF	ON	OFF	OFF	ON	OFF
2	OFF	OFF	ON	OFF	OFF	ON
3	OFF	OFF	OFF	ON	ON	ON
4	Not used. Do not change.					

4.9 SPECIAL TOOLS AND LUBRICANTS

4.9.1 SPECIAL TOOLS

Part Number	Description	Q'ty
A2929500	S5S Test Chart (10 pcs/set)	1
A0069104	Scanner Positioning Pin (4 pcs/set)	1
A0299387	Digital Multimeter - FLUKE 87	1
A2309351	Case - Flash Memory Card	1
N8036701	Flash Memory Card - 4MB	1
B0229590	NVRAM – Zero Counter	1
A2309003	Adjustment Cam – Laser Unit	1
A2679002	Positioning Pin - Laser Unit	1

4.9.2 LUBRICANTS

Part Number	Description	Q'ty
A0289300	Grease Barrierta - JFE 5 5/2	1
52039501	Silicone Grease G-501	1

4.10 USING THE DEBUG LOG

This machine provides a Save Debug Log feature that allows the Customer Engineer to save and retrieve error information for analysis.

Every time an error occurs, debug information is recorded in volatile memory but this information is lost when the machine is switched off and on.



The Save Debug Log feature provides two main features:


- Switching on the debug feature so error information is saved directly to the HDD for later retrieval.
- Copying the error information from the HDD to an IC card.

When a user is experiencing problems with the machine, follow the procedure below to set up the machine so the error information is saved automatically to the HDD.

4.10.1 SWITCHING ON AND SETTING UP SAVE DEBUG LOG

The debug information cannot be saved until the “Save Debug Log” function has been switched on and a target has been selected.

1. Enter the SP mode.
 - Press  (Clear Modes) then use the 10-key pad to enter ①①⑦.
 - Press and hold down  (Clear/Stop) for more than 3 seconds.
 - Press “Copy SP” on the touch-panel.
 - Enter ⑤⑧⑤⑦ then press #.
2. Under “5857 Save Debug Log”, press ①.



3. On the control panel keypad, press “1” then press #. This switches the Save Debug Log feature on.

NOTE: The default setting is “0” (OFF). This feature must be switched on in order for the debug information to be saved.

- Next, select the target destination where the debug information will be saved. Under “5857 Save Debug Log”, touch “2 Target”, enter “2” with the operation panel key to select the hard disk as the target destination, then press $\#$.

```

COPY:  SP-5-857-002
Save Debug Log
Target (2:HDD 3:IC Card)

  2

Initial 2
    
```

NOTE: Select “3 IC Card” to save the debug information directly to the IC card if it is inserted in the service slot.

- Now touch “5858” and specify the events that you want to record in the debug log. SP5858 (Debug Save When) provides the following items for selection.

1	Engine SC Error	Saves data when an engine-related SC code is generated.
2	Controller SC Error	Saves debug data when a controller-related SC Code is generated.
3	Any SC Error	Saves data only for the SC code that you specify by entering code number.
4	Jam	Saves data for jams.

NOTE: More than one event can be selected.

Example 1: To Select Items 1, 2, 4

Touch the appropriate item(s). Press “ON” for each selection. This example shows “Engine SC Error” selected.

```

COPY:  SP-5-858-001
Debug Save When
Engine SC Error

  OFF  ON
    
```

Example 2: To Specify an SC Code

Touch “3 Any SC Error”, enter the 3-digit SC code number with the control panel number keys, then press $\#$. This example shows an entry for SC670.

```

COPY:  SP-5-858-001
Debug Save When
Any SC Error

  670
    
```

NOTE: For details about SC code numbers, please refer to the SC tables in Section “4. Troubleshooting”.

Service Tables

USING THE DEBUG LOG

- Next, select the one or more memory modules for reading and recording debug information. Touch “5859”.

Under “5859” press the appropriate key item for the module that you want to record.

Enter the appropriate 4-digit number, then press (#).

NOTE: Refer to the two tables below for the 4-digit numbers to enter for each key.

The example below shows “Key 1” with “2222” entered.

COPY: SP-5-859-001 Debug Save Key No. Key 1 <div style="text-align: right; margin-right: 50px;"> <input style="width: 60px; height: 20px;" type="text" value="2222"/> </div>

The following keys can be set with the corresponding numbers. (The initials in parentheses indicate the names of the modules.)

4-Digit Entries for Keys 1 to 10

Key No.	Copy	Printer	Scanner	Web
1	2222 (SCS)			
2	2223 (SRM)			
3	256 (IMH)			
4	1000 (ECS)			
5	1025 (MCS)			
6	4848 (COPY)	4400 (GPS)	5375 (Scan)	5682 (NFA)
7	2224 (BCU)	4500 (PDL)	5682 (NFA)	6600 (WebDB)
8		4600 (GPS-PM)	3000 (NCS)	3300 (PTS)
9		2000 (NCS)	2000 (NCS)	6666 (WebSys)
10		2224 (BCU)		2000 (NCS)

NOTE: The default settings for Keys 1 to 10 are all zero (“0”).

Key to Acronyms

Acronym	Meaning	Acronym	Meaning
ECS	Engine Control Service	NFA	Net File Application
GPS	RA2K Print Service	PDL	Printer Design Language
GSP-PM	RA2K Print Service – Print Module	PTS	Print Server
IMH	Image Memory Handler	SCS	System Control Service
MCS	Memory Control Service	SRM	System Resource Management
NCS	Network Control Service	WebDB	Web Document Box (Document Server)

The machine is now set to record the debugging information automatically on the HDD (the target selected with SP5-857-002) for the events that you selected SP5-858 and the memory modules selected with SP5-859.

Please keep the following important points in mind when you are doing this setting:

- Note that the number entries for Keys 1 to 5 are the same for the Copy, Printer, Scanner, and Web memory modules.
- The initial settings are all zero.
- These settings remain in effect until you change them. Be sure to check all the settings, especially the settings for Keys 6 to 10. To switch off a key setting, enter a zero for that key.
- You can select any number of keys from 1 to 10 (or all) by entering the corresponding 4-digit numbers from the table.
- You cannot mix settings for the groups (COPY, PRINTER, etc.) for 006~010. For example, if you want to create a PRINTER debug log you must select the settings from the 9 available selections for the "PRINTER" column only.
- One area of the disk is reserved to store the debug log. The size of this area is limited to 4 MB.



4.10.2 RETRIEVING THE DEBUG LOG FROM THE HDD

1. Insert the IC card into the copier.
2. Enter the SP mode and execute SP5857 007 (Copy HDD to IC Card (Latest 4 MB) to write the debugging data to the IC card.
NOTE: The IC card can hold up to 4MB of data. If the debugging data is larger than 4MB, you can switch to another IC card.
3. After you return to the service center, use a card reader to copy the file and send it for analysis to Ricoh by email, or just send the IC card by mail.

4.10.3 RECORDING ERRORS MANUALLY

Since only SC errors and jams are recorded to the debug log automatically, for any other errors that occur while the customer engineer is not on site, please instruct customers to perform the following immediately after occurrence to save the debug data. Such problems would include a controller or panel freeze.

NOTE: In order to use this feature, the customer engineer must have previously switched on the Save Debug Feature (SP5857-001) and selected the hard disk as the save destination (SP5857-002).

1. When the error occurs, on the operation panel, press  (Clear Modes).
2. On the control panel, enter "01" then hold down  for at least 3 sec. until the machine beeps then release. This saves the debug log to the hard disk for later retrieval with an IC card by the service representatives.
3. Switch the machine off and on to resume operation.

The debug information for the error is saved on the hard disk so the service representatives can retrieve it on their next visit by copying it from the HDD to an IC card.

PREVENTIVE MAINTENANCE

5. PREVENTIVE MAINTENANCE SCHEDULE

5.1 PM TABLE

- NOTE:** 1) The amounts mentioned as the PM interval indicate the number of prints.
2) After carrying out PM, clear the maintenance counter (SP7804).

Symbol key: C: Clean, R: Replace, L: Lubricate, I: Inspect

	EM	120K	240K	360K	NOTE
SCANNER/LASER OPTICS					
Reflector		C	C	C	Optics cloth
1st Mirror	C	C	C	C	Optics cloth
2nd Mirror	C	C	C	C	Optics cloth
3rd Mirror	C	C	C	C	Optics cloth
Scanner Guide Rails		C	C	C	Do not use alcohol.
Platen Sheet Cover	C	I	I	I	Replace the platen sheet, if necessary. Dry cloth or alcohol
Exposure Glass		C	C	C	Dry cloth or alcohol
Toner Shield Glass		C	C	C	Optics cloth
APS Sensor		C	C	C	Dry cloth or blower brush
AROUND THE DRUM					
Transfer/Separation Unit		R	R	R	
ID Sensor		C	C	C	Perform the ID sensor initial setting (SP2-935) after cleaning (blower brush)
PAPER FEED					
Registration Rollers	C	C	C	C	Clean with water
Paper Feed Roller	C	R	R	R	Clean with water
Friction Pad	C	R	R	R	Dry cloth
Paper Feed Guides	C	C	C	C	Clean with alcohol.
Relay Rollers	C	C	C	C	Clean with water.
Bottom Plate Pad	C	C	C	C	Clean with water.
Registration Roller Mylar	C	C	C	C	Clean with water.
FUSING UNIT AND PAPER EXIT					
Fusing Entrance and Exit Guide Plates		C	C	C	Clean with water or alcohol.
Hot Roller		R	R	R	
Pressure Roller		R	R	R	
Fusing Thermistors		R	R	R	

PM TABLE

	EM	120K	240K	360K	NOTE
Cleaning Roller		C	C	C	Clean with water or alcohol.
Cleaning Roller Bushings		C	C	C	Clean with water or alcohol.
Hot Roller Strippers		R	R	R	
Hot Roller and Pressure Roller Bushings	L	L	L	L	Grease Barrierta JFE5 5/2 (A0289300)
Paper Exit Guide Ribs		C	C	C	Clean with water or alcohol.
OTHERS					
Main Motor Drive Gear	L	I	I	I	Silicone Grease G501 (see note 1)

	EM	120K	240K	360K	NOTE
ADF (for originals)					
Pick-up Roller	C	R	R	R	Clean with water
Feed Belt	C	R	R	R	Clean with water
Separation Roller	C	R	R	R	Clean with water
Stamp		I	I	I	Replace if necessary
ADF Exposure Glass	C	C	C	C	Clean with alcohol
White Plate	C	C	C	C	Clean with alcohol
Platen Sheet	C	C	C	C	Clean with alcohol

	EM	120K	240K	360K	NOTE
PAPER TRAY UNIT					
Paper Feed Roller	C	R	R	R	Clean with water
Friction Pad	C	R	R	R	Dry cloth
Paper Feed Guides	C	C	C	C	Clean with alcohol.
Relay Rollers	C	C	C	C	Clean with water.
Bottom Plate Pad	C	C	C	C	Clean with water.
Relay Clutch		I	I	I	Replace if necessary
Paper Feed Clutch		I	I	I	Replace if necessary


	EM	120K	240K	360K	NOTE
LCT					
Paper Feed Roller		R	R	R	
Pick-up Roller		R	R	R	
Separation Roller		R	R	R	
Transport Rollers		C	C	C	Clean with water
Bottom Plate Pad		C	C	C	Clean with water
Relay Clutch		I	I	I	Replace if necessary
Paper Feed Clutch		I	I	I	Replace if necessary

	EM	120K	240K	360K	NOTE
1,000-SHEET FINISHER					
Rollers	C				Clean with water or alcohol.
Brush Roller	I	I	I	I	Replace if necessary.
Discharge Brush	C	C	C	C	Clean with a dry cloth
Sensors	C				Blower brush
Jogger Fences	I	I	I	I	Replace if necessary.

	EM	150K	300K	450K	NOTE
1-BIN TRAY UNIT					
Rollers	C				Dry or damp cloth
Copy Tray	C				Dry or damp cloth
Sensors	C				Blower brush

NOTE 1.

Main Motor Drive Gear



Do the following every EM:

Lubricate the main motor drive gear [A] with silicone grease G501.

REPLACEMENT AND ADJUSTMENT


6. REPLACEMENT AND ADJUSTMENT

⚠ CAUTION

Turn off the main power switch and unplug the machine before attempting any of the procedures in this section.

6.1 SCANNER UNIT


6.1.1 EXPOSURE GLASS



1. Open the ADF or platen cover.
2. Remove the left scale [A] (2 screws).
3. Remove the rear scale [B] (3 screws).
4. Remove the exposure glass [C].


NOTE: When reinstalling the exposure glass, make sure that the mark [D] is positioned at the rear left corner, as shown.

6.1.2 SCANNER EXTERIOR/OPERATION PANEL




1. Remove the ADF or platen cover.
2. Remove the exposure glass. (☛ 6.1.1)
3. Remove the upper front cover [A] (1 screw, 1 hook).
4. Remove the operation panel [B] (5 screws, 1 connector).
5. Remove the right cover [C] (1 screw, 2 hooks).
6. Remove the rear cover [D] (2 screws).
7. Remove the left cover [E] (2 screws, 2 hooks).

6.1.3 LENS BLOCK ASSEMBLY




1. Remove the exposure glass. (☛ 6.1.2)
2. Remove the lens cover [A] (4 screws).
3. Replace the lens block assembly [B] (4 screws, 1 connector, 2 clamps).
NOTE: Do not remove the screws which are locked with white paint.
4. Reassemble the machine and do the scanner and printer copy adjustments. (☛ 6.8)

6.1.4 ORIGINAL SIZE SENSORS



1. Remove the exposure glass. (☛ 6.1.1)
2. Remove the lens cover. (☛ 6.1.3)
3. Remove the original width sensor [A] (1 screw, 1 connector).
4. Remove the lens block. (☛ 6.1.3)
5. Remove the original length sensors [B] (1 screw, 1 connector each).


6.1.5 EXPOSURE LAMP



1. Remove the exposure glass. (☛ 6.1.1)
2. Remove the operation panel, rear cover, and left cover. (☛ 6.1.2)
3. Remove the connector cover [A], disconnect the cable, and remove the rear cover [B] (4 screws).
4. Remove the left upper stay [C] (1 screw).
5. Remove the front frame [D] (5 screws).
6. Remove the rear bracket [E] (5 screws, 2 connectors).
7. Remove the rear frame [F] (2 screws, 1 connector).
8. Push down the part [G] then slide out the exposure lamp [H] (1 connector).


NOTE: 1) Do not touch the glass surface of the exposure lamp with bare hands.
 2) After installing the lamp, the part [G] must be returned to the original position.

6.1.6 SCANNER MOTOR/LAMP STABILIZER




1. Remove the connector cover [A], disconnect the cable, and remove the rear cover [B].
2. Replace the scanner motor [C] (3 screws, 1 spring, 1 connector).
3. Replace the lamp stabilizer [D] (2 connectors).
4. Reassemble the machine and do the scanner and printer copy adjustments. (☛ 6.8)

6.1.7 SCANNER WIRES




1. Remove the exposure glass, operation panel, and all scanner exterior covers. (☛ 6.1.1 and 6.1.2)
2. Remove the left upper stay. (☛ 6.1.5)
3. Remove the front frame. (☛ 6.1.5)
4. Remove the rear bracket. (☛ 6.1.5)
5. Remove the rear frame. (☛ 6.1.5)
6. Remove the lens cover. (☛ 6.1.3)
7. Remove the lens block assembly. (☛ 6.1.3)
8. Remove the front and rear scanner wire pins [A]. Then, remove the 1st scanner.

SCANNER UNIT



9. Remove the tension spring [B].
10. Loosen the screw [C] securing the wire tension bracket [D].
11. Remove the scanner drive pulley [E] (1 set screw).
12. Remove the scanner wire [F].
13. Wrap the new scanner wire around the pulley as shown ①, then temporarily secure the pulley with tape.
14. Re-install the 1st scanner. Then secure the 1st and 2nd scanner with the scanner positioning tools (P/N A0069104), as shown in the illustration on the next page.
15. Wind the new scanner wire around the scanner drive pulley in the correct way, as shown.
16. Wind the end of the new wire with the ball as shown (②).
17. Wind the end of the new wire with the ring as shown (③,④, and ⑤).
18. Install the tension spring on the wire tension bracket (⑤).
19. Wind the new scanner wire for the other side as well.



20. Secure the 1st scanner with the scanner wire pins.
21. Install the tension spring [A] to the tension bracket.
22. Tighten the tension bracket [B].
23. Secure the scanner wire pulley [C] (1 Allen screw).
24. Remove the positioning tools [D]. After sliding the scanner to the right and left several times, re-install the positioning tools to check the scanner wire bracket and tension bracket again.
25. Reassemble the scanner and do the scanner and printer copy adjustments (☛ 6.8).


6.2 LASER UNIT

WARNING


Turn off the main power switch and unplug the machine before attempting any of the procedures in this section. Laser beams can seriously damage your eyes.

6.2.1 CAUTION DECAL LOCATIONS

Two caution decals are located in the laser section as shown below.



6.2.2 LASER UNIT




⚠ WARNING

Turn off the main power switch and unplug the machine before attempting this procedure. Laser beam can seriously damage your eyes.

1. Remove the optional finisher/bridge unit, and either the tray for the optional 1-bin tray unit or optional shift tray, if these units have been installed.
2. Remove the upper front cover [A] (1 screw, 1 hook).
3. Remove the front cover [B] (2 pins).
4. Remove the inner cover [C] (5 screws).
5. Remove the copy tray [D] (1 hook [E]).
6. Remove the toner bottle holder [F].
7. Remove the laser unit [G] (2 screws, 2 connectors).
8. After reassembling the machine, do the scanner and printer copy adjustments. (➡ 6.8)

LASER UNIT


6.2.3 POLYGON MIRROR MOTOR



1. Remove the laser unit (☛ 6.2.2).
2. Remove the heat sink [A] (4 screws).
3. Replace the polygon mirror motor [B] (4 screws, 1 connector).

NOTE: When installing the new polygon mirror motor, do not touch the surface of the mirror with bare hands.


6.2.4 LD UNIT



1. Remove the laser unit (☛ 6.2.2).
2. Replace the LD unit [A] (3 screws, 1 connector).

NOTE: 1) Do not remove the screws [B].
2) Do not touch any variable resistors on the LD unit.

6.2.5 LASER SYNCHRONIZATION DETECTOR




1. Remove the laser unit (☛ 6.2.2).
2. Remove the heat sink [A] (4 screws).
3. Remove the laser unit cover [B] (3 screws).
4. Remove the bracket [C] (1 screw).
5. Replace the laser synchronization detector [D] (1 connector).

PHOTOCONDUCTOR UNIT (PCU)

6.3 PHOTOCONDUCTOR UNIT (PCU)

6.3.1 PCU




1. Open the right cover [A] and front cover [B].
2. Pull the PCU [C] out slightly while pushing the release lever [D].

NOTE: Do not touch the drum surface with bare hands.


6.4 TRANSFER UNIT

6.4.1 TRANSFER ROLLER UNIT



1. Open the right cover [A].
2. Remove the transfer roller unit [B] (1 hook).
NOTE: Do not touch the transfer roller surface.

6.4.2 IMAGE DENSITY SENSOR




1. Open the right cover [A].
2. Remove the unit band [B].
3. Remove the right cover [A] (1 connector),
4. Remove the sub right cover [C] (2 hooks).
5. Replace the image density sensor [D] (1 connector).
6. Initialize the new sensor with SP 2-935.

6.5 FUSING/EXIT

6.5.1 FUSING UNIT


CAUTION

Allow time for the unit to cool before doing the following procedure.




1. Release the duplex unit, if it has been installed, and open the right cover.
2. Remove the fusing unit [A] (2 screws).

6.5.2 THERMISTORS




1. Remove the fusing unit. (☛ 6.5.1).
2. Remove the plates [A] (1 screw each).
3. Replace the thermistors [B] (1 connector).

6.5.3 THERMOFUSE




1. Remove the fusing unit. (☛ 6.5.1)
2. Remove the fusing upper cover [A] (4 screws).
3. Remove the pressure springs [B].
4. Remove the hot roller stripper bracket [C] (3 screws).



5. Remove the thermostat cover [A] (2 tapping screws).
6. Remove the plate [B] (2 screws with spring washer).
7. Remove the thermostat holder [C] (3 screws each).
8. Replace the thermostats [D].


6.5.4 HOT ROLLER AND FUSING LAMP



1. Remove the fusing unit. (☛ 6.5.1)
2. Remove the fusing upper cover. (☛ Thermostat.)
3. Remove the pressure springs. (☛ Thermostat.)
4. Remove the hot roller stripper bracket. (☛ Thermostat.)
5. Remove the fusing lamps (4 screws) and hot roller assembly [A].
NOTE: Do not touch the surface of the fusing lamp with bare hands.
6. Replace the hot roller [B] (2 C-rings, 1 gear, 2 bushings).

- NOTE:**
- 1) Apply grease (Barrierta) to the inner surface of the bushing.
 - 2) Before installing the new hot roller, peel off 3 cm (1 inch) from both ends of the protective sheet on the new roller. After installation, remove the protective sheet.
 - 3) Do not touch the surface of the rollers.
 - 4) When reinstalling the fusing lamp, secure the front screws first.
 - 5) Be careful not to damage the surface of the hot roller.


6.5.5 PRESSURE ROLLER/CLEANING ROLLER



1. Remove the fusing lamp and hot roller assembly. (☛ 6.5.4)
2. Replace the pressure roller [A] (1 E-ring, 2 bushings, 1 spring).
3. Replace the cleaning roller [B].

NOTE: 1) Apply grease (Barrierta) to the inner surface of the bushing for the pressure roller.
2) Do not touch the surface of the rollers.


6.5.6 PAPER EXIT SENSOR/PAPER OVERFLOW SENSOR



1. Remove the front upper cover [A] (1 screw, 1 peg).
2. Remove the exit cover [B].
NOTE: If the optional 1 bin tray unit and/or interchange unit have been installed, remove them.
3. Replace the exit sensor [C] (1 connector).
4. Replace the overflow sensor [D] (1 connector).

6.6 PAPER FEED

6.6.1 FEED ROLLERS: TRAY 1




1. Remove the paper tray [A].
2. Pull the lever [B].
3. Replace the feed roller [C].

NOTE: Do not touch the roller surface with bare hands.
After reinstalling the feed roller, return the lever [B].


PAPER FEED

6.6.2 FEED ROLLER: TRAY 2




1. Remove the first paper tray.
 2. Remove the second paper tray [A].
 3. Raise the white Teflon lever [B] to release the roller.
 4. Replace the feed roller [C].
- NOTE:** Do not touch the roller surface with bare hands.
After reinstalling the feed roller, reset the lever [B].

6.6.3 PAPER END SENSOR




1. Remove the paper tray [A].
2. Remove the paper end sensor assembly (1 screw, 1 connector).
3. Replace the paper end sensor [B].

6.6.4 PAPER TRAY LIFT MOTORS




1. Remove the paper tray.
2. Remove the connector cover [A] (1 screw) and disconnect the cable.
3. Remove the rear cover [B] (4 screws).
4. Remove the duplex connector cover [C] (1 screw).
5. Remove the lower rear cover [D] (2 screws).
6. Replace the paper lift motors [E] (2 screws each, 1 connector each).

6.6.5 REGISTRATION CLUTCH



1. Remove the connector cover and the rear cover. (☛ 6.6.3)
2. Remove the duplex connector cover and lower rear cover. (☛ 6.6.3)
3. Remove the fly wheels [A] (1 screw).
4. Remove the registration clutch [B] (1 E-ring, 1 connector).

6.6.6 PAPER FEED CLUTCHES




Lower Paper Feed Clutch

1. Remove the rear cover. (☛ B022 service manual, 6.6.3)
2. Remove the lower rear cover. (☛ B022 service manual, 6.6.3)
3. Replace the lower paper feed clutch [A] (☛ x 1, ☛ x 1).

Upper Paper Feed Clutch.



4. Disconnect the connectors [B] for the SBCU board as shown (14 connectors).
5. Remove 4 screws [C] securing the SBCU board bracket then swing down the I/O board bracket [D].
6. Remove the bracket [E] (1 screw).
7. Replace the upper paper feed clutch [F] (☛ x 1, ☛ x 1).

6.6.7 RELAY CLUTCHES




1. Remove the optional duplex unit and/or by-pass tray unit if they have been installed.
2. Remove the rear cover and lower rear cover. (☛ B022 service manual, 6.6.3)
3. Remove the lower right cover [A] (2 screws).
4. Remove the scanner right cover. (☛ B022 service manual, 6.1.2)
5. Remove the right cover [B] (4 screws).
6. Swing down the I/O board bracket. (☛ B022 service manual, 6.6.5)
7. Remove the connector bracket [C] (☛ x 2).
8. Replace the upper relay clutch [D] (☛ x 1, ☛ x 1).
9. Remove the right rear cover [E] (1 screw).
10. Replace the lower relay clutch [F] (☛ x 1, ☛ x 1).

6.6.8 PAPER SIZE DETECTOR




1. Remove the right lower cover [A]. (☛ 6.6.6)
2. Remove the paper trays.
3. Remove the paper size detector assembly (1 screw each).
4. Replace the paper size detectors [B] (1 connector each).

6.6.9 REGISTRATION SENSOR



1. Remove the right cover. (☛ 6.4.2)
2. Remove the registration guide plate [A] (2 screws).
3. Remove the paper support roller [B] (2 snap rings, 2 bushings).
4. Remove the sensor bracket [C] (1 screw).
5. Replace the registration sensor [D] (1 connector).

6.6.10 RELAY SENSORS



Upper Relay Sensor


1. Remove the right cover. (☛ 6.4.2)
2. Remove the lower right cover. (☛ 6.6.6)
3. Remove the guide plate [A].
4. Remove the bracket [B] (1 screw).
5. Remove the guide plate [C] (2 screws).
6. Remove the sensor bracket [D] (1 screw).
7. Replace the upper relay sensor [E] (1 connector).

Lower Relay Sensor

1. Remove the right lower door [F] (1 clip).
2. Remove the guide plate [G].
3. Remove the guide plate [H] (2 screws).
4. Remove the sensor bracket [I] (1 screw).
5. Replace the lower relay sensor [J] (1 connector).


6.7 PCBS AND OTHER ITEMS

6.7.1 CONTROLLER BOARD




1. Remove the rear cover. (☛ B022 service manual, 6.6.3)
2. Remove the optional finisher if it has been installed.
3. Remove the application cover [A] (1 screw).
4. Remove the shield plate [B] (8 screws) or the optional fax unit if it has been installed.
5. Remove the controller board [C] (☛ x 2, ☛ x 10).
6. Remove the NVRAM [D], DIMM (printer/scanner, memory, etc), and printer options from the old controller board and put them on the new controller board.

6.7.2 SBCU BOARD




1. Remove the rear cover. (☛ 6.6.3)
2. Remove the SBCU board [A] (All connectors, 6 screws).
NOTE: Make sure that the DIPswitch settings on the new board are the same as those on the old board.

6.7.3 POWER PACK




1. Remove the rear cover. (☛ 6.6.3)
2. Swing down the I/O board bracket. (☛ 6.6.5)
3. Remove the power pack [A] (5 connectors, 3 screws).

6.7.4 MAIN MOTOR



1. Remove the rear cover. (☛ 6.6.3)
2. Swing down the I/O board bracket [A]. (☛ 6.6.5)
3. Remove the fly wheels [B] (1 screw).
4. Replace the main motor [C] (2 connectors, 3 screws).

6.7.5 PSU



1. Remove the optional finisher if it has been installed.
2. Remove the application cover [A] (1 screw).
3. Remove the left cover [B] (6 screws).
4. **220 V machine only:** Remove the transformer [C] (1 screw).
5. Remove the PSU [D] (all connectors, 6 screws, 1 clip).

6.8 COPY ADJUSTMENTS: PRINTING/SCANNING

NOTE: 1) You need to perform these adjustment(s) after replacing any of the following parts:

- Scanner Wire
- Lens Block/SBU Assembly
- Scanner Drive Motor
- Polygon Mirror Motor
- Paper Side Fence
- Memory All Clear

2) For more details about accessing SP modes, refer to section 4.

6.8.1 PRINTING

NOTE: 1) Make sure the paper is installed correctly in each paper tray before you start these adjustments.


2) Use the Trimming Area Pattern (SP2-902-3, No.10) to print the test pattern for the following procedures.

3) Set SP 2-902-3 to 0 again after completing these printing adjustments.

Registration - Leading Edge/Side-to-Side

1. Check the leading edge registration for each paper feed station, and adjust them using SP1-001.
2. Check the side-to-side registration for each paper feed station, and adjust them using SP1-002.

Tray	SP mode	Specification
Any paper tray	SP1-001-1	3 ± 2 mm
By-pass feed	SP1-001-2	
Duplex	SP1-001-3	2 ± 1.5 mm
1st paper feed	SP1-002-1	
2nd paper feed	SP1-002-2	
3rd paper feed (Optional PFU tray 1), or LCT	SP1-002-3	
4th paper feed (Optional PFU tray 2)	SP1-002-4	
By-pass feed	SP1-002-5	
Duplex, side 2	SP1-002-6	



Replacement Adjustment


A: Leading Edge Registration
B: Side-to-side Registration

Blank Margin

NOTE: If the leading edge/side-to-side registration cannot be adjusted within the specifications, adjust the leading/left side edge blank margin.

1. Check the trailing edge and right side edge blank margins, and adjust them using the following SP modes.

	SP mode	Specification
Trailing edge	SP2-101-2/3/4	3 ± 2 mm
Right edge	SP2-101-6	$2 +2.5/-1.5$ mm
Leading edge	SP2-101-1	3 ± 2 mm
Left edge	SP2-101-5	2 ± 1.5 mm
Trailing edge (duplex copy, 2nd side)	SP2-101-7	2 ± 2 mm
Left edge (duplex copy, 2nd side)	SP2-101-8	2 ± 1.5 mm
Right edge (duplex copy, 2nd side)	SP2-101-9	$2 +2.5/-1.5$ mm



- A: Trailing Edge Blank Margin
- B: Right Edge Blank Margin
- C: Leading Edge Blank Margin
- D: Left Edge Blank Margin


Main Scan Magnification

1. Print the single-dot grid pattern (SP2-902, no.5).
2. Check the magnification, and adjust the magnification using SP2-909 if necessary. The specification is $\pm 1\%$.

Parallelogram Image Adjustment

Do the following procedure if a parallelogram is printed while adjusting the printing registration or the printing margin using a trimming area pattern.

NOTE: The following procedure should be done after adjusting the side-to-side registration for each paper tray station.



1. Check whether the trimming area pattern (SP2-902, No.10) is printed as a parallelogram, as shown. If it is, do the following.
2. Remove the laser unit [A] (☛ 6.2).
3. Remove the bracket [B] (2 screws).
4. Install the adjusting cam [C] (P/N: A2309003).
NOTE: At the completion of the adjustment the adjusting cam remains in the machine.
5. Secure the adjustment bracket [D] (P/N A2679002) using the screw which was used for bracket [B]. However, do not tighten the screws at this time.
6. Reinstall the laser unit.
7. Adjust the laser unit position by turning the adjusting cam. (Refer to the above illustration for the relationship between the image and the cam rotation direction).
8. Tighten the adjustment bracket.
9. Print the trimming area pattern to check the image. If it is still unsatisfactory, repeat steps 4 to 8.

6.8.2 SCANNING


- NOTE:** 1) Before doing the following scanner adjustments, perform or check the printing registration/side-to-side adjustment and the blank margin adjustment.
 2) Use an S5S test chart to perform the following adjustments.

Registration: Platen Mode

1. Place the test chart on the exposure glass and make a copy from one of the feed stations.
2. Check the leading edge and side-to-side registration, and adjust them using the following SP modes if necessary.


	SP mode
Leading Edge	SP4-010
Side-to-side	SP4-011

A: Leading Edge Registration
 B: Side-to-side Registration



Magnification

NOTE: Use an S5S test chart to perform the following adjustment.



A: Sub Scan Magnification
 B: Main Scan magnification

1. Place the test chart on the exposure glass and make a copy from one of the feed stations.
2. Check the magnification ratio, and adjust it using the following SP mode if necessary. The specification is $\pm 1\%$.

	SP mode
Sub Scan Magnification	SP4-009
Main Scan Magnification	SP4-008

Standard White Density Adjustment

This adjusts the standard white density level.

Perform this adjustment in any of the following conditions:



- After replacing the standard white plate.
- After replacing the NVRAM on the controller board. (If only controller board is replaced, this adjustment is not necessary, as the NVRAM from the old controller board is installed on the new controller board.)
- After performing a memory all clear (SP5-801).

Procedure:

1. Place 10 sheets of new A4 sideways (do not use any recycled paper) or A3 paper on the exposure glass and close the platen cover or the ADF.
2. Enter SP 4-428 and select "1: Yes". The standard white density is automatically adjusted.

6.8.3 ADF IMAGE ADJUSTMENT

Registration



A: Leading Edge Registration
 B: Side-to-side Registration

NOTE: Make a temporary test chart as shown above using A3/DLT paper.

1. Place the temporary test chart on the ADF and make a copy from one of the feed stations.
2. Check the registration, and adjust using the following SP modes if necessary.

	SP mode
Side-to-side Registration	SP6-006-1
Leading Edge Registration (Simplex)	SP6-006-2
Trailing Edge Blank Margin	SP6-006-3
Side-to-side Registration (Duplex: rear)	SP6-006-4

Sub Scan Magnification

NOTE: Make a temporary test chart as shown above using A3/DLT paper.


1. Place the temporary test chart on the ADF and make a copy from one of the feed stations.
2. Check the magnification, and adjust using the following SP modes if necessary. The specification is $\pm 1\%$.



	SP mode
Sub scan magnification	SP6-006-5



6.8.4 TOUCH SCREEN CALIBRATION

After clearing the memory, or if the touch panel detection function is not working correctly, follow this procedure to calibrate the touch screen.

NOTE: Do not attempt to use items [2] to [9] on the Self-Diagnostic Menu. These items are for design use only.

1. Press , press **1****9****9****3**, and then press **C** 5 times to open the Self-Diagnostics menu.




2. On the touch screen press "Touch Screen Adjust" (or press **1**).
3. Use a pointed (not sharp!) tool to press the upper left mark .
4. Press the lower right mark  after it appears.
5. Touch a few spots on the touch panel to confirm that the marker (+) appears exactly where the screen is touched.
If the + mark does not appear where the screen is touched, press Cancel and repeat from Step 2.
6. When you are finished, press [#] OK on the screen (or press **#**).
7. Touch [#] Exit on the screen to close the Self-Diagnostic menu and save the calibration settings.

6.9 IDENTIFYING SKEWED, TRAPEZOID AND PARALLELOGRAM IMAGES


6.9.1 SKEWED IMAGES

- The image's leading and trailing edges are parallel to one another.
- The image's left and right edges are also parallel.
- However, **all four sides** are slanted with respect to the paper's edge.




6.9.2 TRAPEZOID IMAGES

- Only the image's **trailing edge** is slanted with respect to the paper. The remaining 3 sides are parallel to the paper's edges.




6.9.3 PARALLELOGRAM IMAGES

- Like skewed images, the leading/trailing edges and left/right edges are parallel to each other, however here, the **leading and trailing edges** are both slanted with respect to the paper's edge.



6.10 CHECKING THE IMAGE WITH THE TRIMMING PATTERN



6.11 CORRECTING THE IMAGES

6.11.1 CORRECTING SKEWED IMAGES

1. Test pattern (Trimming Pattern) mode check

Is the image skewed?

No **Yes**

1. Adjust the side fences so that there is no gap between the fences and paper stack.
2. Adjust the amount of paper buckle: SP1-003-1 and 2.

2. Platen mode check

Set an original flush against the left and rear scales and make a copy.

Does the image come out as a parallelogram?

No **Yes**

Attach the Scanner Holder (a supporter normally attached during shipping)

OR

Perform **Procedure A**.

3. ADF mode check

Feed an original through the ADF.

Is the image skewed?

No **Yes**

Are the front and rear transport rollers feeding the original straight?

No **Yes**

Change the position of the right hinge screw to the longer hole, and make any minor positional adjustments necessary.

Perform **Procedure B**.

Procedure complete.

CORRECTING THE IMAGES

Procedure A :




Fig. 1: Rear, left upper side of machine






Fig. 2: (similar view)


1. Remove the rear and left covers, then the left scanner cover.
2. Check to see if there is a gap ([A]) between the scanner unit holder and frame.
3. If there is no gap, this means that the left front section of the scanner unit is positioned lower than the standard.
4. Loosen all 7 screws (Fig. 2) and lift up the left front portion of unit until there is a 1 to 2 mm gap between the two.
5. Tighten the screws.
6. Place a washer (P/N 07080050, 1mm thick) in between the two to occupy the gap [A].
Fix the washer in place using an instant-acting adhesive.
Note: This washer will also act to absorb minor amounts of shock.
7. Check whether the parallelogram image still appears.

Procedure B:**Fig. 3****Fig. 4**

1. Remove the ADF, rear cover, scanner left cover, and scanner rear cover.
2. Check the height difference between the hinge bracket and scanner housing.
3. If this difference is 0.5mm or more, please do one of the following. This is necessary since it has been confirmed that skewing occurs when the hinge bracket is this much lower than the scanner housing:
 - 1) Add a spacer ($t = 0.5$ to 0.8) between the hinge bracket (mainframe) and ADF left hinge, in order to raise the height of the left side of the ADF, **OR**:
 - 2) Adjust the stepped height difference between the hinge bracket and scanner housing until it is within 0 ± 0.3 mm.

6.11.2 CORRECTING TRAPEZOID IMAGES

Procedure 1: Minor Adjustment of the Fusing Unit Height (front-to-rear)



1. Print out the SP2-902-003 Trimming Pattern (value: 10).
2. If the image is a Pattern A trapezoid:
 - 1) Remove and reinsert the Fusing Unit.
 - 2) Tighten the left fixing screw while pushing up on the unit's left side (until it stops).
3. If the image is a Pattern B trapezoid, do the same for the unit's right side.
4. If the image is still printed out as a trapezoid, perform **Procedure 2**.

Procedure 2: Minor Adjustment of the Fusing Unit Position (front-to-rear)

1. Remove the Fusing Unit, then add a washer (t = 0.5 to 1.6) to the front fixing screw. **Note:** This will increase the distance from the mainframe stay.

2. Check the image.

Still NG

OK

Adjustment Complete.

3. Add more washers (t = 0.5 to 1.6, as above).

Note: Too many washers can cause wrinkling in the paper.

Still NG

OK

Adjustment Complete.

4. Remove the Fusing Unit and all the washers added in Steps 1 and 2 above. Then, add washer(s) **in the same way for the rear side.**

Recommended Washers:

t = 0.5 07080040Z

t = 0.8 07080050Z

TROUBLESHOOTING

7. TROUBLESHOOTING

⚠ CAUTION

Never turn off the main power switch when the power LED is lit or flashing. To avoid damaging the hard disk or memory, press the operation power switch to switch the power off, wait for the power LED to go off, and then switch the main power switch off.

NOTE: The main power LED (Ⓢ) lights or flashes while the platen cover or ARDF is open, while the main machine is communicating with a facsimile or the network server, or while the machine is accessing the hard disk or memory for reading or writing data.

7.1 SERVICE CALL CONDITIONS

7.1.1 SUMMARY

There are 4 levels of service call conditions.

Level	Definition	Reset Procedure
A	To prevent damage to the machine, the main machine cannot be operated until the SC has been reset by a service representative (see the note below).	Enter SP mode, and then turn the main power switch off and on.
B	SCs that disable only the features that use the defective item. Although these SCs are not shown to the user under normal conditions, they are displayed on the operation panel only when the defective feature is selected.	Turn the operation switch or main switch off and on.
C	The SC history is updated. The machine can be operated as usual.	The SC will not be displayed. Only the SC history is updated.
D	Turning the main switch off then on resets SCs displayed on the operation panel. These are re-displayed if the error occurs again.	Turn the operation switch off and on.

NOTE: 1) If the problem concerns electrical circuit boards, first disconnect then reconnect the connectors before replacing the PCBs.
2) If the problem concerns a motor lock, first check the mechanical load before replacing motors or sensors.

SERVICE CALL CONDITIONS

7.1.2 SC CODE DESCRIPTIONS

Code No.		Symptom	Possible Cause
101	B	Exposure lamp error	<ul style="list-style-type: none"> • Exposure lamp defective • Lamp stabilizer defective • Exposure lamp connector defective • Standard white plate dirty • Scanner mirror or scanner lens out of position or dirty • SBU defective
		The standard white level was not detected properly when scanning the white plate.	
120	D	Scanner home position error 1	<ul style="list-style-type: none"> • Scanner drive motor defective • Scanner motor defective • Harness between SBCU and scanner drive motor disconnected • Harness between SBCU and scanner drive motor power source disconnected • Scanner HP sensor defective • Harness between SBCU and HP sensor disconnected • Scanner wire, timing belt, pulley, or carriage defective
		The scanner home position sensor does not detect the on condition during initialization or copying.	
121	D	Scanner home position error 2	<ul style="list-style-type: none"> • SIB or scanner drive motor defective • Scanner motor defective • Harness between SBCU and scanner drive motor disconnected • Harness between SBCU and scanner drive motor power source disconnected • Scanner HP sensor defective • Harness between SBCU and HP sensor disconnected • Scanner wire, timing belt, pulley, or carriage defective
		The scanner home position sensor does not detect the off condition during initialization.	
122	B	Scanner HP Sensor – Error 1	<ul style="list-style-type: none"> • SBCU, scanner motor drive board defective • Scanner motor defective • Harness between the SBCU, scanner motor drive board and scanner motor disconnected • HP sensor defective • Harness between SBCU and HP sensor disconnected. • Scanner wire, timing belt, pulley, or carriage installation incorrect
		The HP sensor remains on while the carriage is returning to the home position.	
123	B	Scanner HP sensor – Error 2	<ul style="list-style-type: none"> • SBCU, scanner motor drive board defective • Scanner motor defective • Harness between the SBCU, scanner motor drive board and scanner motor disconnected • HP sensor defective • Harness between SBCU and HP sensor disconnected. • Scanner wire, timing belt, pulley, or carriage installation incorrect
		The HP sensor does not switch on after the carriage has returned to the home position.	

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
144	B	SBU connection error	Cable between SBU and IPU board disconnected.
		The IPU does not detect the SBU connection signal.	
192	B	Automatic SBU adjustment error	<ul style="list-style-type: none"> • SBU defective • SBCU board defective • Exposure lamp stabilizer defective • Exposure lamp defective • Dirty white plate
		An error is detected during automatic SBU adjustment (SP4-428)	
193	B	Image transfer error	<ul style="list-style-type: none"> • IPU board defective • Controller board defective • Video controller defective
		The IPU board does not finish within 1 minute after the image data has been transferred to the controller board.	
195	B	DFGATE assert error	<ul style="list-style-type: none"> • ADF interface cable defective • SBCU board defective • Mismatched firmware between the SBCU board and ADF
		The DFGATE signal does not assert within 30 seconds after the original has been scanned.	
196	B	DFGATE negate error	<ul style="list-style-type: none"> • ADF interface cable defective • SBCU board defective • Mismatched firmware between the SBCU board and ADF
		The DFGATE signal does not negate within 1 minute after the DFGATE has been asserted.	
197	B	DFGATE error	<ul style="list-style-type: none"> • ADF interface cable defective • SBCU board defective • Mismatched firmware between the SBCU board and ADF
		The DFGEATE signal has already been asserted at the original scan.	
198	B	Memory address error	<ul style="list-style-type: none"> • Mismatched firmware between the SBCU board and controller board • Controller defective • SBCU defective • IPU board defective
		The IPU board does not receive the memory address from the controller board.	
199	B	DF scanning finish error	<ul style="list-style-type: none"> • ADF interface cable defective • SBCU board defective • Mismatched firmware between the SBCU board and ADF
		The original does not finish scanning with in 1 minute	
302	B	Charge roller current leak	<ul style="list-style-type: none"> • Charge roller damaged • Charge high voltage supply board defective • Poor connection of the PCU
		A charge roller current leak signal is detected.	
320	B	Polygon motor error	<ul style="list-style-type: none"> • Polygon mirror motor defective • Poor connection between the polygon mirror motor driver and the SBCU board • SBCU board defective
		The polygon motor does not reach its operating speed within 10 seconds after the polygon motor on signal, or the lock signal is not detected for more than 200 ms continuously during operation.	
322	B	Laser synchronization error	<ul style="list-style-type: none"> • Poor connection between the laser synchronization detector board and the SBCU board • Laser synchronization detector board out of position • Laser synchronization detector board defective • SBCU board defective • LD unit defective
		The main scan synchronization detector board cannot detect the laser synchronization signal for more than 10 consecutive 50 ms intervals.	

Trouble-shooting

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
323	B	LD drive current over	<ul style="list-style-type: none"> • LD unit defective (not enough power, due to aging) • Poor connection between the LD unit and the SBCU board • SBCU board defective
		The LD drive board applies more than 100 mA to the LD.	
350	B	ID sensor calibration - Error 1	<ul style="list-style-type: none"> • ID sensor defective or dirty • ID sensor harness disconnected or connector is damaged • SBCU defective • Scanning system or image creation system malfunction • High voltage power supply board (power pack) defective
		One of the following conditions occurred when the ID sensor pattern was calibrated during printing: <ul style="list-style-type: none"> • $V_{sp} > 2.5V$ • $V_{sg} < 2.5V$ • $V_{sp} = 0V$ • $V_{sg} = 0V$ 	
351	B	ID sensor calibration – Error 2	<ul style="list-style-type: none"> • ID sensor dirty or defective • ID sensor harness disconnected, or connector damaged • SBCU board defective • High voltage power supply board (power pack) defective
		The following conditions occurred simultaneously when the ID sensor pattern was calibrated during printing: <ul style="list-style-type: none"> • $V_{sg} = 5V$ • $PWM = 0$ (LED current drop) 	
352	B	ID sensor calibration – Error 3	<ul style="list-style-type: none"> • ID sensor dirty or defective • ID sensor harness disconnected, or connector damaged • SBCU defective • High voltage power supply board (power pack) defective
		During printing the 2.5V value for edge detection of the ID sensor pattern could not be detected after 800 ms.	
353	B	ID sensor adjustment Error 1	<ul style="list-style-type: none"> • ID sensor dirty or defective • ID sensor harness disconnected, or connector damaged • SBCU defective • High voltage power supply board (power pack) defective • Scanning system or image creation system malfunction
		Error occurred during automatic adjustment of V_{sg} : <ul style="list-style-type: none"> • V_{sg} output did not attain 4V, even with $PWM = 255$ (maximum current for LED) • V_{sg} output was greater than 4V, even with $PWM=0$ (no current for the LED) 	
354	B	ID Sensor Adjustment Error 2	<ul style="list-style-type: none"> • ID sensor dirty or defective • ID sensor harness disconnected, or connector damaged • SBCU defective • High voltage power supply board (power pack) defective • Scanning system or image creation system malfunction
		Error occurred during automatic adjustment of V_{sg} . V_{sg} could not be adjusted to $4.0V \pm 0.2V$ within 50 ms even after 20 attempts.	
355	C	ID sensor error	<ul style="list-style-type: none"> • ID sensor dirty or defective • ID sensor harness disconnected, or connector damaged • SBCU board defective • High voltage power supply board (power pack) defective • Scanning system or image creation system malfunction
		For details about the cause of the problem, please refer to SC350~354 above.	

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
389	B	TD sensor error	<ul style="list-style-type: none"> • TD sensor defective • TD sensor connector damaged.
		TD sensor output was less than 0.5V, or more than 0.5V 10 times in succession. If the fax unit is installed, this SC is issued immediately. If the fax unit is not installed, this SC is issued after the prescribed number of copies has printed.	
390	D	TD sensor error	<ul style="list-style-type: none"> • TD sensor abnormal • Poor connection of the PCU
		The TD sensor outputs less than 0.5V or more than 4.0V 10 times consecutively during copying.	
391	B	Development bias leak	<ul style="list-style-type: none"> • Poor connection of the PCU • High voltage supply board defective
		A development bias leak signal is detected.	
392	B	TD sensor initial setting error	<ul style="list-style-type: none"> • Someone forgot to remove the toner seal of the PCU • ID sensor defective • TD sensor abnormal • Drum does not turn • Development roller does not turn • Poor connection of the PCU
		TD sensor output voltage falls out of the adjustment range (2.0 ±<> 0.2 V) after the TD sensor initial setting has been finished.	
399	B	Illegal toner bottle (South Korea only)	<ul style="list-style-type: none"> • Install the correct type of toner bottle.
		The toner bottle installed is not intended for use with this machine.	
401	B	Transfer roller leak error 1	<ul style="list-style-type: none"> • High voltage supply board defective • Poor connection of the PCU • Transfer/separation unit set incorrectly • Transfer roller damaged
402	B	Transfer roller leak error 2 A transfer roller current leak signal is detected. The current feedback signal for the transfer roller is not detected.	
411	B	Separation bias leak error	<ul style="list-style-type: none"> • High voltage supply board defective • Poor connection of the PCU • Discharge plate defective
		A separation bias leak signal is detected.	
490	B	Toner supply motor leak error	Toner supply motor defective
		Over 1 A supplied to the toner supply motor for longer than 200 ms.	
500	B	Main motor lock	<ul style="list-style-type: none"> • Too much load on the drive mechanism • Main motor defective
		A main motor lock signal is not detected for more than 500 ms after the main motor starts to rotate, or the lock signal is not detected for more than 500 ms during rotation after the last signal.	
501	B	1st paper tray lift motor malfunction	<ul style="list-style-type: none"> • Paper lift sensor defective • Tray lift motor defective • Too much load on the drive mechanism • Poor tray lift motor connection
502	B	2nd paper tray lift motor malfunction	
503	B	3rd paper tray lift motor malfunction (optional paper tray unit)	
504	B	4th paper tray lift motor malfunction (optional paper tray unit)	
		The paper lift sensor is not activated after the tray lift motor has been on for 18 seconds.	

Trouble-shooting

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
506	B	Paper tray motor lock (optional paper tray unit)	<ul style="list-style-type: none"> Paper tray unit motor defective Too much load on the drive mechanism
		A motor lock signal is not detected for more than 1.5 s or the lock signal is not detected for more than 1.0 s during rotation.	
508	B	Rear fence drive error (optional LCT)	<ul style="list-style-type: none"> Rear fence motor defective Return position sensor defective Too much load on the drive mechanism
		The return position sensor is not activated after the rear fence drive motor has been on to lower the tandem tray for 8 seconds.	
509	B	Side fence drive error (optional LCT)	<ul style="list-style-type: none"> Side fence motor defective Side fence position sensor defective Side fence close sensor defective Too much load on the drive mechanism
		<p>The side fence positioning sensor is not activated for more 3 seconds when the paper stack in the left tray is moved to the right tray.</p> <p>The side fence close sensor is not activated for more 3 seconds after moving the paper stack to the right tray.</p>	
510	B	LCT lower limit error	<ul style="list-style-type: none"> Tray lift motor defective Poor connection of the tray lift motor Lower limit sensor defective Too much load on the drive mechanism
		The lower limit sensor does not activate within 8 seconds after the tray has been lowered.	
520	B	Paper tray error	<ul style="list-style-type: none"> A defective motor A defective sensor Too much load on the drive mechanism
		An error occurs (i.e motor error, or sensor error, etc) for any paper tray.	
541	A	Fusing thermistor open	<ul style="list-style-type: none"> Fusing thermistor defective or out of position Fusing lamp open Fusing thermostat open Power supply board defective Poor connection of the fusing unit
		<p>The fusing temperature detected by the thermistor was below 0 °C for 5 seconds.</p> <p>The fusing temperature does not rise +15 °C (center) or +12 °C (at the ends) five times within 2 minutes after the fusing lamps have been turned on.</p>	
542	A	Fusing temperature warm-up error	<ul style="list-style-type: none"> Fusing thermistor defective or out of position Fusing lamp open Fusing thermostat open Power supply board defective Poor connection of the fusing unit
		The fusing temperature does not reach the standby temperature within 20 seconds after the main switch is turned on.	
543	A	Fusing overheat error 1	<ul style="list-style-type: none"> Fusing thermistor defective Power supply board defective SBCU board defective
		A fusing temperature of over 231°C is detected for 5 second by the fusing thermistor.	
544	A	Fusing overheat error 2	<ul style="list-style-type: none"> Fusing thermistor defective Power supply board defective SBCU board defective
		A fusing temperature of over 251°C is detected by the fusing temperature monitor circuit in the SBCU board.	

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
545	A	Fusing overheat error 3	<ul style="list-style-type: none"> Hot roller thermistor is out of position Fusing lamp broken Thermostat broken
		After warmup, the hot roller attained full operating temperature and maintained this temperature for 10 sec. without the hot roller rotating.	
546	A	Unstable fusing temperature	<ul style="list-style-type: none"> Thermistor defective Poor connection of the fusing unit Power supply unit defective
		The fusing temperature varies 50°C or more within 1 second twice continuously.	
547	B	Zero cross signal malfunction	<ul style="list-style-type: none"> Power supply board defective SBCU board defective
		Zero cross signals are not detected within a certain period.	
548	A	Fusing unit set error	<ul style="list-style-type: none"> Poor connection of the fusing unit The fusing unit is not installed
		The machine does not detect the fusing unit.	
590	B	Exhaust fan motor error	<ul style="list-style-type: none"> Poor connection of the exhaust fan motor Too much load on the motor drive
		The CPU detects an exhaust fan lock signal for more than 5 seconds.	
611	B	Communication break error between SBCU and ADF	<ul style="list-style-type: none"> Serial line connecting SBCU and ADF unstable External noise ADF main board defective SBCU board defective
		The SBCU receives a break signal from the ADF main board.	
612	B	Communication command error between SBCU and ADF	<ul style="list-style-type: none"> SBCU board defective Download SBCU firmware again
		The SBCU sends a command to the ADF main board that it cannot execute.	
620	B	Communication timeout error between SBCU and finisher	<ul style="list-style-type: none"> Serial line connecting SBCU and finisher unstable External noise SBCU board and finisher main board connection defective or loose Finisher main board defective SBCU board defective
		The SBCU cannot receive a response within 100 ms after 3 attempts after sending data to the finisher.	
621	B	Communication timeout error between SBCU and finisher	<ul style="list-style-type: none"> Serial line connecting SBCU and finisher unstable External noise
		A break (low) signal was received from the finisher.	
630	C	Communication failure with CSS (RSS)	<ul style="list-style-type: none"> Occurred with an SC call, CC call, supply management call, user call, or CE call. Timeout while no response from the LADP, and abnormal signal on the RS-485 line between PI and LADP.
		The communication from the copier was detected as abnormal at the CSS center. This error occurs when the acknowledge signal from the LADP does not complete normally.	
632	D	Counter device error 1 Japan Only	<ul style="list-style-type: none"> Serial line between the optional counter device, the relay board and copier control board is disconnected or damaged Make sure that SP5113 is set to enable the optional counter device.
		After 3 attempts to send a data frame to the optional counter device via the serial communication line, no ACK signal was received within 100 ms.	

Trouble-shooting

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
633	D	Counter device error 2 Japan Only	<ul style="list-style-type: none"> Serial line between the optional counter device, the relay board and copier control board is disconnected or damaged Make sure that SP5113 is set to enable the optional counter device.
		After 3 attempts to send a data frame to the optional counter device via the serial communication line, no ACK signal was received within 100 ms.	
634	D	Counter device error 3 Japan Only	<ul style="list-style-type: none"> Counter device control board defective Backup battery of counter device defective
		A backup RAM error was returned by the counter device.	
635	D	Counter device error 4 Japan Only	<ul style="list-style-type: none"> Counter device control board defective Backup battery of counter device defective
		A backup battery error was returned by the counter device.	
640	C	SBCU control data transfer checksum error	<ul style="list-style-type: none"> Controller board defective External noise SBCU board defective
		A sampling of control data sent from the SBCU to the controller reveals a checksum error. Only the logging count is performed.	
641	C	SBCU control data transfer abnormal	<ul style="list-style-type: none"> Controller board defective External noise SBCU board defective
		A sampling of the control data sent from the SBCU reveals an abnormality.	
650	B	Communication timeout error between SBCU and duplex unit	<ul style="list-style-type: none"> Serial line connecting SBCU and duplex unit unstable External noise SBCU board and duplex main board connection defective or loose Duplex main board defective SBCU board defective
		The SBCU cannot receive a response within 1 second from the duplex unit.	
670	D	Engine response error	<ul style="list-style-type: none"> SBCU installed incorrectly SBCU defective Controller board defective
		After powering on the machine, a response is not received from the engine within 30 seconds.	
672	D	Controller-to-operation panel communication error at startup	<ul style="list-style-type: none"> Controller stall Controller board installed incorrectly Controller board defective Operation panel connector loose or defective
		After powering on the machine, the communication circuit between the controller and the operation panel is not opened, or communication with controller is interrupted after a normal startup.	
720	B	Finisher jogger motor error (500-sheet finisher)	<ul style="list-style-type: none"> Jogger H.P sensor defective Jogger motor defective
		<p>The finisher jogger H.P sensor remains de-activated for a certain time when returning to home position.</p> <p>The finisher jogger H.P sensor remains activated for a certain time when moving away from home position.</p>	

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
722	B	Finisher jogger motor error (1000-sheet finisher)	<ul style="list-style-type: none"> • Jogger H.P sensor defective • Jogger motor defective
		<p>The finisher jogger H.P sensor remains de-activated for a certain time when returning to home position.</p> <p>The finisher jogger H.P sensor remains activated for a certain time when moving away from home position.</p>	
724	B	Finisher staple hammer motor error (1000-sheet finisher)	<ul style="list-style-type: none"> • Staple jam • Stapler overload caused by trying to staple too many sheets • Staple hammer motor defective
		Stapling does not finish within 600 ms after the staple hammer motor turned on.	
725	B	Finisher stack feed-out motor error (1000-sheet finisher)	<ul style="list-style-type: none"> • Stack feed-out H.P sensor defective • Stack feed-out motor defective
		The stack feed-out belt H.P sensor does not activate within a certain time after the stack feed-out motor turned on.	
726	B	Finisher lift motor error (1000-sheet finisher)	<ul style="list-style-type: none"> • Shift tray lift motor defective • Stack height sensor defective
		The stack height sensor does not activate within a certain time after the shift tray lift motor turned on.	
727	B	Finisher staple hammer motor error (500-sheet finisher)	<ul style="list-style-type: none"> • Staple jam • Stapler overload caused by trying to staple too many sheets • Staple hammer motor defective
		Stapling does not finish within a certain time after staple hammer motor turned on.	
728	B	Finisher paper stack height error (500-sheet finisher)	<ul style="list-style-type: none"> • Stack height lever solenoid defective • Stack height sensor defective • Lever sensor defective • Main control board defective
		The stack height detection lever does not return to its home position before going to detect the stack height.	
730	B	Finisher stapler motor error (1000-sheet finisher)	<ul style="list-style-type: none"> • Stapler motor defective • Stapler H.P sensor defective • Poor stapler motor connection
		<p>The stapler does not return to its home position within a certain time after the stapler motor turned on.</p> <p>The stapler H.P sensor does not activate within a certain time after the stapler motor turned on.</p>	
731	B	Output tray motor error (500-sheet finisher)	<p>500-sheet finisher</p> <ul style="list-style-type: none"> • Output tray motor defective • Tray upper limit sensor defective
		<p>Exit guide plate motor error (1000-sheet finisher)</p> <p>The tray upper limit sensor does not activate within a certain time after the shift motor turned on. (500-sheet finisher)</p> <p>The exit guide plate open sensor or exit guide plate HP sensor does not activate within a certain time after the exit guide plate motor turned on. (1000-sheet finisher)</p>	

Trouble-shooting

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
732	B	Finisher shift motor error (1000-sheet finisher)	<ul style="list-style-type: none"> Shift motor defective Shift tray HP sensor defective
		Roller shift does not finish within a certain time after the shift motor turned on.	
770	B	Shift tray shift motor error	<ul style="list-style-type: none"> Shift sensor defective Shift motor defective
		During a shift operation the sensor state did not change (off to on, or on to off) within 2.4 sec.	
791	B	Bridge communication error	<ul style="list-style-type: none"> Poor connection between the main machine and bridge unit SBCU board defective
		The SBCU cannot communicate with the bridge unit properly when the finisher is installed.	
792	B	Finisher connection error	<ul style="list-style-type: none"> Poor connection between the finisher and bridge unit SBCU board defective
		The SBCU cannot communicate with the finisher properly when the bridge unit is installed.	
793	B	Interchange communication error	<ul style="list-style-type: none"> Poor connection between the interchange unit and main machine SBCU board defective
		The SBCU cannot communicate with the interchange unit properly when the duplex unit is installed.	
800	D	Startup without video output end error (K)	Controller board defective
		Video transfer to the engine is started, but the engine did not issue a video transmission end command within the specified time.	
804	D	Startup without video input end (K)	Controller board defective
		A video transmission was requested from the scanner, but the scanner did not issue a video transmission end command within the specified time.	
818	D	Watchdog error	<ul style="list-style-type: none"> Controller board defective Software malfunction – download controller firmware again
		The CPU does not access the watchdog register within a certain time.	
819	D	Kernel mismatch error	Download controller firmware again
		Software bug	
820	D	Self-Diagnostic Error: CPU	<ul style="list-style-type: none"> Controller board defective Download controller firmware again
		The central processing unit returned an error during the self-diagnostic test.	
821	D	Self-Diagnostic Error: ASIC	Controller board defective
		The ASIC returned an error during the self-diagnostic test because the ASIC and CPU timer interrupts were compared and determined to be out of range.	
822	D	Self-Diagnostic Error: HDD	<ul style="list-style-type: none"> HDD defective HDD connector defective Controller board defective
		The hard disk drive returned an error during the self-diagnostic test.	
823	D	Self-diagnostic Error: NIB	<ul style="list-style-type: none"> Network interface board defective Controller board defective
		The network interface board returned an error during the self-diagnostic test.	

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
824	D	Self-diagnostic Error: Resident NVRAM	<ul style="list-style-type: none"> Replace the resident NVRAM on the controller board Replace the controller board
		The resident non-volatile RAM returned an error during the self-diagnostic test.	
825	D	Self-diagnostic Error: Optional NVRAM	<ul style="list-style-type: none"> Replace the optional NVRAM (user account enhancement unit) on the controller board Replace the controller board
		The resident non-volatile RAM returned an error during the self-diagnostic test.	
826	D	Self-diagnostic Error: NVRAM/Optional NVRAM	Replace the NVRAM on the controller board
		The NVRAM or optional NVRAM returned an error during the self-diagnostic test.	
827	D	Self-diagnostic Error: RAM	Download controller firmware again
		The resident RAM returned a verify error during the self-diagnostic test.	
828	D	Self-diagnostic Error: ROM	<ul style="list-style-type: none"> Controller board defective Download controller firmware again
		The resident read-only memory returned an error during the self-diagnostic test.	
829	D	Self-diagnostic Error: Optional RAM	<ul style="list-style-type: none"> Replace the optional memory board Controller board defective
		The optional RAM returned an error during the self-diagnostic test.	
835	D	Self-Diagnostic Error: Parallel Interface	<ul style="list-style-type: none"> Loopback connector not detected IEEE1284 connector defective Controller board defective
		Loopback test error.	
836	D	Self-diagnostic Error: Resident Font ROM	Replace the controller board
		The resident font ROM returned an error during the self-diagnostic test.	
837	D	Self-diagnostic Error: Optional Font ROM	Replace the controller board
		The optional font ROM returned an error during the self-diagnostic test.	
838	D	Self-diagnostic Error: Clock Generator	Replace the controller board
		A verify error occurred when setting data was read from the clock generator via the I2C bus.	
840	D	EEPROM error 1	<ul style="list-style-type: none"> EEPROM defective; replace the controller board EEPROM has reached the end of its service life
		During input/output with the EEPROM, one of the following errors occurred: <ul style="list-style-type: none"> A read error occurred and continued after 3 retries. Write error occurred. 	
841	D	EEPROM error 2	<ul style="list-style-type: none"> EEPROM defective; replace the controller board EEPROM has reached the end of its service life
		The values read from the three areas during the mirroring check phase did not match. The data is being written into the three areas differently.	
850	D	Network I/F Abnormal	<ul style="list-style-type: none"> NIB defective Controller board defective
		NIB interface error.	

Trouble-shooting

SERVICE CALL CONDITIONS

Code No.		Symptom	Possible Cause
851	D	IEEE 1394 I/F Abnormal	<ul style="list-style-type: none"> • IEEE1384 interface board defective • Controller board defective
		IEEE1394 interface error.	
853	D	Wireless LAN card error 1	<ul style="list-style-type: none"> • Wireless LAN card not inserted in the wireless LAN board when machine was switched on
		At startup the wireless LAN board could be accessed, but the wireless LAN card (IEEE 802.11b or Bluetooth) could not access the board.	
854	D	Wireless LAN card error 2	<ul style="list-style-type: none"> • Wireless LAN card has been removed during machine operation.
		The board that holds the wireless LAN card can be accessed, but the wireless LAN card (802.11b/Bluetooth) itself cannot be accessed while the machine is operating	
855	D	Wireless LAN card error 3	<ul style="list-style-type: none"> • Wireless LAN card defective • Wireless card connection not tight
		An error was detected for the wireless LAN card (802.11b or Bluetooth).	
856	D	Wireless LAN board error	<ul style="list-style-type: none"> • Wireless LAN card board defective • PCI connector loose
		An error is detected for the wireless LAN card (802.11b or Bluetooth).	
857	D	USB I/F Error	<ul style="list-style-type: none"> • USB 2.0 disconnected • Controller board defective
		The USB driver is unstable and generated an error. The USB I/F cannot be used. The USB driver can generate three types of errors: RX, CRC, and STALL errors. Only the STALL error can generate this SC code.	
860	B	Startup without HD connection at main power on	<ul style="list-style-type: none"> • Cable between HDC and HDD loose or defective • HDD power connector loose or defective • HDD defective • Replace the controller board
		The hard disk connection is not detected.	
861	B	Startup without HD detection at power key on	<ul style="list-style-type: none"> • Cable between HDC and HDD loose or defective • HDD power connector loose or defective • HDD defective Replace the controller board
		The hard disk connection is not detected.	
862	A	Maximum number of bad sectors detected on HD	SC863 returned while reading data from the HD and the number of registered bad sectors reached 101.
		Up to 101 bad sectors have appeared in the area on the hard disk where image data is archived, and the hard disk may require replacement.	
863	B	Startup without HD data lead	A bad sector occurred during operation of the HDD
		Data stored on the hard disk is not read correctly.	
864	D	HD data CRC error	Data transfer was abnormal in the data read from the HDD.
		During operation of the HD, the HD responded with a CRC error.	

Code No.		Symptom	Possible Cause
870	B	Address Book Data Error	<ul style="list-style-type: none"> • Software defective • HDD defective
		Address book data stored on the hard disk was detected as abnormal when it was accessed from either the operation panel or the network.	
871	D	FCU Flash ROM Error	<ul style="list-style-type: none"> • Flash ROM device defective • Replace flash ROM on the MBU
		The address book written into the flash ROM mounted on the FCU is detected as defective.	
⇒ 872	B	Email Receiving Data Error	<ul style="list-style-type: none"> • Email(s) previously received by the machine and stored in the hard drive may contain damaged data. This can be deleted by executing SP5832-007, however note that doing so will also delete all other received emails. • Defective HDD
		Machine detects an HDD error during warm-up.	
⇒ 873	B	Email Sending Data Error	<ul style="list-style-type: none"> • IEmail(s) previously sent by the machine and stored in the hard drive may contain damaged data. This can be deleted by executing SP5832-008, however note that doing so will also delete all other sent emails, as well as initialize the sender's user name/password and administrator Mail address. • Defective HDD
		Machine detects an HDD error during warm-up.	
880	D	File Format Converter (MLB) Error	<ul style="list-style-type: none"> • MLB defective
		A request for access to the File Format Converter (MLB -Media Link Board) was not answered within the specified time.	
865	D	HD access error	Replace the controller board
		The hard disk detected an error.	
900	D	Electronic total counter error	Replace the NVRAM on the controller board
		The value of the total counter has already exceeded 9999999	
901	D	Mechanical total count error	Mechanical total counter defective
		The SBCU board cannot receive the mechanical total count data.	
920	D	Printer Error 1	<ul style="list-style-type: none"> • Software defective • Insufficient memory
		An internal application error was detected and operation cannot continue.	
925	D	Network File Error	<ul style="list-style-type: none"> • Software defective • Files on the HDD corrupted
		The file that manages NetFile is corrupted and operation cannot continue.	
951	B	F-gate error at write request	<ul style="list-style-type: none"> • Download controller firmware • SBCU board defective
		After the IPU receives an F-gate signal, it receives another F-gate signal.	

Trouble-shooting

Code No.		Symptom	Possible Cause
953	B	Scanner setting error	Download controller firmware
		The IPU does not respond with the scanner setting signal required to start scanning processing.	
954	B	Printer setting error	<ul style="list-style-type: none"> • Replace the IPU board • Replace the controller board • Download the controller firmware
		The IPU does not respond with the settings that are required to start image processing by the printer.	
955	B	Memory setting error	<ul style="list-style-type: none"> • Replace the IPU board • Replace the controller board • Download the controller firmware
		The IPU does not respond with the settings that are required to start image processing using the memory.	
964	B	Printer ready error	<ul style="list-style-type: none"> • Replace the IPU board • Replace the controller board • Download the controller firmware
		The printer ready signal is not generated within 17 seconds after the IPU received the print start signal.	
984	D	Print image data transfer error	<ul style="list-style-type: none"> • Controller board defective • SBCU board defective • Connectors between SBCU and controller loose or defective
		The image transfer from the controller to the engine via the PCI bus does not end within 15 s after starting.	
986	D	Software write parameter setting error	<ul style="list-style-type: none"> • Download controller firmware again
		An unstable area at the storage destination in the settings table is set at NULL for the parameter received by the write module.	
990	D	Software performance error	<ul style="list-style-type: none"> • Software defective • Internal parameter incorrect • Insufficient working memory • When this SC occurs, the file name, address, and data will be stored in NVRAM. This information can be checked by using SP7-403. Note the above data and the situation in which this SC occurs. Then report the data and conditions to your technical control center.
		The software attempted to perform an unexpected operation.	
991	C	Software continuity error	<ul style="list-style-type: none"> • No operation required. This SC code does not appear on the panel, and is only logged.
		The software attempted to perform an unexpected operation. However, unlike SC990, the object of the error is continuity of the software.	
992	D	Unexpected Software Error	<ul style="list-style-type: none"> • Software defective • An error undetectable by any other SC code occurred
		Software encountered an unexpected operation not defined under any SC code.	
995	D	Machine Type Information Error	<ul style="list-style-type: none"> • Replace the controller board with the correct board.
		After the machine is powered on, a mismatch is detected between the CPM information sent from the controller to the engine. The controller boards of the B089 (22 cpm) and B94 (27 cpm) are not interchangeable.	


Code No.		Symptom	Possible Cause
996	B	FCU board error	<ul style="list-style-type: none"> • FCU board defective and requires replacement • Download FCU firmware
		FCU board is connected but not ready.	
997	B	Application function selection error	<ul style="list-style-type: none"> • Download the firmware for the application that failed • An option required by the application (RAM, DIMM, board) is not installed
		The application selected by a key press on operation panel does not start or ends abnormally.	
998	D	Application start error	<ul style="list-style-type: none"> • Download controller firmware • Replace the controller board • An option required by the application (RAM, DIMM, board) is not installed
		After power on, the application does not start within 60 s. (All applications neither start nor end normally.)	
999	D	Program download error	<ul style="list-style-type: none"> • Board installed incorrectly • SBCU board defective • Controller board defective • IC card defective • NVRAM defective • Loss of power during downloading • Important Notes About SC999 • Primarily intended for operating in the download mode, logging is not performed with SC999. • If the machine loses power while downloading, or if for some other reason the download does not end normally, this could damage the controller board or the PCB targeted for the download and prevent subsequent downloading. If this problem occurs, the damaged PCB must be replaced.
		The download (program, print data, language data) from the IC card does not execute normally.	

7.2 SELF-DIAGNOSTIC MODE

7.2.1 SELF-DIAGNOSTIC MODE AT POWER ON

As soon as the main machine is powered on, the controller waits for the initial settings of the copy engine to take effect and then starts an independent self-diagnostic test program. The self-diagnostic test follows the path of the flow chart shown below and checks the CPU, memory, HDD, and so on. An SC code is displayed in the touch panel if the self-diagnostic program detects any malfunction or abnormal condition.

Self-Diagnostic Test Flow



7.2.2 DETAILED SELF-DIAGNOSTIC MODE

In addition to the self-diagnostic test initiated every time the main machine is powered on, you can set the machine in a more detailed diagnostic mode manually in order to test other components or conditions that are not tested during self-diagnosis after power on. The following device is required in order to put the machine in the detailed self-diagnosis mode.

No.	Name
G02119350	Parallel Loopback Connector

Executing Detailed Self-Diagnosis

Follow this procedure to execute detailed self-diagnosis.

1. Switch off the machine, and connect the parallel loopback device to the Centronics I/F port.
2. Hold down $\text{\textcircled{\#}}$, press and hold down $\text{\textcircled{\times}}$, and then while pressing both keys at the same time, switch on the machine.

You will see “Now Loading” on the touch-panel, and then you will see the results of the test.

SELF-DIAGNOSTIC MODE

A report like the one below is printed every time a detailed self-diagnostic test is executed, whether errors were detected or not.

MODEL NAME XXXX

Self-Diagnosis Report

Serial No. : ACLD000034 Firmware P/# : ACP82XXXX [1/1]

Firmware Version : 2.49.01 Wed Nov 22 13:15:30 2000

[System Construction]

Kernel Version : NetBSD 1.3.3 (SHINYOKOHAMA_ROM) #0: Sat Nov 11 16:15:35 JST 2000	CPU Pipeline Clock : 200.0 MHz
CPU System Bus Clock : 100.0 MHz	ASIC Version : 1397306160
Board Type : 7	RAM Capacity : 100.663296 MB
RTC Existence : existence	HDD Model :
HDD Existence : existence	

[Total Counter]

0001000

[Program No. @]


MAIN : ACP82XXXX	ENGINE : Ver1.96
LCDC : V1.39	PI :
ADF : B3515620B	SIB : B0045383
FIN :	FIN_SDL :
BANK : A6825150	LCT :
MBX :	FCU :
DPX :	

[Error List @@@]

SCCODE	(ERROR CODE)	SC CODE	(ERROR CODE)
SC835 (110C)		SC820 (0001)	
SC820 (0004)		SC820 (0005)	
		SC820 (0002)	
			SC820 (0003)

7.3 PAPER FEED TROUBLESHOOTING


When a paper double feed or paper non feed problem occurs, fix the problem in accordance with the following flow chart.



Trouble-shooting

7.4 SKEWED IMAGE

Do the following to fix a skewed image problem.



7.5 ELECTRICAL COMPONENT DEFECTS

7.5.1 SENSORS

Component (Symbol)	CN	Condition	Symptom
Scanner H.P	337-2 (SBCU)	Open	SC120 is displayed.
		Shorted	The CPU does not detect the scanner home position and the scanner motor does not stop.
Platen Cover	337-5 (SBCU)	Open	APS and ARE do not function correctly.
		Shorted	No symptom
Original Width	335-3, -4 (SBCU)	Open	The CPU cannot detect the original size properly. APS and ARE do not function correctly.
		Shorted	
Original Length-1	335-8, -9 (SBCU)	Open	The CPU cannot detect the original size properly. APS and ARE do not function correctly.
		Shorted	
Original Length-2	336-3, -4 (SBCU)	Open	The CPU cannot detect the original size properly. APS and ARE do not function correctly.
		Shorted	
Toner Density	327-3 (SBCU)	Open	SC390 is displayed
		Shorted	
1st Paper End	306-2 (SBCU)	Open	The Paper End indicator lights even if paper is placed in the 1st paper tray.
		Shorted	The Paper End indicator does not light even if there is no paper in the 1st paper tray.
2nd Paper End	307-A2 (SBCU)	Open	The Paper End indicator lights even if paper is placed in the 2nd paper tray.
		Shorted	The Paper End indicator does not light even if there is no paper in the 2nd paper tray.
Image Density	321-3 (SBCU)	Open	SC392 is displayed (see note)
		Shorted	
Paper Over Flow	324-5 (SBCU)	Open	The paper overflow message is not displayed when the paper overfull condition exist.
		Shorted	The paper overflow message is displayed.
Paper Exit	324-2 (SBCU)	Open	The Paper Jam indicator will light whenever a copy is made.
		Shorted	The Paper Jam indicator lights even if there is no paper.
Upper Relay	306-5 (SBCU)	Open	The Paper Jam indicator will light whenever a copy is made.
		Shorted	The Paper Jam indicator lights even if there is no paper.
Lower Relay	307-A5 (SBCU)	Open	The Paper Jam indicator will light whenever a copy is made.
		Shorted	The Paper Jam indicator lights even if there is no paper.

ELECTRICAL COMPONENT DEFECTS

Component (Symbol)	CN	Condition	Symptom
Registration	321-6 (SBCU)	Open	The Paper Jam indicator will light whenever a copy is made.
		Shorted	The Paper Jam indicator lights even if there is no paper.
1st Paper Lift	305-7 (SBCU)	Open	SC501 will be displayed.
		Shorted	Paper jam will occur during copying.
2nd Paper Lift	305-10 (SBCU)	Open	SC502 will be displayed.
		Shorted	Paper jam will occur during copying.
1st Paper Height – 1	307-B2 (SBCU)	Open	The CPU cannot determine the paper near-end condition properly.
		Shorted	
1st Paper Height – 2	307-B5 (SBCU)	Open	The CPU cannot determine the paper near-end condition properly.
		Shorted	
2nd Paper Height – 1	307-B9 (SBCU)	Open	The CPU cannot determine the paper near-end condition properly.
		Shorted	
2nd Paper Height – 2	307-B12 (SBCU)	Open	The CPU cannot determine the paper near-end condition properly.
		Shorted	

NOTE: An SC condition occurs only when a new PCU is being installed in the machine. During copying, if the ID sensor fails, the image density will be changed.

7.5.2 SWITCHES

Component (Symbol)	CN	Condition	Symptom
Main	281-1,2 (PSU)	Open	The machine does not turn on.
		Shorted	The machine does not turn off.
Right Upper Cover	324-8 (SBCU)	Open	The Cover Open indicator is not lit even if the right upper cover is opened.
		Shorted	The Cover Open indicator is lit even if the right upper cover is closed.
Right Cover	308-9 (SBCU)	Open	The Cover Open indicator is not lit even if the right cover is opened.
		Shorted	The Cover Open indicator is lit even if the right cover is closed.
Right Lower Cover	307-A8 (SBCU)	Open	The Cover Open indicator is not lit even if the right lower cover is opened.
		Shorted	The Cover Open indicator is lit even if the right lower cover is closed.
Upper Paper Size	308-1,2,4,5 (SBCU)	Open	The CPU cannot detect the proper paper size, and misfeeds may occur when a copy is made.
		Shorted	
Lower Paper Size	308-6,7,9,10 (SBCU)	Open	The CPU cannot detect the proper paper size, and misfeeds may occur when a copy is made.
		Shorted	
New PCU Detect	327-7 (SBCU)	Open	The TD sensor initial setting procedure is not performed when a new PCU is installed.
		Shorted	The TD sensor initial setting procedure is performed whenever the front cover is closed.
Front Cover Safety	311-2, 4 (SBCU)	Open	The Cover Open indicator is not lit even if the front cover is opened.
		Shorted	The Cover Open indicator is lit even if the front cover is closed.
Operation	105-1 (IPU)	Open	The LCD does not off even if the operation switch is turned off.
		Shorted	The LCD does not on even if the operation switch is turned on.

BLOWN FUSE CONDITIONS

7.6 BLOWN FUSE CONDITIONS

Fuse	Rating		Symptom when turning on the main switch
	115 V	220 ~ 240 V	
Power Supply Board			
FU1	15 A/250 V	----	No response.
FU2	8 A/125 V	5 A/250 V	No response
FU3	2 A/125 V	1 A/250V	Anti-condensation/Tray Heater does not turn on.
FU4	6.3 A/125 V	6.3 A/250V	Optional finisher, bridge unit, and shift tray does not work then SC792 is displayed.
FU5	6.3 A/125 V	6.3 /250 V	Covers Open indicator is lit then SC901 is displayed
FU6	6.3 A/125 V	6.3 A/250V	The touch panel does not turn on.
FU7	4 A/125 V	4 A/250 V	SC990 is displayed

PAPER TRAY UNIT


A860/B390

1. OVERALL MACHINE INFORMATION

1.1 SPECIFICATIONS


Paper Size:	A5 to A3 HLT lengthwise to DLT
Paper Weight:	60 ~ 105 g/m ² , 16 ~ 28 lbs.
Tray Capacity:	500 sheets (80 g/m ² , 20 lbs.) x 2 trays
Paper Feed System:	Feed roller and friction pad
Paper Height Detection:	4 steps (100%, 70%, 30%, Near end)
Power Source:	24 VDC, 5 VDC (from the copier/printer) 120 Vac: 120 V version, from the copier/printer when the optional tray heater is installed 220 ~ 240 Vac: 230 V version, from the copier/printer when the optional tray heater is installed
Power Consumption:	Max: 30 W (Copying/printing) 23 W (Optional Tray Heater On) Average: 17 W (Copying/printing) 15 W (Optional Tray Heater On)
Weight:	25 kg (55 lbs)
Size (W x D x H):	550 mm x 520 mm x 271 mm

1.2 MECHANICAL COMPONENT LAYOUT



- 1. Upper paper feed roller
- 2. Lower paper feed roller
- 3. Upper tray
- 4. Lower tray
- 5. Upper bottom plate
- 6. Lower bottom plate
- 7. Optional tray heater

1.3 ELECTRICAL COMPONENT LAYOUT




- | | |
|---------------------------------|---------------------------------|
| 1. Tray main board | 11. Lower paper height 1 sensor |
| 2. Upper lift sensor | 12. Vertical transport sensor |
| 3. Upper lift motor | 13. Upper paper end sensor |
| 4. Upper paper height 2 sensor | 14. Lower paper end sensor |
| 5. Upper paper height 1 sensor | 15. Lower paper size switch |
| 6. Upper paper feed clutch | 16. Upper paper size switch |
| 7. Relay clutch | 17. Optional tray heater |
| 8. Tray cover switch | 18. Lower lift motor |
| 9. Lower paper feed clutch | 19. Lower lift sensor |
| 10. Lower paper height 2 sensor | 20. Tray motor |

ELECTRICAL COMPONENT DESCRIPTION

1.4 ELECTRICAL COMPONENT DESCRIPTION

Symbol	Name	Function	Index No.
Motors			
M1	Tray	Drives all rollers.	20
M2	Upper Lift	Lifts the upper tray bottom plate.	3
M3	Lower Lift	Lifts the lower tray bottom plate.	18
Sensors			
S1	Upper Lift	Detects when the paper in the upper tray is at the correct feed height.	2
S2	Lower Lift	Detects when the paper in the lower tray is at the correct feed height.	19
S3	Upper Paper End	Informs the copier/printer when the upper tray runs out of paper.	13
S4	Lower Paper End	Informs the copier/printer when the lower tray runs out of paper.	14
S5	Vertical Transport	Detects misfeeds.	12
S6	Upper Paper Height 1	Detects the amount of paper in the upper tray.	5
S7	Upper Paper Height 2	Detects the amount of paper in the upper tray.	4
S8	Lower Paper Height 1	Detects the amount of paper in the lower tray.	11
S9	Lower Paper Height 2	Detects the amount of paper in the lower tray.	10
Switches			
SW1	Tray Cover	Detects when the tray cover is opened.	8
SW2	Upper Paper Size	Determines what paper size is in the upper tray.	16
SW3	Lower Paper Size	Determines what paper size is in the lower tray.	15
Magnetic Clutches			
MC1	Upper Paper Feed	Starts paper feed from the upper tray.	6
MC2	Lower Paper Feed	Starts paper feed from the lower tray.	9
MC3	Relay	Drives the relay rollers.	7
PCBs			
PCB1	Tray Main	Controls the paper tray unit and communicates with the copier/printer.	1
Others			
H1	Optional Tray Heater	Removes humidity from the paper in the trays.	17


1.5 DRIVE LAYOUT



- | | |
|----------------------------|----------------------------|
| 1. Tray motor | 5. Lower paper feed clutch |
| 2. Drive belt | 6. Relay roller |
| 3. Upper paper feed clutch | 7. Lower paper feed roller |
| 4. Relay clutch | 8. Upper paper feed roller |


2. DETAILED DESCRIPTIONS

2.1 PAPER FEED AND SEPARATION MECHANISM



The paper tray holds 500 sheets. The paper feed roller [A] drives the top sheet of paper from the paper tray to the copier/printer. The friction pad [B] allows only one sheet to feed at a time. The friction pad applies pressure to the feed roller with a spring [C].

2.2 PAPER LIFT MECHANISM



The paper size switch detects when the tray is pushed in.

When the paper tray is pushed into the machine, the pin [A] for the lift motor pressure shaft engages the lift motor coupling [B] and the pin [C] for the bottom plate lift shaft in the tray engages the bottom plate pressure lever coupling [D]. The pin [E] on the rear of the tray pushes the lock lever so that the lift motor can lift the bottom plate pressure lever.

The lift motor turns on, and turns clockwise as viewed on the diagram. The main pressure spring [K] pulls the bottom plate pressure lever, and this lifts the tray bottom plate.

When the top of the stack touches the feed roller, the motor cannot pull up the plate any more, so it pulls the actuator [G] into the lift sensor [F].

The pressure of the feed roller on the paper is now too high, so the lift motor reverses to reduce this pressure. It reverses for 300 ms or 600 ms, depending on the paper size. For smaller paper, it reverses the larger amount (600 ms) to reduce the pressure more.

PAPER LIFT MECHANISM

The paper size thresholds for this feature depend on SP1-908-8, 9, 17, and 18. (Note that there are two paper size thresholds for each tray: small and middle. Some models only use the small threshold.) The amount of reverse depends on SP 1-908-1, 2, 3, 10, 11, and 12. (See the table later in this section for details of how these SP modes work.)


For A4-width paper or wider, a projection [H] on the side fence engages the secondary pressure spring [J] through a lever [I]. Then, the secondary pressure spring [J] applies paper feed pressure in addition to the main pressure spring [K], to ensure that extra pressure is applied to wider paper.

As stated earlier, various SP modes control this mechanism. The following table summarizes them.

No Middle Size Programmed	With Middle Size Programmed
<p>Paper width: Tray 1: More than 1-908-8 Tray 2: More than 1-908-17 (Default: Wider than HLT)</p> <p>Amount of reverse: Tray 1: 1-908-1 Tray 2: 1-908-10 (Default 300 ms)</p>	<p>Paper width: Tray 1: More than 1-908-9 Tray 2: More than 1-908-18</p> <p>Amount of reverse: Tray 1: 1-908-1 Tray 2: 1-908-10</p>
<p>Paper width: Tray 1: 1-908-8 or less Tray 2: 1-908-17 or less (Default: HLT or narrower)</p> <p>Amount of reverse: Tray 1: 1-908-2 Tray 2: 1-908-11 (Default: 600 ms)</p>	<p>Paper width: Tray 1: More than 1-908-8, up to and including 1-908-9 Tray 2: More than 1-908-17, up to and including 1-908-18</p> <p>Amount of reverse: Tray 1: 1-908-3 Tray 2: 1-908-12</p>
	<p>Paper width: Tray 1: 1-908-8 or less Tray 2: 1-908-17 or less</p> <p>Amount of reverse: Tray 1: 1-908-2 Tray 2: 1-908-11</p>

When the paper tray is pulled out, the pins [A, C] disengage from the couplings [B, D], and the bottom plate drops. To make it easier to push the tray in, the lift motor rotates backwards 1.7 seconds to return the bottom plate pressure lever coupling [D] to the original position.

2.3 PAPER END DETECTION




If there is some paper in the paper tray, the paper stack raises the paper end feeler [A] and the paper end sensor [B] is deactivated.

When the paper tray runs out of paper, the paper end feeler drops into the cutout [C] in the tray bottom plate and the paper end sensor is activated.

When the paper tray is drawn out with no paper in the tray, the shape of the paper end feeler causes it to lift up.

2.4 PAPER HEIGHT DETECTION



The amount of paper in the tray is detected by the combination of on/off signals from two paper height sensors [A] and [B].

When the amount of paper decreases, the bottom plate pressure lever [C] moves the actuator up.

The following combination of sensor signals is sent to the copier/printer.

Amount of Paper	Paper Height Sensor 1	Paper Height Sensor 2
Near End	OFF	ON
30%	ON	ON
70%	ON	OFF
100%	OFF	OFF

When the tray contains paper of a small width, the paper feed pressure may become too low when the thickness of the remaining stack of paper has decreased. The lift motor rotates forward 300 ms after the sensor detects a certain amount of paper remaining in the tray to increase paper feed pressure, simulating the pressure generated by a full tray.

PAPER HEIGHT DETECTION

The amount of remaining paper depends on SP modes 1-908-6, 7, 15, and 16. The amount of forward rotation depends on SP1-908-4, 5, 13, and 14. Note that there are two paper size thresholds for each tray: small and middle (this is the same as for the paper lift mechanism described earlier). Some models only use the small threshold. The paper size thresholds depend on SP1-908-8, 9, 17, and 18.


The following table summarizes how these SP modes work.

No Middle Size Programmed	With Middle Size Programmed
<p>Paper width: Tray 1: More than 1-908-8 Tray 2: More than 1-908-17 (Default: Wider than HLT)</p> <p>Amount of forward rotation: None</p>	<p>Paper width: Tray 1: More than 1-908-9 Tray 2: More than 1-908-18</p> <p>Amount of forward rotation: None</p>
<p>Paper width: Tray 1: 1-908-8 or less Tray 2: 1-908-17 or less (Default: HLT or narrower)</p> <p>Amount of remaining paper: Tray 1: 1-908-6 Tray 2: 1-908-15 (Default: When near-end is detected)</p> <p>Amount of forward rotation: Tray 1: 1-908-4 Tray 2: 1-908-13 (Default: 300 ms)</p>	<p>Paper width: Tray 1: More than 1-908-8, up to and including 1-908-9 Tray 2: More than 1-908-17, up to and including 1-908-18</p> <p>Amount of remaining paper: Tray 1: 1-908-7 Tray 2: 1-908-16</p> <p>Amount of forward rotation: Tray 1: 1-908-5 Tray 2: 1-908-14</p>
	<p>Paper width: Tray 1: 1-908-8 or less Tray 2: 1-908-17 or less</p> <p>Amount of remaining paper: Tray 1: 1-908-6 Tray 2: 1-908-15</p> <p>Amount of forward rotation: Tray 1: 1-908-4 Tray 2: 1-908-13</p>

1.5 PAPER SIZE DETECTION

Size	SW	1	2	3	4
A3, F (8 1/2" x 13")		●	●	●	○
A4 Lengthwise		●	○	●	○
A4 Sideways		●	○	○	○
A5 Sideways, 11" x 17"		●	●	○	○
B4, 8 1/2" x 14"		○	●	○	○
B5 Sideways, 8 1/2" x 11"		○	○	○	○
B5 Lengthwise, 11" x 8 1/2"		○	○	●	○
* (Asterisk)		○	○	●	●

●: ON (Not pushed)
○: OFF (Pushed)




There are four paper size microswitches [A] on the front right plate of the paper tray unit. The switches are actuated by a paper size actuator [B] behind the paper size indicator plate, which is on the front right of the tray.

Each paper size has its own actuator, with a unique combination of notches. To determine which size has been installed, the CPU reads which microswitches the actuator has switched off.

The CPU disables paper feed from a tray if the paper size cannot be detected. If the paper size actuator is broken, or if there is no tray installed, the Add Paper indicator will light.

When the paper size actuator is at the "*" mark, the paper tray can be set up to accommodate one of a wider range of paper sizes by using user tools. If the paper size for this position is changed without changing the user tool setting, a paper jam will result.

1.6 SIDE AND END FENCES



Side Fences


If the tray is full of paper and it is pushed in strongly, the fences may deform or bend. This may cause the paper to skew or the side-to-side registration to be incorrect. To correct this, each side fence has a stopper [A] attached to it. Each side fence can be secured with a screw [B], for customers who do not want to change the paper size.

End Fence


As the amount of paper in the tray decreases, the bottom plate [C] lifts up gradually. The end fence [D] is connected to the bottom plate. When the tray bottom plate rises, the end fence moves forward and pushes the back of the paper stack to keep it squared up.

3. REPLACEMENT AND ADJUSTMENT

3.1 FEED ROLLER REPLACEMENT



1. Remove the paper tray [A].
2. Move the release lever [B] to the front.
3. Pull the feed roller [C] to the operation side and remove it.
4. Replace the feed roller.




3.2 TRAY MAIN BOARD REPLACEMENT

1. Remove the rear cover [A] (4 screws).
2. Replace the tray main board [B] (4 screws and 8 connectors).

3.3 TRAY MOTOR REPLACEMENT


1. Remove the rear cover (4 screws).
2. Disconnect 8 connectors from the tray main board [B].
3. Remove the tray main board with the bracket (2 screws).
4. Remove the tray motor [C] (6 screws and 1 connector).

3.4 RELAY CLUTCH REPLACEMENT




1. Remove the rear cover [A] (4 screws).
2. Remove the right cover [B] (2 screws).
3. Remove the snap ring [C].
4. Remove the bushing [D].
5. Remove the stopper bracket [E] (2 screws).
6. Replace the relay clutch [F] (1 connector).

3.5 UPPER PAPER FEED CLUTCH REPLACEMENT




1. Remove the rear cover [A] (4 screws).
2. Remove the bracket [B] (2 screws).
3. Remove the snap ring [C].
4. Remove the bushing [D].
5. Remove the stopper bracket [E] (2 screws).
6. Replace the upper paper feed clutch [F] (1 connector).

3.6 LOWER PAPER FEED CLUTCH REPLACEMENT




1. Remove the rear cover [A] (4 screws).
2. Remove the snap ring [B].
3. Replace the lower paper feed clutch [C].

3.7 LIFT MOTOR REPLACEMENT



1. Pull out the paper tray.
2. Remove the rear cover [A] (4 screws) and the bracket [B] (2 screws).
3. Disconnect the 2P connector [C].
4. Remove the spring [D].
5. Remove the lift motor unit [E] (3 screws).
6. Remove the lift motor [F] (2 screws).


3.8 PAPER END SENSOR REPLACEMENT



1. Remove the paper tray.
2. Remove the paper end sensor bracket [A] (1 screw and 1 connector).
3. Replace the paper end sensor [B].


NOTE: After replacing the sensor, pull the sensor cable towards the right side of the frame [C] so that it does not touch the paper in the tray.

3.9 VERTICAL TRANSPORT SENSOR REPLACEMENT



1. Open the right door [A].
2. Remove the right guide plate [B] (2 screws).
3. Remove the vertical transport sensor bracket [C] (1 screw and 1 connector).
4. Replace the vertical transport sensor [D].

3.10 PAPER SIZE SWITCH REPLACEMENT



1. Remove the upper and lower paper trays.
2. Remove the inner cover [A] (2 screws).
3. Replace the paper size switch [B] (1 connector).


LCT
A862/B391

1. OVERALL MACHINE INFORMATION

1.1 SPECIFICATIONS


Paper Size:	A4 sideways/LT sideways
Paper Weight:	60 g/m ² ~ 105 g/m ² , 16 lb ~ 28 lb
Tray Capacity:	2,000 sheets (80 g/m ² , 20lb)
Remaining Paper Detection:	5 steps (100%, 75%, 50%, 25%, Near end)
Power Source:	24 Vdc, 5 Vdc (from copier/printer)
Power Consumption:	26 W (Max.)/14 W (Ave.)
Weight:	25 kg (55 lbs)
Size (W x D x H):	550 mm x 520 mm x 271 mm

1.2 MECHANICAL COMPONENT LAYOUT



- | | |
|-----------------------|---------------------------------|
| 1. Pick-up Roller | 7. Paper Height Sensors 1, 2, 3 |
| 2. Upper Limit Sensor | 8. Lower Limit Sensor |
| 3. Paper Feed Roller | 9. Left Paper End Sensor |
| 4. Relay Sensor | 10. Paper Height Sensors 4,5 |
| 5. Relay Roller | |
| 6. Reverse Roller | |

1.3 ELECTRICAL COMPONENT LAYOUT



- | | |
|------------------------------------|-------------------------------------|
| 1. Main Board | 12. Paper Height Sensors 1, 2, 3 |
| 2. Tray Sensor (Switch) | 13. Lower Limit Sensor |
| 3. Relay Clutch | 14. Side Fence Solenoid |
| 4. Paper Feed Clutch | 15. Rear Fence Return Sensor |
| 5. Tray Motor | 16. Rear Fence Motor |
| 6. Tray Lift Motor | 17. Rear Fence Home Position Sensor |
| 7. Tray Heater (option) | 18. Left Tray Paper End Sensor |
| 8. Right Tray Paper End Sensor | 19. Paper Height Sensors 4, 5 |
| 9. Upper Limit Sensor | 20. Right Cover Switch |
| 10. Relay Sensor | |
| 11. Side Fence Open/Closed Sensors | |


ELECTRICAL COMPONENT DESCRIPTIONS

1.4 ELECTRICAL COMPONENT DESCRIPTIONS

Symbol	Name	Function	Index No.
Motors			
M1	Tray Motor	Drives all rollers.	5
M2	Tray Lift Motor	Drives the paper tray up or down.	6
M3	Rear Fence Motor	Moves the rear fence to transfer the paper stack from the paper storage (left) side of the tray to the paper feed (right) side.	16
Sensors			
S1	Right Tray Paper End	Informs the copier/printer when the paper in the right side (paper feed side) of the tray has been used up. If there is a paper stack in the left side (paper storage side), this is moved into the right tray. If there is no paper stack in the left side, paper end is indicated.	8
S2	Relay	Detects the copy paper coming to the relay roller and checks for misfeeds.	10
S3	Upper Limit	Detects when the paper is at the correct paper feed height.	9
S4	Lower Limit	Detects when the tray is completely lowered, to stop the LCT motor.	13
S5	Paper Height 1, 2, 3	Detects the amount of paper remaining in the right side of the tray.	12
S6	Paper Height 4, 5	Detects the amount of paper remaining in the left side of the tray.	19
S7	Rear Fence Home Position	Detects when the rear fence is at H.P.	17
S8	Tray (Switch)	Detects whether the tray is correctly set.	2
S9	Side Fence Open/Closed	Detects whether the side fence is opened on closed.	11
S10	Rear Fence Return	Detects when the rear fence has moved the paper stack from the left side to the right side.	15
S11	Left Tray Paper End	Informs the copier/printer when there is no paper in the left side (paper storage side) of the tray.	18
Solenoids			
SOL1	Side Fence	Controls open-close movement of the side fence.	14
Magnetic Clutches			
MC1	Paper Feed	Drives the paper feed roller.	4
MC2	Relay	Drives the relay roller.	3
PCBs			
PCB1	Main	Controls the LCT and communicates with the copier/printer.	1
Switches			
SW1	Right Cover	Detects whether the right cover is open.	20

2. DETAILED SECTION DESCRIPTIONS

2.1 PAPER FEED




This products uses an FRR type paper feed mechanism.

The paper feed unit consists of the pickup roller [A], paper feed roller [B], reverse roller [C], and grip and transport rollers.

There is a torque limiter in the back of the reverse roller (ferrite powder type).

2.2 REVERSE ROLLER AND PICK-UP ROLLER RELEASE




To prevent the paper from being torn when pulling out the paper feed tray, the reverse and pickup rollers are set so that they release automatically.

When the paper tray [A] is not inside the machine, the reverse roller [B] is away from the paper feed roller [C] and the pick-up roller [D] stays in the upper position.

When the paper tray is set into the machine, it pushes the release lever [E]. This causes the pick-up roller [D] to go down into contact with the top sheet of paper and the reverse roller [B] to move up and contact the paper feed roller.

2.3 TRAY LIFT



When the paper feed tray is put in the machine, the tray switch [A] on the back face turns on and the tray lift motor [B] starts up. The base plate lift shaft [C] is coupled to the lift motor at shaft [D], so the base plate of the tray is lifted. After a short while, the top of the paper stack contacts the pick-up roller and lifts it up.

When this occurs, the actuator enters the upper limit sensor, the sensor turns off and the lift motor stops. When paper in the tray is used up, the pick-up roller is gradually lowered, and the actuator leaves the upper limit sensor (turning the sensor on). When this happens, the lift motor begins turning again. The tray will then be lifted until the actuator enters the upper limit sensor (turning the sensor off again).

When the tray is removed from the copier, the coupling between the lift motor [B] and base plate lift shaft [C] is broken and the base plate goes into a controlled free fall (using a damper [E] to slow the fall and prevent damage).

2.4 NEAR END/END DETECTION

This tray can hold two stacks of paper, so the machine needs to monitor the status of both these stacks. There are seven sensors to do this.

In the right tray (paper feed side), three height sensors measure the height of the stack, and an end sensor detects when all the paper is used up. As the amount of paper remaining in the tray decreases, the base plate rises and the actuator activates the paper height sensors. When paper runs out in the right tray, the stack in the left tray is moved across to the right tray.

There are also two height sensors ([F] in the diagram on the previous page) and an end sensor in the left tray (paper storage side) ([G] in the diagram on the previous page). When there is no paper in both trays, paper end is detected.


The machine determines the amount of remaining paper based on the sensor outputs, as shown in the following table.

Paper end sensor 1: ○ = Low (no paper), ● = High (paper present)
 Other sensors: ○ = Low (paper present), ● = High (no paper)


	Amount of paper								
	100%	75%		50%					
Paper Height Sensor 1	○	○	○	○	○	○	●	○	○
Paper Height Sensor 2	○	○	○	○	○	●	–	○	●
Paper Height Sensor 3	○	○	●	○	○	–	–	●	–
Paper End Sensor 1	●	●	●	●	●	●	●	●	●
Paper Height Sensor 4	○	●	○	●	●	○	○	●	●
Paper Height Sensor 5	○	○	○	●	●	○	○	○	○
Paper End Sensor 2	○	○	○	○	●	○	○	○	○

	Amount of paper							
	25%				Near-end		End	
Paper Height Sensor 1	●	○	○	○	○	●	●	–
Paper Height Sensor 2	–	–	●	○	●	–	–	–
Paper Height Sensor 3	–	–	–	●	–	–	–	–
Paper End Sensor 1	●	●	●	●	●	●	●	○
Paper Height Sensor 4	○	●	●	●	●	●	●	●
Paper Height Sensor 5	●	○	●	●	●	●	●	●
Paper End Sensor 2	○	○	○	●	●	○	●	●

The following diagram is the sensor layout, as viewed from the front.



1.5 RIGHT TRAY SIDE FENCE



When the paper in the right tray is used up, the side fence solenoid [F] activates and stays on until the side fence open/closed sensor [E] detects that the fence is open. The rear fence [A] then moves the stack of paper from the left tray into the right tray, as described in the following section. When the stack has been transferred to the right tray, the rear fence return sensor [G] detects the rear fence and then the cpu turns off the side fence open solenoid (closing the side fence).


The side fence open/closed sensor [D] detects when the side fence is closed. When it is not closed, the user is prompted at the operation panel to free the mechanism.

1.6 LEFT TRAY REAR FENCE

If the right tray paper end sensor detects that there is no paper in the tray (while the left tray sensor detects that there is still paper in the left tray), the right side fence [C] opens and the rear fence motor [H] turns on. The rear fence of the left tray moves and the paper stack is then transferred from the left tray to the right tray.

When the left tray rear fence activates the rear fence return sensor, the machine detects that the paper stack has been transferred to the right tray and the rear fence motor rotates in the opposite direction. When the rear fence HP sensor [B] comes on, the motor stops.

1.7 RIGHT TRAY PAPER END DETECTION



The paper end sensor [A] detects when copy paper in the right tray runs out.

When there is paper in the tray, the paper pushes up the paper end feeler [B] and causes the actuator to come between the LED and photo diode of the sensor. When paper runs out, the feeler drops and the actuator leaves the photointerruptor, and the machine detects that there is no paper in the tray.


When the tray is being pulled out, the lever [E] lifts the pick-up roller and this also lifts up the feeler.

3. REPLACEMENT AND ADJUSTMENT


3.1 DETACHING THE TRAY FROM THE MAINFRAME

While pressing the stopper attached to the guide rail, pull out the large capacity tray.

NOTE: When reinstalling the tray, set the tray on the guide rail and carefully push the tray in, making sure to keep the tray level.




3.2 REAR FENCE HP SENSOR



1. Pull out the large capacity tray.
2. Remove the left tray rear side fence [A] (2 screws).
3. Remove the rear fence bracket [B] (1 screw).
4. Remove the connector of the rear fence HP sensor.
5. Replace the rear fence HP sensor [C] (1 screw).

NOTE: When securing the sensor in place, be sure to fasten the screw in the proper position.


3.3 CHANGING THE TRAY PAPER SIZE



1. Remove the screws of all side fences [A], [B].
2. The position of the rear fence HP sensor can then be changed (see Rear Fence HP Sensor Removal).
3. The paper size display can then be changed with an SP mode.



NOTE: When securing the right tray side fence, fasten the screw after setting the paper in the right tray and adjusting the fence to the width of the paper.

3.4 LEFT TRAY PAPER END SENSOR




1. Pull out the large capacity tray.
2. Remove the left tray side fence [A] (2 screws).
3. Remove the rear fence bracket [B] (1 screws).
4. Replace the left tray paper end sensor [C] (1 connector).

3.5 TRAY LIFT MOTOR




1. Remove the brackets (1 screw for each).
2. Remove the rear cover [A] (2 screws).
3. Remove the tray lift motor [B] (3 screws, 1 connector).

3.6 TRAY MOTOR



1. Remove the rear cover.
2. Remove bracket #1 [A] (2 screws).
3. Remove bracket #2 [B] (2 screws).
4. Remove the tray motor [C] (6 screws, 1 connector).


3.7 PAPER FEED CLUTCH AND RELAY CLUTCH



1. Remove the rear cover.
2. Remove bracket #1 [A] (2 screws).
3. Remove bracket #2 [B] (2 screws).
4. Remove all bushings.
5. Remove the paper feed clutch [C] and relay clutch [D].
6. Replace the required clutch.


NOTE: Make sure to properly secure both clutches before completing installation.

3.8 PAPER FEED UNIT



1. Remove the paper feed clutch and relay clutch (see Paper Feed Clutch and Relay Clutch Replacement).
2. Remove pulleys A [A], B [B], and C [C].
3. Remove the paper feed harness from the main board.
4. Open the vertical transport guide plate [D].
5. Remove the paper feed unit [E] (2 screws).


3.9 UPPER LIMIT, RIGHT TRAY PAPER END, AND RELAY SENSORS



1. Remove the paper feed unit (see Paper Feed Unit Replacement).
2. Replace the required sensor.
 - Upper limit [A]
 - Relay [B]
 - Right tray paper end [C]


NOTE: When replacing the upper limit [A] and paper end sensor [C], please be sure to do so while pushing the release lever [D].

3.10 REAR FENCE MOTOR



1. Pull out the paper feed tray unit.
2. Remove the paper feed tray front cover [A] (2 screws).
3. Remove the left side fence [B].
4. Remove the rear fence drive gear [C] (1 screw). This is in order to free the end fence [D].
5. Move the end fence to the right (toward the center).
6. Remove the end fence (1 screw).
7. Remove the end fence bracket [E] (2 screws).
8. Remove the bracket [F] (1 screw).
9. Remove the bracket [G] of the rear fence motor assembly (2 screws).
10. Remove the rear fence motor assembly (2 screws).
11. Replace the motor [H] (1 connector).

3.11 PICK-UP/PAPER FEED/REVERSE ROLLERS



1. Remove the paper tray unit (see Paper Tray Unit Replacement).
2. Remove the snap ring (1 each for the paper feed and reverse rollers).
3. Remove the pick up roller [A].
4. Replace each roller [B], [C].

NOTE: Install the paper feed rollers the correct way round, as shown in the illustration. If the rollers are installed incorrectly, this will cause the one-way clutch to lock.


**AUTO REVERSE DOCUMENT FEEDER
B386**

1. OVERALL MACHINE INFORMATION

1.1 SPECIFICATIONS


Original Size:	Standard sizes Single-sided mode: A3 to A5, DLT to HLT Double-sided mode: A3 to A4, DLT to LT Non-standard sizes (Single-sided mode only) Max. width 297 mm Min. width 105 mm Max. length 1260 mm Min. length 128 mm
Original Weight:	Single-sided mode: 52~128 g/m ² , 14~34 lb Double-sided mode: 52~105 g/m ² , 14~28 lb
Table Capacity:	30 sheets (70 kg)
Original Standard Position:	Center
Separation:	FRR
Original Transport:	Roller transport
Original Feed Order:	From the top original
Reproduction Range:	25 to 200 % (Sub scan direction only)
Power Source:	24 & 5 Vdc from the copier
Power Consumption:	50 W
Dimensions (W x D x H):	550 x 470 x 110 mm
Weight:	10 kg

1.2 MECHANICAL COMPONENT LAYOUT



- | | |
|----------------------------------|-----------------------------|
| 1. Separation Roller | 11. Reverse Roller |
| 2. Paper Feed Belt | 12. Junction Gate |
| 3. Pick-up Roller | 13. Exit Roller |
| 4. Original Set Sensor | 14. Original Exit Sensor |
| 5. Original Trailing Edge Sensor | 15. Stamp |
| 6. Original Width Sensor Board | 16. 2nd Transport Roller |
| 7. Original Length Sensor 1 | 17. Original Exposure Guide |
| 8. Original Length Sensor 2 | 18. Registration Sensor |
| 9. Original Table | 19. 1st Transport Roller |
| 10. Reverse Table | |

1.3 ELECTRICAL COMPONENT LAYOUT




Auto Reverse
Document
Feeder
B386

- | | |
|--------------------------------|-----------------------------------|
| 1. DF Feed Clutch | 10. DF Feed Motor |
| 2. Feed Cover Open Sensor | 11. DF Transport Motor |
| 3. Original Width Sensor Board | 12. Original Exit Sensor |
| 4. Original Length Sensor 1 | 13. Stamp Solenoid |
| 5. DF Pick-up Solenoid | 14. Original Trailing Edge Sensor |
| 6. Original Length Sensor 2 | 15. Original Set Sensor |
| 7. Junction Gate Solenoid | 16. Original Reverse Sensor |
| 8. DF Drive PCB | 17. Registration Sensor |
| 9. DF Position Sensor | |

1.4 ELECTRICAL COMPONENT DESCRIPTION

Symbol	Name	Function	Index No.
Motors			
M1	DF Feed	Drives the feed belt, separation, pick-up, and reverse table rollers.	10
M2	DF Transport	Drives the transport and exit rollers	11
Sensors			
S1	DF Position	Detects when the DF is lifted.	9
S2	Registration	Detects the leading edge of the original to turn off the DF feed and transport motors, detects the original exposure timing, and checks for original misfeeds.	17
S3	Feed Cover Open Sensor	Detects when the feed-in cover is opened.	2
S4	Original Width Sensor Board	Detects the original width.	3
S5	Original Length - 1	Detects the original length.	4
S6	Original Length - 2	Detects the original length.	6
S7	Original Set	Detects if an original is on the feed table.	15
S8	Original Exit	Detects the leading edge of the original to turn on the junction gate solenoid and checks for original misfeeds. Detects the trailing edge of the original to turn off the transport and feed motor and junction gate solenoid. In single-sided mode, used to detect original misfeeds.	12
S9	Original Trailing Edge	Detects the trailing edge of the last original to stop copy paper feed and to turn off the transport motor, and checks for original misfeeds.	14
S10	Original Reverse Sensor	Detects when the original is fed from the reverse area during duplex scanning.	16
Solenoids			
SOL1	DF Pick-up	Controls the up-down movement of the original table.	5
SOL2	Stamp	Energizes the stamper to mark the original.	13
SOL3	Junction Gate	Opens and closes the junction gate.	7
Clutches			
MC1	DF Feed	Transfers transport motor drive to the pick-up roller and feed belt.	1
PCBs			
PCB1	DF Drive	Interfaces the sensor signals with the copier, and transfers the magnetic clutch, solenoid and motor drive signals from the copier.	8

1.5 DRIVE LAYOUT




Auto Reverse
Document
Feeder
B386

- | | |
|-----------------------|--------------------------|
| 1. Separation Roller | 6. DF Feed Motor |
| 2. Original Feed Belt | 7. Reverse Table Roller |
| 3. Pick-up Roller | 8. 2nd Transport Roller |
| 4. DF Feed Clutch | 9. Exit Roller |
| 5. DF Transport Motor | 10. 1st Transport Roller |

2. DETAILED SECTION DESCRIPTIONS

2.1 ORIGINAL SIZE DETECTION



The original size detection mechanism consists of the original width sensor board [A] and two original length sensors-1 [B] and -2 [C]. Based on the combined output of the length sensors and the width sensor board, the machine can detect the size of the original. This integrated detection mechanism is detailed in the table on the next page.

Note that the width sensor's terminal plate is attached to the original guide, so the widths of the originals must all be the same.

	NA	EU	Original Width-1	Original Width-2	Original Width-3				Original Length-1	Original Length-2
					P4	P3	P2	P1		
A3 (297 x 420)	X	○	L	L	ON	—	—	—	ON	ON
B4 (257 x 364)	X	○	L	H	—	ON	—	—	ON	ON
A4 (Lengthwise) (210 x 297)	X	○	H	L	—	—	ON	—	ON	—
A4 (297 x 210) (Sideways)	X	○	L	L	ON	—	—	—	—	—
B5 (182 x 257) (Lengthwise)	X	○	H	H	—	—	—	ON	ON	—
B5 (257 x 182) (Sideways)	X	○	L	H	—	ON	—	—	—	—
A5 (148 x 210) (Lengthwise)	X	X	H	H	—	—	—	ON	—	—
A5 (210 x 148) (Sideways)	X	○	H	L	—	—	ON	—	—	—
11" x 17" (DLT)	○	X	L	L	ON	—	—	—	ON	ON
11" x 15"	○	X	L	L	ON	—	—	—	ON	ON
10" x 14"	○	X	L	H	—	ON	—	—	ON	—
8.5" x 14" (LG)	○	X	H	L	—	—	ON	—	ON	—
8.5" x 13" (F4)	X	○	H	L	—	—	ON	—	ON	—
8" x 13" (F)	○	○	H	L	—	—	ON	—	ON	—
8.5" x 11" (Lengthwise)	○	X	H	L	—	—	ON	—	ON	—
8.5" x 11" (Sideways)	○	X	L	L	ON	—	—	—	—	—
10" x 8" (Lengthwise)	○	X	L	H	—	ON	—	—	ON	—
5.5" x 8.5" (Lengthwise) (HLT)	○	X	H	H	—	—	—	ON	—	—
5.5" x 8.5" (Sideways) (HLT)	○	X	H	L	—	—	ON	—	—	—

Key

X: No, ○: Yes


ON: Paper present

NA: North America, EU: Europe

- NOTE:** 1) P1-P4 represent the four positions on the width sensor board. ON indicates the presence of the terminal plate in a given position. "Original Width-1" and "Original Width-2" are the outputs from the sensor board to the DF main board. The state of these outputs (L or H) depends on the position of the terminal plate on the sensor board (P1, P2, P3, or P4). For example, if the terminal plate is at P4, both outputs are L.
- 2) A reading of "L" on either of the width sensor outputs indicates that the terminal plate is connecting the GND pattern with the width sensor output signal line.
- 3) The machine cannot detect more than one size of originals in the same job.

ORIGINAL SIZE DETECTION

Original Width Sensor Board



The signal is "L" when the terminal plate is connected to the GND pattern.

1.2 MIXED ORIGINAL SIZE MODE

This section explains what happens when the user selects mixed original size mode.

Because this ADF is a sheet-through document feeder, the method for original document width detection is the same as when the originals are the same size, but the document length detection method is different. Therefore, the scanning speed is slightly slower.

Document length detection

From when the registration sensor switches on until it switches off, the CPU counts the transport motor pulses. The number of pulses determines the length of the original.

Feed-in cycle

When the original size for the copy modes listed below cannot be determined, the image cannot be correctly scaled (reduced or enlarged) or processed until the original's length has been accurately detected. The length must be determined before the image is scanned.

- Auto Reduce/Enlarge
- Centering
- Erase Center/Border
- Booklet
- Image Repeat


The originals follow this path:

1. Length detection → Scanning glass → Inverter table
2. Inverter table → Scanning glass → Inverter table (restores the original order)
3. Inverter table → Scanning glass (image scanned) → Exit tray

Normal feed-in

In a copy mode other than those listed above, when the reduction/enlargement ratio has been determined, the originals are scanned normally. In order to store the scanned images, a large area of memory (the detected original width x 432 mm length) is prepared. Next, only the portion of the image up to the detected original length is read from memory and printed.

1.3 PICK-UP AND SEPARATION



The original is set with the image facing up. The original pushes actuator [A] and the original set sensor [E] is activated.


After pressing the start button, the pick-up solenoid [D] is activated and the lift plate [C] lifts the original up until it comes in contact with the pick-up roller [B]. The pick-up roller then feeds the top sheet of paper.

After being fed from the pick-up roller, the topmost sheet is separated from the stack by the separation roller and sent to the first transport roller.

The mechanism is an FRR system, consisting of the original feed belt [F] and separation roller [G].


1.4 ORIGINAL TRANSPORT AND EXIT

1.4.1 SINGLE-SIDED ORIGINALS



The DF feed motor feeds the separated original to the first transport roller [A] at maximum speed. When the registration sensor [B] detects the leading edge, the motor stops for a short while. Then the feed and transport motors turn on again, and feed the original through scanning area at a lower speed (the scanning area contains the original exposure guide [D] and DF exposure glass [C]). After scanning, the original is fed out by the second transport roller [E] and exit roller [F].


1.4.2 DOUBLE-SIDED ORIGINALS



When the registration sensor [B] detects the leading edge of the original, the DF feed motor (which drives the feed roller) and transport motor (which drives the transport roller) both switch off. After a brief interval, the transport motor alone reactivates to drive the first [A] and second transport roller [G] and the exit roller [F]. The front side of the original is then scanned.

When the original exit sensor [C] detects the leading edge of the original, the junction gate solenoid is activated and the junction gate [D] opens. The original is then transported towards the reverse table [H].

Soon after the trailing edge of the original passes the exit sensor [C], the junction gate solenoid switches off and the junction gate [D] is closed. When the original has been fed onto the reverse table, the DF feed motor switches on in reverse. The original is then fed by the reverse roller [E] and then by the exit roller [F] and first transport roller [A] to the scanning area (where the reverse side will be scanned).




The original is then sent to the reverse table [H] a second time to be turned over. This is done so that the duplex copies will be properly stacked front side down in the exit tray [J] in the correct order.

1.4.3 ORIGINAL TRAILING EDGE SENSOR

During one-to-one copying, copy paper is fed to the registration roller in advance (while the original is still being scanned), to increase the copy speed. The trailing edge sensor monitors the stack of originals in the feeder, and detects when the trailing edge of the last page has been fed in. The main CPU then stops the copier from feeding an unwanted extra sheet of copy paper.

STAMP

1.5 STAMP



This function is only for fax mode.


There is a stamp [A] between the 2nd transport roller [B] and the exit roller [C], and its solenoid is controlled by the copier directly.

When the original reaches the stamp position, the DF feed motor stops. At 300 milliseconds after stopping the DF feed motor, the stamp solenoid turns on if the page was sent successfully (immediate transmission) or stored successfully (memory transmission). After stamping, the DF feed motor starts again to feed out the document, and its speed is about 1.3 times the normal speed.

The stamping position on the original can be changed by adjusting SP6-010.

1.6 TIMING CHART

LT SIDEWAYS STAMP MODE (DOUBLE-SIDED ORIGINAL MODE)




Auto Reverse
Document
Feeder
B386

1.7 CONDITION OF JAM DETECTION

- JAM 1A:** If the registration sensor does not turn on within 114 mm x 2 since the feed motor started (twice the distance between the original set position and the (registration sensor)).
- JAM 1B:** Duplex mode only: If the registration sensor does not turn on within 161 mm x 1.5 since the feed motor started (1.5 times the distance between the original reverse position and the registration sensor).
- JAM 2:** If the registration sensor does not turn off within 1260 mm x 1.1 since the feed motor started (1.1 times the distance between the paper stop position at registration and the maximum original length).
- JAM 3:** If the original exit sensor does not turn on within 92 mm x 1.5 since the feed motor started (1.5 times the distance between registration sensor and exit sensor)
- JAM 4:** If the original exit sensor does not turn off within original length + 120 mm since the transport motor started after the exit sensor turns on
- JAM 5:** Duplex mode only: If the original reverse sensor does not turn on within 161 mm x 1.4 since the feed motor started (1.4 times the distance between the original reverse position and the registration sensor).
- JAM 6:** If the feeding original is removed.
- JAM 7:** If the cover is opened or the ADF is lifted while the ADF is in operation.
- JAM 8:** If an area outside the maximum scannable area is selected.
- JAM 9:** If scanning of the previous original is not completed when the registration sensor detects the leading edge of the current original.

1.8 OVERALL ELECTRICAL CIRCUIT

The DF CPU controls the transport motor, DF feed motor, DF feed clutch, junction Gate solenoid, stamp solenoid, and pick-up solenoid. The DF CPU also monitors all DF sensors and provides updated status information when prompted at regular intervals by the mainframe, which may then take action based on this information. The DF-mainframe connection is checked automatically just after power is supplied to the mainframe.



Auto Reverse
 Document
 Feeder
 B386


3. SERVICE TABLES

3.1 DIP SWITCHES

SW100				Description
1	2	3	4	
0	0	0	0	Normal operating mode (Default)
0	0	0	1	No function
0	0	1	0	Free run with two-sided original 100%
0	0	1	1	DF feed clutch operates
0	1	0	0	Free run with one-sided original 32.6%
0	1	0	1	DF pick-up solenoid operates
0	1	1	0	Motors rotate
0	1	1	1	No function
1	0	0	0	Free run with one-sided original 100%
1	0	0	1	Junction gate solenoid operates
1	0	1	0	Free run without two-sided original 100%
1	0	1	1	No function
1	1	0	0	Free run without one-sided original 100%
1	1	0	1	Stamp solenoid operates
1	1	1	0	Free run with two-sided original 32.6%
1	1	1	1	Free run without two-sided original 100%


4. REPLACEMENT AND ADJUSTMENT

4.1 DF EXIT TABLE AND COVER




1. Open the DF feed cover.
2. Remove the front cover [A] (3 screws).
Remove the rear cover [B] (3 screws).
3. Open the reverse table [C].
Remove the original exit table [D] (3 screws).

4.2 ORIGINAL FEED UNIT



1. Open the left cover.
2. Detach the paper feed unit by sliding it toward the front of the machine (spring-loaded side) and then lifting the far side.


4.3 LEFT COVER



1. Remove the front and rear covers.
2. Remove the left cover [A].
3. Remove the lower left stay unit [B] (2 screws).


PICK-UP ROLLER

4.4 PICK-UP ROLLER



1. Remove the original feed unit.
2. Replace the pick-up roller [A] (1 snap ring).


4.5 FEED BELT



1. Remove the original feed unit.
2. Open the paper feed guide [A].
3. Remove the belt holders [B].
4. Replace the feed belt [C].


SEPARATION ROLLER

4.6 SEPARATION ROLLER



1. Lift the original feed guide [A].
2. Remove the separation roller cover [B].
3. Replace the separation roller [C].



4.7 ORIGINAL SET/ORIGINAL REVERSE SENSOR



Auto Reverse
Document
Feeder
B386


1. Open the left cover.
2. While pushing the left and right pawls [A], open the original feed guide plate [B].
3. Remove the original set sensor [C]
4. Remove the original reverse sensor [D].

4.8 ORIGINAL SIZE SENSOR




1. Open the original table [A].
2. Remove the upper part of the table (3 screws).
3. Replace the width sensor board [B], length sensor (-1 [C] and -2 [D]) and trailing edge sensor [E].

NOTE: To ensure proper detection of paper size, after wiping off the sensor board and terminal plate with a dry cloth (or cloth with alcohol), apply silicone grease (KS-660) to the terminal plate [F].



4.9 ORIGINAL FEED DRIVE



First remove the rear cover. Then follow the instructions below for each part replacement:

DF Feed Clutch

1. Replace the DF feed clutch [A] (1 E-ring, 1 connector).

Pick-up Solenoid

1. Replace the pick-up solenoid [B] (3 screws, 1 snap ring, 1 connector).


Transport Motor

1. Remove the bracket [C] (2 screws).
2. Replace the transport motor [E] (2 screws, 1 connector).

DF Feed Motor



1. Remove the bracket [C] (2 screws).
2. Replace the DF feed motor [D] (2 screws, 1 connector).

4.10 REGISTRATION SENSOR



1. Remove the front and rear covers.
2. Remove the transport guide plate [A].
3. Replace the registration sensor [B].

4.11 STAMP SOLENOID AND ORIGINAL EXIT SENSOR



1. Remove the rear cover (1 connector). Also remove the upper cover (the exit tray).
2. Open the exit guide plate [A]. Next, detach the unit by inserting a screwdriver or other tool into one of the small openings [B] on either side of the guide plate holder and pushing firmly.
3. Remove the stamp solenoid [C] (1 screw).
4. Remove the original exit sensor [D] (1 connector).

**INTERCHANGE UNIT
B300/B416**


1. OVERALL MACHINE INFORMATION

1.1 SPECIFICATIONS

Paper Size:	Standard sizes A6 lengthwise to A3 HLT to DLT Non-standard sizes Width: 100 to 305 mm Length: 148 to 432 mm
Paper Weight:	52 g/m ² ~ 135 g/m ² , 16 lb ~ 36 lb
Power Consumption:	15 W
Dimensions (W x D x H):	117 x 447 x 92 mm
Weight:	1.6 kg



Interchange
Unit
B300/B416

1.2 MECHANICAL COMPONENT LAYOUT



1. 1-bin Tray (Option)
2. Exit Sensor
3. Duplex Junction Gate
4. Duplex Unit (Option)
5. Exit Junction Gate
6. Fusing Unit (Inside the Copier)
7. Exit Roller
8. Bridge Unit

1.3 DRIVE LAYOUT




- 1. Exit Junction Gate Solenoid
- 2. Exit Sensor
- 3. Duplex Junction Gate Solenoid

- 4. Exit Roller
- 5. Drive Gear

Interchange
 Unit
 B300/B416

2. DETAILED DESCRIPTION

2.1 JUNCTION GATE MECHANISM



Depending on the selected mode, the copies are directed up, left, or right by the exit junction gate [A] and the duplex junction gate [B]. These are controlled by the exit junction gate solenoid [C] and the duplex junction gate solenoid [D].

To the Exit Tray or Bridge Unit (for the Upper Tray on top of the Bridge Unit, or the Finisher)

The exit junction gate solenoid stays off and the paper is directed to the copier exit unit [E].

To the 1-bin Tray


The exit junction gate solenoid turns on and the duplex junction gate solenoid stays off. The paper is directed to the 1-bin tray [F].

To the Duplex Unit

The exit junction gate solenoid and the duplex junction gate solenoid both turn on and the paper is directed to the duplex unit [G].

3. REPLACEMENT AND ADJUSTMENT

3.1 EXIT SENSOR REPLACEMENT



Interchange
Unit
B300/B416

1. Remove the interchange unit.
2. Remove the upper cover [A] of the interchange unit.
3. Remove the exit sensor [B] (1 connector).

**1-BIN TRAY UNIT
A898/B413**


1. OVERALL INFORMATION

1.1 SPECIFICATIONS

Paper Size:	Standard Size: A5 Lengthwise to A3 HLT Lengthwise to DLT Non-standard Size: Paper Width: 90 ~ 297 mm Paper Length: 148 ~ 432 mm
Paper Weight:	60 ~ 105 g/m ² , 16 ~ 28 lbs.
Tray Capacity:	125 sheets (80 g/m ² , 20 lbs.)
Power Source:	5 VDC, 24 VDC (from the copier)
Power Consumption:	17 W
Weight:	1.1 kg
Size (W x D x H):	530 mm x 410 mm x 120 mm


1-Bin Tray
Unit
A898/B413

1.2 MECHANICAL COMPONENT LAYOUT



1. Exit Rollers
2. Junction Gate Gear
3. Drive Gear
4. Paper Tray
5. Paper Sensor
6. Junction Gate (Interchange Unit)

1.3 ELECTRICAL COMPONENT LAYOUT



1. Paper Sensor
2. 1-bin Sorter Exit Tray LED
(located in the copier)


1-Bin Tray
Unit
A898/B413

1.4 ELECTRICAL COMPONENT DESCRIPTION

Symbol	Name	Function	Index No.
Sensors			
S1	Paper	Detects when there is paper on the tray.	1
LEDs			
LED1	1 Bin Exit Tray	Indicates when there is paper in the tray. This sensor is located in the copier.	2

2. DETAILED SECTION DESCRIPTIONS

2.1 BASIC OPERATION



At the appropriate time after the leading edge of the first sheet of copy paper reaches the copier's registration roller, the junction gate solenoid [B] in the interchange unit turns on to switch the junction gate to direct the paper to the tray [C].


The junction gate solenoid turns off at the appropriate time after the paper is directed to the tray. The main motor in the copier stops after the final sheet passes through the paper sensor [E].

The paper sensor [E] turns on when there is paper in the tray, and the paper indicator [F] turns on.

The tray can be opened for easier jam removal by swinging the tray to the left.

3. REPLACEMENT AND ADJUSTMENT

3.1 PAPER SENSOR REMOVAL



1. Remove the 1-bin tray.
2. Remove the 1-bin sorter unit [A].
3. Remove the paper sensor [B] (1 connector).

**SHIFT TRAY UNIT
B313/B459**

1 OVERALL MACHINE INFORMATION


1.1 SPECIFICATIONS

Paper Size:	Standard Size: A5 lengthwise to A3 HLT lengthwise to DLT Non-standard Size: Paper Width: 90 ~ 297 mm Paper Length: 148 ~ 432 mm
Paper Weight:	60 ~ 105 g/m ² , 16 ~ 28 lbs.
Tray Capacity:	125 sheets (80 g/m ² , 20 lbs.): B4 or larger 250 sheets (80 g/m ² , 20 lbs.): A4 or smaller
Power Source:	5 VDC, 24 VDC (from the copier)
Power Consumption:	17 W
Weight:	1.1 kg
Size (W x D x H):	530 mm x 410 mm x 120 mm

Shift Tray
Unit
B313/B459

COMPONENT LAYOUT


1.2 COMPONENT LAYOUT



1. Half Turn Sensor
2. Tray Cover
3. Slip Disc
4. Tray Motor
5. Driver PCB

2. DETAILED SECTION DESCRIPTIONS

2.1 BASIC OPERATION




The shift tray allows copies to be sorted into separate piles on one tray. From the left-right movement of the tray cover [A], the piles of copies are offset into two positions, slightly overlapping one another.

Shift Tray
Unit
B313/B459

2.2 PRIMARY MECHANISMS


2.2.1 TRAY SHIFT



As stated above, the shift tray cover [A] moves from left to right to create two possible positions for the copies to stack up. This motion is driven by the tray motor [B], which connects to the slip disc [C] via a small shaft. The shaft is connected at the rotational center of the disc. However, there is an off-centered white square attached to the top surface of the disc. When the tray cover is attached to the unit, this square fits into a groove [D] (approximately equal to its width) that runs lengthwise along the underside of the tray

When the motor is running, the disc rotation causes the off-centered white square to change position. Since the square only has freedom of movement along the groove [D], the only net motion of the tray is from left to right.

2.2.2 HALF TURN DETECTION




Half turn detection is performed through a combination of two components: the slip disc [A] and half turn sensor [C].

The slip disc has a rim extending below the top surface. However, the rim only extends 180° around the disc. The half turn sensor is below the edge of the disc, opposite the tray motor. The sensor is positioned so that the rim of the disc passes between the LED and photo diode when the disc turns.

While the motor [B] is rotating the disc and moving the tray cover, the disc rim is not between the diode and LED. After the disc has turned its maximum 180°, the rim passes between these two parts and blocks the signal to the LED, stopping the motor. The tray stays in place until the motor is activated again to move the tray across to receive another copy of the original.

3. REPLACEMENT AND ADJUSTMENT

3.1 TRAY COVER REPLACEMENT



3.1.1 TRAY COVER REMOVAL


1. Remove the tray cover [A] by pressing on the two pawls [B] on the left side of the cover.

3.1.2 TRAY COVER ATTACHMENT

NOTE: The right side of the tray cover should be attached first.

1. Fit the pawls [C] (just below the cover fin) around the thin bar [D] on the shift tray.
2. Align the square [E] so that it fits into the groove in the underside of the tray cover and does not interfere with the attachment of the cover.
3. Complete the attachment by inserting the left side pawls [B] into place.

3.2 TRAY MOTOR AND HALF TURN SENSOR REPLACEMENT



3.2.1 REPLACING THE TRAY MOTOR

1. Remove the slip disc [A].
2. Remove the tray motor [B] from the motor holder (1 connector).

3.2.2 REPLACING THE HALF TURN SENSOR:

1. Remove the half turn sensor [C] (1 connector).


BY-PASS
A899/B415

1 OVERALL MACHINE INFORMATION

1.1 SPECIFICATIONS


Paper Size:	Standard sizes A6 lengthwise to A3 HLT lengthwise to DLT Non-standard sizes Width: 90 to 305 mm Length: 148 to 432 mm
Paper Weight:	52 g/m ² ~ 157 g/m ² , 16 lb ~ 42 lb
Tray Capacity:	50 sheets (80 g/m ² , 20 lb)
Paper Feed System:	Friction Pad Paper Feed

1.2 MECHANICAL COMPONENT LAYOUT



1. Paper Feed Roller
2. Paper End Sensor
3. Paper Size Sensor Board

1.3 ELECTRICAL COMPONENT LAYOUT




- 1. Paper End Sensor
- 2. Paper Feed Clutch
- 3. Paper Size Sensor Board

1.4 ELECTRICAL COMPONENT DESCRIPTION

Symbol	Name	Function	Index No.
Sensors			
S1	Paper End	Informs the copier/printer when the by-pass tray runs out of paper.	1
S2	Paper Size Sensor Board	Detects the paper width.	3
Magnetic Clutches			
MC1	Paper Feed	Starts paper feed from the by-pass tray.	2

2 DETAILED DESCRIPTIONS


2.1 BASIC OPERATION



The by-pass unit uses a friction pad paper feed mechanism. The transport roller gear in the main copier/printer drives the gear on the paper feed clutch [B] through a series of gears.

When paper is placed in the tray, the paper end sensor [C] switches off. When the Start button is pressed, the paper feed clutch [B] is activated and the paper feed roller [A] feeds the paper one sheet at a time.


2.2 PAPER SIZE DETECTION



The paper size sensor board [B] monitors the paper width. The rear side fence [A] is connected to the terminal plate. The pattern for each paper width is unique. Therefore, the copier/printer determines which paper has been placed in the by-pass tray by the signal output from the board. However, the copier will not determine the paper length from the by-pass tray hardware (refer to Original Size Detection in the manual for the base copier for details on how paper length is determined).


3 REPLACEMENT AND ADJUSTMENT

3.1 PAPER FEED ROLLER/FRICTION PAD/PAPER END SENSOR



1. Remove the upper cover [A] (2 screws).
2. Remove the paper end sensor bracket [B] (1 screw).
3. Remove the paper feed roller [C] (snap-fit).
4. If removing the friction pad [D], do so at this time.


3.2 PAPER SIZE SENSOR BOARD



1. Remove the rear cover [A] (2 screws).
2. Remove the by-pass tray [B] (1 connector, 2 release levers [C]).
3. Remove the lever [D] (1 snap ring, 1 pin).
4. While pushing the release lever [E], remove the paper tray [F].
5. Remove the by-pass width sensor [G].

NOTE: When installing the by-pass width sensor [G], move the side fence inward all the way so that the seal on the side face gear faces the surface with the seal [H] on the by-pass width sensor.

3.3 PAPER FEED CLUTCH



1. Remove the rear cover [A] (2 screws).
2. Remove the spring.
3. Remove the drive gear and drive gear bracket [B] (1 E-ring, 1 spring).
4. Remove the paper feed clutch bracket [C] (2 screws).
5. Remove the paper feed clutch [D] (1 connector).


DUPLEX
A896/B414

1. OVERALL MACHINE INFORMATION

1.1 SPECIFICATIONS


Paper Size:	Standard sizes A5 lengthwise to A3 HLT to DLT Non-standard sizes Width: 140 to 297 mm Length: 182 to 432 mm
Paper Weight:	64 g/m ² ~ 105 g/m ² , 20 lb ~ 28 lb
Tray Capacity:	1 sheet
Power Consumption:	40 W
Power Source:	DC 24 V, 5 V
Dimensions (W x D x H):	90 x 495 x 452 mm
Weight:	6 kg

1.2 MECHANICAL COMPONENT LAYOUT



- | | |
|---------------------------|----------------------------|
| 1. Inverter Gate | 5. Middle Transport Roller |
| 2. Entrance Sensor | 6. Lower Transport Roller |
| 3. Inverter Roller | 7. Exit Sensor |
| 4. Upper Transport Roller | |

1.3 ELECTRICAL COMPONENT LAYOUT




- | | |
|---------------------------|----------------------------|
| 1. Entrance Sensor | 5. Transport Motor |
| 2. Inverter Gate Solenoid | 6. Exit Sensor |
| 3. Inverter Motor | 7. Duplex Unit Open Switch |
| 4. Main Board | |

1.4 ELECTRICAL COMPONENT DESCRIPTION

Symbol	Name	Function	Index No.
Motors			
M1	Inverter	Drives the inverter roller.	3
M2	Transport	Drives the upper and lower transport rollers.	5
Sensors			
S1	Entrance	Detects the trailing edge of the copy paper to turn on the inverter gate solenoid and turn on the inverter motor in reverse. Checks for misfeeds.	1
S2	Exit	Checks for misfeeds.	6
Switches			
SW1	Duplex Unit Open	Detects whether the duplex unit is opened or not.	7
Solenoids			
SOL1	Inverter Gate	Controls the inverter gate.	2
PCBs			
PCB1	Main	Controls the duplex unit and communicates with the copier.	4

1.5 DRIVE LAYOUT



- | | |
|---------------------------|----------------------------|
| 1. Inverter Roller | 4. Transport Motor |
| 2. Inverter Motor | 5. Lower Transport Roller |
| 3. Upper Transport Roller | 6. Middle Transport Roller |

Duplex
A896/B414

2. DETAILED DESCRIPTIONS


2.1 BASIC OPERATION

To increase the productivity of the duplex unit, copies are printed as follows.

Longer than A4 sideways/LT sideways

The duplex unit can store only one sheet of copy paper.



Example: 8 pages. The number [A] in the illustration shows the order of pages. The number [B] in the illustration shows the order of sheets of copy paper (if shaded, this indicates the second side).



Up to A4 sideways/LT sideways


The duplex unit can store two sheets of copy paper

Example: 8 pages. The number [A] in the illustration shows the order of pages. The number [B] in the illustration shows the order of sheets of copy paper (if shaded, this indicates the second side).



Duplex
A896/B414

2.2 FEED IN AND EXIT MECHANISM



When paper is fed into duplex unit:

As soon as the paper arrives from the interchange unit, it is sent to the inverter section [C] (the inverter gate solenoid [A] remains off during this process).


The inverter section can hold a sheet of paper up to A3 size. Because of this, the cover guide used in the previous model has become obsolete and has been eliminated from the design.

Inversion and Exit:

Shortly after the trailing edge of the paper passes the entrance sensor [G], the inverter gate solenoid [A] switches on and the inverter gate [B] switches over to direct the paper to the exit path [E]. The inverter roller [D] then changes its rotation direction and the paper goes to the exit transport area [F]. The paper is then sent to the registration rollers in the main copier via the transport rollers.

3. REPLACEMENT AND ADJUSTMENT


3.1 COVER REMOVAL



1. Remove the duplex unit cover [A] (4 screws).


ENTRANCE SENSOR REPLACEMENT

3.2 ENTRANCE SENSOR REPLACEMENT



1. Remove the duplex unit cover. (Refer to section 3.1.)
2. Remove the sensor holder [A] (1 screw).
3. Replace the entrance sensor [B] (1 connector, 1 screw).

3.3 EXIT SENSOR REPLACEMENT



1. Open the duplex unit [A].
2. Remove the sensor bracket [B] (1 screw).
3. Replace the exit sensor [C] (1 connector).

Duplex
A896/B414


BRIDGE UNIT
A897/B417

1. OVERALL MACHINE INFORMATION

1.1 SPECIFICATIONS


Paper Size:	Standard sizes A6 lengthwise to A3 HLT to DLT Non-standard sizes Width: 100 to 305 mm Length: 148 to 432 mm
Paper Weight:	52 g/m ² ~ 135 g/m ² , 16 lb ~ 42 lb
Power Source:	DC24 V, 5 V (from the copier/printer)
Dimensions (W x D x H):	413 x 435 x 126 mm
Weight	3.0 kg (6.6 lbs)

1.2 MECHANICAL COMPONENT LAYOUT



- | | |
|-------------------------|-------------------------|
| 1. Upper Exit Roller | 6. 2nd Transport Roller |
| 2. Tray Exit Sensor | 7. 3rd Transport Roller |
| 3. Junction Gate | 8. Left Exit Roller |
| 4. Cooling Fan | 9. Relay Sensor |
| 5. 1st Transport Roller | 10. Paper Tray |

1.3 ELECTRICAL COMPONENT LAYOUT




- | | |
|---------------------------|------------------------------|
| 1. Left Guide Switch | 5. Cooling Fan Motor |
| 2. Right Guide Switch | 6. Relay Sensor |
| 3. Junction Gate Solenoid | 7. Bridge Unit Drive Motor |
| 4. Tray Exit Sensor | 8. Bridge Unit Control Board |

ELECTRICAL COMPONENT DESCRIPTION

1.4 ELECTRICAL COMPONENT DESCRIPTION

Symbol	Name	Function	Index No.
Motors			
M1	Cooling Fan	Cools the transport unit.	5
M2	Bridge Unit Drive	Drives the bridge unit.	7
Sensors			
S1	Tray Exit	Checks for misfeeds.	4
S2	Relay	Checks for misfeeds.	6
Switches			
SW2	Right Guide	Detects when the right guide is opened.	2
SW3	Left Guide	Detects when the left guide is opened.	1
Solenoids			
SOL1	Junction Gate	Moves the junction gate to direct the paper to the upper tray (on top of the bridge unit) or to the finisher.	3
PCBs			
PCB1	Bridge Unit Control Board	Controls the bridge unit.	8


1.5 DRIVE LAYOUT



1. Left Exit Roller
2. 2nd Transport Roller
3. 1st Transport Roller
4. Upper Exit Roller
5. 3rd Transport Roller
6. Bridge Unit Drive Motor

2. DETAILED DESCRIPTION

2.1 JUNCTION GATE MECHANISM




The junction gate [B] directs any paper reaching the bridge unit to either the upper tray (on top of the bridge unit) or to the finisher, depending on which has been selected.

If the junction gate solenoid [A] has been activated, the junction gate [B] points downward and directs the paper to the upper tray [D] (dotted line path in illustration). When the solenoid is off, the junction gate points upward and the paper is fed out to the finisher [C] by the transport and exit rollers (solid line).

3. REPLACEMENT AND ADJUSTMENT


NOTE: When taking apart the bridge unit, first take the unit out of the copier.

3.1 BRIDGE UNIT DRIVE MOTOR REPLACEMENT




1. Remove the bridge unit from the copier. (See the Installation Procedure in the base copier manual.)
2. Remove the rear cover [C] (2 screws).
3. Remove the bridge unit drive motor [D] (2 screws, 1 connector).

3.2 TRAY EXIT SENSOR REPLACEMENT



1. Remove the bridge unit from the copier. (See the Installation Procedure in the base copier manual.)
2. Remove the rear cover (2 screws). See Bridge Unit Drive Motor Replacement.
3. Remove the paper tray [A].
4. Remove the exit guide [B] (2 screws).
5. Remove the tray exit sensor [C] (1 connector).

3.3 RELAY SENSOR REPLACEMENT




1. Remove the bridge unit from the copier. (See the Installation Procedure in the base copier manual.)
2. Stand the bridge unit up as shown in the illustration and remove the sensor [D].

**1,000-SHEET FINISHER
B408**

1. REPLACEMENT AND ADJUSTMENT

1.1 MAIN PCB






1. Rear cover [A] (⌀x 2)
2. Main PCB [B] (⌀x 4, All ⌀)

STAPLER UNIT

1.2 STAPLER UNIT


1. Side cover [A] (⚙️ x 2)
2. Open exit guide plate [B]
3. Upper side cover [C] (⚙️ x 2)
4. Front cover support plate [D] (⚙️ x 1)
5. Front cover [E]
6. Front inner cover [F] (⚙️ x 2)
7. Harness [G]
8. Unhook the spring [H]
9. Turn the stapler unit [I] and take it out.
10. Bracket [J] (⚙️ x 2)



1.3 MOTORS


1.3.1 SHIFT MOTOR

1. Rear cover (●1.1)
2. Shift motor [A] (⚙️ x 2, 📡 x 1)




1.3.2 STAPLER MOTOR

1. Rear cover (●1.1)
2. Stapler motor [B] (⚙️ x 2, 📡 x 1)



1.3.3 UPPER TRANSPORT MOTOR AND EXIT MOTOR


1. Rear cover (●1.1)
2. Motor assembly [C] (⚙️ x 4, 📡 x 2)
3. Upper transport motor [D] (⚙️ x 4)
4. Exit motor [E] (⚙️ x 4)



MOTORS

1.3.4 LOWER TRANSPORT MOTOR




- 1. Main PCB (☛1.1)
- 2. Lower transport motor [A] (⚙️ x 2, ⚙️ x 1)



1.4 MOTORS AND SENSORS


1.4.1 PREPARATION

- 1. Front cover and inner cover (☛1.2)
- 2. Upper side cover [A] (🔩 x 2)
- 3. Shift tray [B] (🔩 x 1)
- 4. Lower side cover [C] (🔩 x 2)
- 5. Loosen the 2 screws [D].
- 6. Lower the lower tray guide plate [E].
- 7. Guide plate [F] (🔩 x 4)




1.4.2 STACK HEIGHT SENSOR

1. Stack height sensor assembly [A] (⚙️ x 1)
2. Stack height sensor [B] (🔌 x 1)




1.4.3 STAPLER TRAY PAPER SENSOR

1. Stapler tray paper sensor [C] (🔌 x 1)




1.4.4 LOWER TRAY LIFT MOTOR

1. Lower tray lift motor [D] (⚙️ x 2, 🔌 x 1)



1.4.5 STACK FEED-OUT MOTOR

- 1. Stack feed-out motor [A] (🔩 x 2, 📏 x 1)



1,000 Sheet
Finisher
B408

2. TROUBLESHOOTING

2.1 JAM DETECTION

Mode		Jam	Content
Shift	Staple		
✓	✓	Entrance sensor: On check	The entrance sensor does not turn on within the normal time after the main machine exit sensor turns on
✓	✓	Entrance sensor: Off check	The entrance sensor does not turn off within the normal time after it turns on.
✓		Lower tray exit sensor: On check	The lower tray exit sensor does not turn on within the normal time after the entrance sensor turns off.
✓		Tray exit sensor: Off check	The tray exit sensor does not turn off within the normal time after it turns on.
	✓	Stapler tray entrance sensor: On check	The stapler tray entrance sensor does not switch on within the normal time after the entrance sensor switched on.
	✓	Stapler tray entrance sensor: Off check	The staple tray entrance sensor does not turn off within the normal time after it turns on.
	✓	Lower tray exit sensor: On check	The lower exit sensor does not turn on after the feed-out pawl feeds out the outputs.
	✓	Lower tray exit sensor: Off check	The lower exit sensor turns on when the feed-out pawl returns to its HP after feeding out the outputs.

3. SERVICE TABLES

3.1 DIP SWITCH SETTINGS


The DIP switch should not be set to any combination other than those described in the table below.

SW100		Description
1	2	
0	0	Normal operation mode (Default)
1	0	Packing mode.

- Before packing the machine, do the following: Set switch 1 to 1 then back to zero. The lower tray moves to the lowest position. Then turn off the main switch.
- After unpacking the machine, do the following: After turning the main switch back on, the lower tray returns to home position automatically.


4. DETAILED DESCRIPTIONS

4.1 GENERAL LAYOUT




- | | |
|----------------------------|----------------------------|
| 1. Upper Tray | 8. Stapler |
| 2. Upper Tray Exit Roller | 9. Stack Feed-out Belt |
| 3. Entrance Roller | 10. Positioning Roller |
| 4. Tray Junction Gate | 11. Shift Roller |
| 5. Upper Transport Roller | 12. Lower Tray |
| 6. Stapler Junction Gate | 13. Lower Tray Exit Roller |
| 7. Lower Transport Rollers | |

4.2 ELECTRICAL COMPONENT LAYOUT

1,000 Sheet
Finisher
B408

- | | |
|----------------------------------|-----------------------------------|
| 1. Upper Cover Switch | 12. Jogger Fence HP Sensor |
| 2. Paper Limit Sensor | 13. Positioning Roller Solenoid |
| 3. Entrance Sensor | 14. Stapler HP Sensor |
| 4. Exit Guide Plate Motor | 15. Stapler Tray Entrance Sensor |
| 5. Exit Guide Plate HP Sensor | 16. Stapler Tray Paper Sensor |
| 6. Front Door Safety Switch | 17. Stapler Hammer Motor |
| 7. Stack Height Sensor | 18. Staple Sheet Sensor |
| 8. Lower Tray Exit Sensor | 19. Stack Feed-out Belt HP Sensor |
| 9. Lower Tray Upper Limit Switch | 20. Stapler Rotation HP Sensor |
| 10. Shift HP Sensor | 21. Staple Sensor |
| 11. Shift Motor | |

ELECTRICAL COMPONENT LAYOUT



- 22. Tray Junction Gate Solenoid
- 23. Lower Tray Lift Motor
- 24. Lower Tray Lower Limit Sensor
- 25. Stapler Motor
- 26. Jogger Fence Motor
- 27. Stack Feed-out Motor
- 28. Main Board
- 29. Lower Transport Motor
- 30. Stapler Junction Gate Solenoid
- 31. Exit Motor
- 32. Upper Transport Motor


4.3 ELECTRICAL COMPONENT DESCRIPTION

Symbol	Name	Function	Index No.
Motors			
M1	Upper Transport	Drives the entrance roller and upper transport rollers.	32
M2	Lower Transport	Drives the lower transport rollers and positioning roller.	29
M3	Jogger Fence	Drives the jogger fences.	26
M4	Staple Hammer	Drives the staple hammer.	17
M5	Stack Feed-out	Drives the stack feed-out belt.	27
M6	Exit Guide Plate	Opens and closes the exit guide plate.	4
M7	Exit	Drives the exit roller.	31
M8	Lower Tray Lift	Moves the lower tray up or down.	23
M9	Shift	Moves the shift roller from side to side.	11
M10	Stapler	Moves the stapler unit from side to side.	25
Sensors			
S1	Entrance	Detects copy paper entering the finisher and checks for misfeeds.	3
S2	Paper Limit	Detects when the paper stack height in the upper tray is at its limit.	2
S3	Jogger Fence HP	Detects when the jogger fence is at home position.	12
S4	Shift HP	Detects when the shift roller is at home position.	10
S5	Stack Feed-out Belt HP	Detects when the stack feed-out belt is at home position.	19
S6	Stapler HP	Detects when the stapler is at home position.	14
S7	Exit Guide Plate HP	Detects when the exit guide plate is at home position.	5
S8	Stapler Tray Entrance	Detects copy paper entering the stapler tray and checks for misfeeds.	15
S9	Lower Tray Exit	Checks for misfeeds.	8
S10	Stack Height	Detects the top of the copy paper stack.	7
S11	Lower Tray Lower Limit	Detects when lower tray is at its lower limit position.	24
S12	Stapler Tray Paper	Detects when there is copy paper in the stapler tray.	16
S13	Staple Sheet	Detects the leading edge of the staple sheet.	18
S14	Stapler Rotation HP	Detects when the staple hammer is at home position.	20
S15	Staple	Detects whether there are staples in the staple cartridge.	21
Solenoids			
SOL1	Tray Junction Gate	Drives the tray junction gate.	22
SOL2	Stapler Junction Gate	Drives the stapler junction gate.	30

ELECTRICAL COMPONENT DESCRIPTION

Symbol	Name	Function	Index No.
SOL3	Positioning Roller	Moves the positioning roller.	13
Switches			
SW1	Lower Tray Upper Limit	Detects when lower tray is at its upper limit position.	9
SW2	Front Door Safety	Cuts the dc power when the front door is opened.	6
SW3	Upper Cover	Cuts the dc power when the upper cover is opened.	1
PCBs			
PCB1	Main	Controls the finisher and communicates with the copier/printer.	28

4.4 DRIVE LAYOUT




- 1. Exit Motor
- 2. Upper Transport Motor
- 3. Lower Transport Motor

- 4. Shift Motor
- 5. Exit Guide Plate Motor
- 6. Lower Tray Lift Motor


1,000 Sheet
Finisher
B408

DRIVE LAYOUT



- 7. Stack Feed-out Motor
- 8. Jogger Motor
- 9. Stapler Motor

4.5 JUNCTION GATES



Depending on the finishing mode, the copies are directed up, straight through, or down by the combination of the tray junction gate [A] and stapler junction gate [B]. These gates are controlled by the tray junction gate solenoid [C] and stapler junction gate solenoid [D].

Upper tray mode

The tray junction gate solenoid remains off. The copies go up to the upper tray.

Sort/stack mode


The tray junction gate solenoid turns on and the stapler junction gate solenoid remains off. The copies are sent to the lower tray directly.

Staple mode

The tray junction gate solenoid and the stapler junction gate solenoid both turn on. The copies go down to the jogger unit.


UPPER TRAY

4.6 UPPER TRAY



When the paper limit sensor [A] switches on during feed-out for each of three consecutive sheets of paper, paper overflow is detected.

4.7 LOWER TRAY UP/DOWN MECHANISMS



The vertical position of the lower tray [A] depends on the height of the copied paper stack on the lower tray. The stack height sensor feeler [B] contacts the top of the stack, and the lower tray lift motor [C] controls the tray height.

When the lower tray reaches its lowest possible position, the actuator [D] turns on the lower tray lower limit sensor [E], and copying stops.

Tray Up

When the copy paper on the tray is removed, the stack height sensor turns off and the tray lifts up. Then, the tray stops when the sensor turns on again (the tray pushes up the feeler).


Sort/stack Mode (Tray Down)

Every five sheets of paper, the tray goes down until the sensor turns off again. Then, it goes up until the sensor is on again.

Staple Mode (Tray Down)

After a stapled copy is fed out, the tray goes up for 220 ms and stops for 300 ms. Then, it goes down for 1 second, waits for 500 ms, then goes up until the sensor turns on.

4.8 PAPER SHIFT MECHANISM




In the sort/stack mode, the shift roller [A] moves from side to side to separate the sets of copies.

The horizontal position of the shift roller is controlled by the shift motor [B] and the shift gear disk [C]. After the trailing edge of the copy passes the upper transport roller, the shift motor turns on, driving the shift gear disk and the link [D].

After the paper is delivered to the lower tray [E], the shift roller moves to the HP, which is detected by the shift HP sensor [F]. Then, when the trailing edge of the next copy passes the upper transport roller, the shift roller shifts again. This operation is done every sheet.

When the trailing edge of each page in the next set of copies passes the upper transport roller, the shift roller shifts in the opposite direction.

4.9 JOGGER UNIT PAPER POSITIONING MECHANISM




1,000 Sheet
Finisher
B408

In staple mode, each sheet of copy paper is vertically and horizontally aligned when it arrives in the jogger unit.

For the vertical paper alignment, the positioning roller solenoid [A] turns on shortly after the stapler tray entrance sensor [B] turns off, and the positioning roller [C] pushes the copy against the bottom of the stack stopper [D].

For the horizontal paper alignment, the jogger front fence [E] and the rear fence [F] move to the waiting position, which is 18 mm away from the side of the paper. When aligning the paper vertically, the jogger fence moves in 14 mm from the waiting position. After the vertical position has been aligned, the jogger fence pushes the paper 4 mm against the rear fence to align the paper horizontally. Then the jogger fence moves back to the previous position.


4.10 EXIT GUIDE PLATE



When stacking a large size of paper (such as A3, DLT) in the jogger unit, the leading edge of the paper reaches the exit rollers. To prevent the paper from running into the exit rollers and not being aligned correctly, the exit guide plate [A] is moved up to make a gap between the exit rollers. This operation is done for all paper sizes, but is only needed for the larger sizes.

The exit guide plate motor [B] and exit roller release cam [C] control the exit guide plate movement. When the exit guide plate motor starts, the cam turns and the exit guide plate moves up. When stapling is finished, the exit guide plate motor turns on again to close the exit guide plate. When the exit guide plate HP sensor [D] turns on, the motor stops.

4.11 STAPLER MECHANISM



The staple hammer motor [A] drives the staple hammer.


The staple sheet sensor [B] detects the leading edge of the staple sheet at the stapling position to prevent the hammer from operating if there are no staples at the stapling position.

If there is no staple cartridge in the stapler unit or no staples in the staple cartridge, staple end is indicated on the operation panel. The stapler sensor [C] detects this.

The stapler rotation HP sensor [D] checks whether the staple hammer mechanism returns to home position after each stack has been stapled.

When excessive load is applied to the staple hammer motor, the copier detects a staple jam. When a staple jam has occurred, the jammed staple is inside the staple cartridge [E]. Therefore, the jammed staple can be removed easily after pulling out the staple cartridge.

4.12 STAPLER UNIT MOVEMENT MECHANISM




The stapler motor moves the stapler [A] from side to side. After the start key is pressed, the stapler moves from its home position to the stapling position.

If two-staple-position mode is selected, the stapler moves to the front stapling position first, then moves to the rear stapling position. However, for the next copy set, it staples in the reverse order (at the rear side first, then at the front side).

After the job is completed, the stapler moves back to its home position. The stapler HP sensor [B] detects this.

4.13 PAPER FEED-OUT MECHANISM



After the copies have been stapled, the stack feed-out motor [A] starts. The pawl [B] on the stack feed-out belt [C] transports the set of stapled copies up and feeds it to the shift roller. The shift roller takes over stack feed-out after the leading edge reaches this roller.

Just before the stapled stack passes through the lower tray exit sensor, the stack-feed-out motor turns off until the shift rollers have completely fed the stack out to the lower tray. Then, the stack-feed-out motor turns on again until the pawl [B] actuates the stack feed-out belt home position sensor [D].

5. OVERALL MACHINE INFORMATION

5.1 SPECIFICATIONS

Upper Tray

Paper Size:	A3 to A6 DLT to HLT
Power Weight:	60 to 157 g/m ² (16 to 42 lb)
Paper Capacity:	250 sheets (A4 sideways / LT sideways or smaller: 80 g/m ² , 20lb) 50 sheets (A3, B4, DLT, LG: 80 g/m ² , 20 lb)

Lower Tray

Paper Size:	No staple mode: A3 to B5 DLT to HLT Staple mode: A3, B4, A4, B5 DLT to LT
Paper Weight:	No staple mode: 60 ~ 157 g/m ² (16 ~ 42 lb) Staple mode: 64 ~ 90 g/m ² (17 ~ 24 lb)
Stapler Capacity:	30 sheets (A3, B4, DLT, LG) 50 sheets (A4, B5 sideways, LT)
Paper Capacity:	No staple mode: 1,000 sheets (A4/LT or smaller: 80 g/m ² , 20 lb) 500 sheets (A3, B4, DLT, LG: 80 g/m ² , 20 lb) Staple mode: (80 g/m ² , 20 lb, number of sets)

Set Size	2 to 9	10 to 50	
Size		10 to 30	31 to 50
A4/LT sideways B5 sideways	100	100 to 20	100 to 20
A4/LT Lengthwise	100	50 to 10	50 to 10
A3, B4, DLT, LG	50	50 to 10	—

Staple positions:	1 Staple: 2 positions (Front, Rear) 2 Staples: 2 positions (Upper, Left)
Staple Replenishment:	Cartridge (5,000 staples/cartridge)
Power Source:	24 Vdc, 5 Vdc (from the copier/printer)
Power Consumption:	50 W
Weight:	25 kg (55.2 lbs)
Dimensions (W x D x H):	527 x 520 x 790 mm (20.8" x 20.5" x 31.1")

500-SHEET FINISHER
G302/B442

1. REPLACEMENT AND ADJUSTMENT


1.1 EXTERIOR

NOTE: This manual uses several symbols. The meanings for these symbols are as follows:

☞: See or refer to 🛠️: screw 📏: connector 📌: clip


Front cover

[A]: : Front cover (🛠️1)



Rear cover


[A]: Rear cover (🛠️1)




EXTERIOR

Top cover

[A]: Top cover (2 links)



Front lower guide



[A]: Output tray (⌘2)


[B]: Front lower guide (⌘2)

- NOTE:** 1) When re-attaching the lower guide, be sure that it is not in contact with the exit lower guide and that the exit lower guide moves smoothly.
2) Make sure that the blue and black cables are in the correct position, as engraved on the inside of the front lower guide.

Right cover


[A]: Grounding plate (⌀1)

[B]: Right cover (⌀2)



500-Sheet
Finisher
G302/B442

1.2 ENTRANCE UPPER GUIDE / PAPER EXIT UNIT



- Front, rear, and top covers and front lower guide (☛ 1.1 Exterior)

[A]: Entrance upper guide (🔩2, 📐1)

[B]: Paddle gear spring

[C]: Paddle gear (📐1)

[D]: Paddle gear holder


[E]: Bushing (📐1)

[F]: Paper exit unit holder (🔩1)

[G]: Rear paper exit unit holder (🔩1)

[H]: Exit unit

NOTE: Keep the paper exit unit stays in the upper position. Rotate the paddle roller into the position shown in the illustration [a]. Then, insert the paddle gear, making sure that the pawl on the gear's outer frame is resting on the clutch link [b].



1.3 ENTRANCE LOWER GUIDE

- Entrance upper guide (☛ 1.2 Entrance upper guide / Exit unit)
- Exit unit (☛ 1.2 Entrance upper guide / Exit unit)


[A]: Release tension bracket (🔩1)

[B]: Reverse roller gear bracket (🔩2)

[C]: Timing belt

[D]: Entrance lower guide

NOTE: When re-assembling the tension bracket, rotate the main motor counter clockwise to tighten the timing belt.



500-Sheet
Finisher
G302/B442


1.4 PAPER EXIT UNIT GEAR / PADDLE ROLLER SOLENOID

- Front cover (☛ 1.1 Exterior)

[A]: Gear bracket (🔩3)

[B]: Paper exit unit gear

[C]: Paddle roller solenoid (🔩1)




STAPLER UNIT

1.5 STAPLER UNIT

- Rear cover (☛1.1 Exterior)

[A]: Stapler unit bracket (🔧2, 📄1)

[B]: Stapler unit (🔧3)




1.6 JOGGER TRAY UNIT

- Entrance upper guide and paper exit unit (☛1.2 Entrance upper guide / paper exit unit)
- Entrance lower guide (☛1.2 Entrance lower guide)
- Paper exit unit gear and Paddle roller solenoid (☛1.4 Paper exit unit gear / Paddle roller solenoid)
- Stapler unit (☛ 1.5 Stapler unit)

[A]: Jogger tray unit holders (🔧2)


[B]: Jogger tray unit (🔧1, 📄3)

NOTE: Be sure to connect the black cable to the paper exit sensor and the blue one to the jogger home position sensor.



1.7 PAPER EXIT SENSOR FEELER


- Jogger tray unit (☛1.6 Jogger tray unit)
 - Jogger motor (☛1.9 Jogger motor)
- [A]: Paper exit sensor feeler



500-Sheet
Finisher
G302/B442

1.8 MAIN MOTOR


- Right cover (☛1.1 Exterior)
- [A]: Release tension bracket (☛1)
- [B]: Main motor (☛2, ☛1)



JOGGER MOTOR


1.9 JOGGER MOTOR

- Front lower guide (☛1.1 Exterior)
- [A]: Jogger motor (🔧2, 📁3)




1.10 CONTROL BOARD

- Front lower guide (☛1.1 Exterior)
- [A]: Control board (🔧1, 📁12)




1.11 OUTPUT TRAY UNIT



- [A]: Output tray cover (🔩2)
- [B]: Tray holder (🔩1)
- [C]: Links
- [D]: Connector cover
- [E]: Output tray motor link unit (🔩1)
- [F]: Rear cover (🔩1)
- [G]: Output tray motor (🔩1)

NOTE: When re-attaching the motor link unit, the arrows on each of the gears need to face each other as shown in the illustration.




2. DETAILED DESCRIPTIONS

2.1 OVERALL MACHINE INFORMATION


2.1.1 COMPONENT LAYOUT

Mechanical component layout



- | | |
|---------------------------------|-------------------------|
| 1. Output tray | 6. Lower entrance guide |
| 2. Stack height detection lever | 7. Upper entrance guide |
| 3. Paper exit roller | 8. Paper exit unit |
| 4. Jogger tray | 9. Paddle roller |
| 5. Reverse roller | 10. Lower exit guide |

Drive layout




500-Sheet
Finisher
G302/B442

- | | |
|----------------------------|-------------------------------|
| 1. Main motor | 5. Output tray link gears |
| 2. Exit roller timing belt | 6. Paper exit unit drive gear |
| 3. Main motor timing belt | 7. Reverse roller |
| 4. Output tray motor | 8. Paper exit roller |

OVERALL MACHINE INFORMATION

1.1.2 ELECTRICAL COMPONENT DESCRIPTIONS



See the next page for the component description table.

OVERALL MACHINE INFORMATION


Symbols	Name	Function	Index No.
Motors			
M1	Main	Drives all the rollers	6
M2	Jogger	Drives the jogger fence	9
M3	Output Tray	Drives the tray up and down	12
M4	Stapler	Drives the stapler	16
Sensors			
S1	Entrance	Detects paper at the entrance	3
S2	Exit	Detects paper at the exit	15
S3	Stack height	Detects the top of the paper stack	13
S4	Lever	Detects the position of stack height lever	14
S5	Jogger home position	Detects the position of the jogger fence	2
S6	Top cover	Detects if the top cover is open	1
S7	Tray upper limit	Detects when the tray is lifted to the upper limit	11
S8	Stack near-limit	Detects when the tray is at its lowest limit (almost full)	10
Solenoids			
SOL1	Exit unit gear	Moves the paper exit unit up and down	7
SOL2	Paddle roller	Switches paddle roller rotation on and off.	5
SOL3	Stack height lever	Moves the stack height lever into contact with the top of the stack.	8
PCBs			
PCB1	Main control	Controls all finisher functions	4
Switches			
SW1	Paper exit unit	Switches DC for the stapler unit on and off.	18
SW2	Staple unit cover	Cuts DC when staple unit cover is open.	17

500-Sheet
Finisher
G302/B442

1.2 DETAILED SECTION DESCRIPTIONS

1.2.1 OUTPUT TRAY MECHANISM

Stack height detection



Stack height detection lever [A]: Driven by stack height lever solenoid [B].

Two sensors detect the height of the stack in the output tray: the stack height [C] and lever [D] sensors.

Stack height sensor	Lever sensor	Status
Off	Off	The stack height is below the target. The output tray is lifted to the target position.
Off	On	Target position
On	On	The stack height is more the target. The output tray is lowered to the target position.
On	Off	The stack height detection lever is at home position.


Off: Actuator not in sensor

At the start of a print job, the solenoid turns off. The stack height detection lever comes down, to detect the current stack level.

When a sheet of paper is being fed out, the solenoid turns on and the lever goes back up to home position (inside the unit).

After paper has been fed out, the solenoid turns on again, and the lever detects the level of the stack.

Output tray up/down mechanism



500-Sheet
Finisher
G302/B442

Overview

The output tray motor [A] lifts/lowers the tray if the stack height is not at the target position.

Gears [B] and [C] keep the angle of the tray constant at any tray position.

Output Tray Downward Movement

The top of the paper stack is checked after every page (or set of pages) has been fed out. If the top of the stack is higher than the target level, the output tray motor moves the tray down.

When the stack near-limit sensor [D] detects the actuator on gear [C], a stack near-limit signal is transferred to the main frame. The tray cannot move any lower. The next time the top of the stack height is above the target level, printing stops.

Output Tray Upward Movement

If paper is removed from the stack, the top of the stack will be lower than the target level, and the output tray motor moves the tray up.

When the tray upper limit sensor [E] detects the actuator on gear [B], the tray cannot be moved up any more, so the motor stops.

DETAILED SECTION DESCRIPTIONS

1.2.2 PAPER FEED

Overview


The following paper feed out modes can be selected at the printer driver.

Mode	Description
Straight feed out mode	Paper is fed directly to the output tray without shifting or stapling.
Shift sorting mode	Alternate sets are shifted before being fed to the output tray.
Stapling mode	All sets are shifted and stapled, then fed to the output tray.

Straight feed out mode

Before the job, the exit unit [A] is up, and the exit unit gear solenoid [B] is on, pulling lever [C] away from the exit unit gear [D].

At the start of the job, the stack height detection lever detects the top of the stack. The tray moves up or down if the top of the stack is not at the correct level.



When the paper exit sensor in the main frame turns on, the finisher main motor starts. It drives the exit unit gear [D] through idle gear [E]. The gear pulls paper exit unit [A] down, using the paper exit link [F]. The link also moves the paper exit roller [H] up through the exit roller drive gear [G].


When the motor starts, the solenoid switches off and a spring pushes lever [C] into contact with the exit unit gear [D].

When a part of the exit unit gear without threads [I] faces the idle gear, the gear stops turning (see the left-hand diagram). The lever [C] catches a peg on the exit unit gear, to make sure that it stops at the correct position. The paper exit rollers [H] now contact each other and the main motor feeds out the paper.

When the last page has been fed out, the solenoid turns on to pull the lever away from the gear. The gear starts turning, to lift the exit unit to the standby position.

When the other part of the exit unit gear without threads [J] faces the idle gear, the exit unit gear stops. Then, the main motor stops and the solenoid turns off.

Shift sorting mode



500-Sheet
Finisher
G302/B442


At the start of the job, and for odd numbered sets of copies, the mechanism is the same as the straight feed out mode. However, even numbered sets are fed back to the jogger tray, which shifts the sets to one side before feeding them out.

This section describes what happens for even-numbered sets (sets 2, 4, 6 etc) of the job.

A short time after the entrance sensor [A] detects the first page of the set, the paper exit unit solenoid turns on to restart the rotation of the paper exit unit gear, raising the paper exit unit to the standby position. It stays there until after the last page of the set.

The paper cannot feed out, so it drops into the jogger tray [B]. The paddle roller solenoid [C] turns on and the paddle roller [D] feeds the paper to the reverse roller [E]. The reverse roller feeds the paper to the end fence [F] of the jogger tray.

DETAILED SECTION DESCRIPTIONS




After the paper reaches the end fence [A], the jogger fence [B] shifts the paper across. The jogger motor [C] drives the jogger fence. The home position sensor [D] detects when the jogger fence has returned to home position.

When the next set begins, the paper exit unit moves down, and the machine operates the same way as straight feed out mode. At this time, the entire set in the jogger tray is fed out at the same time as the first page of the next set. However, the set coming from the jogger tray has been shifted to one side.

If the last set is an even-numbered set, the paper exit unit must be pulled down to feed the final set out of the jogger tray. Then the exit unit moves back up to the standby position.

The capacity of the jogger tray is 30 sheets. If the set contains more than 30 sheets, the machine feeds out the first 30 from the jogger tray, then continues with the rest of the set, using the jogger tray.

Stapling mode



500-Sheet
Finisher
G302/B442

The stapler is attached to the jogger tray, so all sets go to the jogger tray.

After all pages of a set have entered the jogger tray and been shifted across, the paper exit link [A] pulls the paper exit unit [B] down until knob [C] on the exit unit pushes the link lever [D] for the exit unit switch [E]. This turns on the exit unit switch. When this switch is on, dc is supplied to the stapler unit [F] and the main motor is turned off.

The exit unit switch is activated when the exit unit is pulled part-way down. After stapling the set of prints, the paper exit unit is pulled down again until the unit comes in contact with the paper exit roller [G], and the stapled set is fed out.

DETAILED SECTION DESCRIPTIONS

1.2.3 JAM CONDITIONS

	Sensors	Conditions
Remaining paper detection	Entrance Exit	Either the entrance or exit sensor detects paper just after the unit is initialized.
Non-feed at the entrance	Entrance	The entrance sensor is not activated within a certain period after the paper exit sensor detects paper.
Jamming at the entrance	Entrance	The entrance sensor is not de-activated after paper is fed 1.3 times the length of the paper.
Non-feed inside the unit (Straight feed out mode only)	Exit	The exit sensor is not activated within a certain period after the entrance sensor detects paper.
Jamming at the exit	Exit	The exit sensor is not de-activated after paper is fed for a certain period.
Jogger tray	Exit	The exit sensor is de-activated during paper shifting or stapling.

1.2.4 ERROR DETECTION

	Conditions
Jogger motor error	Jogger home position sensor does not shut off after jogger motor starts.
Jogger motor home position detection error	Jogger home position sensor does not turn on after paper shifting.
Stapler error	Stapler home position sensor (inside stapler unit) does not turn on after stapling.
Output tray upper limit error	Tray upper limit sensor is activated.
Output tray motor error	The output tray is away from the target position for more than 10 seconds.
Stack height detection error	The stack height detection lever does not return to its home position before going to detect the stack height.

NOTE: The above errors are indicated as “Finisher jam” at the first occurrence.
If the same error happens again in the next job, “finisher error” is indicated.

3. OVERALL MACHINE INFORMATION

3.1 SPECIFICATIONS







Paper Size:	A3, B4, A4, B5 sideways (Metric) DLT, LG, LT (Inch)
Paper Weight	52 ~ 128 g/m ² , 14 ~ 34 lb.
Staple Capacity:	20 sheets (A3, B4, DLT, LG : 80 g/m ² , 20 lb) 30 sheets (A4, B5 sideways, LT : 80 g/m ² , 20 lb)
Stack Capacity (Maximum):	500 sheets (A4/LT or smaller: 80 g/m ² , 20 lb.) 250 sheets (A3, B4, DLT and LG: 80 g/m ² , 20 lb.)
Stapling Positions:	1
Staple Replenishment:	Cartridge (3,000 staples/cartridge)
Power Source:	24 V DC, 5 V DC (from the copier/printer)
Power Consumption:	48 W
Weight:	8.3 kg (18.4 lbs.)
Dimensions (W x D x H):	350 x 490 x 230 mm


500-Sheet
Finisher
G302/B442

**FAX OPTION TYPE 2027
B576
SERVICE MANUAL**


Conventions in this Manual

This manual uses several symbols.

Symbol	What it means
	Refer to section number
	See Core Tech Manual for details
	Screw
	Connector
	E-ring
	Clip ring



Short Edge Feed (SEF)



Long Edge Feed (LEF)

1. INSTALLATION

1.1 CAUTIONS AND WARNINGS

WARNING

1. Never install telephone wiring during a lightning storm.
2. Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
3. Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
4. Use caution when installing or modifying telephone lines.
5. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be remote risk of electric shock from lightning.
6. Do not use a telephone or cellular phone to report a gas leak in the vicinity of the leak.


CAUTION

1. Before installing the fax unit, switch off the main switch, and disconnect the power cord.
2. The fax unit contains a lithium battery. The danger of explosion exists if a battery of this type is incorrectly replaced. Replace only with the same or an equivalent type recommended by the manufacture. Discard batteries in accordance with the manufacture's instructions and local regulations.

NOTE FOR AUSTRALIA

Unit must be connected to Telecommunication Network through a line cord which meets the requirements of ACA Technical Standard TS008.

1.2 FAX OPTION TYPE 2027 INSTALLATION







⚠ CAUTION

Before installing this option, do the following:

- 1. If there is a printer option in the machine, print out all data in the printer buffer.**
- 2. Turn off the main switch and disconnect the power cord and the network cable.**


1. Remove the small cover [A] (1 rivet) and the rear cover [B] (⚙ x 4).
2. Attach the NCU unit [C] (⚙ x 4) into the machine.
3. Remove the shield cover [D] (⚙ x 8).

FAX OPTION TYPE 2027 INSTALLATION



4. Turn on the battery switch (SW1) [A] on the MBU board, then attach the FCU unit [B] (⌀ x 6). Connect harnesses [C], then clamp harness [D] as shown. Replace the rear cover and the small cover.
5. Remove parts [E], [G] and [J], then install parts [F], [H] and [I].
6. Affix the FCC decal [K] and the serial number decal [L] on the rear cover as shown. Then install the small cover [M] on the rear cover.
7. Affix the super G3 decal [N] as shown.

FAX OPTION TYPE 2027 INSTALLATION




8. If the ADF has been installed, insert the stamp cartridge [A] into the ADF as shown.
9. Connect the telephone line to the "LINE" jack at the rear of the machine.
10. Plug in the machine and turn on the main power switch.
NOTE: The copier must be connected to a properly - grounded socket outlet.
11. Be sure to set the clock. (Date and time)
12. Enter service mode and program the serial number into the fax unit (Fax SP-3-102-000). The serial number can be found on the serial number label (attached to the machine in Step 6).

1.3 G3 INTERFACE UNIT TYPE 2027 INSTALLATION

NOTE: This installation procedure uses the following symbols.

: Screws

: Connectors







Fax Option
B576


CAUTION

Before installing this option, do the following:

3. If there is a printer option in the machine, print out all data in the printer buffer.
4. Turn off the main switch and disconnect the power cord and the network.

1. Remove the small cover [A] (1 rivet) and the rear cover [B] ( x 4). Then cut away the jack window [C].
2. Remove the NCU unit [D] ( x 4,  x 2)
3. Remove the NCU [E] from the NCU unit ( x 4). Connect harness [F] to the FCU.

G3 INTERFACE UNIT TYPE 2027 INSTALLATION



4. Attach the G3 unit [A] to the machine (⚙ x 6, ⚙ x 1).
5. Connect harness [B] to the interface board and attach bracket [C] (⚙ x 1). Then attach the NCU [D] (removed from the NCU unit in step 3) to the G3 unit (⚙ x 4). After that, connect harness [E] to the NCU [D], then clamp harness [E] as shown.
6. Replace the rear cover and the small cover.
7. Connect the cable to the LINE2 jack, then plug in the machine and turn the main switch on.
8. Enter service mode and set bit 1 of communication switch 16 to "1". After that turn the main switch off and on.
9. Print the system parameter list and ensure that "SG3-D" is listed as an option.
10. Set up and program the items required for PSTN-2 communications.

2. TROUBLESHOOTING

2.1 ERROR CODES

If an error code occurs, retry the communication. If the same problem occurs, try to fix the problem as suggested below. Note that some error codes appear only in the error code display and on the service report.

Code	Meaning	Suggested Cause/Action
0-00	DIS/NSF not detected within 40 s of Start being pressed	<ul style="list-style-type: none"> • Check the line connection. • Check the NCU - FCU connectors. • The machine at the other end may be incompatible. • Replace the NCU or FCU. • Check for DIS/NSF with an oscilloscope. • If the rx signal is weak, there may be a bad line.
0-01	DCN received unexpectedly	<ul style="list-style-type: none"> • The other party is out of paper or has a jammed printer. • The other party pressed Stop during communication.
0-03	Incompatible modem at the other end	<ul style="list-style-type: none"> • The other terminal is incompatible.
0-04	CFR or FTT not received after modem training	<ul style="list-style-type: none"> • Check the line connection. • Check the NCU - FCU connectors. • Try changing the tx level and/or cable equalizer settings. • Replace the FCU or NCU. • The other terminal may be faulty; try sending to another machine. • If the rx signal is weak or defective, there may be a bad line. <p>Cross reference</p> <ul style="list-style-type: none"> • Tx level - NCU Parameter 01 (PSTN) • Cable equalizer - G3 Switch 07 (PSTN) • Dedicated Tx parameters - Section 4
0-05	Unsuccessful after modem training at 2400 bps	<ul style="list-style-type: none"> • Check the line connection. • Check the NCU - FCU connectors. • Try adjusting the tx level and/or cable equalizer. • Replace the FCU or NCU. • Check for line problems. <p>Cross reference</p> <ul style="list-style-type: none"> • See error code 0-04.

ERROR CODES

Code	Meaning	Suggested Cause/Action
0-06	The other terminal did not reply to DCS	<ul style="list-style-type: none"> • Check the line connection. • Check the FCU - NCU connectors. • Try adjusting the tx level and/or cable equalizer settings. • Replace the NCU or FCU. • The other end may be defective or incompatible; try sending to another machine. • Check for line problems. <p>Cross reference</p> <ul style="list-style-type: none"> • See error code 0-04.
0-07	No post-message response from the other end after a page was sent	<ul style="list-style-type: none"> • Check the line connection. • Check the FCU - NCU connectors. • Replace the NCU or FCU. • The other end may have jammed or run out of paper. • The other end user may have disconnected the call. • Check for a bad line. • The other end may be defective; try sending to another machine.
0-08	The other end sent RTN or PIN after receiving a page, because there were too many errors	<ul style="list-style-type: none"> • Check the line connection. • Check the FCU - NCU connectors. • Replace the NCU or FCU. • The other end may have jammed, or run out of paper or memory space. • Try adjusting the tx level and/or cable equalizer settings. • The other end may have a defective modem/NCU/FCU; try sending to another machine. • Check for line problems and noise. <p>Cross reference</p> <ul style="list-style-type: none"> • Tx level - NCU Parameter 01 (PSTN) • Cable equalizer - G3 Switch 07 (PSTN) • Dedicated Tx parameters - Section 4
0-14	Non-standard post message response code received	<ul style="list-style-type: none"> • Check the FCU - NCU connectors. • Incompatible or defective remote terminal; try sending to another machine. • Noisy line: resend. • Try adjusting the tx level and/or cable equalizer settings. • Replace the NCU or FCU. <p>Cross reference</p> <ul style="list-style-type: none"> • See error code 0-08.

Code	Meaning	Suggested Cause/Action
0-15	The other terminal is not capable of specific functions.	<p>The other terminal is not capable of accepting the following functions, or the other terminal's memory is full.</p> <ul style="list-style-type: none"> • Confidential rx • Transfer function • SEP/SUB/PWD/SID
0-16	CFR or FTT not detected after modem training in confidential or transfer mode	<ul style="list-style-type: none"> • Check the line connection. • Check the FCU - NCU connectors. • Replace the NCU or FCU. • Try adjusting the tx level and/or cable equalizer settings. • The other end may have disconnected, or it may be defective; try calling another machine. • If the rx signal level is too low, there may be a line problem. <p>Cross reference</p> <ul style="list-style-type: none"> • See error code 0-08.
0-17	Communication was interrupted by pressing the Stop key.	<p>If the Stop key was not pressed and this error keeps occurring, replace the operation panel.</p>
0-20	Facsimile data not received within 6 s of retraining	<ul style="list-style-type: none"> • Check the line connection. • Check the FCU - NCU connectors. • Replace the NCU or FCU. • Check for line problems. • Try calling another fax machine. • Try adjusting the reconstruction time for the first line and/or rx cable equalizer setting. <p>Cross reference</p> <ul style="list-style-type: none"> • Reconstruction time - G3 Switch 0A, bit 6 • Rx cable equalizer - G3 Switch 07 (PSTN)
0-21	EOL signal (end-of-line) from the other end not received within 5 s of the previous EOL signal	<ul style="list-style-type: none"> • Check the connections between the FCU, NCU, & line. • Check for line noise or other line problems. • Replace the NCU or FCU. • The remote machine may be defective or may have disconnected. <p>Cross reference</p> <ul style="list-style-type: none"> • Maximum interval between EOLs and between ECM frames - G3 Bit Switch 0A, bit 4
0-22	The signal from the other end was interrupted for more than the acceptable modem carrier drop time (default: 200 ms)	<ul style="list-style-type: none"> • Check the line connection. • Check the FCU - NCU connectors. • Replace the NCU or FCU. • Defective remote terminal. • Check for line noise or other line problems. • Try adjusting the acceptable modem carrier drop time. <p>Cross reference</p> <ul style="list-style-type: none"> • Acceptable modem carrier drop time - G3 Switch 0A, bits 0 and 1

Fax Option
B576

ERROR CODES

Code	Meaning	Suggested Cause/Action
0-23	Too many errors during reception	<ul style="list-style-type: none"> • Check the line connection. • Check the FCU - NCU connectors. • Replace the NCU or FCU. • Defective remote terminal. • Check for line noise or other line problems. • Try asking the other end to adjust their tx level. • Try adjusting the rx cable equalizer setting and/or rx error criteria. <p>Cross reference</p> <ul style="list-style-type: none"> • Rx cable equalizer - G3 Switch 07 (PSTN) • Rx error criteria - Communication Switch 02, bits 0 and 1
0-30	The other terminal did not reply to NSS(A) in AI short protocol mode	<ul style="list-style-type: none"> • Check the line connection. • Check the FCU - NCU connectors. • Try adjusting the tx level and/or cable equalizer settings. • The other terminal may not be compatible. <p>Cross reference</p> <ul style="list-style-type: none"> • Dedicated tx parameters - Section 4
0-32	The other terminal sent a DCS, which contained functions that the receiving machine cannot handle.	<ul style="list-style-type: none"> • Check the protocol dump list. • Ask the other party to contact the manufacturer.
0-52	Polarity changed during communication	<ul style="list-style-type: none"> • Check the line connection. • Retry communication.
0-70	The communication mode specified in CM/JM was not available (V.8 calling and called terminal)	<ul style="list-style-type: none"> • The other terminal did not have a compatible communication mode (e.g., the other terminal was a V.34 data modem and not a fax modem.) • A polling tx file was not ready at the other terminal when polling rx was initiated from the calling terminal.
0-74	The calling terminal fell back to T.30 mode, because it could not detect ANSam after sending CI.	<ul style="list-style-type: none"> • The calling terminal could not detect ANSam due to noise, etc. • ANSam was too short to detect. • Check the line connection and condition. • Try making a call to another V.8/V.34 fax.
0-75	The called terminal fell back to T.30 mode, because it could not detect a CM in response to ANSam (ANSam timeout).	<ul style="list-style-type: none"> • The terminal could not detect ANSam. • Check the line connection and condition. • Try receiving a call from another V.8/V.34 fax.
0-76	The calling terminal fell back to T.30 mode, because it could not detect a JM in response to a CM (CM timeout).	<ul style="list-style-type: none"> • The called terminal could not detect a CM due to noise, etc. • Check the line connection and condition. • Try making a call to another V.8/V.34 fax.

Code	Meaning	Suggested Cause/Action
0-77	The called terminal fell back to T.30 mode, because it could not detect a CJ in response to JM (JM timeout).	<ul style="list-style-type: none"> The calling terminal could not detect a JM due to noise, etc. A network that has narrow bandwidth cannot pass JM to the other end. Check the line connection and condition. Try receiving a call from another V.8/V.34 fax.
0-79	The called terminal detected CI while waiting for a V.21 signal.	Check for line noise or other line problems. If this error occurs, the called terminal falls back to T.30 mode.
0-80	The line was disconnected due to a timeout in V.34 phase 2 – line probing.	<ul style="list-style-type: none"> The guard timer expired while starting these phases. Serious noise, narrow bandwidth, or low signal level can cause these errors.
0-81	The line was disconnected due to a timeout in V.34 phase 3 – equalizer training.	<p>If these errors happen at the transmitting terminal:</p> <ul style="list-style-type: none"> Try making a call at a later time. Try using V.17 or a slower modem using dedicated tx parameters. Try increasing the tx level. Try adjusting the tx cable equalizer setting.
0-82	The line was disconnected due to a timeout in the V.34 phase 4 – control channel start-up.	<p>If these errors happen at the receiving terminal:</p> <ul style="list-style-type: none"> Try adjusting the rx cable equalizer setting. Try increasing the tx level. Try using V.17 or a slower modem if the same error is frequent when receiving from multiple senders.
0-83	The line was disconnected due to a timeout in the V.34 control channel restart sequence.	<ul style="list-style-type: none"> Try adjusting the rx cable equalizer setting. Try increasing the tx level. Try using V.17 or a slower modem if the same error is frequent when receiving from multiple senders.
0-84	The line was disconnected due to abnormal signaling in V.34 phase 4 – control channel start-up.	<ul style="list-style-type: none"> The signal did not stop within 10 s. Turn off the machine, then turn it back on. If the same error is frequent, replace the FCU.
0-85	The line was disconnected due to abnormal signaling in V.34 control channel restart.	<ul style="list-style-type: none"> The signal did not stop within 10 s. Turn off the machine, then turn it back on. If the same error is frequent, replace the FCU.
0-86	The line was disconnected because the other terminal requested a data rate using MPh that was not available in the currently selected symbol rate.	<ul style="list-style-type: none"> The other terminal was incompatible. Ask the other party to contact the manufacturer.
0-87	The control channel started after an unsuccessful primary channel.	<ul style="list-style-type: none"> The receiving terminal restarted the control channel because data reception in the primary channel was not successful. This does not result in an error communication.
0-88	The line was disconnected because PPR was transmitted/received 9 (default) times within the same ECM frame.	<ul style="list-style-type: none"> Try using a lower data rate at the start. Try adjusting the cable equalizer setting.
2-10	The modem cannot enter tx mode	<ul style="list-style-type: none"> Replace the FCU.
2-11	Only one V.21 connection flag was received	<ul style="list-style-type: none"> Replace the FCU.

ERROR CODES

Code	Meaning	Suggested Cause/Action
2-12	Modem clock irregularity	<ul style="list-style-type: none"> • Replace the FCU.
2-13	Modem initialization error	<ul style="list-style-type: none"> • Turn off the machine, then turn it back on. • Update the modem ROM. • Replace the FCU.
2-20	Abnormal coding/decoding (cpu not ready)	<ul style="list-style-type: none"> • Replace the FCU.
2-23	JBIG compression or reconstruction error	<ul style="list-style-type: none"> • Turn off the machine, then turn it back on. • Replace the EXFUNC board if the error is frequent.
2-24	JBIG ASIC error	<ul style="list-style-type: none"> • Turn off the machine, then turn it back on. • Replace the EXFUNC board if the error is frequent.
2-25	JBIG data reconstruction error (BIH error)	<ul style="list-style-type: none"> • JBIG data error • Check the sender's JBIG function. • Update the MBU ROM.
2-26	JBIG data reconstruction error (Float marker error)	
2-27	JBIG data reconstruction error (End marker error)	
2-28	JBIG data reconstruction error (Timeout)	
2-50	The machine resets itself for a fatal FCU system error	<ul style="list-style-type: none"> • If this is frequent, update the ROM, or replace the FCU.
2-51	The machine resets itself because of a fatal communication error	<ul style="list-style-type: none"> • If this is frequent, update the ROM, or replace the FCU.
3-00	G4 interface board reset	<ul style="list-style-type: none"> • Replace the G4 interface board or FCU.
3-10	Disconnection during ISDN G3 communication	<ul style="list-style-type: none"> • Check the other terminal and the ISDN line. • The other terminal may have dialed a wrong number.
3-11	Disconnection during ISDN G4 communication	<ul style="list-style-type: none"> • Check the other terminal and the ISDN line.
3-20	A CSA signal was received during ISDN G4 communication	<ul style="list-style-type: none"> • The operator at the other terminal may have interrupted the communication.
3-21	A CSA signal was sent during ISDN G4 communication, because the Stop key was pressed	<ul style="list-style-type: none"> • The local operator has interrupted the communication.
3-30	Mismatched specifications (rx capability)	<ul style="list-style-type: none"> • Check the receive capabilities requested from the other terminal.
4-01	Line current was cut	<ul style="list-style-type: none"> • Check the line connector. • Check the connection between FCU and NCU. • Check for line problems. • Replace the FCU or the NCU.
4-10	Communication failed because of an ID Code mismatch (Closed Network) or Tel. No./CSI mismatch (Protection against Wrong Connections)	<ul style="list-style-type: none"> • Get the ID Codes the same and/or the CSIs programmed correctly, then resend. • The machine at the other end may be defective.

Code	Meaning	Suggested Cause/Action
5-00	Data construction not possible	<ul style="list-style-type: none"> • Replace the FCU.
5-01	Data reconstruction not possible	
5-10	DCR timer expired	
5-20	Storage impossible because of a lack of memory	<ul style="list-style-type: none"> • Temporary memory shortage. • Test the SAF memory. • Replace the FCU or optional EXMEM board
5-21	Memory overflow	
5-22	Mode table overflow after the second page of a scanned document	<ul style="list-style-type: none"> • Wait for the messages which are currently in the memory to be sent or delete some files from memory.
5-23	Print data error when printing a substitute rx or confidential rx message	<ul style="list-style-type: none"> • Test the SAF memory. • Ask the other end to resend the message. • Replace the FCU or optional EXMEM board.
5-24	Memory overflow after the second page of a scanned document	<ul style="list-style-type: none"> • Try using a lower resolution setting. • Wait for the messages which are currently in the memory to be sent or delete some files from memory.
5-25	SAF file access error	<ul style="list-style-type: none"> • Replace the FCU or EXMEM board.
6-00	G3 ECM - T1 time out during reception of facsimile data	<ul style="list-style-type: none"> • Try adjusting the rx cable equalizer. • Replace the FCU or NCU.
6-01	G3 ECM - no V.21 signal was received	
6-02	G3 ECM - EOR was received	
6-04	G3 ECM - RTC not detected	<ul style="list-style-type: none"> • Check the line connection. • Check connections from the NCU to the FCU. • Check for a bad line or defective remote terminal. • Replace the FCU or NCU.
6-05	G3 ECM - facsimile data frame not received within 18 s of CFR, but there was no line fail	<ul style="list-style-type: none"> • Check the line connection. • Check connections from the NCU to the FCU. • Check for a bad line or defective remote terminal. • Replace the FCU or NCU. • Try adjusting the rx cable equalizer <p>Cross reference</p> <ul style="list-style-type: none"> • Rx cable equalizer - G3 Switch 07 (PSTN)
6-06	G3 ECM - coding/decoding error	<ul style="list-style-type: none"> • Defective FCU. • The other terminal may be defective.
6-08	G3 ECM - PIP/PIN received in reply to PPS.NULL	<ul style="list-style-type: none"> • The other end pressed Stop during communication. • The other terminal may be defective.
6-09	G3 ECM - ERR received	<ul style="list-style-type: none"> • Check for a noisy line. • Adjust the tx levels of the communicating machines. • See code 6-05.

ERROR CODES

Code	Meaning	Suggested Cause/Action
6-10	G3 ECM - error frames still received at the other end after all communication attempts at 2400 bps	<ul style="list-style-type: none"> • Check for line noise. • Adjust the tx level (use NCU parameter 01 or the dedicated tx parameter for that address). • Check the line connection. • Defective remote terminal.
6-21	V.21 flag detected during high speed modem communication	<ul style="list-style-type: none"> • The other terminal may be defective or incompatible.
6-22	The machine resets the sequence because of an abnormal handshake in the V.34 control channel	<ul style="list-style-type: none"> • Check for line noise. • If the same error occurs frequently, replace the FCU. • Defective remote terminal.
6-99	V.21 signal not stopped within 6 s	<ul style="list-style-type: none"> • Replace the FCU.
22-00	Original length exceeded the maximum scan length	<ul style="list-style-type: none"> • Divide the original into more than one page. • Check the resolution used for scanning. Lower the scan resolution if possible. • Add optional page memory.
22-01	Memory overflow while receiving	<ul style="list-style-type: none"> • Wait for the files in the queue to be sent. • Delete unnecessary files from memory. • Transfer the substitute reception files to an another fax machine, if the machine's printer is busy or out of order. • Add an optional SAF memory card or hard disk.
22-02	Tx or rx job stalled due to line disconnection at the other end	<ul style="list-style-type: none"> • The job started normally but did not finish normally; data may or may not have been received fully. • Restart the machine.
22-04	The machine cannot store received data in the SAF	<ul style="list-style-type: none"> • Update the ROM • Replace the FCU.
23-00	Data read timeout during construction	<ul style="list-style-type: none"> • Restart the machine. • Replace the FCU
25-00	The machine software resets itself after a fatal transmission error occurred	<ul style="list-style-type: none"> • Update the ROM • Replace the FCU.
F0-xx	V.34 modem error	<ul style="list-style-type: none"> • Replace the FCU.

2.2 FAX SC CODE AND ERROR MESSAGES

SC871 FCU Flash ROM Abnormal

Message: **Flash ROM error.
Quick Dial Table is Unavailable
Please call service.**

The flash ROM mounted in the fax unit where the address book is stored has been detected as abnormal.

- Replace the FCU.

FCU Flash ROM Access Limit Exceeded

Message: **Flash ROM replacement is now
necessary for the Quick Dial Table.**

The access limit of the flash ROM mounted in the fax unit has exceeded the limit. You can continue to use the machine after this error occurs.

- Replace the FCU.

SRAM Abnormal

Message: **Functional problems with facsimile.
Data will be initialized.**

This message may appear immediately after the fax unit is installed, or when the SRAM (backup RAM) is detected abnormal.

On this message screen:

- Initialize SRAM.
- Set the SRAM backup switch to ON.

Expansion SRAM Abnormal

Message: **Some data will be deleted by installing Fax Memory Board.
Will you continue to install it? If you want to cancel, turn main power switch
off and take the Board out.**

This message may appear immediately after installation of the Function Upgrade Kit, or when the SRAM (backup RAM) is detected abnormal.

On this message screen:

- Initialize the expansion SRAM
- For the Function Upgrade Kit, set the backup switch to ON.

3. SERVICE TABLES

CAUTION

Never turn off the main power switch when the power LED is lit or flashing. To avoid damaging the hard disk or memory, press the operation power switch to switch the power off, wait for the power LED to go off, and then switch the main power switch off.




NOTE: The main power LED lights or flashes while the platen cover or ARDF is open, while the main machine is communicating with a facsimile or the network server, or while the machine is accessing the hard disk or memory for reading or writing data.

3.1 SERVICE PROGRAM MODE

3.1.1 SERVICE PROGRAM MODE OPERATION

The service program (SP) mode is used to check electrical data, change modes, and adjust values.

Entering and Exiting SP mode

- | | |
|---|--|
|  | 1 Press the Clear Mode key. |
| . | . |
|  | 2 Use the keypad to enter "107". |
| . | . |
|  | 3 Hold down Clear/Stop for at least 3 seconds. |
| . | . |
| Fax SP | 4 On the touch-panel, press Fax SP. |
| . | . |
| Exit | 5 Press Exit twice to return to the copy window. |
| . | . |

SERVICE PROGRAM MODE

SP1-XXX (Bit Switches) ➤ Section 3.2 Bit Switches

1	Mode No.		Function
101	System Switch		Change the bit switches for system settings for the fax option ➤ Section 3.2 Bit Switches
	001 – 032	00 – 1F	
102	Ifax Switch		Change the bit switches for scanner settings for the fax option ➤ Section 3.2 Bit Switches
	001 – 016	00 – 0F	
103	Printer Switch		Change the bit switches for printer settings for the fax option ➤ Section 3.2 Bit Switches
	001 – 016	00 – 0F	
104	Communication Switch		Change the bit switches for communication settings for the fax option ➤ Section 3.2 Bit Switches
	001 – 032	00 – 1F	
105	G3-1 Switch		Change the bit switches for the protocol settings of the standard G3 board ➤ Section 3.2 Bit Switches
	001 – 016	00 – 0F	
106	G3-2 Switch		Change the bit switches for the protocol settings of the optional G3 board ➤ Section 3.2 Bit Switches
	001 – 016	00 – 0F	
108	Not used. Do not change these settings.		
109	Not used. Do not change these settings.		


SP2-XXX (RAM Data)

2	Mode No.		Function
101	RAM Read/Write		
	001		Change RAM data for the fax board directly. ☛ Section 3.5 Service RAM Addresses
102	Memory Dump		
	001	G3-1 Memory Dump	Print out RAM data for the fax board. ☛ Section 3.5 Service RAM Addresses
	002	G3-2 Memory Dump	Print out RAM data for the SG3 board.
	004	Not used. Do not change setting.	
103	G3-1 NCU Parameters		
	001 – 023	CC, 01 – 22	NCU parameter settings for the standard G3 board. ☛ Section 3.3 NCU Parameters
104	G3-2 NCU Parameters		
	001 – 023	CC, 01 – 22	NCU parameter settings for the optional G3 board. ☛ Section 3.3 NCU Parameters

Fax Option
B576**SP3-XXX (Machine Settings)**

3	Mode No.		Function
101	Service Station		
	001	Fax Number	Enter the fax number of the service station.
	002	Select Line	Select the line type.
102	Serial Number		
	000		Enter the fax unit's serial number.
103	PSTN-1 Port Settings		
	001	Select Line	Select the line type setting for the G3-1 line. If the machine is installed on a PABX line, select "PABX", "PABX(GND)" or "PABX(FLASH)".
	002	PSTN Access Number	Enter the PSTN access number for the G3-1 line.
	003	Memory Lock Disabled	If the customer does not want to receive transmissions using Memory Lock on this line, turn this SP on.
104	PSTN-2 Port Settings		
	001	Select Line	Select the line setting for the G3-2 line. If the machine is installed on a PABX line, select "PABX", "PABX(GND)" or "PABX(FLASH)".
	002	PSTN Access Number	Enter the PSTN access number for the G3- 2 line.

SERVICE PROGRAM MODE

3	Mode No.		Function
104	003	Memory Lock Disabled	If the customer does not want to receive transmissions using Memory Lock on this line, change this SP to on.
	004	Transmission Disabled	If you turn this SP on, the machine does not send any fax messages on the G3-2 line.
105	PSTN-3 Port settings		
	001	Select Line	Select the line setting for the G3-3 line. If the machine is installed on a PABX line, select "PABX", "PABX(GND)" or "PABX(FLASH)".
	002	PSTN Access Number	Enter the PSTN access number for the G3-3 line.
	003	Memory Lock Disabled	If the customer does not want to receive transmissions using Memory Lock on this line, change this SP to on
	004	Transmission Disabled	If you turn this SP on, the machine does not send any fax messages on the G3-3 line.
106	ISDN Port Settings		
	001	Select Line	Not used. Do not change these settings.
	002	PSTN Access Number	
	003	Memory Lock Disabled	
	004	Transmission Disabled	
201	FAX Switches		Change the bit switches for scanner settings for the fax option  Section 3.2 Bit Switches
	001 – 032	00 – 1F	

SP4-XXX (ROM Versions)

4	Mode No.		Function
101	001	FCU ROM Version	Displays the FCU ROM version.
102	001	Error Codes	Displays the latest 64 fax error codes.
103	001	G3-1 ROM Version	Displays the G3-1 modem version.
104	001	G3-2 ROM Version	Displays the G3-2 modem version.
106	001	G4 ROM Version	Not used.
107	001	Charge ROM Version	Not used.

SP5-XXX (RAM Clear)

5	Mode No.		Function
101	Initialize SRAM		Initializes the bit switches and user parameters, user data in the SRAM, files in the SAF memory, and clock.
	000		
102	Erase All Files		Erases all files stored in the SAF memory.
	000		
103	Reset Bit Switches		Resets the bit switches and user parameters.
	000		
104	Factory setting		Resets the bit switches and user parameters, user data in the SRAM and files in the SAF memory.
	000		

Fax Option
B576

SERVICE PROGRAM MODE

SP6-XXX (Reports)

6	Mode No.		Function
101	System Parameter List		
	000		Touch the "ON" button to print the system parameter list.
102	Service Monitor Report		
	000		Touch the "ON" button to print the service monitor report.
103	G3 Protocol Dump List		
	001	G3 All Communications	Prints the protocol dump list of all communications for all G3 lines.
	002	G3-1 (All Communications)	Prints the protocol dump list of all communications for the G3-1 line.
	003	G3-1 (1 Communication)	Prints the protocol dump list of the last communication for the G3-1 line.
	004	G3-2 (All Communications)	Prints the protocol dump list of all communications for the G3-2 line.
	005	G3-2 (1 Communication)	Prints the protocol dump list of the last communication for the G3-2 line.
104	G4 Protocol Dump List		
	001	Dch + Bch 1	Not used. Do not change these settings.
	002	Dch	
	003	Bch 1 Link Layer	
	004	Dch Link Layer	
	005	Dch +Bch 2	
	006	Bch 2 Link Layer	
105	All Files print out		
	000		Prints out all the user files in the SAF memory, including confidential messages. NOTE: Do not use this function, unless the customer is having trouble printing confidential messages or recovering files stored using the memory lock feature.
106	Journal Print out		
	001	All Journals	The machine prints all the communication records on the report.
	002	Specified Date	The machine prints all communication records after the specified date.

6	Mode No.	Function	
107	Log List Print out		
	001	All log files	These log print out functions are for designer use only.
	002	Printer	
	003	SC/TRAPStored	
	004	Decompression	
	005	Scanner	
	006	JOB/SAF	
	007	Reconstruction	
	008	JBIG	
	009	Fax Driver	
	010	G3 CCU	
	011	Fax Job	
	012	CCU	
013	Scanner Condition		

Fax Option
B576

SERVICE PROGRAM MODE

SP7-XXX (Test)

These are the test modes for PTT approval.

7	Function	
101	G3-1 Modem Tests	
102	G3-1 DTMF Tests	
103	Ringer Test	
104	G3-1 V34 (S2400baud)	
105	G3-1 V34 (S2800baud)	
106	G3-1 V34 (S3000baud)	
107	G3-1 V34 (S3200baud)	
108	G3-1 V34 (S3429baud)	
109	Recorded Message Test	
110	G3-2 Modem Tests	
111	G3-2 DTMF Tests	
112	G3-2 V34 (S2400baud)	
113	G3-2 V34 (S2800baud)	
114	G3-2 V34 (S3000baud)	
115	G3-2 V34 (S3200baud)	
116	G3-2 V34 (S3429baud)	
124	IG3-1 Modem Tests	Not used. Do not change these settings.
125	IG3-1 DTMF Tests	
126	IG3-1 V34 (S2400baud)	
127	IG3-1 V34 (S2800baud)	
128	IG3-1 V34 (S3000baud)	
129	IG3-1 V34 (S3200baud)	
130	IG3-1 V34 (S3429baud)	
131	IG3-2 Modem Tests	
132	IG3-2 DTMF Tests	
133	IG3-2 V34 (S2400baud)	
134	IG3-2 V34 (S2800baud)	
135	IG3-2 V34 (S3000baud)	
136	IG3-2 V34 (S3200baud)	
137	IG3-2 V34 (S3429baud)	

3.2 BIT SWITCHES

⚠ WARNING
Do not adjust a bit switch or use a setting that is described as “Not used”, as this may cause the machine to malfunction or to operate in a manner that is not accepted by local regulations. Such bits are for use only in other areas, such as Japan.

NOTE: Default settings for bit switches are not listed in this manual. Refer to the System Parameter List printed by the machine.

3.2.1 SYSTEM SWITCHES

System Switch 00		SP No. 1-101-001
No	FUNCTION	COMMENTS
0	Dedicated transmission parameter programming 0: Disabled 1: Enabled	Set this bit to 1 before changing any dedicated transmission parameters. Reset this bit to 0 after programming dedicated transmission parameters.
1	Not used	Do not change the setting.
2	Technical data printout on the Journal 0: Disabled 1: Enabled	1: Instead of the personal name, the following data are listed on the Journal for each G3 communication.
<p>e.g. 0000 32V34 288/264 L0100 03 04 (1) (2)(3) (4) (5) (6) (7) (8)</p> <p>(1): EQM value (Line quality data). A larger number means more errors. (2): Symbol rate (V.34 only) (3): Final modem type used (4): Starting data rate (for example, 288 means 28.8 kbps) (5): Final data rate (6): Rx level (refer to the note after this table for how to read the rx level) (7): Total number of error lines that occurred during non-ECM reception. (8): Total number of burst error lines that occurred during non-ECM reception.</p> <p>Note: EQM and rx level are fixed at “FFFF” in tx mode. The seventh and eighth numbers are fixed at “00” for transmission records and ECM reception records.</p>		

Fax Option
B576

BIT SWITCHES

System Switch 00		SP No. 1-101-001
No	FUNCTION	COMMENTS
2	<p>Rx level calculation</p> <p>Example: 0000 32 V34 288/264 L <u>01 00</u> 03 04</p> <p>The four-digit hexadecimal value (N) after “L” indicates the rx level. The <u>high</u> byte is given first, followed by the <u>low</u> byte. Divide the decimal value of N by -16 to get the rx level.</p> <p>In the above example, the decimal value of N (= 0100 [H]) is 256. So, the actual rx level is 256/-16 = -16 dB</p>	
3-4	Not used	Do not change the settings.
5	<p>G3 communication parameter display</p> <p>0: Disabled</p> <p>1: Enabled</p>	<p>This is a fault-finding aid. The LCD shows the key parameters (see below). This is normally disabled because it cancels the CSI display for the user. Be sure to reset this bit to 0 after testing.</p>
6	<p>Protocol dump list output after each communication</p> <p>0: Off</p> <p>1: On</p>	<p>This is only used for communication troubleshooting. It shows the content of the transmitted facsimile protocol signals. Always reset this bit to 0 after finishing testing. If system switch 09 bit 6 is at “1”, the list is only printed if there was an error during the communication.</p>
7	Not used	Do not change the setting.

G3 Communication Parameters

Modem rate	336: 33600 bps 168: 16800 bps 312: 31200 bps 144: 14400 bps 288: 28800 bps 120: 12000 bps 264: 26400 bps 96: 9600 bps 240: 24000 bps 72: 7200 bps 216: 21600 bps 48: 4800 bps 192: 19200 bps 24: 2400 bps
Resolution	S: Standard (8 x 3.85 dots/mm) D: Detail (8 x 7.7 dots/mm) F: Fine (8 x 15.4 dots/mm) SF: Superfine (16 x 15.4 dots/mm) 21: Standard (200 x 100 dpi) 22: Detail (200 x 200 dpi) 44: Superfine (400 x 400 dpi)
Compression mode	MMR: MMR compression MR: MR compression MH: MH compression JBO: JBIG compression (Optional mode) JBB: JBIG compression (Basic mode)
Communication mode	ECM: With ECM NML: With no ECM
Width and reduction	A4: A4 (8.3"), no reduction B4: B4 (10.1"), no reduction A3: A3 (11.7"), no reduction
I/O rate	0: 0 ms/line 10: 10 ms/line 25: 2.5 ms/line 20: 20 ms/line 5: 5 ms/line 40: 40 ms/line Note: "40" is displayed while receiving a fax message using AI short protocol.

Fax Option
B576

System Switch 01 - Not used (Do not change the factory settings.)

BIT SWITCHES

System Switch 02		SP No. 1-101-003
No	FUNCTION	COMMENTS
0-1	Not used Bit 1 Bit 2: Not used.	Do not change the settings.
2	Communication stall fail safe. 0: Disabled 1: Enabled	If enabled, the machine cuts communication within one hour of a communication error but the connection remains established.
3	Not used.	Do not change the setting.
4	File retention time 0: Depends on User Parameter 24 [18(H)] 1: No limit	1: A file that had a communication error will not be erased unless the communication is successful.
5	Not used	Do not change the setting.
6 to 7	Memory read/write by RDS Bit 7 6 Setting 0 0 Always disabled 0 1 User selectable 1 0 User selectable 1 1 Always enabled	(0,0): All RDS systems are always locked out. (0,1), (1,0): Normally, RDS systems are locked out, but the user can temporarily switch RDS on to allow RDS operations to take place. RDS will automatically be locked out again after a certain time, which is stored in System Switch 03. Note that if an RDS operation takes place, RDS will not switch off until this time limit has expired. (1,1): At any time, an RDS system can access the machine.

System Switch 03		SP No. 1-101-004
No	FUNCTION	COMMENTS
0 to 7	Length of time that RDS is temporarily switched on when bits 6 and 7 of System Switch 02 are set to "User selectable"	00 - 99 hours (BCD). This setting is only valid if bits 6 and 7 of System Switch 02 are set to "User selectable". The default setting is 24 hours.

System Switch 04		SP No. 1-101-005
No	FUNCTION	COMMENTS
0	Program registration list output key display selection	This setting determines whether the key to print the program registration list is displayed on the screen.
1-2	Not used	Do not change the settings.
3	Printing dedicated tx parameters on Quick/Speed Dial Lists 0: Disabled 1: Enabled	1: Each Quick/Speed dial number on the list is printed with the dedicated tx parameters (10 bytes each). The first 10 bytes of data are the programmed dedicated tx parameters; 34 bytes of data are printed (the other 24 bytes have no use for service technicians).
4-7	Not used	Do not change the settings.

System Switch 05 - Not used (Do not change the factory settings.)

System Switch 06		SP No. 1-101-007
No	FUNCTION	COMMENTS
0 to 7	Reduction ratio for reduced TX function	71~99% (BCD) This setting is less than 71 (BCD) handled as 71%.

System Switch 07 - Not used (Do not change the factory settings.)
System Switch 08 - Not used (Do not change the factory settings.)

System Switch 09		SP No. 1-101-010
No	FUNCTION	COMMENTS
0	Addition of image data from confidential transmissions on the transmission result report 0: Disabled 1: Enabled	If this feature is enabled, the top half of the first page of confidential messages will be printed on transmission result reports.
1	Inclusion of communications on the Journal when no image data was exchanged. 0: Disabled 1: Enabled	0: Communications that reached phase C (message tx/rx) of the T.30 protocol are listed on the Journal. 1: Communications that reached phase A (call setup) of T.30 protocol are listed on the Journal. This will include telephone calls.
2	Automatic error report printout 0: Disabled 1: Enabled	0: Error reports will not be printed. 1: Error reports will be printed automatically after failed communications.
3	Printing of the error code on the error report 0: No 1: Yes	1: Error codes are printed on the error reports.
4	Not used	Do not change the setting.
5	Power failure report 0: Disabled 1: Enabled	1: A power failure report will be automatically printed after the power is switched on if a fax message disappeared from the memory when the power was turned off last.
6	Conditions for printing the protocol dump list 0: Print for all communications 1: Print only when there is a communication error	This switch becomes effective only when system switch 00 bit 6 is set to 1. 1: Set this bit to 1 when you wish to print a protocol dump list only for communications with errors.
7	Priority given to various types of remote terminal ID when printing reports 0: RTI > CSI > Dial label > Tel. number 1: Dial label > Tel. number > RTI > CSI	This bit determines which set of priorities the machine uses when listing remote terminal names on reports. Dial Label: The name stored, by the user, for the Quick/Speed Dial number.

Fax Option
B576

BIT SWITCHES

System Switch 0A		SP No. 1-101-011
No	FUNCTION	COMMENTS
0-2	Not used	Do not change the settings.
3	Continuous polling reception 0: Disabled 1: Enabled	This feature allows a series of stations to be polled in a continuous cycle. This will continue until the polling reception file is erased. The dialing interval is the same as memory transmission.
4	Dialing on the ten-key pad when the external telephone is off-hook 0: Disabled 1: Enabled	0: Prevents dialing from the ten-key pad while the external telephone is off-hook. Use this setting when the external telephone is not by the machine, or if a wireless telephone is connected as an external telephone. 1: The user can dial on the machine's ten-key pad when the handset is off-hook.
5	On hook dial 0: Disabled 1: Enabled	0: On hook dial is disabled.
6-7	Not used	Do not change the settings.

System Switch 0B - Not used (Do not change the factory settings.)
System Switch 0C - Not used (Do not change the factory settings.)
System Switch 0D - Not used (Do not change the factory settings.)

System Switch 0E		SP No. 1-101-015
No	FUNCTION	COMMENTS
0-2	Not used	Do not change the settings.
3	Action when the external handset goes off-hook 0: Manual tx and rx operation 1: Memory tx and rx operation (the display remains the same)	0: Manual tx and rx are possible while the external handset is off-hook. However, memory tx is not possible. 1: The display stays in standby mode even when the external handset is used, so that other people can use the machine for memory tx operation. Note that manual tx and rx are not possible with this setting.
4-7	Not used	Do not change the settings.

System Switch 0F		SP No. 1-101-016
No	FUNCTION	COMMENTS
0 to 7	Country/area code for functional settings (Hex) 00: France 11: USA 01: Germany 12: Asia 02: UK 13: Japan 03: Italy 14: Hong Kong 04: Austria 15: South Africa 05: Belgium 16: Australia 06: Denmark 17: New Zealand 07: Finland 18: Singapore 08: Ireland 19: Malaysia 09: Norway 1A: China 0A: Sweden 1B: Taiwan 0B: Switz. 1C: Korea 0C: Portugal 20: Turkey 0D: Holland 21: Greece 0E: Spain 22: Hungary 0F: Israel 23: Czech 10: Canada 24: Poland	This country/area code determines the factory settings of bit switches and RAM addresses. However, it has no effect on the NCU parameter settings and communication parameter RAM addresses. Cross reference NCU country code: SP2-103, 104, parameter C.C.

Fax Option
B576

System Switch 10 - Not used (Do not change the factory settings.)

BIT SWITCHES

System Switch 11		SP No. 1-101-018
No	FUNCTION	COMMENTS
0	TTI printing position 0: Superimposed on the page data 1: Printed before the data leading edge	Change this bit to 1 if the TTI overprints information that the customer considers to be important (G3 transmissions).
1	TSI (G3) printing position 0: Superimposed on the page data 1: Printed before the data leading edge	Change this bit to 1 if the TSI (G3) overprints information that the customer considers to be important.
2-7	Not used	Do not change the factory setting.

System Switch 12		SP No. 1-101-019
No	FUNCTION	COMMENTS
0 to 7	TTI printing position in the main scan direction	TTI/CIL: 08 to 92 (BCD) mm Input even numbers only. This setting determines the print start position for the TTI and CIL from the left edge of the paper. If the TTI is moved too far to the right, it may overwrite the file number which is on the top right of the page.

System Switch 13 - Not used (do not change the settings)
System Switch 14 - Not used (do not change the settings)

System Switch 15		SP No. 1-101-022
No	FUNCTION	COMMENTS
0	Not used	Do not change the setting.
1	Going into the Energy Saver mode automatically 0: Enabled 1: Disabled	1: The machine will restart from the Energy Saver mode quickly, because the +5V power supply is active even in the Energy Saver mode.
2-7	Not used	Do not change the settings.

System Switch 16		SP No. 1-101-023
No	FUNCTION	COMMENTS
0	Parallel Broadcasting 0: Disabled 1: Enabled	1: When the G3 unit is installed, the machine sends messages simultaneously using both available ports (PSTN/ISDN) during broadcasting.
2	Not used	Do not change the settings.

System Switch 17 - Not used (do not change the settings)
System Switch 18 - Not used (do not change the settings)

System Switch 19		SP No. 1-101-026
No	FUNCTION	COMMENTS
0-2	Not used	Do not change the settings.
3	Selects a temporary address for the number PC-FAX #.	0: When prefixed by #, handled only as a stored address. 1: When prefixed by #, when a digit exists that prevents handling the transaction as a Quick, Speed, or Group dialing, handles temporarily.
4	Number of jobs controlled for PC-FAX TX 0: 64 Jobs 1: No limitations (but conforms to device limitations)	Sets the number of jobs controlled for PC-FAX transactions. If "1" is selected (no limitations), control is relinquished to the device (standard 400, expandable to 800).
6	Not used	Do not change the settings.
7	Special Original mode 0: Disabled 1: Enabled	1: If the customer frequently wishes to transmit a form or letterhead which has a colored or printed background, change this bit to "1". "Original 1" and "Original 2" can be selected in addition to the "Text", "Text/Photo" and "Photo" modes.

Fax Option
B576

BIT SWITCHES

System Switch 1A		SP No. 1-101-026
No	FUNCTION	COMMENTS
0 to 7	LS RX memory remaining refresh value setting	Sets a value of 4K. If the amount of memory remaining falls below 4K, documents received in memory are printed to create more space in memory. Initial value: 0x80 (512K) 00-FF (0-1020 KB: Hex)

System Switch 1B - Not used (do not change the settings)
System Switch 1C - Not used (do not change the settings)

System Switch 1D		SP No. 1-101-030
No	FUNCTION	COMMENTS
0	RTI/CSI display 0: Disabled 1: Enabled	1: RTI/CSI is displayed on the top line of the LCD panel during communication.
1-7	Not used	Do not change the settings.

System Switch 1E		SP No. 1-101-031
No	FUNCTION	COMMENTS
0	Communication after the Journal data storage area has become full 0: Impossible 1: Possible	This setting is effective only when Automatic Journal printout is enabled but the machine cannot print the report (e.g., no paper). 0: If the buffer memory of the communication records for the Journal has become full, fax communications will become impossible, to prevent overwriting the communication records before the machine prints them out. 1: If the buffer memory of the communication records for the Journal is full, fax communications are still possible. But the machine will overwrite the oldest communication records. Cross Reference <input type="checkbox"/> Automatic Journal output - User switch 03 bit 7 <input type="checkbox"/> Number of communication records for the Journal: 200 records (standard) 1000 records (with the Function Upgrade unit installed)
1	Action when the SAF memory has become full during scanning 0: The current page is erased. 1: The entire file is erased.	0: If the SAF memory becomes full during scanning, the successfully scanned pages are transmitted. 1: If the SAF memory becomes full during scanning, the file is erased and no pages are transmitted. This bit switch is ignored for parallel memory transmission.

System Switch 1E		SP No. 1-101-031
No	FUNCTION	COMMENTS
2	RTI/CSI display priority 0: RTI 1: CSI	This bit determines which identifier, RTI or CSI, is displayed on the LCD while the machine is communicating in G3 non-standard mode.
3	File No. printing 0: Enabled 1: Disabled	1: File numbers are not printed on any reports.
4	This switch allows or prohibits all fax reception when Authorized Reception is enabled and no RTI/CSIs have been programmed. 0: All fax receptions are enabled 1: All fax receptions are disabled	This switch is only effective when Authorized Reception is enabled and there are no RTI/CSIs programmed. Under these two conditions: The default setting of "0" allows the machine to receive all incoming faxes. This is useful in cases where the customer has mistakenly enabled Authorized Reception with no RTI/CSIs programmed. Setting this switch to "1" will cause the machine to reject all incoming transmissions.
5-6	Not used	Do not change the setting.
7	RAM initialization after the optional Function Upgrade unit is installed or removed 0: Enabled 1: Disabled	When the machine detects that a Function Upgrade unit has been installed or removed, the machine shows the following message on the display for the customer. <i>"Adding/Removing FAX Feature Expander causes data loss. Turn Main Power Switch off and remove/replace it to avoid loss. To continue, press Yes."</i> If Yes is pressed, the machine initializes the RAM to the "with" or "without card" configuration. However, changing this bit to "1" disables this initialization, even if Yes is pressed. Change this bit to 1 after installing the Function Upgrade unit. 0: When the above message is displayed, the machine initializes the RAM if Yes is pressed. The amount of data lost depends on whether the board is in or out. To avoid losing data, the user must switch off immediately and put the Function Upgrade unit back in. 1: When the above message is displayed, the machine does not initialize the RAM even if Yes is pressed. However, the fax unit cannot be used until the user switches off, puts the Function Upgrade unit back in, then switches back on. No data is lost.



Fax Option
B576

BIT SWITCHES

System Switch 1F		SP No. 1-101-032
No	FUNCTION	COMMENTS
0	Not used	Do not change the setting.
1	Report printout after an original jam during SAF storage or if the SAF memory fills up 0: Enabled 1: Disabled	0: When an original jams, or the SAF memory overflows during scanning, a report will be printed. Change this bit to "1" if the customer does not want to have a report in these cases. Memory tx – Memory storage report Parallel memory tx – Transmission result report
2	Not used	Do not change the setting.
3	Received fax print start timing (G3 reception) 0: After receiving each page 1: After receiving all pages	0: The machine prints each page immediately after the machine receives it. 1: The machine prints the complete message after the machine receives all the pages in the memory.
4-6	Not used	Do not change the factory settings.
7	Action when a fax SC has occurred 0: Automatic reset 1: Fax unit stops	0: When the fax unit detects a fax SC code other than SC1201 and SC1207, the fax unit automatically resets itself. 1: When the fax unit detects any fax SC code, the fax unit stops. Cross Reference Fax SC codes - See "Troubleshooting"

3.2.2 IFAX SWITCHES

Please refer to the IFAX Service Manual.

3.2.3 PRINTER SWITCHES

Printer Switch 00		SP No. 1-103-001
No	FUNCTION	COMMENTS
0	Page separation mark 0: Disabled 1: Enabled	0: No marks are printed. 1: If a received page has to be printed out on two sheets, an asterisk inside square brackets is printed at the bottom right hand corner of the first sheet, and a "2" inside a small box is printed at the top right hand corner of the second sheet. This helps the user to identify pages that have been split.
1	Repetition of data when the received page is longer than the printer paper 0: Disabled 1: Enabled	0: The next page continues from where the previous page left off. 1: The final few mm of the previous page are repeated at the top of the next page. The amount of repeated data depends on printer switch 04, bits 5 and 6.
2	Prints the date and time on received fax messages 0: Disabled 1: Enabled	This switch is only effective when user parameter 02 - bit 2 (printing the received date and time on received fax messages) is enabled. 1: The machine prints the received and printed date and time at the bottom of each received page.
3-7	Not used	Do not change the settings.

Fax Option
B576

Printer Switch 01		SP No. 1-103-002
No	FUNCTION	COMMENTS
0-2	Not used	Do not change the settings.
3-4	Maximum print width used in the setup protocol Bit 4 3 Setting 0 0 Not used 0 1 A3 1 0 B4 1 1 A4	These bits are only effective when bit 7 of printer switch 01 is "1".
5-6	Not used	Do not change the settings.
7	Received message width restriction in the protocol signal to the sender 0: Disabled 1: Enabled	0: The machine informs the transmitting machine of the print width depending on the paper size available from the paper feed stations. Refer to the table on the next page for how the machine chooses the paper width used in the setup protocol (NSF/DIS). 1: The machine informs the transmitting machine of the fixed paper width which is specified by bits 3 and 4 above.

BIT SWITCHES

Relationship between available paper sizes and printer width used in the setup protocol

Available Paper Size	Printer width used in the Protocol (NSF/DIS)
A4 or 8.5" x 11"	297 mm width
B5	256 mm width
A5 or 8.5" x 5.5"	216 mm width
No paper available (Paper end)	216 mm width

Printer Switch 02		SP No. 1-103-003
No	FUNCTION	COMMENTS
0	1st paper feed station usage for fax printing 0: Enabled 1: Disabled	<p>0: The paper feed station can be used to print fax messages and reports.</p> <p>1: The specified paper feed station will not be used for printing fax messages and reports.</p> <p>Note: Do not disable usage for a paper feed station which has been specified by User Parameter Switch 0F (15), or which is used for the Specified Cassette Selection feature.</p>
1	2nd paper feed station usage for fax printing 0: Enabled 1: Disabled	
2	3rd paper feed station usage for fax printing 0: Enabled 1: Disabled	
3	4th paper feed station usage for fax printing 0: Enabled 1: Disabled	
4	LCT usage for fax printing 0: Enabled 1: Disabled	
5-7	Not used	Do not change the settings.

Printer Switch 03		SP No. 1-103-004
No	FUNCTION	COMMENTS
0	Length reduction of received data 0: Disabled 1: Enabled	<p>0: Incoming pages are printed without length reduction. (Page separation threshold: Printer Switch 03, bits 4 to 7)</p> <p>1: Incoming page length is reduced when printing. (Maximum reducible length: Printer Switches 04, bits 0 to 4)</p>
1-3	Not used	Do not change the settings

Printer Switch 03		SP No. 1-103-004						
No	FUNCTION	COMMENTS						
4 to 7	<p>Page separation threshold (with reduction disabled with switch 03-0 above)</p> <p>If the incoming page is up to x mm longer than the length of copy paper, the excess portion will not be printed. If the incoming page is more than x mm longer than the length of copy paper, the excess portion will be printed on the next page. The value of x is determined by these four bits.</p> <p>Hex value of bits 4 to 7 x (mm)</p> <table style="margin-left: 40px;"> <tr><td>0</td><td>0</td></tr> <tr><td>1</td><td>1</td></tr> </table> <p>and so on until</p> <table style="margin-left: 40px;"> <tr><td>F</td><td>15</td></tr> </table> <p>Default setting: 6 mm</p> <p>Cross reference Length reduction On/Off: Printer Switch 03, Bit 0</p>	0	0	1	1	F	15	
0	0							
1	1							
F	15							

Fax Option
B576

Printer Switch 04		SP No. 1-103-005																																										
No	FUNCTION	COMMENTS																																										
0 to 4	<p>Maximum reducible length when length reduction is enabled with switch 03-0 above. <Maximum reducible length> = <Paper length> + (N x 5mm) "N" is the decimal value of the binary setting of bits 0 to 4.</p> <p>Bit 4 3 2 1 0 Setting</p> <table style="margin-left: 40px;"> <tr><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0 mm</td><td>Not Used</td></tr> <tr><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>5 mm</td><td></td></tr> <tr><td colspan="7"> </td></tr> <tr><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>20 mm</td><td>(default setting)</td></tr> <tr><td colspan="7"> </td></tr> <tr><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>155 mm</td><td></td></tr> </table> <p>For A5 sideways and B5 sideways paper <Maximum reducible length> = <Paper length> + 0.75 x (N x 5mm)</p>	0	0	0	0	0	0 mm	Not Used	0	0	0	0	1	5 mm									0	0	1	0	0	20 mm	(default setting)								1	1	1	1	1	155 mm		
0	0	0	0	0	0 mm	Not Used																																						
0	0	0	0	1	5 mm																																							
0	0	1	0	0	20 mm	(default setting)																																						
1	1	1	1	1	155 mm																																							
5 to 6	<p>Length of the duplicated image on the next page, when page separation has taken place.</p> <p>$\begin{pmatrix} 0 \\ 0 \end{pmatrix} = 4 \text{ mm}$ $\begin{pmatrix} 1 \\ 0 \end{pmatrix} = 10 \text{ mm}$ $\begin{pmatrix} 0 \\ 1 \end{pmatrix} = 15 \text{ mm}$ $\begin{pmatrix} 1 \\ 1 \end{pmatrix} = \text{Not used}$</p>																																											
7	Not used.	Do not change the setting.																																										

Printer Switch 05 - Not used (do not change the settings)
--

BIT SWITCHES

Printer Switch 06		SP No. 1-103-007
No	FUNCTION	COMMENTS
0	Printing while a paper cassette is pulled out, when the Just Size Printing feature is enabled. 0: Printing will not start 1: Printing will start if another cassette has a suitable size of paper, based on the paper size selection priority tables.	Cross reference Just size printing on/off – User switch 05, bit 5
1-7	Not used.	Do not change the settings.

Printer Switch 07		SP No. 1-103-008
No	FUNCTION	COMMENTS
0	Reduction for Journal printing 0: Off 1: On	1: The Journal is reduced to 91% to ensure that there is enough space in the left margin for punch holes or staples.
2-3	Not used.	Do not change the settings.
4	List of destinations in the Communication Failure Report for broadcasting 0: All destinations 1: Only destinations where communication failure occurred	1: Only destinations where communication failure occurred are printed on the Communication Failure Report.
5-7	Not used.	Do not change the settings.

Printer Switch 08 - Not used (do not change the settings)
Printer Switch 09 - Not used (do not change the settings)
Printer Switch 0A - Not used (do not change the settings)
Printer Switch 0B - Not used (do not change the settings)
Printer Switch 0C - Not used (do not change the settings)
Printer Switch 0D - Not used (do not change the settings)

Printer Switch 0E		SP No. 1-103-015
No	FUNCTION	COMMENTS
0	Paper size selection priority 0: Width 1: Length	0: A paper size that has the same width as the received data is selected first. 1: A paper size which has enough length to print all the received lines without reduction is selected first.
1	Paper size selected for printing A4 width fax data 0: 8.5" x 11" size 1: A4 size	This switch determines which paper size is selected for printing A4 width fax data, when the machine has both A4 and 8.5" x 11" size paper.
2	Page separation 0: Enabled 1: Disabled	1: If all paper sizes in the machine require page separation to print a received fax message, the machine does not print the message (Substitute Reception is used). After a larger size of paper is set in a cassette, the machine automatically prints the fax message.
3 to 4	Printing the sample image on reports Bit 4 Bit 3 Setting 0 0 The upper half only 0 1 50% reduction in sub-scan only 1 0 Same size 1 1 Not used	"Same size" means the sample image is printed at 100%, even if page separation occurs. User Parameter Switch 19 (13H) bit 4 must be set to "0" to enable this switch. Refer to Detailed Section Descriptions for more on this feature.
5-6	Not used	Do not change the settings.
7	Equalizing the reduction ratio among separated pages (Page Separation) 0: Enabled 1: Disabled	0: When page separation has taken place, all the pages are reduced with the same reduction ratio. 1: Only the last page is reduced to fit the selected paper size when page separation has taken place. Other pages are printed without reduction.

Fax Option
B576

BIT SWITCHES

Printer Switch 0F			SP No. 1-103-016
No	FUNCTION		COMMENTS
0 to 1	Smoothing feature Bit 1 Bit 0 Setting 0 0 Disabled 0 1 Disabled 1 0 Enabled 1 1 Not used		(0, 0) (0, 1): Disable smoothing if the machine receives halftone images from other manufacturers fax machines frequently.
2	Duplex printing 0: Disabled 1: Enabled		1: The machine always prints received fax messages in duplex printing mode:
3	Binding direction for Duplex printing 0: Left binding 1: Top binding		
4	Printing fax messages in user code mode 0: Enabled 1: Disabled		1: The machine holds the received fax messages until the machine exits the restricted access mode (user code or key counter). If the machine enters the restricted access mode again while printing fax messages, the machine stops printing the machine exits the mode again.
5-7	Not used		Do not change the settings.

3.2.4 COMMUNICATION SWITCHES

Communication Switch 00		SP No. 1-104-001
No	FUNCTION	COMMENTS
0 to 1	Compression modes available in receive mode Bit 1 0 Modes 0 0 MH only 0 1 MH/MR 1 0 MH/MR/MMR 1 1 MH/MR/MMR/JBIG	These bits determine the compression capabilities to be declared in phase B (handshaking) of the T.30 protocol.
2 to 3	Compression modes available in transmit mode Bit 3 2 Modes 0 0 MH only 0 1 MH/MR 1 0 MH/MR/MMR 1 1 MH/MR/MMR/JBIG	These bits determine the compression capabilities to be used in the transmission and to be declared in phase B (handshaking) of the T.30 protocol.
4	Not used	Do not change the setting.
5	JBIG compression method: Reception 0: Only basic supported 1: Basic and optional both supported	Change the setting when communication problems occur using JBIG compression.
6	JBIG compression method: Transmission 0: Basic mode priority 1: Optional mode priority	Change the setting when communication problems occur using JBIG compression.
7	Closed network (reception) 0: Disabled 1: Enabled	1: Reception will not go ahead if the ID code of the other terminal does not match the ID code of this terminal. This function is only available in NSF/NSS mode.

BIT SWITCHES

Communication Switch 01		SP No. 1-104-002
No	FUNCTION	COMMENTS
0	ECM 0: Off 1: On	If this bit is set to 0, ECM is switched off for all communications. In addition, V.8 protocol and JBIG compression are switched off automatically.
1	Not used	Do not change the setting.
2 to 3	Wrong connection prevention method Bit 3 Bit 2 Setting 0 0 None 0 1 8 digit CSI 1 0 4 digit CSI 1 1 CSI/RTI	(0,1) - The machine will disconnect the line without sending a fax message, if the last 8 digits of the received CSI do not match the last 8 digits of the dialed telephone number. This does not work when manually dialed. (1,0) - The same as above, except that only the last 4 digits are compared. (1,1) - The machine will disconnect the line without sending a fax message, if the other end does not identify itself with an RTI or CSI. (0,0) - Nothing is checked; transmission will always go ahead. Note: This function does not work when dialing is done from the external telephone.
4-5	Not used	Do not change the settings.
6 to 7	Maximum printable page length available Bit 7 6 Setting 0 0 No limit 0 1 B4 (364 mm) 1 0 A4 (297 mm) 1 1 Not used	The setting determined by these bits is informed to the transmitting terminal in the pre-message protocol exchange (in the DIS/NSF frames).

Communication Switch 02		SP No. 1-104-003
No	FUNCTION	COMMENTS
0	Burst error threshold 0: Low 1: High	If there are more consecutive error lines in the received page than the threshold, the machine will send a negative response. The Low and High threshold values depend on the sub-scan resolution, and are as follows. Resolution 100 dpi 200 dpi 400 dpi 3.85 l/mm 7.7 l/mm 15.4 l/mm Low settings 6 12 24 High settings 12 24 48
1	Acceptable total error line ratio 0: 5% 1: 10%	If the error line ratio for a page exceeds the acceptable ratio, RTN will be sent to the other end.
2	Treatment of pages received with errors during G3 reception 0: Deleted from memory without printing 1: Printed	0: Pages received with errors are not printed.
3	Hang-up decision when a negative code (RTN or PIN) is received during G3 immediate transmission 0: No hang-up, 1: Hang-up	0: The next page will be sent even if RTN or PIN is received. 1: The machine will send DCN and hang up if it receives RTN or PIN. This bit is ignored for memory transmissions or if ECM is being used.
4-7	Not used	Do not change the settings.

Fax Option
B576

Communication Switch 03		SP No. 1-104-004
No	FUNCTION	COMMENTS
0 to 7	Maximum number of page retransmissions in a G3 memory transmission	00 - FF (Hex) times. This setting is not used if ECM is switched on. Default setting - 03(H)

Communication Switch 04 - Not used (do not change the settings)
Communication Switch 05 - Not used (do not change the settings)
Communication Switch 06 - Not used (do not change the settings)
Communication Switch 07 - Not used (do not change the settings)
Communication Switch 08 - Not used (do not change the settings)
Communication Switch 09 - Not used (do not change the settings)

BIT SWITCHES

Communication Switch 0A		SP No. 1-104-011
No	FUNCTION	COMMENTS
0	Point of resumption of memory transmission upon redialing 0: From the error page 1: From page 1	0: The transmission begins from the page where transmission failed the previous time. 1: Transmission begins from the first page, using normal memory transmission.
1-7	Not used	Do not change the settings.

Communication Switch 0B		SP No. 1-104-012
No	FUNCTION	COMMENTS
0	Use of Economy Transmission during a Transfer operation to end receivers 0: Disabled 1: Enabled	These bits determine whether the machine uses the Economy Transmission feature when it is carrying out a Transfer operation as a Transfer Station.
1	Use of Economy Transmission during a Transfer operation to the Next Transfer Stations 0: Disabled 1: Enabled	
2	Use of Label Insertion for the End Receivers in a Transfer operation 0: Disabled 1: Enabled	This bit determines whether the machine uses the Label Insertion feature when it is carrying out a Transfer operation as a Transfer Station.
3	Conditions required for Transfer Result Report transmission 0: Always transmitted 1: Only transmitted if there was an error	0: When acting as a Transfer Station, the machine will always send a Transfer Result Report back to the Requesting Station after completing the Transfer Request, even if there were no problems. 1: The machine will only send back a Transfer Result Report if there were errors during communication, meaning one or more of the End Receivers could not be contacted.
4	Printout of the message when acting as a Transfer Station 0: Disabled 1: Enabled	When the machine is acting as a Transfer Station, this bit determines whether the machine prints the fax message coming in from the Requesting Terminal.
5	Action when there is no fax number in the programmed Quick/Speed dials which meets the requesting terminal's own fax number 0: Transfer is disabled 1: Transfer is enabled	After the machine receives a transfer request, the machine compares the last N digits of the requesting terminal's own fax number with all the Quick/Speed dials programmed in the machine. (N is the number programmed in communication switch 0C.) 0: If there is no matching number programmed in the machine, the machine rejects the transfer request. 1: Even if there is no matching number programmed in the machine, the machine accepts the transfer request. The result report will be printed at the transfer terminal, but will not be sent back to the requesting terminal.
6-7	Not used	Do not change the settings.

Communication Switch 0C		SP No. 1-104-013
No	FUNCTION	COMMENTS
0 to 4	Number of digits compared to find the requester's fax number from the programmed Quick/Speed Dials when acting as a Transfer Station	00 - 1F (0 to 31 digits) After the machine receives a transfer request, the machine compares the own telephone number sent from the Requesting Terminal with all Quick/Speed Dials programmed in the machine, starting from Quick Dial 01 to the end of the Speed Dials. This number determines how many digits from the end of the telephone numbers the machine compares. If it is set to 00, the machine will send the report to the first Quick/Speed Dial that the machine compared. If Quick Dial 01 is programmed, the machine will send the report to Quick 01. If Quick Dial 01 through 04 are not programmed and Quick Dial 05 is programmed, the machine will send the report to Quick 05. Default setting - 05(H) = 5 digits
5-7	Not used	Do not change the settings.

Communication Switch 0D		SP No. 1-104-014
No	FUNCTION	COMMENTS
0 to 7	The available memory threshold, below which ringing detection (and therefore reception into memory) is disabled	00 to FF (Hex), unit = 4 kbytes (e.g., 06(H) = 24 kbytes) One page is about 24 kbytes. The machine refers to this setting before each fax reception. If the amount of remaining memory is below this threshold, the machine cannot receive any fax messages. If this setting is kept at 0, the machine will detect ringing signals and go into receive mode even if there is no memory available. This will result in communication failure.

Communication Switch 0E		SP No. 1-104-015
No	FUNCTION	COMMENTS
0 to 7	Minimum interval between automatic dialing attempts	06 to FF (Hex), unit = 2 s (e.g., 06(H) = 12 s) This value is the minimum time that the machine waits before it dials the next destination.

Communication Switch 0F - Not used (do not change the settings.)

BIT SWITCHES

Communication Switch 10		SP No. 1-104-017
No	FUNCTION	COMMENTS
0 to 7	Memory transmission: Maximum number of dialing attempts to the same destination	01 - FE (Hex) times

Communication Switch 11 - Not used (do not change the settings.)

Communication Switch 12		SP No. 1-104-019
No	FUNCTION	COMMENTS
0 to 7	Memory transmission: Interval between dialing attempts to the same destination	01 - FF (Hex) minutes

Communication Switch 13 - Not used (do not change the settings.)

Communication Switch 14		SP No. 1-104-021															
No	FUNCTION	COMMENTS															
0	Inch-to-mm conversion during transmission 0: Disabled 1: Enabled	0: In immediate transmission, data scanned in inch format are transmitted without conversion. In memory transmission, data stored in the SAF memory in mm format are transmitted without conversion. Note: When storing the scanned data into SAF memory, the fax unit always converts the data into mm format. 1: The machine converts the scanned data or stored data in the SAF memory to the format which was specified in the set-up protocol (DIS/NSF) before transmission.															
1-5	Not used	Do not change the factory settings.															
6 to 7	Available unit of resolution in which fax messages are received <table border="0"> <tr> <td>Bit 7</td> <td>Bit 6</td> <td>Unit</td> </tr> <tr> <td>0</td> <td>0</td> <td>mm</td> </tr> <tr> <td>0</td> <td>1</td> <td>inch</td> </tr> <tr> <td>1</td> <td>0</td> <td>mm and inch (default)</td> </tr> <tr> <td>1</td> <td>1</td> <td>Not used</td> </tr> </table>	Bit 7	Bit 6	Unit	0	0	mm	0	1	inch	1	0	mm and inch (default)	1	1	Not used	For the best performance, do not change the factory settings. The setting determined by these bits is informed to the transmitting terminal in the pre-message protocol exchange (in the DIS/NSF frames).
Bit 7	Bit 6	Unit															
0	0	mm															
0	1	inch															
1	0	mm and inch (default)															
1	1	Not used															

Communication Switch 15 - Not used (do not change the settings.)

Communication Switch 16		SP No. 1-104-023
No	FUNCTION	COMMENTS
0	Not used.	Do not change setting.
1	Optional G3 unit (G3-2) 0: Not installed 1: Installed	Change this bit to 1 when installing the first optional G3 unit.
2 to 7	Not used.	Do not change setting.

Communication Switch 17		SP No. 1-104-024
No	FUNCTION	COMMENTS
0	SEP reception 0: Disabled 1: Enabled	0: Polling transmission to another maker's machine using the SEP (Selective Polling) signal is disabled.
1	SUB reception 0: Disabled 1: Enabled	0: Confidential reception to another maker's machine using the SUB (Sub-address) signal is disabled.
2	PWD reception 0: Disabled 1: Enabled	0: Disables features that require PWD (Password) signal reception.
3-6	Not used	Do not change the settings.
7	Action when there is no box with an F-code that matches the received SUB code 0: Disconnect the line 1: Receive the message (using normal reception mode)	Change this setting when the customer requires.

Fax Option B576

Communication Switch 18 - Not used (do not change the settings)
Communication Switch 19 - Not used (do not change the settings)
Communication Switch 1A - Not used (do not change the settings)

Communication Switch 1B		SP No. 1-104-028
No	FUNCTION	COMMENTS
0 to 7	Extension access code (0 to 7) to turn V.8 protocol On/Off 0: On 1: Off	If the PABX does not support V.8/V.34 protocol procedure, set this bit to "1" to disable V.8. Example: If "0" is the PSTN access code, set bit 0 to 1. When the machine detects "0" as the first dialed number, it automatically disables V.8 protocol. (Alternatively, if "3" is the PSTN access code, set bit 3 to 1.)

BIT SWITCHES

Communication Switch 1C		SP No. 1-104-029
No	FUNCTION	COMMENTS
0 to 1	Extension access code (8 and 9) to turn V.8 protocol On/Off 0: On 1: Off	Refer to communication switch 1E. Example: If "8" is the PSTN access code, set bit 0 to 1. When the machine detects "8" as the first dialed number, it automatically disables V.8 protocol. (If "9" is the PSTN access code, use bit 1.)
2-7	Not used	Do not change the settings.

Communication Switch 1D - Not used (do not change the settings)
Communication Switch 1E - Not used (do not change the settings)
Communication Switch 1F - Not used (do not change the settings)

3.2.5 G3-1 SWITCHES

G3-1 Switch 00			SP No. 1-105-001															
No	FUNCTION	COMMENTS																
0	Monitor speaker during communication (tx and rx)	(0, 0): The monitor speaker is disabled all through the communication.																
1	<table border="0"> <tr> <td>Bit 1</td> <td>Bit 0</td> <td>Setting</td> </tr> <tr> <td>0</td> <td>0</td> <td>Disabled</td> </tr> <tr> <td>0</td> <td>1</td> <td>Up to Phase B</td> </tr> <tr> <td>1</td> <td>0</td> <td>All the time</td> </tr> <tr> <td>1</td> <td>1</td> <td>Not used</td> </tr> </table>	Bit 1	Bit 0	Setting	0	0	Disabled	0	1	Up to Phase B	1	0	All the time	1	1	Not used	(0, 1): The monitor speaker is on up to phase B in the T.30 protocol. (1, 0): Used for testing. The monitor speaker is on all through the communication. Make sure that you reset these bits after testing.	
Bit 1	Bit 0	Setting																
0	0	Disabled																
0	1	Up to Phase B																
1	0	All the time																
1	1	Not used																
2	Monitor speaker during memory transmission 0: Disabled 1: Enabled	1: The monitor speaker is enabled during memory transmission.																
3-7	Not used	Do not change the settings.																

G3-1 Switch 01			SP No. 1-105-002
No	FUNCTION	COMMENTS	
0-3	Not used	Do not change the settings.	
4	DIS frame length 0: 10 bytes 1: 4 bytes	1: The bytes in the DIS frame after the 4th byte will not be transmitted (set to 1 if there are communication problems with PC-based faxes which cannot receive the extended DIS frames).	
5	Not used	Do not change the setting.	
6	CED/ANSam transmission 0: Disabled 1: Enabled	Do not change this setting, unless the communication problem is caused by the CED/ANSam transmission.	
7	Not used	Do not change the setting.	

G3-1 Switch 02			SP No. 1-105-003
No	FUNCTION	COMMENTS	
0	G3 protocol mode used 0: Standard and non-standard 1: Standard only	Change this bit to 1 only when the other end can only communicate with machines that send T.30-standard frames only. 1: Disables NSF/NSS signals (these are used in non-standard mode communication)	
1-4	Not used	Do not change the settings.	
5	Use of modem rate history for transmission using Quick/Speed Dials 0: Disabled 1: Enabled	0: Communications using Quick/Speed Dials always start from the highest modem rate. 1: The machine refers to the modem rate history for communications with the same machine when determining the most suitable rate for the current communication.	
6	AI short protocol (transmission and reception) 0: Disabled 1: Enabled	Refer to Appendix B in the Group 3 Facsimile Manual for details about AI Short Protocol.	
7	Short preamble 0: Disabled 1: Enabled	Refer to Appendix B in the Group 3 Facsimile Manual for details about Short Preamble.	

BIT SWITCHES

G3-1 Switch 03		SP No. 1-105-004
No	FUNCTION	COMMENTS
0	DIS detection number (Echo countermeasure) 0: 1 1: 2	0: The machine will hang up if it receives the same DIS frame twice. 1: Before sending DCS, the machine will wait for the second DIS which is caused by echo on the line.
1	V.8 protocol in manual reception 0: Disabled 1: Enabled	0: The machine sends CED instead of ANSam when starting a manual reception. 1: The machine sends ANSam during manual reception.
2	V.8 protocol 0: Disabled 1: Enabled	0: V.8/V.34 communications will not be possible. Note: Do not set to 0 unless the line condition is always bad enough to slow down the data rate to 14.4 kbps or lower.
3	ECM frame size 0: 256 bytes 1: 64 bytes	Keep this bit at "0" in most cases.
4	CTC transmission conditions 0: After one PPR signal received 1: After four PPR signals received (ITU-T standard)	0: When using ECM in non-standard (NSF/NSS) mode, the machine sends a CTC to drop back the modem rate after receiving a PPR, if the following condition is met in communications at 14.4, 12.0, 9.6, and 7.2 kbps. $\sqrt{N_{\text{Transmit}}} \leq N_{\text{Resend}}$ N _{Transmit} - Number of transmitted frames N _{Resend} - Number of frames to be retransmitted 1: When using ECM, the machine sends a CTC to drop back the modem rate after receiving four PPRs. PPR, CTC: These are ECM protocol signals. This bit is not effective in V.34 communications.
5	Modem rate used for the next page after receiving a negative code (RTN or PIN) 0: No change 1: Fallback	1: The machine's tx modem rate will fall back before sending the next page if a negative code is received. This bit is ignored if ECM is being used.
6	V.8 protocol in manual transmission 0: Disabled 1: Enabled	1: The machine detects either ANSam or CED during manual transmission.
7	Not used	Do not change the setting.

G3-1 Switch 04		SP No. 1-105-005
No	FUNCTION	COMMENTS
0 to 3	Training error detection threshold	0 - F (Hex); 0 - 15 bits If the number of error bits in the received TCF is below this threshold, the machine informs the sender that training has succeeded.
4-7	Not used	Do not change the settings.

G3-1 Switch 05		SP No. 1-105-006
No	FUNCTION	COMMENTS
0 to 3	Initial Tx modem rate Bit 3 2 1 0 Setting (bps) 0 0 0 1 2.4 k 0 0 1 0 4.8 k 0 0 1 1 7.2 k 0 1 0 0 9.6 k 0 1 0 1 12.0 k 0 1 1 0 14.4 k 0 1 1 1 16.8 k 1 0 0 0 19.2 k 1 0 0 1 21.6 k 1 0 1 0 24.0 k 1 0 1 1 26.4 k 1 1 0 0 28.8 k 1 1 0 1 31.2 k 1 1 1 0 33.6 k Other settings - Not used	These bits set the initial starting modem rate for transmission. Use the dedicated transmission parameters if you need to change this for specific receivers. If a modem rate 14.4 kbps or slower is selected, V.8 protocol should be disabled manually. Cross reference V.8 protocol on/off - G3 switch 03, bit2
4 to 5	Initial modem type for 9.6 k or 7.2 kbps. Bit 5 Bit 4 Setting 0 0 V.29 0 1 V.17 1 0 V.34 1 1 Not used	These bits set the initial modem type for 9.6 and 7.2 kbps, if the initial modem rate is set at these speeds.
6-7	Not used	Do not change the settings.

Fax Option B576

BIT SWITCHES

G3-1 Switch 06		SP No. 1-105-007
No	FUNCTION	COMMENTS
0 to 3	<p>Initial Rx modem rate</p> <p>Bit 3 2 1 0 Setting (bps)</p> <p>0 0 0 1 2.4 k</p> <p>0 0 1 0 4.8 k</p> <p>0 0 1 1 7.2 k</p> <p>0 1 0 0 9.6 k</p> <p>0 1 0 1 12.0 k</p> <p>0 1 1 0 14.4 k</p> <p>0 1 1 1 16.8 k</p> <p>1 0 0 0 19.2 k</p> <p>1 0 0 1 21.6 k</p> <p>1 0 1 0 24.0 k</p> <p>1 0 1 1 26.4 k</p> <p>1 1 0 0 28.8 k</p> <p>1 1 0 1 31.2 k</p> <p>1 1 1 0 33.6 k</p> <p>Other settings - Not used</p>	<p>These bits set the initial starting modem rate for reception.</p> <p>Use a lower setting if high speeds pose problems during reception.</p> <p>If a modem rate 14.4 kbps or slower is selected, V.8 protocol should be disabled manually.</p> <p>Cross reference V.8 protocol on/off - G3 switch 03, bit2</p>
4 to 7	<p>Modem types available for reception</p> <p>Bit 7 6 5 4 Setting</p> <p>0 0 0 1 V.27ter</p> <p>0 0 1 0 V.27ter, V.29</p> <p>0 0 1 1 V.27ter, V.29 V.33</p> <p>0 1 0 0 V.27ter, V.29, V.17/V.33</p> <p>0 1 0 1 V.27ter, V.29, V.17/V33, V.34</p> <p>Other settings - Not used</p>	<p>The setting of these bits is used to inform the transmitting terminal of the available modem type for the machine in receive mode.</p> <p>If V.34 is not selected, V.8 protocol must be disabled manually.</p> <p>Cross reference V.8 protocol on/off - G3 switch 03, bit2</p>

G3-1 Switch 07		SP No. 1-105-008
No	FUNCTION	COMMENTS
0 to 1	PSTN cable equalizer (tx mode: Internal) Bit 1 Bit 0 Setting 0 0 None 0 1 Low 1 0 Medium 1 1 High	Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone exchange. Use the dedicated transmission parameters for specific receivers. Also, try using the cable equalizer if one or more of the following symptoms occurs. <ul style="list-style-type: none"> • Communication error • Modem rate fallback occurs frequently. <p>Note: This setting is not effective in V.34 communications.</p>
2 to 3	PSTN cable equalizer (rx mode: Internal) Bit 3 Bit 2 Setting 0 0 None 0 1 Low 1 0 Medium 1 1 High	Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone exchange. Also, try using the cable equalizer if one or more of the following symptoms occurs. <ul style="list-style-type: none"> • Communication error with error codes such as 0-20, 0-23, etc. • Modem rate fallback occurs frequently. <p>Note: This setting is not effective in V.34 communications.</p>
4	PSTN cable equalizer (V.8/V.17 rx mode: External) 0: Disabled 1: Enabled	Keep this bit at "1".
5-7	Not used	Do not change the settings.

Fax Option B576

G3-1 Switch 08 - Not used (do not change the settings)
G3-1 Switch 09 - Not used (do not change the settings)

BIT SWITCHES

G3-1 Switch 0A		SP No. 1-105-011
No	FUNCTION	COMMENTS
1	Maximum allowable carrier drop during image data reception Bit 1 Bit 0 Value (ms) 0 0 200 0 1 400 1 0 800 1 1 Not used	These bits set the acceptable modem carrier drop time. Try using a longer setting if error code 0-22 is frequent.
2	Non-ECM Carrier Drop 0: Maintain connection 1: Disconnect	Determines how the machine will respond when it detects a drop in the carrier signal during non-ECM communication.
3	Not used	Do not change the settings.
4	Maximum allowable frame interval during image data reception. 0: 5 s 1: 13 s	This bit set the maximum interval between EOL (end-of-line) signals and the maximum interval between ECM frames from the other end. Try using a longer setting if error code 0-21 is frequent.
5	Not used	Do not change the setting.
6	Reconstruction time for the first line in receive mode 0: 6 s 1: 12 s	When the sending terminal is controlled by a computer, there may be a delay in receiving page data after the local machine accepts set-up data and sends CFR. This is outside the T.30 recommendation. But, if this delay occurs, set this bit to 1 to give the sending machine more time to send data. Refer to error code 0-20. ITU-T T.30 recommendation: The first line should come within 5 s of CFR.
7	Not used	Do not change the setting.

G3-1 Switch 0B		SP No. 1-105-012
No	FUNCTION	COMMENTS
0	Protocol requirements: Europe 0: Disabled 1: Enabled	The machine does not automatically reset these bits for each country after a country code (System Switch 0F) is programmed. Change the required bits manually at installation.
1	Protocol requirements: Spain 0: Disabled 1: Enabled	
2	Protocol requirements: Germany 0: Disabled 1: Enabled	
3	Protocol requirements: France 0: Disabled 1: Enabled	
4	PTT requirements: Germany 0: Disabled 1: Enabled	
5	PTT requirements: France 0: Disabled 1: Enabled	
6	Not used	Do not change the setting.
7	DTS requirements : Germany 0: Disabled 1: Enabled	Change this bit manually if required.

Fax Option
B576

G3-1 Switch 0C		SP No. 1-105-013															
No	FUNCTION	COMMENTS															
0	Pulse dialing method	P = Number of pulses sent out, N = Number dialed.															
1	<table border="0"> <tr> <td>Bit 1</td> <td>Bit 0</td> <td>Setting</td> </tr> <tr> <td>0</td> <td>0</td> <td>Normal(P=N)</td> </tr> <tr> <td>0</td> <td>1</td> <td>Oslo (P=10 - N)</td> </tr> <tr> <td>1</td> <td>0</td> <td>Sweden (N+1)</td> </tr> <tr> <td>1</td> <td>1</td> <td>Not used</td> </tr> </table>		Bit 1	Bit 0	Setting	0	0	Normal(P=N)	0	1	Oslo (P=10 - N)	1	0	Sweden (N+1)	1	1	Not used
Bit 1	Bit 0		Setting														
0	0		Normal(P=N)														
0	1		Oslo (P=10 - N)														
1	0	Sweden (N+1)															
1	1	Not used															
2-7	Not used	Do not change the settings.															

G3-1 Switch 0D - Not used (do not change the settings)

G3-1 Switch 0E		SP No. 1-105-015
No	FUNCTION	COMMENTS
0 to 7	<p>CNG transmission OFF interval.</p> <p>To input a value more than 3 s, use bits 3 to 0, and keep bits 4 to 7 at 0.</p> <p style="text-align: center;">$3000 + 50 \times N \text{ ms}$</p> <p>To input a value less than 3 s, use bits 4 to 7, and keep bits 0 to 3 at 1.</p> <p style="text-align: center;">$3000 - 50 \times N \text{ ms}$</p>	<p>Examples:</p> <p>3100 ms: $50 \times 2 = 100$ Bits 4 to 7 must be 0 Bits 0 to 3 must be 2(H) So, enter 02H.</p> <p>2800 ms: $50 \times 4 = 200$ Bits 0 to 3 must be F(H) Bits 4 to 7 must be 4(H) So, enter 4FH</p>

BIT SWITCHES

G3-1 Switch 0F		SP No. 1-105-016
No	FUNCTION	COMMENTS
0	Alarm when an error occurred in Phase C or later 0 : Disabled 1 : Enabled	If the customer wants to hear an alarm after each error communication, change this bit to "1".
1	Alarm when the handset is off-hook at the end of communication 0 : Disabled 1 : Enabled	If the customer wants to hear an alarm if the handset is off-hook at the end of fax communication, change this bit to "1".
2-7	Not used	Do not change the settings.

3.2.6 G3-2 SWITCHES

These switches require an optional G3 interface unit.

G3-2 Switch 00			SP No. 1-106-001
No	FUNCTION	COMMENTS	
0-1	Monitor speaker during communication (tx and rx)	(0, 0): The monitor speaker is disabled all through the communication.	
	Bit 1 Bit 0 Setting	(0, 1): The monitor speaker is on up to phase B in the T.30 protocol.	
	0 0 Disabled	(1, 0): Used for testing. The monitor speaker is on all through the communication. Make sure that you reset these bits after testing.	
	0 1 Up to Phase B		
	1 0 All the time		
1 1 Not used			
2	Monitor speaker during memory transmission 0: Disabled 1: Enabled	1: The monitor speaker is enabled during memory transmission.	
3-6	Not used	Do not change the settings.	

G3-2 Switch 01			SP No. 1-106-002
No	FUNCTION	COMMENTS	
0-3	Not used	Do not change the settings.	
4	DIS frame length 0: 10 bytes 1: 4 bytes	1: The bytes in the DIS frame after the 4th byte will not be transmitted (set to 1 if there are communication problems with PC-based faxes which cannot receive the extended DIS frames).	
5	Not used	Do not change the setting.	
6	CED/ANSam transmission 0: Disabled 1: Enabled	Do not change this setting, unless the communication problem is caused by the CED/ANSam transmission.	
7	Not used	Do not change the setting.	

BIT SWITCHES

G3-2 Switch 02		SP No. 1-106-003
No	FUNCTION	COMMENTS
0	G3 protocol mode used 0: Standard and non-standard 1: Standard only	Change this bit to 1 only when the other end can only communicate with machines that send T.30-standard frames only. 1: Disables NSF/NSS signals (these are used in non-standard mode communication)
1-4	Not used	Do not change the settings.
5	Use of modem rate history for transmission using Quick/Speed Dials 0: Disabled 1: Enabled	0: Communications using Quick/Speed Dials always start from the highest modem rate. 1: The machine refers to the modem rate history for communications with the same machine when determining the most suitable rate for the current communication.
6	AI short protocol (transmission and reception) 0: Disabled 1: Enabled	Refer to Appendix B in the Group 3 Facsimile Manual for details about AI Short Protocol.
7	Short preamble 0: Disabled 1: Enabled	Refer to Appendix B in the Group 3 Facsimile Manual for details about Short Preamble.

G3-2 Switch 03		SP No. 1-106-004
No	FUNCTION	COMMENTS
0	DIS detection number (Echo countermeasure) 0: 1 1: 2	0: The machine will hang up if it receives the same DIS frame twice. 1: Before sending DCS, the machine will wait for the second DIS which is caused by echo on the line.
1	Not used	Do not change the setting.
2	V.8 protocol 0: Disabled 1: Enabled	0: V.8/V.34 communications will not be possible. Note: Do not set to 0 unless the line condition is always bad enough to slow down the data rate to 14.4 kbps or lower.
3	ECM frame size 0: 256 bytes 1: 64 bytes	Keep this bit at "0" in most cases.
4	CTC transmission conditions 0: After one PPR signal received 1: After four PPR signals received (ITU-T standard)	0: When using ECM in non-standard (NSF/NSS) mode, the machine sends a CTC to drop back the modem rate after receiving a PPR, if the following condition is met in communications at 14.4, 12.0, 9.6, and 7.2 kbps. $\sqrt{N_{\text{Transmit}} \leq N_{\text{Resend}}}$ N _{Transmit} - Number of transmitted frames N _{Resend} - Number of frames to be retransmitted 1: When using ECM, the machine sends a CTC to drop back the modem rate after receiving four PPRs. PPR, CTC: These are ECM protocol signals. This bit is not effective in V.34 communications.
5	Modem rate used for the next page after receiving a negative code (RTN or PIN) 0: No change 1: Fallback	1: The machine's tx modem rate will fall back before sending the next page if a negative code is received. This bit is ignored if ECM is being used.
6-7	Not used	Do not change the settings.

Fax Option
B576

G3-2 Switch 04		SP No. 1-106-005
No	FUNCTION	COMMENTS
0 to 3	Training error detection threshold	0 - F (Hex); 0 - 15 bits If the number of error bits in the received TCF is below this threshold, the machine informs the sender that training has succeeded.
4-7	Not used	Do not change the settings.

BIT SWITCHES

G3-2 Switch 05		SP No. 1-106-006
No	FUNCTION	COMMENTS
0 to 3	Initial Tx modem rate Bit 3 2 1 0 Setting (bps) 0 0 0 1 2.4 k 0 0 1 0 4.8 k 0 0 1 1 7.2 k 0 1 0 0 9.6 k 0 1 0 1 12.0 k 0 1 1 0 14.4 k 0 1 1 1 16.8 k 1 0 0 0 19.2 k 1 0 0 1 21.6 k 1 0 1 0 24.0 k 1 0 1 1 26.4 k 1 1 0 0 28.8 k 1 1 0 1 31.2 k 1 1 1 0 33.6 k Other settings - Not used	These bits set the initial starting modem rate for transmission. Use the dedicated transmission parameters if you need to change this for specific receivers. If a modem rate 14.4 kbps or slower is selected, V.8 protocol should be disabled manually. Cross reference V.8 protocol on/off - SG3 switch 03, bit 2
4 to 5	Initial modem type for 9.6 k or 7.2 kbps. Bit 5 Bit 4 Setting 0 0 V.29 0 1 V.17 1 0 V.34 1 1 Not used	These bits set the initial modem type for 9.6 and 7.2 kbps, if the initial modem rate is set at these speeds.
6-7	Not used	Do not change the settings.

G3-2 Switch 06		SP No. 1-106-007
No	FUNCTION	COMMENTS
0 to 3	<p>Initial Rx modem rate</p> <p>Bit 3 2 1 0 Setting (bps)</p> <p>0 0 0 1 2.4 k</p> <p>0 0 1 0 4.8 k</p> <p>0 0 1 1 7.2 k</p> <p>0 1 0 0 9.6 k</p> <p>0 1 0 1 12.0 k</p> <p>0 1 1 0 14.4 k</p> <p>0 1 1 1 16.8 k</p> <p>1 0 0 0 19.2 k</p> <p>1 0 0 1 21.6 k</p> <p>1 0 1 0 24.0 k</p> <p>1 0 1 1 26.4 k</p> <p>1 1 0 0 28.8 k</p> <p>1 1 0 1 31.2 k</p> <p>1 1 1 0 33.6 k</p> <p>Other settings - Not used</p>	<p>These bits set the initial starting modem rate for reception.</p> <p>Use a lower setting if high speeds pose problems during reception.</p> <p>If a modem rate 14.4 kbps or slower is selected, V.8 protocol should be disabled manually.</p> <p>Cross reference V.8 protocol on/off - SG3 switch 03, bit 2</p>
4 to 7	<p>Modem types available for reception</p> <p>Bit 7 6 5 4 Setting</p> <p>0 0 0 1 V.27ter</p> <p>0 0 1 0 V.27ter, V.29</p> <p>0 0 1 1 V.27ter, V.29 V.33</p> <p>0 1 0 0 V.27ter, V.29, V.17/V.33</p> <p>0 1 0 1 V.27ter, V.29, V.17/V33, V.34</p> <p>Other settings - Not used</p>	<p>The setting of these bits is used to inform the transmitting terminal of the available modem type for the machine in receive mode.</p> <p>If V.34 is not selected, V.8 protocol must be disabled manually.</p> <p>Cross reference V.8 protocol on/off - SG3 switch 03, bit 2</p>

Fax Option
B576

BIT SWITCHES

G3-2 Switch 07		SP No. 1-106-008															
No	FUNCTION	COMMENTS															
0 to 1	PSTN cable equalizer (tx mode: Internal) <table border="1"> <thead> <tr> <th>Bit 1</th> <th>Bit 0</th> <th>Setting</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>None</td> </tr> <tr> <td>0</td> <td>1</td> <td>Low</td> </tr> <tr> <td>1</td> <td>0</td> <td>Medium</td> </tr> <tr> <td>1</td> <td>1</td> <td>High</td> </tr> </tbody> </table>	Bit 1	Bit 0	Setting	0	0	None	0	1	Low	1	0	Medium	1	1	High	Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone exchange. Use the dedicated transmission parameters for specific receivers. Also, try using the cable equalizer if one or more of the following symptoms occurs. <ul style="list-style-type: none"> • Communication error • Modem rate fallback occurs frequently. Note: This setting is not effective in V.34 communications.
Bit 1	Bit 0	Setting															
0	0	None															
0	1	Low															
1	0	Medium															
1	1	High															
2 to 3	PSTN cable equalizer (rx mode: Internal) <table border="1"> <thead> <tr> <th>Bit 3</th> <th>Bit 2</th> <th>Setting</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>None</td> </tr> <tr> <td>0</td> <td>1</td> <td>Low</td> </tr> <tr> <td>1</td> <td>0</td> <td>Medium</td> </tr> <tr> <td>1</td> <td>1</td> <td>High</td> </tr> </tbody> </table>	Bit 3	Bit 2	Setting	0	0	None	0	1	Low	1	0	Medium	1	1	High	Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone exchange. Also, try using the cable equalizer if one or more of the following symptoms occurs. <ul style="list-style-type: none"> • Communication error with error codes such as 0-20, 0-23, etc. • Modem rate fallback occurs frequently. Note: This setting is not effective in V.34 communications.
Bit 3	Bit 2	Setting															
0	0	None															
0	1	Low															
1	0	Medium															
1	1	High															
4	PSTN cable equalizer (V.8/V.17 rx mode: External) 0 : Disabled 1 : Enabled	Keep this bit at "1".															
5	PSTN cable equalizer (V.34 rx mode; External)	Keep this bit at "1".															
6-7	Not used	Do not change the settings.															

G3-2 Switch 08 - Not used (do not change the settings)
G3-2 Switch 09 - Not used (do not change the settings)

G3-2 Switch 0A			SP No. 1-106-011
No	FUNCTION	COMMENTS	
0 1	Maximum allowable carrier drop during image data reception Bit 1 Bit 0 Value (ms) 0 0 200 0 1 400 1 0 800 1 1 Not used	These bits set the acceptable modem carrier drop time. Try using a longer setting if error code 0-22 is frequent.	
2	Non-ECM Carrier Drop 0: Maintain connection 1: Disconnect	Determines how the machine will respond when it detects a drop in the carrier signal during non-ECM communication.	
3	Not used	Do not change the settings.	
4	Maximum allowable frame interval during image data reception. 0: 5 s 1: 13 s	This bit set the maximum interval between EOL (end-of-line) signals and the maximum interval between ECM frames from the other end. Try using a longer setting if error code 0-21 is frequent.	
5	Not used	Do not change the setting.	
6	Reconstruction time for the first line in receive mode 0: 6 s 1: 12 s	When the sending terminal is controlled by a computer, there may be a delay in receiving page data after the local machine accepts set-up data and sends CFR. This is outside the T.30 recommendation. But, if this delay occurs, set this bit to 1 to give the sending machine more time to send data. Refer to error code 0-20. ITU-T T.30 recommendation: The first line should come within 5 s of CFR.	
7	Not used	Do not change the setting.	

Fax Option
B576

G3-2 Switch 0B			SP No. 1-106-012
No	FUNCTION	COMMENTS	
0	Protocol requirements: Europe 0: Disabled 1: Enabled	The machine does not automatically reset these bits for each country after a country code (System Switch 0F) is programmed. Change the required bits manually at installation.	
1	Protocol requirements: Spain 0: Disabled 1: Enabled		
2	Protocol requirements: Germany 0: Disabled 1: Enabled		
3	Protocol requirements: France 0: Disabled 1: Enabled		
4	PTT requirements: Germany 0: Disabled 1: Enabled		
5	PTT requirements: France 0: Disabled 1: Enabled		
6-7	Not used	Do not change the setting.	

BIT SWITCHES

G3-2 Switch 0C			SP No. 1-106-013
No	FUNCTION		COMMENTS
0	Pulse dialing method		P = Number of pulses sent out, N = Number dialed.
1	Bit 1 Bit 0 Setting		
	0 0 Normal(P=N)		
	0 1 Oslo (P=10 - N)		
	1 0 Sweden (N+1)		
	1 1 Not used		
2-7	Not used		Do not change the settings.

G3-2 Switch 0D - Not used (do not change the settings)
G3-2 Switch 0E - Not used (do not change the settings)
G3-2 Switch 0F - Not used (do not change the settings)

3.2.7 FAX SWITCHES

FAX Switch 00 - Not used (do not change the settings)
--

FAX Switch 01		SP No. 3-201-002
No	FUNCTION	COMMENTS
0 to 7	Scan density step value (Text mode)	<p>When scan density is adjusted manually away from the Normal setting, the threshold value for binary picture processing changes for each step from the value specified by Scanner Switch 02, by the amount programmed here.</p> <p>For example, with the default setting (14), the threshold value changes as follows.</p> <p>+3 (Darkest) : 71 (= 85 – 14) +2 : 85 (= 99 – 14) +1 : 99 (= 113 – 14) 0 (Normal) : 113 (Scanner Switch 02 setting) -1 : 127 (= 113 + 14) -2 : 141 (= 127 + 14) -3 (Lightest) : 155 (= 141 + 14)</p> <p>For smaller steps, input a lower value.</p>

Fax Option
B576

FAX Switch 02		SP No. 3-201-003
No	FUNCTION	COMMENTS
0 to 7	Binary picture processing: Threshold for Text mode - Normal setting (center position)	<p>This setting determines the threshold value for binary picture processing in Text mode (when the scan density setting is at the center).</p> <p>The value can be between 01 and FF. For a darker threshold, input a lower value.</p> <p>Default setting: 71(H) = 113(D)</p>

FAX Switch 03 - Not used (do not change the settings)
--

FAX Switch 04		SP No. 3-201-005
No	FUNCTION	COMMENTS
0 to 7	Binary picture processing: Threshold for monotone background special original 1 mode - Normal setting (center position)	<p>This setting determines the threshold value for binary picture processing in monotone background special original 1 mode (when the scan density setting is at the center).</p> <p>The value can be between 01 and FF. For a darker threshold, input a lower value.</p> <p>Default setting: A4(H) = 164(D)</p>

BIT SWITCHES

FAX Switch 05		SP No. 3-201-006
No	FUNCTION	COMMENTS
0 to 7	Binary picture processing: Threshold for colored background special original 2 mode - Normal setting (center position)	This setting determines the threshold value for binary picture processing in colored background special original 2 mode (when the scan density setting is at the center). The value can be between 01 and FF. For a darker threshold, input a lower value. Default setting: 28(H) = 40(D)

FAX Switch 06		SP No. 3-201-007
No	FUNCTION	COMMENTS
0 to 3	MTF filter level (Text mode) The value can be between 0(Off) and F. For a weaker threshold, input a lower value. Default setting: 7 This setting is independent from the threshold specified by the copier SP modes.	
4 to 7	MTF filter level (Text/Photo mode) The value can be between 0(Off) and F. For a weaker threshold, input a lower value. Default setting: 7 This setting is independent from the threshold specified by the copier SP modes.	

FAX Switch 07		SP No. 3-201-008
No	FUNCTION	COMMENTS
0 to 2	Smoothing filter level (Photo mode)	The value can be between 0(Off) and 7. For a weaker threshold, input a lower value. Default setting: 2 This setting is independent from the threshold setting specified by the copier SP modes.
3-7	Not used	Do not change the settings.

FAX Switch 08 – Not used (do not change the settings)	SP No. 3-201-009
FAX Switch 09 – Not used (do not change the settings)	SP No. 3-201-010

FAX Switch 0A		SP No. 3-201-011
No	FUNCTION	COMMENTS
0-3	Not used	Do not change the settings.
4 to 7	MTF filter level (Colored background special original mode) The value can be between 0 (Off) and F. For a weaker threshold, input a lower value. Default setting: 7 This setting is independent from the threshold specified by the copier SP modes.	

FAX Switch 0B		SP No. 3-201-012
No	FUNCTION	COMMENTS
0 to 3	Scan margin setting (right and left margin in book scan ADF mode) The setting can be between 0 and F (H) (unit 0.5 mm). Default setting: 2 mm	
4 to 7	Scan margin setting (top and bottom margin in book scan and ADF mode) The setting can be between 0 and 7 (H) (unit 0.5 mm). Default setting: 3 mm	

FAX Switch 0C		SP No. 3-201-013
No	FUNCTION	COMMENTS
0	Action when an original jam has occurred while scanning the original into memory for memory tx 0: Continues scanning after recovery 1: Stops scanning and erases all scanned pages for that job	This bit is only effective when parallel memory tx is disabled (user parameter 07 - bit 2). If parallel memory tx is enabled, the machine always erases the scanned pages when an original jam occurs. The machine then asks the user to retry from the first page, even if the parallel memory tx is not actually used. 0: The machine displays a message asking the user to put the jammed page back into the original stack, and continues scanning. The message is displayed for the time period specified by scanner switch 0E, bit 2. 1: The machine erases all the scanned pages and asks the user to retry from the first page.
1 to 2	Setting when an original size cannot be recognized Bit 2 1 Setting 0 0 No original 0 1 A5 <input type="checkbox"/> 1 0 A5 <input type="checkbox"/> 1 1 No original	
3-7	Not used	Do not change the settings.

FAX Switch 0D		SP No. 3-201-014
No	FUNCTION	COMMENTS
0-6	Not used	Do not change the settings.
7	Scan width for A5 lengthwise or B5 lengthwise originals 0: 210 mm (8.5") 1: Original width	0: The machine scans the original as 210 mm (8.5") width. The transmitted image has a blank area on the right. 1: The machine scans 148 mm (A5) or 182 mm (B5) and centers the scanned data on a 216 mm width transmitted image.

Fax Option
B576

BIT SWITCHES

FAX Switch 0E		SP No. 3-201-015
No	FUNCTION	COMMENTS
0	Not used	Do not change the settings.
1	Scan resolution unit 0: mm 1: inches	This bit determines which resolution unit will be used for scanning a fax message. Default setting: mm
2-7	Not used	Do not change the settings.

Scanner Switch 0F		SP No. 3-201-016
No	FUNCTION	COMMENTS
0	Image rotation before transmission (A4/LT sideways) 0: Disabled 1: Enabled	This bit determines whether the machine rotates the scanned image by 90 degrees before transmission. If this bit is set at 1, A4 (LT) sideways images (297 mm width in the protocol) will be transmitted as A4 (LT) lengthwise images (216 mm width in the protocol).
1	Not used	Do not change the settings
2	Image rotation before transmission (A5/HLT lengthwise) 0: Disabled 1: Enabled	This bit determines whether the machine rotates the scanned image by 90 degrees before transmission. If this bit is set at "1", A5 (HLT) lengthwise images will be transmitted as A4 (LT) width images (216 mm width in the protocol).
3-7	Not used	Do not change the settings.

3.3 NCU PARAMETERS

The following tables give the RAM addresses and the parameter calculation units that the machine uses for ringing signal detection and automatic dialing. The factory settings for each country are also given. Most of these must be changed by RAM read/write (SP2-101), but some can be changed using NCU Parameter programming (SP2-103 and 104); if SP2-103 and 104 can be used, this will be indicated in the Remarks column. The RAM is programmed in hex code unless (BCD) is included in the Unit column.

NOTE: The following addresses describe settings for the standard NCU. Change the fourth digit from “5” to “6” (e.g. 680500 to 680600) for the settings for the optional G3 interface unit.

NCU PARAMETERS

Address	Function	Unit	Remarks																																																																																																
680500	Country/Area code for NCU parameters	Use the Hex value to program the country/area code directly into this address, or use the decimal value to program it using SP2-103-001 <table border="1"> <thead> <tr> <th>Country/Area</th> <th>Decimal</th> <th>Hex</th> </tr> </thead> <tbody> <tr><td>France</td><td>00</td><td>00</td></tr> <tr><td>Germany</td><td>01</td><td>01</td></tr> <tr><td>UK</td><td>02</td><td>02</td></tr> <tr><td>Italy</td><td>03</td><td>03</td></tr> <tr><td>Austria</td><td>04</td><td>04</td></tr> <tr><td>Belgium</td><td>05</td><td>05</td></tr> <tr><td>Denmark</td><td>06</td><td>06</td></tr> <tr><td>Finland</td><td>07</td><td>07</td></tr> <tr><td>Ireland</td><td>08</td><td>08</td></tr> <tr><td>Norway</td><td>09</td><td>09</td></tr> <tr><td>Sweden</td><td>10</td><td>0A</td></tr> <tr><td>Switzerland</td><td>11</td><td>0B</td></tr> <tr><td>Portugal</td><td>12</td><td>0C</td></tr> <tr><td>Holland</td><td>13</td><td>0D</td></tr> <tr><td>Spain</td><td>14</td><td>0E</td></tr> <tr><td>Israel</td><td>15</td><td>0F</td></tr> <tr><td>USA</td><td>17</td><td>11</td></tr> <tr><td>Asia</td><td>18</td><td>12</td></tr> <tr><td>Hong Kong</td><td>20</td><td>14</td></tr> <tr><td>South Africa</td><td>21</td><td>15</td></tr> <tr><td>Australia</td><td>22</td><td>16</td></tr> <tr><td>New Zealand</td><td>23</td><td>17</td></tr> <tr><td>Singapore</td><td>24</td><td>18</td></tr> <tr><td>Malaysia</td><td>25</td><td>19</td></tr> <tr><td>China</td><td>26</td><td>1A</td></tr> <tr><td>Taiwan</td><td>27</td><td>1B</td></tr> <tr><td>Korea</td><td>28</td><td>1C</td></tr> <tr><td>Greece</td><td>33</td><td>21</td></tr> <tr><td>Hungary</td><td>34</td><td>22</td></tr> <tr><td>Czech</td><td>35</td><td>23</td></tr> <tr><td>Poland</td><td>36</td><td>24</td></tr> </tbody> </table>		Country/Area	Decimal	Hex	France	00	00	Germany	01	01	UK	02	02	Italy	03	03	Austria	04	04	Belgium	05	05	Denmark	06	06	Finland	07	07	Ireland	08	08	Norway	09	09	Sweden	10	0A	Switzerland	11	0B	Portugal	12	0C	Holland	13	0D	Spain	14	0E	Israel	15	0F	USA	17	11	Asia	18	12	Hong Kong	20	14	South Africa	21	15	Australia	22	16	New Zealand	23	17	Singapore	24	18	Malaysia	25	19	China	26	1A	Taiwan	27	1B	Korea	28	1C	Greece	33	21	Hungary	34	22	Czech	35	23	Poland	36	24
Country/Area	Decimal	Hex																																																																																																	
France	00	00																																																																																																	
Germany	01	01																																																																																																	
UK	02	02																																																																																																	
Italy	03	03																																																																																																	
Austria	04	04																																																																																																	
Belgium	05	05																																																																																																	
Denmark	06	06																																																																																																	
Finland	07	07																																																																																																	
Ireland	08	08																																																																																																	
Norway	09	09																																																																																																	
Sweden	10	0A																																																																																																	
Switzerland	11	0B																																																																																																	
Portugal	12	0C																																																																																																	
Holland	13	0D																																																																																																	
Spain	14	0E																																																																																																	
Israel	15	0F																																																																																																	
USA	17	11																																																																																																	
Asia	18	12																																																																																																	
Hong Kong	20	14																																																																																																	
South Africa	21	15																																																																																																	
Australia	22	16																																																																																																	
New Zealand	23	17																																																																																																	
Singapore	24	18																																																																																																	
Malaysia	25	19																																																																																																	
China	26	1A																																																																																																	
Taiwan	27	1B																																																																																																	
Korea	28	1C																																																																																																	
Greece	33	21																																																																																																	
Hungary	34	22																																																																																																	
Czech	35	23																																																																																																	
Poland	36	24																																																																																																	
680501	Line current detection time	20 ms	Line current detection is disabled. Line current is not detected if 680501 contains FF.																																																																																																
680502	Line current wait time																																																																																																		
680503	Line current drop detect time																																																																																																		
680504	PSTN dial tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.																																																																																																
680505	PSTN dial tone frequency upper limit (low byte)																																																																																																		
680506	PSTN dial tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.																																																																																																
680507	PSTN dial tone frequency lower limit (low byte)																																																																																																		

NCU PARAMETERS

Address	Function	Unit	Remarks
680508	PSTN dial tone detection time	20 ms	If 680508 contains FF(H), the machine pauses for the pause time (address 68050D / 68050E). Italy: See Note 2.
680509	PSTN dial tone reset time (LOW)		
68050A	PSTN dial tone reset time (HIGH)		
68050B	PSTN dial tone continuous tone time		
68050C	PSTN dial tone permissible drop time		
68050D	PSTN wait interval (LOW)		
68050E	PSTN wait interval (HIGH)	20 ms	Detection is disabled if this contains FF.
68050F	PSTN ring-back tone detection time		
680510	PSTN ring-back tone off detection time	20 ms	
680511	PSTN detection time for silent period after ring-back tone detected (LOW)	20 ms	
680512	PSTN detection time for silent period after ring-back tone detected (HIGH)	20 ms	
680513	PSTN busy tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.
680514	PSTN busy tone frequency upper limit (low byte)		
680515	PSTN busy tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.
680516	PSTN busy tone frequency lower limit (low byte)		
680517	PABX dial tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.
680518	PABX dial tone frequency upper limit (low byte)		
680519	PABX dial tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.
68051A	PABX dial tone frequency lower limit (low byte)		
68051B	PABX dial tone detection time	20 ms	If 68051B contains FF, the machine pauses for the pause time (680520 / 680521).
68051C	PABX dial tone reset time (LOW)		
68051D	PABX dial tone reset time (HIGH)		
68051E	PABX dial tone continuous tone time		
68051F	PABX dial tone permissible drop time		
680520	PABX wait interval (LOW)		
680521	PABX wait interval (HIGH)	20 ms	If both addresses contain FF(H), tone detection is disabled.
680522	PABX ringback tone detection time		
680523	PABX ringback tone off detection time	20 ms	
680524	PABX detection time for silent period after ringback tone detected (LOW)	20 ms	If both addresses contain FF(H), tone detection is disabled.
680525	PABX detection time for silent period after ringback tone detected (HIGH)		

Fax Option
B576

NCU PARAMETERS

Address	Function	Unit	Remarks																				
680526	PABX busy tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.																				
680527	PABX busy tone frequency upper limit (low byte)																						
680528	PABX busy tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.																				
680529	PABX busy tone frequency lower limit (low byte)																						
68052A	Busy tone ON time: range 1	20 ms																					
68052B	Busy tone OFF time: range 1																						
68052C	Busy tone ON time: range 2																						
68052D	Busy tone OFF time: range 2																						
68052E	Busy tone ON time: range 3																						
68052F	Busy tone OFF time: range 3																						
680530	Busy tone ON time: range 4																						
680531	Busy tone OFF time: range 4																						
680532	Busy tone continuous tone detection time																						
680533	<p>Busy tone signal state time tolerance for all ranges, and number of cycles required for detection (a setting of 4 cycles means that ON-OFF-ON or OFF-ON-OFF must be detected twice).</p> <p>Tolerance (\pm)</p> <table border="0"> <tr> <td>Bit</td> <td>1</td> <td>0</td> <td></td> </tr> <tr> <td></td> <td>0</td> <td>0</td> <td>75% Bits 2 and 3 must always</td> </tr> <tr> <td></td> <td>0</td> <td>1</td> <td>50% be kept at 0.</td> </tr> <tr> <td></td> <td>1</td> <td>0</td> <td>25%</td> </tr> <tr> <td></td> <td>1</td> <td>1</td> <td>12.5%</td> </tr> </table> <p>Bits 7, 6, 5, 4 - number of cycles required for cadence detection</p>			Bit	1	0			0	0	75% Bits 2 and 3 must always		0	1	50% be kept at 0.		1	0	25%		1	1	12.5%
Bit	1	0																					
	0	0	75% Bits 2 and 3 must always																				
	0	1	50% be kept at 0.																				
	1	0	25%																				
	1	1	12.5%																				
680534	International dial tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.																				
680535	International dial tone frequency upper limit (low byte)																						
680536	International dial tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.																				
680537	International dial tone frequency lower limit (low byte)																						
680538	International dial tone detection time	20 ms	<p>If 680538 contains FF, the machine pauses for the pause time (68053D / 68053E).</p> <p>Belgium: See Note 2.</p>																				
680539	International dial tone reset time (LOW)																						
68053A	International dial tone reset time (HIGH)																						
68053B	International dial tone continuous tone time																						
68053C	International dial tone permissible drop time																						
68053D	International dial wait interval (LOW)																						
68053E	International dial wait interval (HIGH)																						

NCU PARAMETERS

Address	Function	Unit	Remarks
68053F	Country dial tone upper frequency limit (HIGH)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.
680540	Country dial tone upper frequency limit (LOW)		
680541	Country dial tone lower frequency limit (HIGH)		If both addresses contain FF(H), tone detection is disabled.
680542	Country dial tone lower frequency limit (LOW)		
680543	Country dial tone detection time	20 ms	If 680543 contains FF, the machine pauses for the pause time (680548 / 680549).
680544	Country dial tone reset time (LOW)		
680545	Country dial tone reset time (HIGH)		
680546	Country dial tone continuous tone time		
680547	Country dial tone permissible drop time		
680548	Country dial wait interval (LOW)		
680549	Country dial wait interval (HIGH)		
68054A	Time between opening or closing the DO relay and opening the OHDI relay	1 ms	See Notes 3, 6 and 8. SP2-103-11
68054B	Break time for pulse dialing	1 ms	See Note 3. SP2-103-12
68054C	Make time for pulse dialing	1 ms	See Note 3. SP2-103-13
68054D	Time between final OHDI relay closure and DO relay opening or closing	1 ms	See Notes 3, 6 and 8. SP2-103-14 This parameter is only valid in Europe.
68054E	Minimum pause between dialed digits (pulse dial mode)	20 ms	See Note 3 and 8. SP2-103-15
68054F	Time waited when a pause is entered at the operation panel		SP2-103-16 See Note 3.
680550	DTMF tone on time	1 ms	SP2-103-17
680551	DTMF tone off time		SP2-103-18
680552	Tone attenuation level of DTMF signals while dialing	-N x 0.5 -3.5 dBm	SP2-103-19 See Note 5.
680553	Tone attenuation value difference between high frequency tone and low frequency tone in DTMF signals	-dBm x 0.5	SP2-103-20 The setting must be less than -5dBm, and should not exceed the setting at 680552h above. See Note 5.
680554	PSTN: DTMF tone attenuation level after dialling	-N x 0.5 -3.5 dBm	SP2-103-21 See Note 5.
680555	ISDN: DTMF tone attenuation level after dialling	-dBm x 0.5	See Note 5
680556	Not used		Do not change the settings.

Fax Option
B576

NCU PARAMETERS

Address	Function	Unit	Remarks
680557	Time between 68054Dh (NCU parameter 14) and 68054Eh (NCU parameter 15)	1 ms	This parameter takes effect when the country code is set to France.
680558	Not used		Do not change the setting.
680559	Grounding time (ground start mode)	20 ms	The Gs relay is closed for this interval.
68055A	Break time (flash start mode)	1 ms	The OHDI relay is open for this interval.
68055B	International dial access code (High)	BCD	For a code of 100: 68055B - F1 68055C - 00
68055C	International dial access code (Low)		
68055D	PSTN access pause time	20 ms	This time is waited for each pause input after the PSTN access code. If this address contains FF[H], the pause time stored in address 68054F is used. Do not set a number more than 7 in the UK.
68055E	Progress tone detection level, and cadence detection enable flags	Bit 7 Bit 6 Bit 5 dBm 0 0 0 -25.0 0 0 1 -35.0 0 1 0 -30.0 1 0 0 -40.0 1 1 0 -49.0 Bits 2, 0 - See Note 2.	
68055F to 680564	Not used		Do not change the settings.
680565	Long distance call prefix (HIGH)	BCD	For a code of 0: 680565 - FF 680566 - F0
680566	Long distance call prefix (LOW)	BCD	
680567 to 680571	Not used		Do not change the settings.
680572	Acceptable ringing signal frequency: range 1, upper limit	1000/ N (Hz).	SP2-103-2
680573	Acceptable ringing signal frequency: range 1, lower limit		SP2-103-3
680574	Acceptable ringing signal frequency: range 2, upper limit		SP2-103-4
680575	Acceptable ringing signal frequency: range 2, lower limit		SP2-103-5

NCU PARAMETERS

Address	Function	Unit	Remarks
680576	Number of rings until a call is detected	1	SP2-103-6 The setting must not be zero.
680577	Minimum required length of the first ring	20 ms	See Note 4. SP2-103-7
680578	Minimum required length of the second and subsequent rings	20 ms	SP2-103-8
680579	Ringing signal detection reset time (LOW)	20 ms	SP2-103-9
68057A	Ringing signal detection reset time (HIGH)		SP2-103-10
68057B to 680580	Not used		Do not change the settings.
680581	Interval between dialing the last digit and switching the Oh relay over to the external telephone when dialing from the operation panel in handset mode.	20 ms	Factory setting: 500 ms
680582	Bits 0 and 1 - Handset off-hook detection time Bit 1 0 Setting 0 0 200 ms 0 1 800 ms Other Not used Bits 2 and 3 - Handset on-hook detection time Bit 3 2 Setting 0 0 200 ms 0 1 800 ms Other Not used Bits 4 to 7 - Not used		
680583 to 6805A0	Not used		Do not change the settings.
6805A1	Acceptable CED detection frequency upper limit (high byte)	BCD (Hz)	If both addresses contain FF(H), tone detection is disabled.
6805A2	Acceptable CED detection frequency upper limit (low byte)		
6805A3	Acceptable CED detection frequency lower limit (high byte)	BCD (Hz)	If both addresses contain FF(H), tone detection is disabled.
6805A4	Acceptable CED detection frequency lower limit (low byte)		
6805A5	CED detection time	20 ms ± 20 ms	Factory setting: 200 ms
6805A6	Acceptable CNG detection frequency upper limit (high byte)	BCD (Hz)	If both addresses contain FF(H), tone detection is disabled.
6805A7	Acceptable CNG detection frequency upper limit (low byte)		

Fax Option
B576

NCU PARAMETERS

Address	Function	Unit	Remarks
6805A8	Acceptable CNG detection frequency lower limit (high byte)	BCD (Hz)	If both addresses contain FF(H), tone detection is disabled.
6805A9	Acceptable CNG detection frequency lower limit (low byte)		
6805AA	Not used		Do not change the setting.
6805AB	CNG on time	20 ms	Factory setting: 500 ms
6805AC	CNG off time	20 ms	Factory setting: 200 ms
6805AD	Number of CNG cycles required for detection		The data is coded in the same way as address 680533.
6805AE	Not used		Do not change the settings.
6805AF	Acceptable AI short protocol tone (800Hz) detection frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.
6805B0	Acceptable AI short protocol tone (800Hz) detection frequency upper limit (low byte)		
6805B1	Acceptable AI short protocol tone (800Hz) detection frequency lower limit (high byte)	Hz(BCD)	If both addresses contain FF(H), tone detection is disabled.
6805B2	Acceptable AI short protocol tone (800Hz) detection frequency lower limit (low byte)		
6805B3	Detection time for 800 Hz AI short protocol tone	20 ms	Factory setting: 360 ms
6805B4	PSTN: Tx level from the modem	-N – 3 dBm	SP2-103-1
6805B5	PSTN: 1100 Hz tone transmission level	- N 6805B4 - 0.5N 6805B5 –3.5 (dB) See Note 7.	
6805B6	PSTN: 2100 Hz tone transmission level	- N6805B4 - 0.5N 6805B6 –3 (dB) See Note 7.	
6805B7	PABX: Tx level from the modem	- dBm	
6805B8	PABX: 1100 Hz tone transmission level	- N 6805B7 - 0.5N 6805B8 (dB)	
6805B9	PABX: 2100 Hz tone transmission level	- N 6805B7 - 0.5N 6805B9 (dB)	
6805BA	ISDN: Tx level from the modem	- dBm	The setting must be between -12dBm and -15dBm.
6805BB	ISDN: 1100 Hz tone transmission level	- N 6805BA - 0.5N 6805BB (dB)	
6805BC	ISDN: 2100 Hz tone transmission level	- N 6805BA - 0.5N 6805BC (dB)	
6805BD	Modem turn-on level (incoming signal detection level)	-37-0.5N (dBm)	
6805BE to 6805C6	Not used		Do not change the settings.

Address	Function	Unit	Remarks
6805C7	Bits 0 to 3 – Not used. Bit 4 – V.34 protocol dump 0 : Simple, 1 : Detailed (default) Bits 5 to 7 – Not used.		
6805C8 to 6805D9	Not used		Do not change the settings.
⇒ 6805DA	T.30 T1 timer	1 s	
⇒ 6805E4 bit 2	Threshold for ring level	Change bit 2 to 1 This will increase the threshold for ringing level detection.	
⇒ 6805E4 bit 3	On-Hook impedance level	Change bit 3 0 to 1 This will decrease the on-hook impedance level	

NOTES:

1. If a setting is not required, store FF in the address.
2. Italy and Belgium only

RAM address 68055E: the lower four bits have the following meaning.

Bit 2 - 1: International dial tone cadence detection enabled (Belgium)

Bit 1 - Not used

Bit 0 - 1: PSTN dial tone cadence detection enabled (Italy)

If bit 0 or bit 2 is set to 1, the functions of the following RAM addresses are changed.

680508 (if bit 0 = 1) or 680538 (if bit 2 = 1): tolerance for on or off state duration (%), and number of cycles required for detection, coded as in address 680533.

68050B (if bit 0 = 1) or 68053B (if bit 2 = 1): on time, hex code (unit = 20 ms)

68050C (if bit 0 = 1) or 68053C (if bit 2 = 1): off time, hex code (unit = 20 ms)

3. Pulse dial parameters (addresses 68054A to 68054F) are the values for 10 pps. If 20 pps is used, the machine automatically compensates.
4. The first ring may not be detected until 1 to 2.5 wavelengths after the time specified by this parameter.
5. The calculated level must be between 0 and 10.
The attenuation levels calculated from RAM data are:
High frequency tone: $-0.5 \times N_{680552/680554} - 3.5$ dBm
 $-0.5 \times N_{680555}$ dBm
Low frequency tone: $-0.5 \times (N_{680552/680554} + N_{680553}) - 3.5$ dBm
 $-0.5 \times (N_{680555} + N_{680553})$ dBm
NOTE: N_{680552} , for example, means the value stored in address 680552(H)
6. 68054A: Europe - Between Ds opening and Di opening, France - Between Ds closing and Di opening
68054D: Europe - Between Ds closing and Di closing, France - Between Ds opening and Di closing
7. Tone signals which frequency is lower than 1500Hz (e.g., 800Hz tone for AI short protocol) refer to the setting at 6805B5h. Tones which frequency is higher than 1500Hz refer to the setting at 6805B6h.
8. 68054A, 68054D, 68054E: The actual inter-digit pause (pulse dial mode) is the sum of the period specified by the RAM addresses 68054A, 68054D, and 68054E.

3.4 DEDICATED TRANSMISSION PARAMETERS

Each Quick Dial Key has eight bytes of programmable parameters allocated to it. If transmissions to a particular machine often experience problems, store that terminal's fax number as a Quick Dial and adjust the parameters allocated to that number.

The programming procedure will be explained first. Then, the eight bytes will be described.

3.4.1 PROGRAMMING PROCEDURE

1. Set the bit 0 of System Bit Switch 00 to 1.
2. Press User Tools> System Settings> Key Operator Tools> Address Book Management.
3. Select the destination where you want to change the settings.
4. Press "Fax Dest."
5. When the programmed dial number is displayed, press "Start". Make sure that the LED of the Start button is lit as green.
6. The settings for the switch 00 are now displayed. Press the bit number that you wish to change.
7. To scroll through the parameter switches:
Select the next switch: press "Next"
-or-
Select the previous switch: "Prev." until the correct switch is displayed.
Then go back to step 6.
8. After the setting is changed, press "OK".
9. After finishing, reset bit 0 of System Bit Switch 00 to 0.

DEDICATED TRANSMISSION PARAMETERS

3.4.2 PARAMETERS

The initial settings of the following parameters are all FF(H) - all the parameters are disabled.

Switch 00	
FUNCTION AND COMMENTS	
ITU-T T1 time (for PSTN G3 mode) If the connection time to a particular terminal is longer than the NCU parameter setting, adjust this byte. The T1 time is the value stored in this byte (in hex code), multiplied by 1 second.	
Range: 0 to 120 s (00h to 78h) FFh - The local NCU parameter factory setting is used. Do not program a value between 79h and FEh.	

Switch 01		
No	FUNCTION	COMMENTS
0 to 4	Tx level	If communication with a particular remote terminal often contains errors, the signal level may be inappropriate. Adjust the Tx level for communications with that terminal until the results are better. If the setting is "Disabled", the NCU parameter 01 setting is used. Note: Do not use settings other than listed on the left.
	Bit 4 3 2 1 0 Setting	
	0 0 0 0 0 0	
	0 0 0 0 1 -1	
	0 0 0 1 0 -2	
	0 0 0 1 1 -3	
	0 0 1 0 0 -4	
:		
:		
0 1 1 1 1 -15		
1 1 1 1 1 Disabled		
5 to 7	Cable equalizer	Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone exchange when calling the number stored in this Quick/Speed Dial. Also, try using the cable equalizer if one or more of the following symptoms occurs. <ul style="list-style-type: none"> • Communication error with error codes such as 0-20, 0-23, etc. • Modem rate fallback occurs frequently. Note: Do not use settings other than listed on the left. If the setting is "Disabled", the bit switch setting is used.
	Bit 7 6 5 Setting	
	0 0 0 None	
	0 0 1 Low	
	0 1 0 Medium	
	0 1 1 High	
1 1 1 Disabled		

DEDICATED TRANSMISSION PARAMETERS

Switch 02						
No	FUNCTION			COMMENTS		
0 to 3	Initial Tx modem rate			<p>If training with a particular remote terminal always takes too long, the initial modem rate may be too high. Reduce the initial Tx modem rate using these bits.</p> <p>For the settings 14.4 or kbps slower, Switch 04 bit 4 must be changed to 0.</p> <p>Note: Do not use settings other than listed on the left.</p> <p>If the setting is "Disabled", the bit switch setting is used.</p>		
	Bit3	2	1 0		Setting (bps)	
	0	0	0		0	Not used
	0	0	0		1	2,400
	0	0	1		0	4,800
	0	0	1		1	7,200
	0	1	0		0	9,600
	0	1	0		1	12,000
	0	1	1		0	14,400
	0	1	1		1	16,800
	1	0	0		0	19,200
	1	0	0		1	21,600
	1	0	1		0	24,000
	1	0	1		1	26,400
	1	1	0		0	28,800
	1	1	0		1	31,200
	1	1	1		0	33,600
1	1	1	1	Disabled		
Other settings: Not used						
4-5	Not used			Do not change the settings.		
6	AI short protocol 0: Off 1: Disabled			Refer to Appendix B in the Group 3 Facsimile Manual for details about AI Short Protocol. If the setting is "Disabled", the bit switch setting is used.		
7	Not used			Do not change the settings.		

Fax Option
B576

DEDICATED TRANSMISSION PARAMETERS

Switch 03				
No	FUNCTION			COMMENTS
0 to 1	Inch-mm conversion before tx Bit 1 0 0 1 1	Bit 0 0 1 0 1	Setting Inch-mm conversion available Inch only Not used Disabled	The machine uses inch-based resolutions for scanning. If "inch only" is selected, the printed copy may be slightly distorted at the other end if that machine uses mm-based resolutions. If the setting is "Disabled", the bit switch setting is used.
2 to 3	DIS/NSF detection method Bit 3 0 0 1 1	Bit 2 0 1 0 1	Setting First DIS or NSF Second DIS or NSF Not used Disabled	(0, 1): Use this setting if echoes on the line are interfering with the set-up protocol at the start of transmission. The machine will then wait for the second DIS or NSF before sending DCS or NSS. If the setting is "Disabled", the bit switch setting is used.
4	V.8 protocol 0: Off 1: Disabled			If transmissions to a specific destination always end at a lower modem rate (14,400 bps or lower), disable V.8 protocol so as not to use V.34 protocol. 0: V.34 communication will not be possible. If the setting is "Disabled", the bit switch setting is used.
5	Compression modes available in transmit mode 0: MH only 1: Disabled			This bit determines the capabilities that are informed to the other terminal during transmission. If the setting is "Disabled", the bit switch setting is used.
6 to 7	ECM during transmission Bit 7 0 0 1 1	Bit 6 0 1 0 1	Setting Off On Not used Disabled	For example, if ECM is switched on but is not wanted when sending to a particular terminal, use the (0, 0) setting. Note that V.8/V.34 protocol and JBIG compression are automatically disabled if ECM is disabled. If the setting is "Disabled", the bit switch setting is used.

Switch 04 - Not used (do not change the settings)
Switch 05 - Not used (do not change the settings)
Switch 06 - Not used (do not change the settings)
Switch 07 - Not used (do not change the settings)
Switch 08 - Not used (do not change the settings)
Switch 09 - Not used (do not change the settings)

3.5 SERVICE RAM ADDRESSES

⚠ CAUTION

Do not change the settings which are marked as “Not used” or “Read only.”
--

680001 to 680004(H) - ROM version (Read only)

- 680001(H) - Revision number (BCD)
- 680002(H) - Year (BCD)
- 680003(H) - Month (BCD)
- 680004(H) - Day (BCD)

680006 to 680015(H) - Machine's serial number (16 digits - ASCII)

- 680018(H)** - Total program checksum (low)
- 680019(H)** - Total program checksum (high)

- 680020 to 68003F(H)** - System bit switches
- 680050 to 68005F(H)** - Printer bit switches
- 680060 to 68007F(H)** - Communication bit switches
- 680080 to 68008F(H)** - G3 bit switches
- 680090 to 68009F(H)** - G3-2 bit switches

6800D0(H) - User parameter switch 00 (SWUER_00) : Not used

6800D1(H) - User parameter switch 01 (SWUSR_01) : Not used

6800D2(H) - User parameter switch 02 (SWUSR_02)

- Bit 0: Forwarding mark printing on forwarded messages
0: Disabled
1: Enabled
- Bit 1: Center mark printing on received copies. (This switch is not printed on the user parameter list.)
0: Disabled
1: Enabled
- Bit 2: Reception time printing. (This switch is not printed on the user parameter list.)
0: Disabled
1: Enabled
- Bit 3: TSI print on received messages
0: Disabled
1: Enabled
- Bit 4: Checkered mark printing. (This switch is not printed on the user parameter list.)
0: Disabled
1: Enabled
- Bit 5 to 7: Not used.

SERVICE RAM ADDRESSES

6800D3(H) - User parameter switch 03 (SWUSR_03: Automatic report printout)

Bit 0: Transmission result report (memory transmissions) 0: Off, 1: On

Bit 1: Not used

Bit 2: Memory storage report 0: Off, 1: On

Bit 3: Polling reserve report (polling reception) 0: Off, 1: On

Bit 4: Polling result report (polling reception) 0: Off, 1: On

Bit 5: Transmission result report (immediate transmissions) 0: Off, 1: On

Bit 6: Polling clear report 0: Off, 1: On

Bit 7: Journal 0: Off, 1: On

6800D4(H) - User parameter switch 04 (SWUSR_04: Automatic report printout)

Bit 0: Automatic confidential reception report output 0: Off, 1: On

Bits 1 to 6: Not used

Bit 7: Inclusion of a sample image on reports 0: Off, 1: On

6800D5(H) - User parameter switch 05 (SWUSR_05)

Bit 0: Substitute reception when the base copier is in an SC condition

0: Enabled, 1: Disabled

Bits 1 and 2: Condition for substitute rx when the machine cannot print messages (Paper end, toner end, jam, and during night mode)

Bit 2 1 Setting

0 0 The machine receives all the fax messages.

0 1 The machine receives the fax messages with RTI or CSI.

1 0 The machine receives the fax messages with the same ID code.

1 1 The machine does not receive anything.

Bit 3 and 4: Not used

Bit 5: Just size printing 0: Off, 1: On

Bit 6: Not used

Bit 7: Add paper display when a cassette is empty 0: Off, 1: On

6800D6(H) - User parameter switch 06 (SWUSR_06)

Bits 0 to 5: Not used

Bit 6: Scan sequence in Book transmission

0: Left page then right page, 1: Right page then left page

Bit 7: Not used

6800D7(H) - User parameter switch 07 (SWUSR_07)

Bits 0 and 1: Not used

Bit 2: Parallel memory transmission 0: Off, 1: On

Bits 3 to 7: Not used

6800D8(H) - User parameter switch 08 (SWUSR_08)

Bits 0 and 1: Not used.

Bit 2: Authorized reception

0: Only faxes from senders whose RTIs/CSIs are specified for this feature are accepted.

1: Only faxes from senders whose RTIs/CSIs are not specified for this feature are accepted.

Bits 3 to 7: Not used.

6800D9(H) - User parameter switch 09 (SWUSR_09) : Not used

6800DA(H) - User parameter switch 10 (SWUSR_0A)

Bit 0: Not used

Bit 1: 2 into 1 0: Off, 1: On

Bit 2: Not used

Bit 3: Page reduction 0: Off, 1: On

Bits 4 to 7: Not used

6800DB(H) - User parameter switch 11 (SWUSR_0B)

Bit 0 to 5: Not used

Bit 6: Printout of messages received while acting as a forwarding station

0: Off, 1: On

Bit 7: Polling Standby duration 0: Once, 1: No limit

6800DC(H) - User parameter switch 12 (SWUSR_0C): Not used

6800DD(H) - User parameter switch 13 (SWUSR_0D): Not used

6800DE(H) - User parameter switch 14 (SWUSR_0E)

Bit 0: Message printout while the machine is in Night Printing mode 0: On, 1: Off

Bit 1: Maximum document length detection

0: Double letter, 1: Longer than double-letter (well log) – up to 1,200 mm

Bit 2: Batch transmission 0: Off, 1: On

Bit 3: Fax mode settings, such as resolution, before a mode key (Copy/Fax/Printer/Scanner) is pressed

0: Not cleared, 1: Cleared

Bits 4 to 6: Not used

Bit 7: Manual service call (sends the system parameter list to the service station)

0: Off, 1: On

SERVICE RAM ADDRESSES

6800DF(H) - User parameter switch 15 (SWUSR_0F)

Bits 0, 1 and 2: Cassette for fax printout

Bit 2	1	0	Setting
0	0	1	1st paper feed station
0	1	0	2nd paper feed station
0	1	1	3rd paper feed station
1	0	0	4th paper feed station
1	0	1	LCT

Other settings Not used

Bits 3 and 4: Not used

Bit 5: Using the cassette specified by bits 0, 1 and 2 above only 0: On, 1: Off

Bits 6 and 7: Not used

6800E0(H) – User parameter switch 16 (SWUSR_10)

(This switch is not printed on the user parameter list.)

Bits 0 and 1: Not used

Bit 2: Paper size selection priority for an A4 size fax message when A4/LT size paper is not available.

0: A3 has priority, 1: B4 has priority

Bits 3 to 7: Not used

6800E1(H) – User parameter switch 17 (SWUSR_11)

Bits 0 and 1: Not used

Bit 2: Inclusion of the “Add” button when a sequence of Quick/Speed dials is selected for broadcasting

0:Not needed, 1: Needed

Bits 3 to 6: Not used

Bit 7: Press “Start” key without an original when using the on hook dial or the external telephone,

0: displays “Cannot detect original size”.

1: Receives fax messages.

6800E2(H) - User parameter switch 18 (SWUSR_12)

Bit 0: TTI date 0: Off, 1: On

Bit 1: TTI sender 0: Off, 1: On

Bit 2: TTI file number 0: Off, 1: On

Bit 3: TTI page number 0: Off, 1: On

Bit 4 to 7: Not used

6800E3(H) - User parameter switch 19 (SWUSR_13)

Bit 0: Offset sort function for the fax (only using the shift tray on the 1,000 sheet finisher)

0: Disabled, 1: Enabled

Bit 1: Journal format

0: The Journal is separated into transmissions and receptions

1: The Journal is separated into G3-1 and G3-2 communications

Bit 2: Action when the paper cassette that was selected by the specified cassette selection feature becomes empty.

(This switch is not printed on the user parameter list.)

0: The machine will not print any received files until paper is added.

1: The machine will use other cassettes to print received files that are not specified by this feature.

Bit 3: 90° image rotation during B5 portrait Tx

(This switch is not printed on the user parameter list.)

0: Off, 1: On

Bit 4: Reduction of sample images on reports to 50% in the main scan and sub-scan directions. (This switch is not printed on the user parameter list.)

0: Technician adjustment (printer switch 0E bits 3 and 4), 1: 50% reduction

Bit 5: Use of A5 size paper for reports

(This switch is not printed on the user parameter list.)

0: Off, 1: On

Bits 6 and 7: Not used

6800E4(H) - User parameter switch 20 (SWUSR_14)

Bit 0: Automatic printing of the PC FAX error report

0: Off, 1: On

Bit 1: Reprint the documents fail to print from PC Fax driver

0: Off, 1: On

Bits 2 to 5: Store documents in memory which could not be printed from PC Fax driver

Bit	5	4	3	2	Setting
	0	0	0	0	0 min.
	0	0	0	1	1 min.
			↓		↓
	1	1	1	0	14 min.
	1	1	1	1	15 min.

Bits 6: Not used.

Bit 7: PC fax result notification mail, 0: Off, 1: On

6800E5(H) - User parameter switch 21 (SWUSR_15)

Bit 0: Print E-mail Reception Notice, 0: Off, 1: On

Bit 1: Respond to E-mail Reception Acknowledgement Request, 0: Off, 1: On

Bit 2 and 3: Not used.

Bit 4: Transmit Journal by E-Mail, 0: Off, 1: On

Bit 5 and 6: Not used.

Bit 7: Transmit Error Mail Notification, 0: Off, 1: On

SERVICE RAM ADDRESSES

6800E6(H) - User parameter switch 22 (SWUSR_16): Not used

6800E7(H) - User Parameter switch 23 (SWUSR_17) : Not used

6800E8(H) - User parameter switch 24 (SWUSR_18)

Bits 0 and 1: File retention time (Cross reference: System switch 02 bit 4)

Bit	1	0	Setting
	0	0	File retention impossible
	0	1	24 hours
	1	0	File retention impossible
	1	1	72 hours

Bits 2 to 7: Not used

6800E9(H) - User parameter switch 25 (SWUSR_19)

Bits 0 to 3: Not used

Bit 4: RDS operation

0: Not acceptable

1: Acceptable for the limit specified by system switch 03

Note: This bit is only effective when RDS operation can be selected by the user (see system switch 02).

Bits 5 to 7: Not used

6800EA to 6800EF(H) - User parameter switch 26 to 31 (SWUSR_1A to 1F),
Not used

6800F0 - User Parameter Switch 32 (SWUSR_20)

Bit 0: Priority destination for transfer, 0: Fax number, 1: E-mail address

Bits 2 to 7: Not used

680180 to 68019F(H) - Service station's fax number (SP3-101)

See 68036C(H) for the type of network used for this number.

6801A0 to 6801A3(H) - Own fax PABX extension number

6801AA to 6801B3(H) - Own fax number (PSTN)

6801F8 to 68020B(H) - PSTN-1 RTI (Max. 20 characters - ASCII) - See the following note.

68020C to 68021F(H) - PSTN-2 RTI (Max. 20 characters - ASCII) - See the following note.

680237 to 680276(H) - TTI 1 (Max. 64 characters - ASCII) - See the following note.

680277 to 6802B6(H) - TTI 2 (Max. 64 characters - ASCII) - See the following note.

6802F7 to 68030A(H) - PSTN-1 CSI (Max. 20 characters - ASCII)

68030B to 68031E(H) - PSTN-2 CSI (Max.20 characters - ASCII)

680333(H) - Number of PSTN-1 CSI characters (Hex)

680334(H) - Number of PSTN-2 CSI characters (Hex)

If the number of characters is less than the maximum (20 for RTI, 64 for TTI), add a stop code (FF[H]) after the last character.

680340 to 680342(H) - PSTN-1 line settings

680340

Bits 0 and 1: PSTN access method from behind a PABX.

Bit	1	0	Setting
	0	0	Loop start
	0	1	Ground start
	1	0	Flash start
	1	1	Not used

Bit 2: Telephone line type.

0: PSTN, 1: PABX

Bits 3 and 4: Dialing type.

Bit	4	3	Setting
	0	0	Pulse dialing
	0	1	Not used
	1	0	Tone dialing
	1	1	Not used

Bits 4 to 7: Not used

680341: PSTN access number for loop start

Access number Hex value to program (BCD)

0	F0
↓	↓
9	F9
00	00
↓	↓
99	99

680342

Bit 0: Transmission disabled

0: Tx and Rx, 1: Rx only

Bit 1: Memory Lock reception

0: Enabled, 1: Disabled

Bits 2 to 7: Not used

680348 to 68034A(H) - PSTN-2 line settings**680360(H)** – Polling ID Code (Low – Hex)**680361(H)** – Polling ID Code (High – Hex)**680362(H)** - Confidential ID (low - BCD)**680363(H)** - Confidential ID (high - BCD)**680364(H)** - Memory Lock ID (low - BCD)**680365(H)** - Memory Lock ID (high - BCD)

SERVICE RAM ADDRESSES

68036C(H) - Network type used for the service station number

- 0 1 (H) - PSTN-1
- 0 2 (H) - PSTN-2
- 0 3 (H) - Not used
- 1 0 (H) - Not used
- 0 7 (H) - G3 auto selection

680370 to 680377(H) - Last power off time (Read only)

- 680370(H) - 01(H) - 24-hour clock, 00(H) - 12-hour clock (AM),
02(H) - 12-hour clock (PM)
- 680371(H) - Year (BCD)
- 680372(H) - Month (BCD)
- 680373(H) - Day (BCD)
- 680374(H) - Hour
- 680375(H) - Minute
- 680376(H) - Second
- 680377(H) - 00: Monday, 01: Tuesday, 02: Wednesday, , 06: Sunday

680384(H) - Optional equipment (Read only – Do not change the settings)

- Bit 0 to 3: Not used
- Bit 4: Function Upgrade unit 0: Not installed, 1: Installed
- Bit 5 to 7: Not used

680385(H) - Optional equipment (Read only – Do not change the settings)

- Bit 0: Function Upgrade unit 0: Not installed, 1: Installed
- Bit 1 to 3: Not used
- Bit 4: G3-2 0: Not installed, 1: Installed

6803F6 to 6803FA(H) – Option G3 board (G3-2) ROM information (Read only)

- 6803F6(H) - Suffix (BCD)
- 6803F7(H) - Version (BCD)
- 6803F8(H) - Year (BCD)
- 6803F9(H) - Month (BCD)
- 6803FA(H) - Day (BCD)

680402(H) - Option G3 board (G3-2) modem ROM version (Read only)

680406 to 68040B(H) - Modem ROM version (Read only)

- 680406(H) - Part number (low)
- 680407(H) - Part number (high)
- 680408(H) - Control (low)
- 680409(H) - Control (high)
- 68040A(H) - DSP (low)
- 68040B(H) - DSP (high)

680464(H) - Time for economy transmission (hour in 24h clock format - BCD)

680465(H) - Time for economy transmission (minute - BCD)

SERVICE RAM ADDRESSES

680482(H) - Transmission monitor volume 00 - 07(H)

680483(H) - Reception monitor volume 00 - 07(H)

680484(H) - On-hook monitor volume 00 - 07(H)

680485(H) - Dialing monitor volume 00 - 07(H)

680486(H) - Buzzer volume 00 - 07(H)


6BA000 – 6BA1FF(H) – Latest 64 error codes (Read only)

6BE988 – 6BF35F(H) – Latest 20 error communication records

Fax Option
B576

4. DETAILED SECTION DESCRIPTIONS

4.1 OVERVIEW



Fax Option
B576

The basic fax unit consists of three PCBs: an FCU, an MBU and an NCU.


The FCU controls all the fax communications and fax features, in cooperation with the controller board. The MBU contains the ROM and SRAM. The NCU switches the analog line between the fax unit and the external telephone.

Fax Options:

1. Extra G3 Interface option: This provides one more analog line interface. This allows full dual access. Only one extra G3 interface option can be installed. The optional G3 unit consists of three PCBs: G3 board, NCU, and CCUIF.
2. Fax Function Upgrade Unit: JBIG compression becomes available. In addition, this expands the system's SRAM capacity to hold programmed telephone numbers, memory files, etc.
3. Memory Expansion: This expands the SAF memory and the page memory (used for image rotation); without this expansion, the page memory is not big enough for image rotation at 400 dpi, so transmission at 400 dpi is not possible.

4.2 BOARDS

4.2.1 FCU



The FCU (Facsimile Control Unit) controls fax communications, the video interface to the base copier's engine, and all the fax options.

FACE2 (Fax Application Control Engine)

- CPU
- Data compression and reconstruction (DCR)
- DMA control
- Clock generation
- DRAM backup control
- Ringing signal/tone detection

FBI (FACE Bridge Interface)

- Interface between the PCI bus and the FACE
- DMA control

Modem (Panasonic MN195006-E)

- V.34, V33, V17, V.29, V.27ter, V.21, and V.8

DRAM

- The 16 MB of DRAM is shared as follows.
SAF memory : 4 MB
Working memory : 4 MB
Page memory : 8 MB
- The SAF memory is backed up by a rechargeable battery.

Memory back-up

- A Rechargeable battery backs up the SAF memory (DRAM) for 1 hour.

Switches

Item	Description
SW1	Reset switch, to reboot the FCU board

Fax Option
B576**4.2.2 MBU**

On this board, the flash ROM contains the FCU firmware, and the SRAM contains the system data and user parameters. Even if the FCU is changed, the system data and user parameters are kept on the MBU board.

ROM

- 3MB flash ROMs for system software storage
2MB (16bit x 1MB) + 1MB (16bit x 512K)

SRAM

- The 256 KB SRAM for system and user parameter storage is backed up by a lithium battery.

Memory back-up


- A lithium battery backs up the system parameters and programmed items in the SRAM, in case the base copier's main switch is turned off.

Switches

Item	Description
SW1	Switches the SRAM backup battery on/off.

BOARDS


4.2.3 NCU (US)



Jumpers

Item	Description
JP7	These jumpers should be shorted when the machine is connected to a dry line.
JP8	
DB1	Also remove DB1 when the machine is connected to a dry line.

4.2.4 NCU (EUROPE/ASIA)



Fax Option B576


Control Signals and Jumpers

	CSEL1	RSEL
Country	CN2-5	CN1-13
CTR21	H	H
Australia	H	H
South Africa	H	H
Malaysia	H	H
Hong Kong	L	L
New Zealand	L	L
Singapore	L	L
Asia	L	L
	L: Low, H: High	

CTR21 (Common Technical Regulation 21):

France, Germany, UK, Italy, Austria, Belgium, Denmark, Finland, Ireland, Norway, Sweden, Switzerland, Portugal, Holland, Spain, Israel, Greece

4.2.5 SG3-D BOARD



The SG3-D board allows up to two simultaneous communications when used with the the FCU.

NCCP (New Communication Control Processor)

- Controls the SG3-D board
- CPU (RU30)
- Modem (V.34)
- JBIG

Flash ROM

- 8 MB flash ROM shared between the SG3 software and modem software.

SDRAM

- 16 MB DRAM shared between the ECM buffer, line buffer, and work memory.

CODEC

- Converts analog data to binary data.
- Converts binary data to analog data.

AFE (Analog Front End)

- Analog circuit
- Data transfer

4.3 ADDRESS BOOK


The address book (directory) for this machine combines under one user name the fax address and mail address.

All the address data is stored on the HDD. Up to a maximum of 2,000 items can be stored for addresses.

4.3.1 ADDRESS BOOK BACKUP

The address data can be backed up, and frequently backing up the address book data is recommended. If for any reason data can no longer be read from the HDD, you can use the backed up data to restore the address book.

Overview of Data Backup



ADDRESS BOOK

There are three methods you can use to back up address book data:

- HDD ↔ IC Card
- FCU (MBU) ↔ IC Card
- HDD ↔ FCU

Each is described below.

1. HDD ↔ IC Card

Address data stored on the HDD can be uploaded to an IC card with SP5846 51 (UCS Settings - All Directory Info. Upload), or address data backed up on the IC card can be downloaded to the HDD with SP5846 52 (UCS Settings – All Directory Info. Download).

2. FCU (MBU) ↔ IC Card

Address data stored in the FCU (MBU) can be uploaded to an IC card with SP5846 51 (UCS Settings - All Directory Info. Upload), or address data backed up on the IC card can be downloaded to the FCU with SP5846 52 (UCS Settings – All Directory Info. Download).

3. HDD ↔ FCU

Address data stored on the HDD can be uploaded to the FCU (MBU) with SP5846 80 (UCS Settings - FCU Backup), or when there is address data in the FCU and the HDD has just been replaced, this data is downloaded automatically to the new HDD.

SP Modes

1. SP5846 051 UCS Settings - All Directory Info. Upload

This SP mode is used to upload address data to an IC card. The machine automatically detects where the address data is stored. If there is address data on the HDD, the address data from the HDD is uploaded to the IC card. If the HDD is not present, then the address data from the FCU is uploaded. If one IC card is not large enough to hold all the address data, as many IC cards as needed can be used to hold all of the address data.

2. SP5846 052 UCS Settings – All Directory Info. Download

This SP mode downloads address data from an IC card. The machine automatically determines where to store the address data. If there is address data on the HDD, then the data is downloaded to the HDD. If HDD is not present, then the address data is downloaded to the FCU.

3. SP5846 080 UCS Settings - FCU Backup

This SP mode is used to take fax address data from among the address data on the HDD and upload it to the FCU. However, the FCU is capable of holding only up to 500 items for address data, so if more than 500 address items are stored on the HDD, only the first and oldest 500 address on the HDD are backed up. If FAX Function Upgrade Unit (Option) is installed, up to 1200 address items can be backed up.

NOTE: In preparation for the possibility that data can no longer be read from the HDD, we recommend that the CE back up the address data to the FCU when visiting the customer. However, when address data is backed up to the FCU, only the fax data in the address book is backed up, and the other data (e-mail address, etc.) are not backed up. For this reason, the customer should be instructed about how to frequently back up the address book data using SmartNet – Monitor Admin.

SPECIFICATIONS

1. GENERAL SPECIFICATIONS

Type:	Desktop type transceiver
Circuit:	PSTN (max. 2 ch.) PABX
Connection:	Direct couple
Original Size:	Book (Face down) Maximum Length: 432 mm [17 ins] Maximum Width: 297 mm [11.7 ins] ARDF (Face up) (single sided document) Length: 128 - 1200 mm [5.0 - 47.2 ins] Width: 105 - 297 mm [4.1 - 11.7 inch] (double sided document) Length: 128 - 432 mm [5.0 - 17 inch] Width: 105 - 297 mm [4.1 - 11.7 inch]
Scanning Method:	Flat bed, with CCD
Resolution:	G3 8 x 3.85 lines/mm (Standard) 8 x 7.7 lines/mm (Detail) 8 x 15.4 line/mm (Fine) Note1 16 x 15.4 line/mm (Super Fine) See Note 1 200 x 100 dpi (Standard) 200 x 200 dpi (Detail) 400 x 400 dpi (Super Fine) See Note 1 NOTE: 1. Optional Expansion Memory required
Transmission Time:	G3: 3 s at 28800 bps; Measured with G3 ECM using memory for an ITU-T #1 test document (Slerexe letter) at standard resolution
Data Compression:	MH, MR, MMR JBIG (optional Fax Function Upgrade Unit required)
Protocol:	Group 3 with ECM
Modulation:	V.34, V.33, V.17 (TCM), V.29 (QAM), V.27ter (PHM), V.8, V.21 (FM)
Data Rate:	G3: 33600/31200/28800/26400/24000/21600/ 19200/16800/14400/12000/9600/7200/4800/2400 bps Automatic fallback
I/O Rate:	With ECM: 0 ms/line Without ECM: 2.5, 5, 10, 20, or 40 ms/line

SPECIFICATIONS

Memory Capacity: ECM: 128 KB
SAF
Standard: 4 MB
With optional Expansion Memory: 32 MB (4 MB+ 28 MB)
Page Memory
Standard: 8 MB (Print: 4 MB + Scanner: 4 MB)
With optional Expansion Memory: 16 MB (8 MB + 8 MB)
(Print 8 MB + Scanner: 4 MB)

2. CAPABILITIES OF PROGRAMMABLE ITEMS

The following table shows how the capabilities of each programmable item will change after the optional Fax Function Upgrade Unit is installed.

Item	Standard	With Fax Function Upgrade Unit
Quick Dial	500	1200 (2000*)
Groups	100	100
Destination per Group	500	500
Boxes (Information/Personal/Transfer)	150	400
Destinations dialed from the ten-key pad overall	500	2000
Programs	100	200
Auto Document	6	18
Communication records for Journal stored in the memory	200	1000
Specific Senders	30	50

* With the Printer/Scanner Option

The following table shows how the capabilities of the document memory will change after the optional Fax Function Upgrade Unit and the Expansion Memory are installed.

		Without the Expansion Memory	With the Expansion Memory
Memory Transmission file	Without the Fax Function Upgrade Unit	800	800
Maximum number of page for memory transmission		1000	3000
Memory capacity for memory transmission (Note1)		320	2240
Memory Transmission file	With the Fax Function Upgrade Unit	800	800
Maximum number of page for memory transmission		1000	3000
Memory capacity for memory transmission (Note1)		320	2240

Fax Option
B576

NOTE: 1) Measured using an ITU-T #1 test document (Slerexe letter) at the standard resolution, the auto image density mode and the Text mode.

3. MACHINE CONFIGURATION

Item	Machine Code	Remarks
Fax Option Type 2027	B576	
G3 Interface Unit Type 2027	B593	
Fax Function Upgrade Type 185	A892	Used in common with A250 and B022.
Handset Type 1018	B433	USA only
Marker Type 30	H903	Refill ink for stamp
Expansion Memory	-	Used in common with A250, A265, and B022.

**Internet Fax (IFAX)
SERVICE MANUAL**

1. INSTALLATION

1.1 IFAX INSTALLATION

IFAX requires the installation of the Fax Unit and the Printer/Scanner Controllers. For details about installation, please refer to the Fax Unit and the Printer/Scanner option manuals for the machine.

1.2 INITIAL SETTINGS

Users can set the IFAX initial settings. Please refer to the Network Guide Operating Instructions.

Make sure that the following items are registered in the mail server before machine installation.

- IP address
- Host name
- Mail account and the password

CAUTION: The initial settings include items related to user security, such as the login password and IP addresses. So, please ask the user to input the initial settings of the IFAX. If the user asks you to input the initial settings, be sure to keep the settings confidential.

To enable IFAX functions, do the following procedure in the User Tools mode:

User Tools> Facsimile Features> E-Mail Settings> Internet Fax Settings> Internet Fax> OFF → ON

2. TROUBLESHOOTING

2.1 ERROR CODES FOR LAN COMMUNICATION

If an error code occurs, retry the communication. If the same problem occurs, try to solve the problem as suggested below.

Code	Meaning	Cause	Action
14-00	SMTP Send Error	Error occurred during sending to the SMTP server. Occurs for any error other than 14-01 to 16. For example, the mail address of the system administrator is not registered.	<ul style="list-style-type: none"> • Register the address of the system administrator. • Set the User Parameter Switch 21 (15[H]) Bit 4 to "Off".
14-01	SMTP Connection Failed	Failed to connect to the SMTP server (timeout) because the server could not be found. <ul style="list-style-type: none"> • The IP address for the SMTP server is not stored in the machine. • The DNS IP address is not registered. • Network not operating correctly. 	<ul style="list-style-type: none"> • Check the IP address of the SMTP/DNS server. • Check the traffic on the LAN. • Check the machine settings such as the SMTP port setting, DNS server setting, and so on.
14-02	No Service by SMTP Service (421)	SMTP server operating incorrectly.	Contact the network administrator. Confirm correct SMTP server settings and operation.
14-03	Access to SMTP Server Denied (450)	SMTP server operating incorrectly	Contact the network administrator. Confirm correct SMTP server settings and operation.
14-04	Access to SMTP Server Denied (550)	SMTP server operating incorrectly	Contact the network administrator. Confirm correct SMTP server settings and operation.
14-05	SMTP Server HDD Full (452)	SMTP Server hard disk full.	Contact the network administrator. Free space on the HDD of the SMTP server.
14-06	User Not Found on SMTP Server (551)	The user does not exist locally.	<ul style="list-style-type: none"> • Check that the mail address is correct. • Contact the network administrator. Check that the e-mail the user intended to send exists on the SMTP server.
14-07	Data Send to SMTP Server Failed (4XX)	SMTP server operating incorrectly	Contact the network administrator. Confirm correct SMTP server settings and operation.
14-08	Data Send to SMTP Server Failed (5XX)	SMTP server operating incorrectly	Contact the network administrator. Confirm correct SMTP server settings and operation.

ERROR CODES FOR LAN COMMUNICATION

Code	Meaning	Cause	Action
14-09	Authorization Failed for Sending to SMTP Server	POP-Before-SMTP or SMTP authorization failed.	POP-Before-SMTP: <ul style="list-style-type: none"> • Check the IFAX user name and password. • Check that POP server is set correctly. • Check the SMTP server settings. SMTP Authorization: <ul style="list-style-type: none"> • Check the SMTP server user name and password. • Check the encryption settings. • Check the SMTP server settings.
14-10	Addresses Exceeded	Number of broadcast addresses exceeded the limit for the SMTP server.	The maximum number of addresses depends on the SMTP server.
14-11	Buffer Full	The send buffer is full so the transmission could not be completed. Buffer is full due to using Scan-to-Email while the buffer is being used send mail at the same time.	No action required. The transmission will be recalled and sent as soon as buffer space is available.
14-12	Data Size Too Large	Transmission was cancelled because the detected size of the file was too large.	<ul style="list-style-type: none"> • Divide the original into sections and send as separate files. • Use G3 to send the original. • Reduce the TX mail size.
14-13	Send Cancelled	Processing is interrupted because the user pressed Stop.	No action required.
14-30	MCS File Creation Failed	Failed to create the MCS file because: <ul style="list-style-type: none"> • The number of files created with other applications on the Document Server has exceeded the limit. • HDD is full or not operating correctly. • Software error. 	<ul style="list-style-type: none"> • Delete unneeded files from the Document Server. • Initialize the HDD. • If initialization fails to correct the problem, replace the HDD. • Update the software.
14-31	UFS File Creation Failed	UFS file could not be created: <ul style="list-style-type: none"> • Not enough space in UFS area to handle both Scan-to-Email and IFAX transmission. • HDD full or not operating correctly. • Software error. 	No action required. Once the job currently using the UFS area is finished sufficient space will become available. If this does not solve the problem: <ul style="list-style-type: none"> • Initialize the HDD. • If initialization fails to correct the problem, replace the HDD. • Update the software.
14-32	Cancelled the Mail Due to Error Detected by NFAX	Error detected with NFAX and send was cancelled due to a software error.	Update the software.
14-33	No Mail Address For the Machine	Neither the mail address of the machine nor the mail address of the network administrator is registered.	Contact the network administrator. Check that these e-mail addresses are registered correctly.
14-50	Mail Job Task Error	Due to an FCU mail job task error, the send was cancelled: <ul style="list-style-type: none"> • Address book was being edited during creation of the notification mail. • Software error. 	No action required. If the problem persists, update the firmware.

ERROR CODES FOR LAN COMMUNICATION

Code	Meaning	Cause	Action
14-51	UCS Destination Download Error	Not even one return notification can be downloaded: <ul style="list-style-type: none"> The address book was being edited. The number for the specified destination does not exist (it was deleted or edited after the job was created). 	Check the address in the address book.
14-60	Send Cancel Failed	The cancel operation by the user failed to cancel the send operation.	No action required.
14-61	Notification Mail Send Failed for All Destinations	All addresses for return notification mail failed.	<ul style="list-style-type: none"> Correct the mail address for the PC. Contact the network administrator. Check the other error codes to determine if other errors occur at the same time.
15-01	POP3/IMAP4 Server Not Registered	At startup, the system detected that the IP address of the POP3/IMAP4 server has not been registered in the machine.	Register the name of the POP3/IMAP4 server.
15-02	POP3/IMAP4 Mail Account Information Not Registered	The POP3/IMAP4 mail account has not been registered.	Register the e-mail account, user name, and password.
15-03	Mail Address Not Registered	The mail address has not been registered.	Register the e-mail account and e-mail address.
15-10	DCS Mail Receive Error	Error other than 15-11 to 15-18.	Update the firmware, update the server software.
15-11	Connection Error	The DNS or POP3/IMAP4 server could not be found: <ul style="list-style-type: none"> The IP address for DNS or POP3/IMAP4 server is not stored in the machine. The DNS IP address is not registered. Network not operating correctly. 	Contact the network administrator. <ul style="list-style-type: none"> Check that the DNS address is correct. Check that the POP3/IMAP4 IP addresses are correct. Confirm correct operation of the network.
15-12	Authorization Error	POP3/IMAP4 send authorization failed: <ul style="list-style-type: none"> Incorrect IFAX user name or password. Access was attempted by another device, such as the PC. POP3/IMAP4 settings incorrect. 	Contact the network administrator: <ul style="list-style-type: none"> Check that the IFAX user name and password are correct. Determine whether another device of the same account attempted access at same time. Check that the POP/IMAP4 settings are correct.
15-13	Receive Buffer Full	Occurs only during manual reception. Transmission cannot be received due to insufficient buffer space. The buffer is being used for mail send or Scan-to-Email.	No action required. The next transmission can be received as soon as the other application releases the buffer area.
15-14	Mail Header Format Error	The mail header is not standard format. For example, the Date line description is incorrect.	Advise the sender to send e-mails in the standard format.
15-15	Mail Divide Error	The e-mail is not in standard format. There is no boundary between parts of the e-mail, including the header.	Advise the sender to send e-mails in the standard format.

ERROR CODES FOR LAN COMMUNICATION

Code	Meaning	Cause	Action
15-16	Mail Size Receive Error	The mail cannot be received because it is too large.	<ul style="list-style-type: none"> • Increase the setting that limits the size of e-mail that can be received (in the User Tools> System Settings> File Transfer menu). • Ask the sender to break the e-mail into smaller parts and send them separately.
15-17	Receive Timeout	May occur during manual receiving only because the network is not operating correctly.	Contact the network administrator and check that the network is operating correctly.
15-18	Incomplete Mail Received	Only one portion of the mail was received.	Ask the sender to send as one transmission.
15-31	Final Destination for Transfer Request Reception Format Error	The format of the final destination for the transfer request was incorrect.	Ask the sender to check the final destination.
15-39	Send/Delivery Destination Error	The transmission cannot be delivered to the final destination: <ul style="list-style-type: none"> • Destination file format is incorrect. • Could not create the destination for the file transmission. 	<ul style="list-style-type: none"> • Delete the destination file to enable receiving. • Ask the sender to check the transfer destination and final destination.
15-41	SMTP Receive Error	Reception rejected because the transaction exceeded the limit for the "Auth. E-mail RX" setting.	<ul style="list-style-type: none"> • Check the content of the "From" entry in the mail header. • Check the "Auth. E-mail RX" setting.
15-42	Off Ramp Gateway Error	The delivery destination address was specified with Off Ramp Gateway OFF.	<ul style="list-style-type: none"> • Enable the Off Ramp Gateway function. • Ask the sender not to specify the Off Ramp Gateway address.
15-43	Address Format Error	Format error in the address of the Off Ramp Gateway.	Ask the sender to check the mail destination.
15-44	Addresses Over	The number of addresses for the Off Ramp Gateway exceeded the limit of 30.	Ask the sender to check the mail destination.
15-61	Attachment File Format Error	The attached file is not TIFF format.	Try to check the format of the sent mail, then ask the user to use TIFF format.
15-62	TIFF File Compatibility Error	Could not receive transmission due to: <p>Resolution error</p> <ul style="list-style-type: none"> • Image of resolution greater than 200 dpi without extended memory. • Resolution is not supported. <p>Page size error</p> <ul style="list-style-type: none"> • The page size was larger than A3. <p>Compression error</p> <ul style="list-style-type: none"> • File was compressed with other than MH, MR, or MMR. 	<p>Ask the sender to check the following:</p> <ul style="list-style-type: none"> • File was sent in TIFF format. • Compatibility of the resolution setting. • Size of the page. • Method used to compress the file.
15-63	TIFF Parameter Error	The TIFF file sent as the attachment could not be received because the TIFF header is incorrect: <ul style="list-style-type: none"> • The TIFF file attachment is a type not supported. • The TIFF file attachment is corrupted. • Software error. 	<ul style="list-style-type: none"> • Ask the sender to check that the attachment was sent in correct TIFF format. • If the problem persists, update the software.

ERROR CODES FOR LAN COMMUNICATION

Code	Meaning	Cause	Action
15-64	TIFF Decompression Error	The file received as an attachment caused the TIFF decompression error: <ul style="list-style-type: none"> • The TIFF format of the attachment is corrupted. • Software error. 	<ul style="list-style-type: none"> • Ask the sender to check that the attachment was sent in correct TIFF format. • If the problem persists, update the software.
15-71	Not Binary Image Data	The file could not be received because the attachment was not binary image data.	Ask the sender to check the content of the attachment.
15-73	MDN Status Error	Could not find the Disposition line in the header of the Return Receipt, or there is a problem with the firmware.	Ask the sender to resend the mail. If the problem persists, update the firmware.
15-74	MSDN Message ID Error	Could not find the Original Message ID line in the header of the Return Receipt, or there is a problem with the firmware.	Ask the sender to resend the mail. If the problem persists, update the firmware.
15-80	Mail Job Task Read Error	Could not receive the transmission because the destination buffer is full and the destination could not be created (this error may occur when receiving a transfer request or a request for notification of reception).	No action required. When destinations are used and a space opens in the buffer, the transmission will be received.
15-81	Repeated Destination Registration Error	Could not repeat receive the transmission because the destination buffer is full and the destination could not be created (this error may occur when receiving a transfer request or a request for notification of reception).	No action required. When destinations are used and a space opens in the buffer, the transmission will be received.
15-91	Send Registration Error	Could not receive the file for transfer to the final destination: <ul style="list-style-type: none"> • The format of the final destination or the transfer destination is incorrect. • Destinations are full so the final and transfer destinations could not be created. 	<ul style="list-style-type: none"> • As the send to check both the transfer destination and the final destination. • When destinations open, the transmission will be received.
15-92	Memory Overflow	Transmission could not be received because memory overflowed during the transaction.	<ul style="list-style-type: none"> • Expand SAF memory. • Ask the sender to break up the file and send the parts separately.
15-93	Memory Access Error	Transaction could not complete due to a malfunction of SAF memory.	Initialize memory. If the problem persists, replace the MBU.
15-94	Incorrect ID Code	The machine rejected an incoming e-mail for transfer request, because the ID code in the incoming e-mail did not match the ID code registered in the machine.	<ul style="list-style-type: none"> • Ask the sender to correct the ID code. • Set IFAX SW03 Bit 3 to "1".
15-95	Transfer Station Function	The machine rejected an incoming e-mail for transfer because the transfer function was unavailable.	Inform the transfer requester that this machine does not support the transfer station function.

Internet Fax
(IFAX)

2.2 TROUBLESHOOTING PROCEDURES

Use the following procedures to determine whether the machine or another part of the network is causing the problem.

Communication Route	Item	Action	Remarks
General LAN	1. Connection with the LAN	<ul style="list-style-type: none"> • Check that the LAN cable is connected to the machine. • Check that the LEDs on the hub are lit. 	
	2. LAN activity	<ul style="list-style-type: none"> • Check that other devices connected to the LAN can communicate through the LAN. 	
Between IFAX and PC	1. Network settings on the PC	<ul style="list-style-type: none"> • Check the network settings on the PC. 	<ul style="list-style-type: none"> • Is the IP address registered in the TCP/IP properties in the network setup correct? Check the IP address with the administrator of the network.
	2. Check that PC can connect with the machine	<ul style="list-style-type: none"> • Use the "ping" command on the PC to contact the machine. 	<ul style="list-style-type: none"> • At the MS-DOS prompt, type ping then the IP address of the machine, then press Enter.
	3. LAN settings in the machine	<ul style="list-style-type: none"> • Check the LAN parameters • Check if there is an IP address conflict with other PCs. 	<ul style="list-style-type: none"> • Use the "Network" function in the User Tools. • If there is an IP address conflict, inform the administrator.
Between machine and e-mail server	1. LAN settings in the machine	<ul style="list-style-type: none"> • Check the LAN parameters • Check if there is an IP address conflict with other PCs. 	<ul style="list-style-type: none"> • Use the "Network" function in the User Tools. • If there is an IP address conflict, inform the administrator.
	2. E-mail account on the server	<ul style="list-style-type: none"> • Make sure that the machine can log into the e-mail server. • Check that the account and password stored in the server are the same as in the machine. 	<ul style="list-style-type: none"> • Ask the administrator to check.
Between machine and e-mail server	3. E-mail server	<ul style="list-style-type: none"> • Make sure that the client devices which have an account in the server can send/receive e-mail. 	<ul style="list-style-type: none"> • Ask the administrator to check. • Send a test e-mail with the machine's own number as the destination. The machine receives the returned e-mail if the communication is performed successfully.
Between e-mail server and internet	1. E-mail account on the Server	<ul style="list-style-type: none"> • Make sure that the PC can log into the e-mail server. • Check that the account and password stored in the server are the same as in the machine. 	<ul style="list-style-type: none"> • Ask the administrator to check.



TROUBLESHOOTING PROCEDURES

Communication Route	Item	Action	Remarks
	2. E-mail server	<ul style="list-style-type: none"> • Make sure that the client devices which have an account in the server can send/receive e-mail. 	<ul style="list-style-type: none"> • Ask the administrator to check. • Send a test e-mail with the machine's own number as the destination. The machine receives the returned e-mail if the communication is performed successfully.
	3. Destination e-mail address	<p>Make sure that the e-mail address is actually used. Check that the e-mail address contains no incorrect characters such as spaces.</p>	
	4. Router settings	<p>Use the "ping" command to contact the router. Check that other devices connected to the router can send data over the router.</p>	<ul style="list-style-type: none"> • Ask the administrator of the server to check.
Between e-mail server and internet	1. Error message by e-mail from the network of the destination.	<ul style="list-style-type: none"> • Check whether e-mail can be sent to another address on the same network, using the application e-mail software. • Check the error e-mail message. 	<ul style="list-style-type: none"> • Inform the administrator of the LAN.

Internet Fax (IFAX)

3. SERVICE TABLES AND PROCEDURES

3.1 ACCESSING IFAX BIT SWITCHES

1. Ensure that the machine is in standby mode.
2. Press , enter ① ① ⑦ with the 10-key pad, then hold down  for more than 3 seconds. The SP mode main menu opens.
3. Touch “Fax SPs” on the touch-panel to enter the fax service mode.
4. Use SP1102 1~16 to set the bit switches for IFAX. For details, refer to the Service Tables on the following pages.

 WARNING

Never adjust a bit switched marked “DFU” or “Japan Only,” as this may cause the machine to malfunction or to operate in a manner that is not accepted by local regulations. Such bits are for use only in other areas, such as Japan.

NOTE: Default settings for bit switches are not listed in this manual. Refer to the System Parameter List print out.

3.2 SP1102 IFAX SWITCH

Only one SP number is used to access IFAX bit switches. These bit switches are described in the tables below.

SP	IFAX SW														
1102 1	00														
	<p>Bits 0~6: Original Width of TX Attachment File</p> <p>This setting sets the maximum size of the original that the destination can receive. (Bits 3~7 are reserved for future use or not used.)</p> <p>0: On 1: Off</p> <p>Note: If more than one of these three bits is set to "1", the larger size has priority. For example, if both Bit 2 and Bit 1 are set to "1" then the maximum size is "A3" (Bit 2).</p> <table border="1"> <thead> <tr> <th>Bit 6</th> <th>Bit 5</th> <th>Bit 4</th> <th>Bit 3</th> <th>Bit 2</th> <th>Bit 1</th> <th>Bit 0</th> </tr> </thead> <tbody> <tr> <td>Reserved</td> <td>Reserved</td> <td>Reserved</td> <td>Reserved</td> <td>A3</td> <td>B4</td> <td>A4</td> </tr> </tbody> </table> <p>When mail is sent, there is no negotiation with the receiving machine at the destination, so the sending machine cannot make a selection for the receiving capabilities (original width setting) of the receiving machine. The original width selected with this switch is used as the RX machine's original width setting, and the original is reduced to this size before sending. The default is A4.</p> <p><i>If the width selected with this switch is higher than the receiving machine can accept, the machine detects this and this causes an error.</i></p>	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Reserved	Reserved	Reserved	Reserved	A3	B4	A4
Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0									
Reserved	Reserved	Reserved	Reserved	A3	B4	A4									
	Bit 7: Not Used.														

SP	IFAX SW					
1102 2	01					
Bits 0~ 6: Original Line Resolution of TX Attachment File						
<p>This setting sets the maximum resolution of the original that the destination can receive.</p> <p>0: Not selected 1: Selected</p> <p>Note: If more than one of these three bits is set to “1”, the higher resolution has priority. For example, if both Bit 3 and Bit 2 are set to “1” then the resolution is set for “300 x 300” (Bit 3).</p>						
Bit 6		Bit 5		Bit 4		Bit 3
Reserved		Reserved		400 x 400 Super Fine		Reserved
				200x400 Fine		200x200 Detail
						200x100 Standard
<p>When mail is sent, there is no negotiation with the receiving machine at the destination, so the sending machine cannot make a selection for the receiving capabilities (resolution setting) of the receiving machine.</p> <p>The resolution selected with this switch is used as the RX machine’s resolution setting, and the original resolution is converted before sending.</p> <p>The default is both 200 x 100 and 200 x 200 are selected.</p> <p>If the resolution set with this switch is higher than the receiving fax can accept, the machine detects this and this causes an error.</p>						
Bit 7: mm/inch						
<p>This setting selects mm/inch conversion for mail transmission.</p> <p>0: Off (No conversion) 1: On (Conversion)</p> <p>When on (set to “1”), the machine converts millimeters to inches for sending mail. There is no switch for converting inches to millimeters.</p> <p>Note: Unlike G3 fax transmissions which can negotiate between sender and receiver to determine the setting, mail cannot negotiate between terminals; the mm/inch selection is determined by the sender fax.</p> <p>Only two choices are available for transmission: inch statements and inch images, or inch statements and mm images.</p> <p>When this switch is Off (0):</p> <ul style="list-style-type: none"> • Images scanned in inches are sent in inches. • Images scanned in mm are sent in mm. • Images received in inches are transmitted in inches. • Images received in mm are transmitted in mm. <p>When this switch is On (1):</p> <ul style="list-style-type: none"> • Images scanned in inches are sent in inches. • <i>Images scanned in mm are converted to inches.</i> • <i>Images received in inches are transmitted in inches.</i> • <i>Images received in mm are converted to inches.</i> 						



SP	IFAX SW
1102 3	02
Bit 0: RX Text Mail Header Processing	
<p>This setting determines whether the header information is printed with text e-mails when they are received.</p> <p>0: Prints only text mail.</p> <p>1: Prints mail header information attached to text mail.</p> <ul style="list-style-type: none"> • When a text mail is received with this switch On (1), the “From” address and “Subject” address are printed as header information. • When a mail with only binary data is received (a TIFF-F file, for example), this setting is ignored and no header is printed. 	
Bit 1: Output from Attached Document at E-mail TX Error	
<p>This setting determines whether only the first page or all pages of an e-mail attachment are printed at the sending station when a transmission error occurs. This allows the customer to see which documents have not reached their intended destinations if sent to the wrong e-mail addresses, for example.</p> <p>0: Prints 1st page only.</p> <p>1: Prints all pages.</p>	
Bits 2~3: Text String for Return Receipt	
<p>This setting determines the text string output for the Return Receipt that confirms the transmission was received normally at the destination.</p> <p>00: “Dispatched” Sends from PC mail a request for a Return Receipt. Receives the Return Receipt with “dispatched” in the 2nd part: Disposition: Automatic-action/MDN-send automatically; <u>dispatched</u> The “dispatched” string is included in the Subject string.</p> <p>01: “Displayed” Sends from PC mail a request for a Return Receipt. Receives the Return Receipt with “displayed” in the 2nd part: Disposition: Automatic-action/MDN-send automatically; <u>displayed</u> The “displayed” string is included in the Subject string.</p> <p>10: Reserved</p> <p>11: Reserved</p> <p>Note: A mail requesting a Return Receipt sent from an IFAX with this switch set to “00” (for “dispatched”) received by Microsoft Outlook 2000 may cause an error. If any setting other than “displayed” (01) causes a problem, change the setting to “01” to enable normal sending of the Return Receipt.</p>	
Bits 4~6: Not Used.	
Bit 7: Image Resolution of RX Text Mail	
<p>This setting determines the image resolution of the received mail.</p> <p>0: 200 x 200</p> <p>1: 400 x 400</p> <p>Note: The “1” setting requires installation of the Function Upgrade Card in order to have enough SAF (Store and Forward) memory to receive images at 400 x 400 resolution.</p>	

SP	IFAX SW
1102 4	03
	<p>Bit 0: Original Output at Transfer Station</p> <p>This setting determines whether the original is output at the transfer station when it is received from the sender that initiated the transfer transmission. This feature is the same as for G3 transfer transmissions.</p> <p>0: Received original not output at the transfer station. 1: Received original output. The original is printed after the transfer station has transferred it to the destinations, so its output confirms that the original has been transferred.</p>
	<p>Bit 1: Transfer Result Report</p> <p>This setting determines when a Transfer Result Report is generated and returned to the transfer requestor.</p> <p>0: Returns the report after each transfer. 1: Returns the report only if an error occurred during transfer.</p>
	<p>Bit 2: Destination Error Handling for Reception Transfer Request</p> <p>This setting restricts transfer transmission based on whether the final destinations are correct or not.</p> <p>0: The transfer station transmits to correct destinations only (addresses with no errors in them). 1: If any address has an error in it, the transfer station transfers no transmissions and returns a transfer transmission failure report to the requestor that initiated the transfer.</p> <p>There is no negotiation between the transfer initiator and the transfer station to determine whether the final destination addresses are correct or not. This setting determines whether or not the transfer station transfers the transmissions if there is a mistake in even one of the final destination addresses.</p>
	<p>Bit 3: Polling ID Check for Reception of Transfer Request</p> <p>This setting determines whether the polling IDs of incoming transmissions are checked to ensure that the polling IDs match.</p> <p>0: Receives and transfers only messages that have matching polling IDs. 1: Receives and transfers all messages, even if the polling IDs do not match.</p>
	<p>Bits 4~7: Not Used</p>



SP	IFAX SW
1102 5	04
	<p>Bit 0: Subject for Delivery TX/Memory Transfer</p> <p>This setting determines whether the RTI/CSI registered on this machine or the RTI/CSI of the originator is used in the subject lines of transferred documents.</p> <p>0: Puts the RTI/CSI of the originator in the Subject line. If this is used, either the RTI or CSI is used. Only one of these can be received for use in the subject line. 1: Puts the RTI/CSI registered on this machine in the Subject line.</p> <p>When this switch is used to transfer and deliver mail to a PC, the information in the Subject line that indicates where the transmission originated can be used to determine automatically the destination folder for each e-mail.</p>
	<p>Bits 1~7: Not Used</p>

SP1102 IFAX SWITCH

SP	IFAX SW
1102 6	05
	Bit 0: Mail Addresses of SMTP Broadcast Recipients
	Determines whether the e-mail addresses of the destinations that receive transmissions broadcasted using SMTP protocol are recorded in the Journal. For example: '1st destination + Total number of destinations: 9' in the Journal indicates a broadcast to 9 destinations. 0: Not recorded 1: Recorded
	Bits 1~7: Not Used

SP	IFAX SW
1102 7	06
	Not Used

SP	IFAX SW
1102 8	07
	Not Used

SP	IFAX SW
1102 9	08
	Bits 0~7: Memory Threshold for POP Mail Reception
	This setting determines the amount of SAF (Store and Forward) memory. (SAF stores fax messages to send later for transmission to more than one location, and also holds incoming messages if they cannot be printed.) When the amount of SAF memory available falls below this setting, mail can no longer be received; received mail is then stored on the mail server. 00-FF (0 to 1024 KB: HEX) Note: The hexadecimal number you enter is multiplied by 4 KB to determine the amount of memory.

SP	IFAX SW
1102 10	09
	Bits 0~3: Not Used
	Bits 4~7: Restrict TX Retries
	This setting determines the number of retries when connection and transmission fails due to errors. 01-F (1-15 Hex)

SP	IFAX SW
1102 11	0A
	Not Used.

SP	IFAX SW
1102 12	0B
	Not Used.

SP	IFAX SW
1102 13	0C
	Not Used.

SP	IFAX SW
1102 14	0D
	Not Used

SP	IFAX SW
1102 15	0E
	Not Used

SP	IFAX SW
1102 16	0F
	Bit 0: Delivery Method for SMTP RX Files
	This setting determines whether files received with SMTP protocol are delivered or output immediately.
	0: Off. Files received via SMTP are output immediately without delivery.
	1: On. Files received via SMTP are delivered immediately to their destinations.
	Bits 1~7: Not Used

Internet Fax
(IFAX)

3.3 FIRMWARE UPDATE PROCEDURE

When you need to update the firmware for IFAX, follow the firmware update procedures described in the main machine Service Manual.

3.4 IFAX RAM ADDRESSES

Parameter	Function	Data Format	Address	Comments
Mail Address	Mail address of the fax account.	ASC: 128 bytes	69FEAE	128 x 3 area provided, but only the first is used.
User Name	User name of the fax account.	ASC: 64 bytes	6A002E	64 x 3 area provided, but only the first is used.
Password	Password of the fax account.	ASC: 64 bytes	6A00EE	64 x 3 area provided, but only the first is used.
RX Mail Capacity	---	4 Bytes	6A01AE	64-1024 Kbytes
SMTP RX Permission Address	Address or partial address that is used to limit access to mail delivery (see pg. 4-11, "Auth E-Mail Rx").	ASC: 128 bytes	6A01B2	
Doc. Svr. RX Notification No	Number of RX Notification Mails that have been sent in order to notify receipt of a fax message on the document server.	2 bytes	6A0232	

Internet Fax
(IFAX)

4. DETAILED SECTION DESCRIPTIONS

4.1 INTERNET FAX

4.1.1 INTERNET FAX FEATURES

The Internet fax produced by Ricoh is also known as IFAX.

An Internet fax converts fax hard copy document data to e-mail format and transmits the data over the Internet. Another IFAX or a PC can receive the e-mail sent by an IFAX. Rather than inputting the telephone number of the destination, the user inputs the applicable e-mail address.

Documents are sent as e-mail messages with an attached TIFF-F image (the scanned original), so a MIME-compatible e-mail reader is required in order to view documents received on a PC. To view an attached image, software capable of displaying TIFF-F formatted images is required.

NOTE: The IFAX must be connected to a LAN and set up correctly in order to use its Internet fax functions.

The main IFAX features are:

- TCP/IP communication protocols that support connection to a LAN with e-mail.
- Easy-to-master operations that are identical to those of a standard fax machine.
- Fax transmission and reception over a telephone line.
- Using a browser (such as Netscape or Internet Explorer) to check the settings and status of an IFAX from a PC This uses the Web Status Monitor application built into the machine.
- Transferring or mailing received faxes directly to a PC.
- Using the Internet to reduce communication costs.
- Reducing paper expenses by eliminating the use of paper for fax transmission and reception.
- The IFAX communicates with a server over a LAN (it does not communicate directly with another party).
- If an error occurs, a mail error report is sent back to the sender.

Some minor restrictions of IFAX are:

- If an Internet related error occurs, the sender might not receive an error report.
- The level of security for Internet communications is low. The use of standard subscriber lines is recommended for confidential communication.
- Voice communications are not supported over a LAN.
- Internet fax delivery might be delayed due to network congestion. Use standard fax communication whenever time is a crucial factor.

INTERNET FAX

The following functions are supported with standard fax transmission, but not with Internet faxing.

These functions are not supported by e-mail transmission:

- Immediate Transmission
- Confidential Transmission
- ID Transmission
- Polling Transmission
- Chain Dial
- Transmission by F-Code (SUB) - e-mail protocol cannot specify an F-Code
- On Hook Dial
- Manual Dial
- JBIG Transmission
- Batch Transmission
- ECM (Error Correction Mode)

These functions are not supported by e-mail reception:

- Confidential Reception
- Memory Lock Reception
- Polling Reception
- F-Code (SUB) Reception using Personal Box (e-mail protocol cannot specify an F-Code)
- Preventing nuisance faxes by destination
- Setting Reception Print by Destination

4.1.2 DNS SERVICE


IFAX supports DNS (Domain Name System). See the Core Technology Manual for more details (Facsimile Processes – Faxing From a PC – Internet/LAN Fax Boards – E-mail Basics).

The IFAX can use the Domain Names for the SMTP and POP3/IMAP4 server instead of the actual IP addresses, if there is a DNS server on the same LAN as the SMTP server, POP3/IMAP4 server, and the IFAX.

With models that do not support DNS, the user has to input the actual IP addresses of the SMTP server and the POP3/IMAP4 server.

4.2 INTERNET MAIL COMMUNICATION

4.2.1 MAIL TRANSMISSION



Procedure

Scanned documents are sent as electronic mail (e-mail).

All messages are sent using memory transmission.

All e-mail transmissions are controlled using Simple Mail Transfer Protocol (SMTP) procedures. There must be an SMTP server on the same LAN as the sending machine, or the machine will not be able to send e-mail (it is not necessary to set up an SMTP account).

Data Formats

The scanned data is converted into a TIFF-F formatted file (only MH compression can be used).

The fields of the e-mail and their contents are as follows:

Field	Content
From	Mail address of the sender
Reply To	Destination requested for reply
To	Mail address of the destination
Bcc	Backup mail address
Subject	From CSI or RTI (Fax Message No. xxxx)
Content Type	Multipart/mixed Attached files: image/tiff
Content Transfer Encoding	Base 64, 7-bit, 8-bit, Quoted Printable
Message Body	MIME-converted TIFF-F (MIME standards specify how files are attached to e-mail messages)

Errors

An error report is generated if an error occurs during communication between the machine and the SMTP server. However, it is possible that the sender will not

INTERNET MAIL COMMUNICATION

receive reports of errors that occurred between the SMTP server and the receiving terminal.

The interval between attempts to resend mail to the same destination when an SMTP error occurs is the same as for G3 fax transmission.

To view what happens when an error occurs when the machine is receiving, refer to the Mail Reception section.

Results

The transmission result is listed in the Journal. The file list for e-mail transmissions is created in the same way as for G3 memory transmissions. The TTI for the mail message includes the word "Mail" at the head of the information in the TTI column.

Selectable Options

These options are available for selection:

- With the default settings, the scan resolution can be either standard or detail. Inch-mm conversion before TX depends on IFAX SW01 Bit 7. Detail resolution will be used if Super Fine resolution is selected, unless Fine resolution is enabled with IFAX SW01.
- The requirements for originals (document size, scan width, and memory capacity) are the same as for G3 fax memory tx.
- The default compression is TIFF-F format.
- IFAX SW00: Acceptable paper widths for sending
- IFAX SW09: Maximum number of attempts to the same destination

Secure Internet Transmission

To transmit e-mail via the Internet more securely, use SMTP authentication, and POP before SMTP for IFAX.

- **SMTP Authentication.** SMTP Authentication requires user authentication before they can access the server. This prevents unauthorized access to the server. To use SMTP authentication, your server must support CRAM-MD5, PLAIN, or LOGIN. The account name and password specified in the “Mail Server” settings are used for SMTP authentication. Other account names and passwords cannot be specified.

To set up SMTP Authentication:


User Tools> System Settings> File Transfer> SMTP Authentication

- **POP Before SMTP.** Prevents unauthorized access to the SMTP server and requires users to access and log onto the POP3 server before sending e-mail.

To set up POP Before SMTP:

User Tools> System Settings> File Transfer> POP Before SMTP

4.2.2 MAIL RECEPTION



This machine supports three types of e-mail reception:

- POP3 (Post Office Protocol Ver. 3.)
- IMAP4 (Internet Messaging Access Protocol)
- SMTP (Simple Mail Transfer Protocol)

POP3/IMAP4 Mail Reception Procedure

In order for the fax machine to receive e-mail, 1) there must be a POP3/IMAP4 server on the same LAN as the IFAX, and 2) an account must be set up for the fax machine.

The machine automatically picks up e-mail from the server at an interval which is adjustable in the range 2 to 1440 min. in 1-minute steps:

User Tools> System Settings> File Transfer> E-mail Reception Interval

When the arrival of new e-mail is detected, the IFAX receives the mail.

If the POP3/IMAP4 server is holding several e-mails for the IFAX, the machine picks up the e-mails one at a time, in the order of arrival at the server.

After POP3 has picked up the mail from a POP3 server, it deletes it from the server. IMAP4 also picks up the mail from a server, but it does not delete the mail from the server.

- However, the server setting is given higher priority than the machine setting.

E-mail reception conforms to POP3 (Post Office Protocol version 3.0) procedures or IMAP4 (Internet Message Access Protocol).

Characteristics of POP3/IMAP4 Reception

Here are some general characteristics of POP3/IMAP4 receiving:

- **No MX record registration.** There is no need to register the machine in the MX record of the DNS server.
- **Power can be switched off.** As long as the machine is not receiving mail, mail stored in the mail server is not lost when the power is switched off. With SMTP reception, if the machine is switched off, the SMTP server sends an error report back to the sender, and the machine will not receive the mail unless the sender sends it again after the machine is switched on.
- **Dial-up compliance.** POP3/IMAP4 can be accessed spontaneously, making it ideal for dial-up operation.

SMTP Reception

SMTP Mail Reception Procedure

By registering the IFAX as an SMTP server in the MX record of the DNS server, you can enable direct receiving of mail from the SMTP server.

When mail is sent to the mail address specified for the IFAX, it is received immediately without checking the server for the arrival of new mail (as is done in the POP/IMAP protocol). Also, with SMTP, the received mail can be routed to another fax (this is known as 'delivery').

Setting Method

The following settings are required for SMTP receiving:

- The IFAX must be registered as an SMTP server in the MX record of the DNS server, and the address of the received mail must specify the IFAX.
- Enable SMTP reception:

User Tools> System Settings> File Transfer> Reception Protocol

Even if the MX record on the DNS server includes the IFAX, mail cannot be received with SMTP until SMTP reception is enabled:

However, if SMTP reception is selected and the machine is not registered in the MX record of the DNS server, then either IMAP4 or POP3 is used, depending on the setting:

User Tools> System Settings> File Transfer> Reception Protocol

SMTP Reception Characteristics

- **Expanded RX mail delivery.** The Off Ramp Gateway feature allows expansion for RX mail delivery to a G3 fax. The machine transfers incoming mail is sent to the G3 fax specified by the local part. For example, in a destination address specified as:

`fax=0454778907@c101.dom1.ricoh.co.jp`

the 'local part' is **0454778907**.


- **A POP3/IMAP4 server is not required.** For example, in an environment where there is only a UNIX server or in an intranet environment where Notes is used for mail, mail received from outside is handled via the SMTP gateway.
- **Immediacy of response is slightly better.** There is no interval in the acquisition of mail as with POP3/IMAP4, thus slightly improving the response time.
- **Easier error handling.** When an error occurs with POP3/IMAP4, the receiving terminal sends an error mail back to the sender in order to inform them that an error has occurred. With SMTP mail reception, however, in almost all cases the SMTP server sends the error mail to the sender.

Delivery: Transferring Mail Received With SMTP (Off Ramp Gateway)

Overview

If the address of the mail received with SMTP contains the following information, it can be delivered to another G3 fax:

Fax = " Delivery Number"@IFAX Host Name.Domain"



IFAXD901.WMF

How to Set Up Mail Delivery

The sender must set the mail address in the following format:

- 1) When dialing using a fax number

fax=<Delivery Destination Fax Number>@<IFAX Host Name>.<Domain Name>

Example:

fax=0454771459@cl01.dom1g.ricoh.co.jp → Delivers to fax number 0454771459

- 2) When dialing using a Quick dial destination

fax=<# Quick Dial Number>@<IFAX Host Name>.<Domain Name>

Example:

fax=#001@cl01.dom1g.ricoh.co.jp → Delivers to the number registered for Quick Dial key 001.

- 3) When dialing using a Group destination

fax=<#Group Dial Number>@<IFAX Host Name>.<Domain Name>**

Example:

fax=#**05@cl01.dom1g.ricoh.co.jp → Delivers to numbers registered for Group dial key 05.

Mail Delivery Conditions

- 1) The machine must be set up for SMTP mail delivery:
User Tools> Facsimile Features> E-mail Settings> SMTP RX File Delivery Settings
- 2) If the user wishes to limit this feature so that the machine will only deliver mail from designated senders, the machine's "Auth. E-mail RX" feature must be selected (User Tools> Facsimile Features> E-mail Settings> SMTP RX File Delivery Settings).
- 3) If the "SMTP RX File Delivery Setting" is set to 0 to prohibit SMTP receiving, and if there is mail designated for delivery, then the machine responds with an error. (User Tools> Facsimile Features> E-mail Settings> SMTP RX File Delivery Settings)
- 4) The "fax=" setting does not distinguish between upper and lower case letters.
- 5) More than one destination cannot be specified in the mail address. A Group counts as 1 destination.
- 6) If the quick dial, speed dial, or group dial entry is incorrect, the mail transmission is lost, and the IFAX issues an error to the SMTP server and outputs an error report.

Auth. E-mail RX

In order to limit access to mail delivery with IFAX, the addresses of senders must be limited using the Access Limit Entry. Only one entry can be registered.

1) Access Limit Entry

For example, to limit access to @IFAX.ricoh.co.jp:

gts@IFAX.ricoh.co.jp	Matches and is delivered.
gts@IFAX.abcde.co.jp	Does not match and is not delivered.
IFAX@ricoh.co.jp	Does not match and is not delivered.

2) Conditions

- The length of the Access Limit Entry is limited to 127 characters.
- If the Access Limit Entry address and the mail address of the incoming mail do not match, the incoming mail is discarded and not delivered, and the SMTP server responds with an error. However, in this case an error report is not output.
- If the Access Limit Entry address is not registered, and if the incoming mail specifies a delivery destination, then the mail is delivered unconditionally.

Handling Mail Reception Errors***Errors during POP3/IMAP4 procedures***

When an error of this type occurs, the machine stops receiving and the message stays in the server. An error report is output. After a prescribed interval, the machine calls the server and starts to receive, starting with the interrupted message. If there is an incomplete received message in memory, it will be erased.

Abnormal files

When an error of this type occurs, the machine stops receiving and commands the server to erase the message. Then the machine prints an error report and sends information about the error by e-mail to the sender address (specified in the "From" or "Reply-to" field of the message). If there is an incomplete received message in the machine memory, it will be erased.

The machine prints an error message when it fails to send the receive error notification after a certain number of attempts.

The following types of files are judged to be abnormal if one or more of the following are detected:

1. Unsupported MIME headers.

Supported types of MIME header

Header	Supported Types
Content-Type	Multipart/mixed, text/plain, message/rfc822 Image/tiff
Charset	US-ASCII, ISO 8859 X. Other types cannot be handled, and some garbage may appear in the data.
Content-Transfer-Encoding	Base 64, 7-bit, 8-bit, Quoted Printable

2. MIME decoding errors
3. File format not recognized as TIFF-F format
4. Resolution, document size, or compression type cannot be accepted

Remaining SAF capacity error

The machine calls the server but does not receive e-mail if the remaining SAF capacity is less than a certain value (the value depends on IFAX Switch 08. The e-mail will be received when the SAF capacity increases (for example, after substitute reception files have been printed). The error handling method for this type of error is the same as for 'Abnormal files'.

If the capacity of the SAF memory drops to zero during reception, the machine operates in the same way as when receiving an abnormal file (refer to 'Abnormal files' above).

Printing Received Mail

To print received e-mail:

- The machine detects whether it has received a TIFF-F format image, then prints it.
- Text in US ASCII or ISO 8859 X format can also be printed. When a line of text is longer than the paper width, the excess data will be truncated and lost.

Multi-part Messages

When a multi-part e-mail message contains several text parts and binary files, the message will be divided by boundaries, and each portion will be printed separately. If the machine cannot determine where the boundary is, it will print an error report, and then send error information e-mail back to the sender.

Manual e-mail reception

The manual e-mail reception function can be stored in a Quick Operation Key. When the key is pressed, the machine calls the POP3/IMAP4 server immediately.

The timer for automatic e-mail reception is not reset when the machine calls the POP3/IMAP4 server manually.

Here is an example of the sequence

- Automatic e-mail reception interval: 30 minutes.
- The machine calls the POP3 server (automatic e-mail reception)
- 10 minutes later, the user calls the POP3 server (manual e-mail reception)
- The machine will call the POP3 server again automatically after 20 minutes.

Secure Internet Reception


APOP. Passwords are encrypted when e-mail is received, making it safer than POP3 authentication (clear text), which is not encrypted. APOP requires a POP server that supports APOP.

IMAP-AUTH (Mail Reception). If the IMAP Server supports the AUTHENTICATE command (CRAM-MD5, PLAIN, or LOGIN confirmation), then higher-level security confirmation can be implemented for users logging in.

To enable password encryption and higher level security:

User Tools> System Settings> File Transfer> POP3/IMAP4 Settings> Encryption (set to 'On')

4.2.3 MAIL BROADCASTING (E-MAIL AND G3 FAX ARE COMBINED)



IFAXD913.WMF

The machine can send the same message to several destinations in one operation. Some destinations can be G3 faxes and others can be e-mail. For the G3 fax transmissions, each address has to be dialed separately. However, all e-mail addresses can be sent with the message to the SMTP server in one transmission. The SMTP server then sends the message to each destination.

The following example for broadcasting to three e-mail destinations and two G3 fax destinations shows how G3 fax messages are each sent individually. However, the e-mail destinations are all sent to the server at the same time.

- Order of inputting the addresses at the operation panel
G3 fax (1) - mail (1) - G3 fax (2) - mail (2) - mail (3)
- Order of transmission
G3 fax (1) - mail (1), (2), (3) - G3 fax (2)


The SMTP server cannot broadcast the message if the message contents included individual information for each terminal in the transmitted data (such as a label insertion). If this type of feature is used, the machine sends the e-mails to the server one by one.

With the default settings, up to 500 destinations (including both e-mail and G3 fax) can be dialed for one broadcast. The maximum number of e-mail destinations in a broadcast depends on the limitations of the mail server.

4.2.4 TRANSFER REQUEST

Operation at the Transfer Requester

Request by Mail



IFAXD914.WMF

The requesting terminal dials the Transfer Station, and requests it to transfer the message to end receivers stored as quick dials, speed dials, and group dials in the Transfer Station.

- A quick dial number is indicated by a “#” and 1 to 5 digits.
- A group dial is indicated by “#**” and 1 to 5 digits.

The machine can request transfer to a maximum of 30 end receivers for each Transfer Station. The end receivers can be a mixture of e-mail and G3 fax addresses.

The transfer request goes to the SMTP server as an e-mail message. The dialing codes (Quick, Speed, Group) and the ID code are included in the mail body field of the e-mail as text. The message arrives at the POP3/IMAP4 server of the Transfer Station.

The Transfer Station sends the message to the end receivers.


The Transfer Station sends back a transfer result report. The original may be attached to the transfer result report, depending on the G3 settings of the fax machine. For transmissions to e-mail end receivers, the transfer result report only indicates whether the message was successfully transmitted from the Transfer Station to its SMTP server.

INTERNET MAIL COMMUNICATION

The fields of the e-mail and their contents are as follows:

Field	Content
From	E-mail address of the requesting terminal
To	Destination address (Transfer Station address)
Bcc	Backup mail address
Subject	From TSI (Fax Message No. xxxx)
Content-Type	Multipart/mixed Text/Plain (for a text part), image/tiff (for attached files)
Content-Transfer-Encoding	Base 64, 7-Bit, 8-bit, Quoted Printable
Mail body (text part)	RELAY-ID-: xxxx (xxxx: 4 digits for an ID code) RELAY: #01#*X#**01....
Message body	MIME-converted TIFF-F.

Request by G3 Fax



The procedures are the same as for a normal G3 fax machine.

The requesting terminal dials the Transfer Station, and requests it to transfer the message to end receivers stored as quick dials, speed dials, and group dials in the Transfer Station.


The machine uses NSF to send an ID code and the machine telephone number. Up to 30 end receivers can be requested.

End receiver destinations can also be selected using tone signals, in the same way as for other recent fax models. An e-mail address can also be selected in this way, as end receivers and as the destinations for receiving the transfer result report.

The receiving IFAX machine receives the transfer request on the PSTN connection. It then handles the transfer request in the same way as explained in "Request by Mail".

Operation at the Transfer Station

Request by Mail



IFAXD605.WMF

The IFAX polls the POP3/IMAP4 server at regular intervals. If a transfer request has come in, it receives the e-mail from the server, then sends the message to the end receivers by G3 fax or e-mail, depending on the type of end receiver address.

The IFAX sends each G3 fax as an individual transmission. However, for the e-mail, the IFAX sends the message to the SMTP server once, and the server broadcasts the message to the e-mail end receivers one at a time.


The Transfer Station sends back a transfer result report to the address in the "From" field of the received e-mail. If an administrator address is registered, the result report is also sent to that address. The original may also be attached to the transfer result report, depending on the G3 settings of the fax machine.

For transmission to e-mail end receivers, the transfer result report only indicates whether the message was successfully transmitted from the Transfer Station to its SMTP server. The Transfer Station does not know what happens to the messages on the way to the end receivers.

If a communication error occurs between the machine and the SMTP server during result report transmission, the machine prints the result report.

INTERNET MAIL COMMUNICATION

Request by Fax




IFAXD916.WMF

When the machine receives a transfer request by G3 fax, it sends the message to the e-mail and G3 end receivers in the same way as for a request by mail.

The machine sends back the transfer result report to the telephone number of the requesting terminal, which it specified in the NSF signal. The machine prints the result report if it cannot be sent.

The IFAX can accept end receiver destinations and transfer result report destinations that were sent from the requester as DTMF tones. This applies to e-mail or PSTN G3 addresses.

4.2.5 AUTOROUTING



When a G3 fax message is received with a SUB code (max. 20 digits), the machine compares this SUB code with the Personal Box SUB codes stored in the machine with e-mail addresses. If there is a match, the machine routes the message to that e-mail address by e-mail.

There can be only one destination. If there is no destination attached to the SUB code of the personal box, the incoming message is kept in the fax machine's SAF memory.

A communication failure report will be printed if a transmission error occurs between the machine and the SMTP server.

The RTI or CSI of the forwarding machine is indicated in the subject field of the forwarded e-mail. The format is "From RTI (or CSI) (Fax Message No.xxxx)".

4.2.6 TRANSFER BOX

When a G3 fax message is received with a SUB code, the machine compares this SUB code with the Transfer Box SUB codes stored in the machine with e-mail addresses. If there is a match, the machine uses e-mail to transfer the message to the e-mail addresses specified in the Transfer Box.

Up to 5 destinations, including both e-mail and G3 fax addresses, can be stored in one Transfer Box. There must be at least one destination.

4.3 E-MAIL OPTIONS (SUB TX MODE)

The following features are available as options for mail sending: entering a subject, designating the level of importance, confirming reception of the mail.

4.3.1 SUBJECT AND LEVEL OF IMPORTANCE

You can enter a subject message with: Sub TX Mode> E-mail Options

The Subject entry for the mail being sent is limited to 64 characters. The subject can also be prefixed with an “Urgent” or “High” notation.

How the Subject Differs According to Mail Type

Mail Type	①	②		③
Subject Entry	---	Entry Condition		Fax Message No. + File No.
No Subject Entry		1. “CSI” (“RTI”)		
		2. “RTI”	CSI not registered	
		3. “CSI”	RTI not registered	
		4. None	CSI, RTI not registered	
Confirmation of Reception	From	1. “CSI” (“RTI”)		Normal: Return Receipt (dispatched). You can select ‘displayed’ with IFAX SW02 Bits 2 and 3.
		2. “RTI”	CSI not registered	
		3. “CSI”	RTI not registered	Error: Return Receipt (processed/error)
		4. None	CSI, RTI not registered	
Mail delivery, memory transfer, SMTP receiving and delivery	From	RTI or CSI of the station designated for delivery	Mail delivery	Fax Message No. + File Number
		RTI or CSI of sender	Mail sending from G3 memory	
		Mail address of sender	Memory sending	
		Mail address of sender	SMTP receiving and delivery (Off Ramp Gateway)	
Mail error notification	---	Error Message No. xxxx From CSI (RTI)		

Items ① ② ③ of the table above are in the Subject.

Subjects Displayed on the PC

Sender	Date	Size	Subject
Substation 2	04/25/2002	1,513	Parts List
Substation 2	04/26/2002	1,147	Specifications
Main Station	05/09/2002	33,551	[Urgent] Memo 2041
		21,624,288	

IFAXD919.WMF

4.3.2 E-MAIL MESSAGES

After entering the subject, you can enter a message with:

Sub TX Mode> E-mail Options

An e-mail message (up to 5 lines) can be pre-registered with:

User Tools> System Settings> File Transfer> Program/Change/Delete E-mail Message

Limitations on Entries

Item	Maximum
Number of Lines	5 lines
Line Length	80 characters
Name Length	20 characters


4.3.3 MESSAGE DISPOSITION NOTIFICATION (MDN)

The network system administrator can confirm whether a sent mail has been received correctly or not. This confirmation is done in four steps.

1. Send request for confirmation of mail reception. To enable or disable this request (known as MDN):
Sub TX Mode> E-mail Options
2. Mail reception (receive confirmation request)
3. Send confirmation of mail reception
4. Receive confirmation of mail reception


The other party's machine will not respond to the request unless the two conditions below are met:

- The other party's machine must be set up to respond to the confirmation request.
- The other party's machine must support MDN (Message Disposition Notification).



① *** JOURNAL ***

Time	ADDRESS	Mode	Time	PAGE	RESULT
10:17AM	s_tadasi@abcde.ne.jp	MailSMQ	0'09"	2	--



③ *** JOURNAL ***

Time	ADDRESS	Mode	Time	PAGE	RESULT
10:18AM	SF2@dom1g.ricoh	MailSMA	0'09"	2	--

④ *** JOURNAL ***

Time	ADDRESS	Mode	Time	PAGE	RESULT
10:17AM	s_tadasi@abcde.ne.jp	MailSMQ	0'09"	2	OK

IFAXD920.WMF

Handling Mail

Handling Mail on the Send Side

When mail is sent, a "Disposition Notification To" notation is included in the header as a request for confirmation that the mail was received.

```

X-Mozilla Status      : 0001
X-Mozilla Status2    : 00000000
Message-ID           : <3A23379A.81BE0ABD@domlg.ricoh.co.jp>
Disposition-Notification-To : T.Suzuki <s_tadashi@domlg.ricoh.co.jp>
Date                 : Tue, 28 Nov 2000 13:4203 +0900
From                 : T.Suzuki <s_tadashi@domlg.ricoh.co.jp>
X-Mailer             : Mozilla 4.73 [ja]C-CCK-MCD BDP jm-Sony 3
                      (Win95: U)
X-Accept-Language   : ja
MIME-Version         : 1.0
To                   : fuser_01@domlg.ricoh.co.jp
Subject              : Mail Request for Reception Confirmation
Content-Type         : text/plain: charset=iso-2022-jp
Content-Transfer-Encoding : 7bit

```

Handling Mail on the Receive Side

```

Return Path: <>
Received      : From fuser_01 ([133.139.157.20]) by domlg.ricoh.co.jp (post
                office MTA V1.9.3 ID# 0100110-37392) with SMTP id AAA163
                for<S_tadasi@domlg.ricoh.co.jp>
Date          : 28 Nov 2000 13:4236 +0900
X-Mailer      : ICFAX Version 1.0
MIME-Version  : 1.0
Content-Type  : multipart/report: report-type=disposition-notification:
                boundary="--ICFAX_000000EF48--"
To            : T.Suzuki <s_tadashi@domlg.ricoh.co.jp>
Message-ID    : <20001128133423664.ICFAX-XFC9BE-X26986@133.139.157.20>
From          : fuser_01@domlg.ricoh.co.jp
Subject       : From @81454771459" ("RICOH GTS) (Return Receipt) (dispatched)
X-Mozilla-status : 8001
X-Mozilla-Status2 : 00000000
X-UIDL       : 20001128044713447.AAA163@fuser_01

This is a Return Receipt for the mail that you sent to "fuser_01@domlg.ricoh.co.jp"
Final Receipt: rfc822:fuser_01#domlg.ricoh.co.jp
Original Message ID: <3A23379A.81BE0ABD@domlg.ricoh.co.jp>
Disposition: automatic action/MDN-send-automatically: dispatched      Respond Mail Text

```

Internet Fax
(IFAX)

Setting up the Receiving Party

The receiving party will respond to the confirmation request if:

- 1) The 'Disposition Notification To' field is in the received mail header (automatically inserted in the 4th line in the upper table on the previous page, if MDN is enabled), and
- 2) Sending the disposition notification must be enabled (User Parameter Setting SW21 (15 [H]) Bit 1 for this model). The content of the response is as follows:

Normal reception:	"Return Receipt (dispatched)" in the Subject line
IFAX SW02 (Bit 2, 3)	"Return Receipt (displayed)" in the Subject line
Error:	"Return Receipt (processed/error)" in the Subject line

Handling Reports

1. Sending a Request for a Return Receipt by Mail

After the mail sender transmits a request for a return receipt, the mail sender's journal is annotated with two hyphens (--) in the Result column and a "Q" in the Mode column.

2. Mail Receipt (Request for Receipt Confirmation) and Sending Mail Receipt Response

After the mail receiver sends a response to the request for a return receipt, the mail receiver's journal is annotated with two hyphens (--) in the Result column and an "A" in the Mode column.

3. Receiving the Return Receipt Mail

- After the mail sender receives a return receipt, the information in the mail sender's journal about the receipt request is replaced, i.e. the journal is annotated with "OK" in the Result column.
- When the return receipt reports an error, the journal is annotated with an "E" in the Result column.
- The arrival of the return receipt is not recorded in the journal as a separate communication. Its arrival is only reported by the presence of "OK" or "E" in the Result column.
- If the mail address used by the sender specifies a mailing list (i.e., a Group destination; the machine sends the mail to more than one location. See "How to set up Mail Delivery"), the Result column of the Journal is updated every time a return receipt is received. For example, if the mailing list was to 5 destinations, the Result column indicates the result of the communication with the 5th destination only. The results of the communications to the first 4 destinations are not shown.

Exceptions:

If one of the communications had an error, the Result column will indicate E, even if subsequent communications were OK.

If two of the communications had an error, the Journal will indicate the destination for the first error only.

E-MAIL OPTIONS (SUB TX MODE)

Report Sample

DATE	TIME	ADDRESS	MODE	TIME	PAGE	RESULT
MAY. 5	10:15	fuser_01@dom1g. ricoh. co.	Mail SM	0'09"	2	--
	10:16	fuser_01@dom1g. ricoh. co.	Mail SMQ	0'05"	1	--
	10:17	s_tadashi@dom1g. ricoh. co.	Mail SMQ	0'09"	2	OK
	10:19	m_masataka@dom1g. ricoh. co.	Mail SMA	0'05"	1	--

IFAXD921.WMF

Internet Fax
(IFAX)

SPECIFICATIONS

1. IFAX SPECIFICATIONS

Type

Fax Unit and Printer/Scanner Unit

Connectivity

Local area network
Ethernet 100base-Tx/10base-T

Connection

100base-Tx/10base-T direct
connection

Resolution

Main scan: 200 dpi
Sub scan: 400 dpi, 200 dpi, 100 dpi

NOTE: To use 400 dpi, IFAX SW01 Bit
4 must be set to "1".

Transmission Time

1 s (through a LAN to the server)
Condition: ITU-T #1 test document
(Selerexe Letter)
MTF correction: OFF
TTI: None
Resolution: 200 x 100 dpi
Communication speed: 10 Mbps
Correspondent device: E-mail server
Line conditions: No terminal access

Document Size

Maximum message width is A4/LT.
Note: To use B4 and A3 width, IFAX
SW00 Bit 1 (B4) and/or Bit 2 (A3)
must be set to "1".

E-mail File Format

Single/multi-part
MIME conversion
Image: TIFF-F (MH) format only

Protocol

(Supported by TCP/IP protocol)

Transmission:

IETF RFC821 SMTP procedure

Reception:

IETF RFC1725 POP3 procedure
IETF RFC2026 IMAP4 procedure

Data rate

100 Mbps(100base-Tx)
10 Mbps (10base-T)

Remark

The machine must be set up as an e-
mail client before installation. Any
client PCs connected to the machine
through a LAN must also be e-mail
clients, or some features will not work
(e.g. Autorouting).

**PRINTER/SCANNER
B577
SERVICE MANUAL**

Trademarks

Microsoft[®], Windows[®], and MS-DOS[®] are registered trademarks of Microsoft Corporation in the United States and /or other countries.

PostScript[®] is a registered trademark of Adobe Systems, Incorporated.

PCL[®] is a registered trademark of Hewlett-Packard Company.

Ethernet[®] is a registered trademark of Xerox Corporation.

Other product names used herein are for identification purposes only and may be trademarks of their respective companies. We disclaim any and all rights involved with those marks.

1. INSTALLATION

1.1 INSTALLATION REQUIREMENTS

Please refer to section 3 of the main unit service manual.

1.2 PRINTER/SCANNER INSTALLATION

Accessories

Check the accessories and their quantities against the following list:

Description	Q'ty
1. HDD.....	1
2. NIB.....	1
3. Keytop - Copy.....	1
4. Keytop – Document Server.....	1
5. Keytop - Printer.....	1
6. Keytop – Scanner.....	1
7. CD-ROM: Printer.....	1
8. CD-ROM: Scanner.....	1
9. CD-ROM: Operation Manual.....	1
10. Operating Instructions.....	1
11. FCC Label (USA only).....	1



2. TROUBLESHOOTING

2.1 CONTROLLER ERRORS

Refer to section 7.1 of the main unit service manual for descriptions on SC code information because the RA2K architecture includes controller SC codes in the main unit SC code table.

3. SERVICE TABLES

3.1 PRINTER SERVICE MODE

Service Table Key

Notation:	What it means
[range / default / step]:	Example: [-9 ~ +9 / +3.0 / 0.1 mm step]. The setting can be adjusted in the range ± 9 , value reset to +3.0 after an NVRAM reset, and the value can be changed in 0.1 mm steps with each key press.
Italics:	Comments added for your reference.
*:	This value is stored in NVRAM. After a RAM reset, the default value (factory setting) is restored.
DFU:	Denotes "Design or Factory Use". Do not change this value.

3.1.2 PRINTER SERVICE MODE TABLES

⇒	1001	Bit Switch Settings	
		Adjusts bit switch settings. Note: Currently the bit switches are not being used except for Bit Switch 2 bit 3 (See PUB(C)-051 for details).	
	1003	Clear Setting	
		1	Initialized Printer System
		2	Delete Program DFU
	1004	Print Summary	
		Prints the service summary sheet (An error log is printed in addition to the configuration page).	
	1005	Display Version	
		Displays the version of the controller firmware.	
	1006	Sample/Locked Print	Not Available

Printer/
Scanner
B577

3.1.3 SP MODES RELATED TO THE PRINTER CONTROLLER

The following SP modes are located in the copier SP mode. Refer to section 5.1 of the main unit service manual.

5104	<p>A3/DLT Double Count</p> <p>Specifies whether the counter is doubled for A3/DLT. 0: No, 1: Yes If ① is selected, the total counter and the current user code counter count up twice when A3 or DLT paper is used.</p>
5801	<p>Memory All Clear</p> <p>Resets data for process control and all software counters, and returns all modes and adjustments to their defaults values. ➤ Section 5.1.8 of the main unit manual for details.</p>
5907	<p>Plug & Play</p> <p>Selects the brand name and the production name for Windows Plug & Play. This information is stored in NVRAM.</p>
7832	<p>Detailed Display of Self-Diagnostics</p> <p>Displays the controller self-diagnostic result. ➤ Section 3.6 of this manual for details.</p>

3.2 SCANNER SERVICE MODE

3.2.1 SCANNER PROGRAM MODE TABLE

1004*	Compression Type	Selects the compression type for binary picture processing. [1: MH , 2: MR, 3: MMR]
-------	------------------	---

1005*	Erase Margin	Creates an erase margin for all edges of the scanned image. <i>If the machine has scanned the edge of the original, create a margin.</i> [0 – 5 / 0mm / 1mm step]
-------	--------------	--

1007	Store Priority	1: Send 2: Store Only 3: Send & Store
------	----------------	--

2002	Text (Print) Mode Settings	
1*	MTF Filter Coefficient (Main scan)	Selects the MTF filter coefficient in the main scan direction for Text mode. <i>Select a higher number for a stronger filter.</i> <i>If this is "0", the MTF filter is not applied.</i> [0-13 / 8 / 1 step]
2*	MTF Filter Coefficient (Sub scan)	As above, for sub scan [0-13 / 7 / 1 step]
3*	MTF Filter Strength (Main scan)	Selects the MTF filter strength in the main scan direction for Text mode. <i>Select a higher number for a stronger filter.</i> [0-7 / 4 / 1 step]
4*	MTF Filter Strength (Sub scan)	As above, for sub scan [0-7 / 4 / 1 step]
5*	Independent Dot Erase	Selects the independent dot erase level. <i>With a larger SP setting, more dots are detected as independent dots and erased.</i> <i>If this is "0", independent dot erase is disabled.</i> [0-7 / 0 / 1 step]
6*	Unevenness correction	Selects whether the unevenness correction is done. <i>This function is like an FCI function. If this is "1", the edges of characters in scanned images will be smoothed.</i> [0: OFF , 1: ON]
7*	Smoothing Filter	Selects the smoothing pattern for Text mode when using binary picture processing mode. <i>A larger value could cause moiré to appear in the image.</i> [0-7 / 0 / 1 step]
8*	Scanner Gamma	Selects the scanner gamma type for Text mode when using binary picture processing mode. [0-11 / 4 / 1 step]

SCANNER SERVICE MODE

2002	Text (Print) Mode Settings	
11*	Brightness – Notch 7	Adjusts the image density for each image density level for Text mode when using binary picture processing mode. [0-255 / 128 / 1 step]
12*	Contrast – Notch 7	[0-255 / 128 / 1 step]
13*	Threshold Level – Notch 7	[0-255 / 128 / 1 step]
14*	Brightness – Notch 6	[0-255 / 128 / 1 step]
15*	Contrast – Notch 6	[0-255 / 128 / 1 step]
16*	Threshold Level – Notch 6	[0-255 / 128 / 1 step]
17*	Brightness – Notch 5	[0-255 / 128 / 1 step]
18*	Contrast – Notch 5	[0-255 / 128 / 1 step]
19*	Threshold Level – Notch 5	[0-255 / 128 / 1 step]
20*	Brightness – Notch 4	[0-255 / 128 / 1 step]
21*	Contrast – Notch 4	[0-255 / 128 / 1 step]
22*	Threshold Level – Notch 4	[0-255 / 128 / 1 step]
23*	Brightness – Notch 3	[0-255 / 128 / 1 step]
24*	Contrast – Notch 3	Adjusts the image density for each image density level for Text mode when using binary picture processing mode. [0-255 / 128 / 1 step]
25*	Threshold Level – Notch 3	[0-255 / 128 / 1 step]
26*	Brightness – Notch 2	[0-255 / 128 / 1 step]
27*	Contrast – Notch 2	[0-255 / 128 / 1 step]
28*	Threshold Level – Notch 2	[0-255 / 128 / 1 step]
29*	Brightness – Notch 1	[0-255 / 128 / 1 step]
30*	Contrast – Notch 1	[0-255 / 128 / 1 step]
31*	Threshold Level – Notch 1	[0-255 / 128 / 1 step]

2003	Text (OCR) Mode Settings	
1*	MTF Filter Coefficient (Main scan)	Selects the MTF filter coefficient in the main scan direction for Text (OCR) mode. <i>Select a higher number for a stronger filter.</i> <i>If this is "0", the MTF filter is not applied.</i> [0-13 / 5 / 1 step]
2*	MTF Filter Coefficient (Sub scan)	As above, for sub scan [0-13 / 5 / 1 step]
3*	MTF Filter Strength (Main scan)	Selects the MTF filter strength in the main scan direction for Text (OCR) mode. <i>Select a higher number for a stronger filter.</i> [0-7 / 5 / 1 step]
4*	MTF Filter Strength (Sub scan)	As above, for sub scan [0-7 / 5 / 1 step]
5*	Independent Dot Erase	Selects the independent dot erase level. <i>With a larger SP setting, more dots are detected as independent dots and erased.</i> <i>If this is "0", independent dot erase is disabled.</i> [0-7 / 0 / 1 step]

2003	Text (OCR) Mode Settings	
6*	Unevenness correction	Selects whether the unevenness correction is done. <i>This function is like an FCI function. If this is "1", the edges of characters in scanned images will be smoothed.</i> [0: OFF, 1: ON]
7*	Smoothing Filter	Selects the smoothing pattern for Text (OCR) mode when using binary picture processing mode. <i>A larger value could cause moiré to appear in the image.</i> [0-7 / 0 / 1 step]
8*	Scanner Gamma	Selects the scanner gamma type for Text (OCR) mode when using binary picture processing mode. [0-11 / 5 / 1 step]
11*	Brightness – Notch 7	Adjusts the image density for each image density level for Text (OCR) mode when using binary picture processing mode. [0-255 / 128 / 1 step]
12*	Contrast – Notch 7	[0-255 / 128 / 1 step]
13*	Threshold Level – Notch 7	[0-255 / 208 / 1 step]
14*	Brightness – Notch 6	[0-255 / 128 / 1 step]
15*	Contrast – Notch 6	[0-255 / 128 / 1 step]
16*	Threshold Level – Notch 6	[0-255 / 188 / 1 step]
17*	Brightness – Notch 5	[0-255 / 128 / 1 step]
18*	Contrast – Notch 5	[0-255 / 128 / 1 step]
19*	Threshold Level – Notch 5	[0-255 / 158 / 1 step]
20*	Brightness – Notch 4	[0-255 / 128 / 1 step]
21*	Contrast – Notch 4	[0-255 / 128 / 1 step]
22*	Threshold Level – Notch 4	[0-255 / 128 / 1 step]
23*	Brightness – Notch 3	[0-255 / 128 / 1 step]
24*	Contrast – Notch 3	Adjusts the image density for each image density level for Text (OCR) mode when using binary picture processing mode. [0-255 / 128 / 1 step]
25*	Threshold Level – Notch 3	[0-255 / 108 / 1 step]
26*	Brightness – Notch 2	[0-255 / 128 / 1 step]
27*	Contrast – Notch 2	[0-255 / 10 / 1 step]
28*	Threshold Level – Notch 2	[0-255 / 88 / 1 step]
29*	Brightness – Notch 1	[0-255 / 128 / 1 step]
30*	Contrast – Notch 1	[0-255 / 128 / 1 step]
31*	Threshold Level – Notch 1	[0-255 / 68 / 1 step]

SCANNER SERVICE MODE

2004	Text/Photo Mode Settings	
1*	MTF Filter Coefficient (Main Scan)	Selects the MTF filter coefficient in the main scan direction for Text/Photo mode. <i>Select a higher number for a stronger filter.</i> <i>If this is "0", the MTF filter is not applied.</i> [0-13 / 3 / 1 step]
2*	MTF Filter Coefficient (Sub Scan)	As above, for sub scan [0-13 / 1 / 1 step]
3*	MTF Filter Strength (Main Scan)	Selects the MTF filter strength in the main scan direction for Text/Photo mode. <i>Select a higher number for a stronger filter.</i> [0-7 / 4 / 1 step]
4*	MTF Filter Strength (Sub Scan)	As above, for sub scan [0-7 / 4 / 1 step]
7*	Smoothing Filter	Selects the smoothing pattern for Text/Photo mode when using binary picture processing mode. <i>A larger value could cause moiré to appear in the image.</i> [0-7 / 0 / 1 step]
8*	Scanner Gamma	Selects the scanner gamma type for Text/Photo mode when using binary picture processing mode. [0-11 / 6 / 1 step]
11*	Brightness – Notch 7	Adjusts the image density for each image density level for Text/Photo mode when using binary picture processing mode. [0-255 / 128 / 1 step]
12*	Contrast – Notch 7	[0-255 / 128 / 1 step]
13*	Threshold Level – Notch 7	[0-255 / 128 / 1 step]
14*	Brightness – Notch 6	[0-255 / 128 / 1 step]
15*	Contrast – Notch 6	[0-255 / 128 / 1 step]
16*	Threshold Level – Notch 6	[0-255 / 128 / 1 step]
17*	Brightness – Notch 5	[0-255 / 128 / 1 step]
18*	Contrast – Notch 5	[0-255 / 128 / 1 step]
19*	Threshold Level – Notch 5	[0-255 / 128 / 1 step]
20*	Brightness – Notch 4	[0-255 / 128 / 1 step]
21*	Contrast – Notch 4	[0-255 / 128 / 1 step]
22*	Threshold Level – Notch 4	[0-255 / 128 / 1 step]
23*	Brightness – Notch 3	[0-255 / 128 / 1 step]
24*	Contrast – Notch 3	[0-255 / 128 / 1 step]
25*	Threshold Level – Notch 3	[0-255 / 128 / 1 step]
26*	Brightness – Notch 2	[0-255 / 128 / 1 step]
27*	Contrast – Notch 2	[0-255 / 128 / 1 step]
28*	Threshold Level – Notch 2	[0-255 / 128 / 1 step]
29*	Brightness – Notch 1	[0-255 / 128 / 1 step]
30*	Contrast – Notch 1	[0-255 / 128 / 1 step]
31*	Threshold Level – Notch 1	[0-255 / 128 / 1 step]

2005	Photo Mode Settings	
1*	MTF Filter Coefficient (Main Scan)	Selects the MTF filter coefficient in the main scan direction for Photo mode. <i>Select a higher number for a stronger filter.</i> <i>If this is "0", the MTF filter is not applied.</i> [0-13 / 0 / 1 step]
2*	MTF Filter Coefficient (Sub Scan)	As above, for sub scan [0-13 / 0 / 1 step]
3*	MTF Filter Strength (Main Scan)	Selects the MTF filter strength in the main scan direction for Photo mode. <i>Select a higher number for a stronger filter.</i> [0-7 / 0 / 1 step]
4*	MTF Filter Strength (Sub Scan)	As above, for sub scan [0-7 / 0 / 1 step]
7*	Smoothing Filter	Selects the smoothing pattern for Photo mode when using binary picture processing mode. <i>A larger value could cause moiré to appear in the image.</i> [0-7 / 6 / 1 step]
8*	Scanner Gamma	Selects the scanner gamma type for Photo mode when using binary picture processing mode. [0-11 / 7 / 1 step]
9*	Dither Matrix Filter	Selects the dither matrix type for Photo mode when using binary picture processing mode. [1-11 / 11 / 1 step]
11*	Brightness – Notch 7	Adjusts the image density for each image density level for Photo mode when using binary picture processing mode. [0-255 / 128 / 1 step]
12*	Contrast – Notch 7	[0-255 / 128 / 1 step]
13*	Threshold Level – Notch 7	[0-255 / 128 / 1 step]
14*	Brightness – Notch 6	[0-255 / 128 / 1 step]
15*	Contrast – Notch 6	[0-255 / 128 / 1 step]
16*	Threshold Level – Notch 6	[0-255 / 128 / 1 step]
17*	Brightness – Notch 5	[0-255 / 128 / 1 step]
18*	Contrast – Notch 5	[0-255 / 128 / 1 step]
19*	Threshold Level – Notch 5	Not available. [0-255 / 128 / 1 step]
20*	Brightness – Notch 4	[0-255 / 128 / 1 step]
21*	Contrast – Notch 4	Adjusts the image density for each image density level for Photo mode when using binary picture processing mode. [0-255 / 128 / 1 step]
22*	Threshold Level – Notch 4	[0-255 / 128 / 1 step]
23*	Brightness – Notch 3	[0-255 / 128 / 1 step]
24*	Contrast – Notch 3	[0-255 / 128 / 1 step]
25*	Threshold Level – Notch 3	[0-255 / 128 / 1 step]

SCANNER SERVICE MODE

2005	Photo Mode Settings	
26*	Brightness – Notch 2	[0-255 / 128 / 1 step]
27*	Contrast – Notch 2	[0-255 / 128 / 1 step]
28*	Threshold Level – Notch 2	[0-255 / 128 / 1 step]
29*	Brightness – Notch 1	[0-255 / 128 / 1 step]
30*	Contrast – Notch 1	[0-255 / 128 / 1 step]
31*	Threshold Level – Notch 1	[0-255 / 128 / 1 step]

2006	Grayscale Mode Settings	
1*	MTF Filter Coefficient	Selects the MTF filter coefficient in the main scan direction when using grayscale processing mode. <i>Select a higher number for a stronger filter.</i> <i>If this is "0", the MTF filter is not applied</i> [0-15 / 0 / 1 step]
2*	MTF Filter Coefficient	As above, for sub scan [0-13 / 0 / 1 step]
3*	MTF Filter Strength (Main Scan)	Selects the MTF filter strength in the main scan direction when using grayscale processing mode. <i>Select a higher number for a stronger filter.</i> [0-7 / 0 / 1 step]
4*	MTF Filter Strength (Sub scan)	As above, for sub scan [0-7 / 0 / 1 step]
7*	Smoothing Filter	Selects the smoothing pattern when using grayscale processing mode. <i>A larger value could cause moiré to appear in the image.</i> [0-7 / 0 / 1 step]
8*	Scanner Gamma	Selects the scanner gamma type when using grayscale processing mode. [0-6 / 11 / 1 step]
11*	Brightness – Notch 7	Adjusts the image density for each image density level when using the grayscale processing mode. [0-255 / 128 / 1 step]
12*	Contrast – Notch 7	[0-255 / 128 / 1 step]
13*	Threshold Level – Notch 7	Not available. [0-255 / 98 / 1 step]
14*	Brightness – Notch 6	[0-255 / 128 / 1 step]
15*	Contrast – Notch 6	[0-255 / 128 / 1 step]
16*	Threshold Level – Notch 6	Not available. [0-255 / 128 / 1 step]
17*	Brightness – Notch 5	[0-255 / 128 / 1 step]
18*	Contrast – Notch 5	[0-255 / 118 / 1 step]
19*	Threshold Level – Notch 5	Not available. [0-255 / 128 / 1 step]
20*	Brightness – Notch 4	[0-255 / 128 / 1 step]
21*	Contrast – Notch 4	[0-255 / 128 / 1 step]
22*	Threshold Level – Notch 4	Not available. [0-255 / 128 / 1 step]


2006	Grayscale Mode Settings	
23*	Brightness – Notch 3	[0-255 / 128 / 1 step]
24*	Contrast – Notch 3	[0-255 / 128 / 1 step]
25*	Threshold Level – Notch 3	Not available. [0-255 / 128 / 1 step]
26*	Brightness – Notch 2	[0-255 / 128 / 1 step]
27*	Contrast – Notch 2	[0-255 / 128 / 1 step]
28*	Threshold Level – Notch 2	Not available. [0-255 / 128 / 1 step]
29*	Brightness – Notch 1	[0-255 / 128 / 1 step]
30*	Contrast – Notch 1	[0-255 / 128 / 1 step]
31*	Threshold Level – Notch 1	Not available. [0-255 / 128 / 1 step]

2021	Compression Ratio	
1*	Normal image	Selects the compression ratio for grayscale processing mode. <i>For a lower compression rate, input a smaller value.</i> [5-95 / 50 / 1 step]
2*	High Quality image	[5-95 / 60 / 1 step]
3*	Low Quality image	[5-95 / 40 / 1 step]

4. DETAILS

4.1 ETHERNET BOARD

4.1.1 ETHERNET BOARD LAYOUT



The Ethernet board is provided as a standard feature of this machine.

Function Blocks	Description
PHY (Physical Layer Device)	Completely standardized physical layer device for the functions of each device in the network.
EEPROM	Stores the MAC address.


The physical layer device, the lowest layer of the OSI reference model, refers to the physical components of the network: cables, connectors, and so on. OSI, the *Operating Standard Interface*, is a framework upon which networking standards are arranged. It is commonly diagramed as a layered cake.

Printer/
Scanner
B577

ETHERNET BOARD

4.1.2 ETHERNET BOARD OPERATION

The NIB is a standard IEEE802.3u type which implements 10/100Mbps auto negotiation. System initialization sets the network for 10Mbps/100Mbps.



LED 1 (Green)	Indicates the link status: ON Link Safe OFF Link Fail
LED 2 (Orange)	Indicates the operation mode: ON 100 Mbps mode OFF 10 Mbps mode


4.2 IEEE1394 BOARD (FIREWIRE)

4.2.1 OVERVIEW

An IEEE1394 interface board is available as an option for this machine to provide high speed connectivity through what is commonly called Firewire or i.LINK (Sony). Some important advantages of Firewire are:

- High speed data transmission at 400 Mbps.
- Easier connectivity (many devices can be connected without a host).
- Devices in a computer can be connected to external devices on a shared bus.

IEEE1394 supports two printing methods: 1) SCSI Print, and 2) IP Over 1394. IP Over 1394 supports printing by setting an IP address, and SCSI supports printing without an IP address.



Printer/
Scanner
B577

NOTE: 1) Windows Me and Windows XP support IP over 1394.
2) Windows XP and 2000 support IEEE1394 SCSI printing.

IEEE1394 BOARD (FIREWIRE)

When the host computer powers up, it queries all the devices connected to the bus and assigns each one an address, a process called enumeration. Here are some general features of Firewire:

- Firewire is Plug-and-Play.
- Firewire devices are hot pluggable (they can be plugged while the system is operating).
- Firewire uses 64-bit fixed addressing, based on the IEEE 1212 standard. There are three parts to each packet of information sent by a device over FireWire:
 - 10-bit Bus ID. Used to determine the Firewire bus where the data came from.
 - 6-bit Physical ID. Used to identify the device that sent the data.
 - 48-bit Storage Area. Capable of addressing 256 terabytes of information for each node
- The Bus ID and Physical ID comprise the 16-bit Node ID. 64,000 nodes are allowed on each system.
- Up to 16 hops are allowed (4.5 m/hop) for a total of 72 meters devices are daisy-chained.
- Firewire allows its devices to draw power from the Firewire connection. Two power connectors in the cable can supply power (8 to 40 V, 1.5 amp max.)
- An important element of Firewire is its support of isochronous devices. When isochronous devices are in the isochronous mode, data streams between the device and the host in real time with guaranteed bandwidth and no error correction. Essentially, this means that a device like a digital camcorder can request that the host computer allocate enough bandwidth for the camcorder to send uncompressed video in real time to the computer. The camera can send data via the Firewire connection in a steady flow to the computer without anything disrupting the process. This is one of the main reasons why 1394 has been widely adopted by the consumer electronics industry.

4.3 USB

4.3.1 SPECIFICATIONS

USB connectivity is provided as an option for this machine.

Interface:	USB 1.1, USB 2.0
Data rates:	480 Mbps (high speed), 12 Mbps (full speed), 1.5 Mbps (low speed) High speed mode is only supported by USB 2.0.

4.3.2 USB 1.1/2.0

USB (Universal Serial Bus) offers simple connectivity for computers, printers, keyboards, and other peripherals. In a USB environment, terminators, device IDs (like SCSI), and DIP switch settings are not necessary.

USB 1.1 provides the following features:

- Plug & Play. As soon as a new device is connected via USB, the operating system recognizes it, and the appropriate driver is installed for it automatically if the driver is available. If the driver is not available, a message prompts the user for the driver disk for immediate installation.
- Hot swapping (cables can be connected and disconnected while the computer and other devices are switched on)
- No terminator or device ID required
- Data rates of 12 Mbps (full speed), and 1.5 Mbps (low speed)
- Common connectors for different devices
- Bi-directional data communication between device and host computer via a 4-byte header and DEVICE ID.


USB 2.0 is an evolution of the USB 1.1 specification. It uses the same cables, connectors, and software interfaces so the user will see no change. It provides an easy-to-use connection to a wide range of products with a maximum data rate of 480Mbps (high speed).

Up to 127 devices can be connected and 6 cascade connections are allowed. Power is supplied from the computer and the maximum cable length is 5 m.


4.3.3 USB CONNECTORS

USB is a serial protocol and a physical link, which transmits all data on a single pair of wires. Another pair provides power to downstream peripherals. The USB standard specifies two types of connectors, type “A” connectors for upstream connection to the host system, and type “B” connectors for downstream connection to the USB device.

Type “A” connector




Type “A” connector



4.3.4 PIN ASSIGNMENT

The controller has a type “B” receptacle (CN10).



Pin No.	Signal Description	Wiring Assignment
1	Power	Red
2	Data -	White
3	Data +	Green
4	Power GND	White

4.3.5 REMARKS ABOUT USB

- The machine does not print reports specifically for USB.
- Only one host computer is allowed for the USB connection.
- After starting a job using USB, do not switch the printer off until the job has been completed. When a user cancels a print job, if data transmitted to the printer has not been printed at the time of cancellation, the job will continue to print up to the page where the print job was cancelled
- When the controller board is replaced, the host computer will recognize the machine as a different device.

Related SP Mode

“USB Settings” in the printer engine service mode. Data rates can be adjusted to full speed fixed (12 Mbps). This switch may be used for troubleshooting if there is a data transfer error using the high speed mode (480Mbps).

Data rates can also be adjusted using the UP mode “USB Setting” in the Host Interface in the System menu. This mode can be accessed only when the “Enter”, “Escape”, then “Menu” keys are pressed to enter the UP mode.

4.4 IEEE 802.11B (WIRELESS LAN)

4.4.1 SPECIFICATIONS

The IEEE 802.11b wireless LAN interface card is available as an option for this machine.

A wireless LAN is a flexible data communication system used to extend or replace a wired LAN. Wireless LAN employs radio frequency technology to transmit and receive data over the air and minimize the need for wired connections.

- With wireless LANs, users can access information on a network without looking for a place to plug into the network.
- Network managers can set up or expand networks without installing or moving wires.
- Most wireless LANs can be integrated into existing wired networks. Once installed, the network treats wireless nodes like any other physically wired network component.
- Flexibility and mobility make wireless LANs both effective extensions of and attractive alternatives to wired networks.

Standard applied:	IEEE802.11b	
Data transmission rates:	Speed	Distance
	11 Mbps	140 m (153 yd.)
	5.5 Mbps	200 m (219 yd.)
	2 Mbps	270 m (295 yd.)
	1 Mbps	400 m (437 yd.)
Network protocols:	TCP/IP, Apple Talk, NetBEUI, IPX/SPX	
Bandwidth:	2.4GHz (divided over 14 channels, 2400 to 2497 MHz for each channel)	

NOTE: The wireless LAN cannot be active at the same time as the Ethernet LAN. The following user tool setting determines which LAN is active: System Settings – Interface Settings – Network - LAN Type.

LED Indicators

LED	Description	ON	OFF
LED 1 (Green)	Link Status	Linked	No Link
LED 2 (Orange)	Power Distribution	Power On	Power Off


4.4.2 TRANSMISSION MODES

Wireless communication has two modes: 1) ad hoc mode, and 2) infrastructure mode.

Ad Hoc Mode


The ad hoc mode allows communication between each device (station) in a simple peer-to-peer network. In this mode, all devices must use the same channel to communicate. In this machine, the default transmission mode is ad hoc mode and the default channel is 11. First, set up the machine in ad hoc mode and program the necessary settings, even if the machine will be used in the infrastructure mode.

To switch between ad hoc and infrastructure modes, use the following user tool: Host Interface Menu - IEEE802.11b - Comm Mode



Infrastructure Mode

The infrastructure mode allows communication between each computer and the printer via an access point equipped with an antenna and wired into the network. This arrangement is used in more complex topologies. The wireless LAN client must use the same SSID (Service Set ID) as the access point in order to communicate.



4.4.3 SECURITY FEATURES

SSID (Service Set ID)

The SSID is used by the access point to recognize the client and allow access to the network. Only clients that share the same SSID with the access point can access the network.

NOTE: 1) If the SSID is not set, clients connect to the nearest access point.
2) The SSID can be set using the web status monitor or telnet.

Using the SSID in Ad hoc mode

When the SSID is used in ad hoc mode and nothing is set, the machine automatically uses "ASSID" as the SSID. In such a case, "ASSID" must also be set at the client.

NOTE: SSID in ad hoc mode is sometimes called "Network Name."

Some devices automatically change from ad hoc mode to infrastructure mode when the same SSID is used in ad hoc mode and infrastructure mode. In such a case, to use the device in ad hoc mode, use a specified SSID in infrastructure mode and use "ASSID" in the ad hoc mode.

WEP (Wired Equivalent Privacy)

WEP is a coding system designed to protect wireless data transmission. In order to unlock encoded data, the same WEP key is required on the receiving side. There are 64 bit and 128 bit WEP keys. However, this machine supports only 64 bit WEP.

NOTE: The WEP key can be set using the Web Status Monitor or Telnet.

MAC Address

When the infrastructure mode is used, access to the network can also be limited at the access points using the MAC address. This setting may not be available with some types of access points.

4.4.4 WIRELESS LAN TROUBLESHOOTING NOTES

Communication Status

Wireless LAN communication status can be checked with the UP mode “W.LAN Signal” in the Maintenance menu. This can also be checked using the Web Status Monitor or Telnet.

The status is described on a simple number scale.


Status Display	Communication Status
Good	76 ~ 100
Fair	41 ~ 75
Poor	21 ~ 40
Unavailable	0 ~ 20

NOTE: Communication status can be measured only when the infrastructure mode is being used.

Channel Settings

If a communication error occurs because of electrical noise, interference with other electrical devices, etc., you may have to change the channel settings.

To avoid interference with neighboring channels, it is recommended to change by 3 channels. For example, if there are problems using channel 11 (default), try using channel 8.



Troubleshooting Procedure

If there are problems using the wireless LAN, check the following.

- 1) Check the LED indicator on the wireless LAN card.
- 2) Check if "IEEE802.11b" is selected in the following user tool: Host Interface menu - Network Setup - LAN Type.
- 3) Check if the channel settings are correct.
- 4) Check if the SSID and WEP are correctly set.

If infrastructure mode is being used,

- 1) Check if the MAC address is properly set.
- 2) Check the communication status.

If the communication status is poor, bring the machine closer to the access point, or check for any obstructions between the machine and the access point.

If the problem cannot be solved, try changing the channel setting.

4.5 BLUETOOTH

4.5.1 SPECIFICATIONS

Bluetooth wireless provides radio links between mobile computers, mobile phones and other portable handheld devices.

Bluetooth contains the following features.

- Cheaper compared to the IEEE802.11b wireless LAN.
- Many protocols for infrared transmission (IrDA) can be used with Bluetooth.
- A Bluetooth device can connect to other Bluetooth devices without any settings.

Standard applied: Bluetooth 1.1 (Bluetooth Special Interest Group)

Data transfer rates: 1 Mbps


Bandwidth: 2.4GHz Frequency Hopping Spread Spectrum (FHSS)

Piconet. Bluetooth devices communicate with each other device in the ad hoc mode. This network is called a "Piconet". A Piconet may contain a maximum of 8 Bluetooth devices.

There is one master device and seven slave devices in a Piconet. The master device controls the hopping frequency and timing, as well as storing the ID codes of the slave devices. The master and slave devices can be swapped. Once the master device leaves the Piconet, a slave device becomes the new master.

Machines with the Bluetooth option become potential slave devices to connect to the PC.

FHSS (Frequency Hopping Spread Spectrum). The Bluetooth device divides 2402 to 2480 MHz into 79 channels of 1 MHz width, and changes the channel 1600 times per second. If other devices in the LAN are using the same radio band, Bluetooth can avoid interference from the other devices.



4.5.2 BLUETOOTH PROFILES

A Bluetooth device will not operate if it is located too close to another Bluetooth device. However, the Bluetooth device should support the protocols to communicate with each other. There are many types of Bluetooth and service protocols. These are listed below.

Here are 14 profiles for Bluetooth as follows.

- Generic Access Profile
- Service Discovery Profile
- Cordless Telephony Profile
- Intercom Profile
- Serial Port Profile
- Headset Profile
- Dial-up Networking Profile
- Fax Profile
- LAN Access Profile
- Generic Object Exchange Profile
- Object Push Profile
- File Transfer Profile
- Synchronization Profile
- Hardcopy Cable Replacement Profile

Serial Port Profile (SPP) and Hardcopy Cable Replacement Profile (HCRP) are used for the printer products.

SPP is used in place of the serial port, while HCRP is used in place of the parallel port.

4.5.3 BLUETOOTH SECURITY FEATURES

Public and Private Mode. The PC can browse Bluetooth devices. The machine's default is public mode. The PC cannot browse the machine if it has been changed to private mode.

PIN Code (Personal Identification Number). When the PIN code is used, the PC connects to the device that sent the PIN code. The PIN code is a 4 digit number. This machine uses the last four digits of the machine's serial number. It cannot be changed.

4.6 FILE FORMAT CONVERTER (MLB)

In previous models (such as A-C2, R-C2), DeskTopBinder V2 could retrieve copy and print jobs from the document server and convert them to TIFF. However, this software-based conversion was slow for many users.


So, for this machine, this conversion has been made hardware-based, using the optional File Format Converter. Without the File Format Converter, copy and print jobs cannot be downloaded to a PC (or e-Cabinet) from the document server.

Two common target formats are provided for conversion to files that can be selected by the SP modes: JPEG, and TIFF.

In scanner mode, users can select file format from TIFF, JPEG, or PDF. The time to create TIFF and JPEG files will be shortened with the File Format Converter, especially for high scanning resolution and large image size. When the customer selects PDF, the machine creates a TIFF or JPEG file from the scanned image first then converts it to PDF. So, the total time to create a PDF is also shortened with the File Format Converter.

SPECIFICATIONS

1. SYSTEM COMPONENTS



No.	Item	Code	Remarks
1	Memory 128 MB	G331	Common with B079
2	File Format Converter (MLB)	B519	Common with B135
3	IEEE 1394 (FireWire)	G336	Common with B079
4	IEEE 802.11b (Wireless LAN)	B515	Common with B079
5	USB 2.0	B525-01	Common with B079
6	Bluetooth	G354	Common with B079
7	PostScript 3	G354-05	---
8	Printer/Scanner Module (ROM DIMM)	B577	Provided with HDD and NIB
9	NIB (Network Interface Board)	B525-17	Common with B079

Printer/Scanner B577

2. LED INDICATORS

LED	Description	On	Off
LED 1 (Green)	Link Status	Link success	Link failure
LED 2 (Orange)	Power distribution	Power on	Power off

SPECIFICATIONS

3. PRINTER SPECIFICATIONS

Printing Speed:	Maximum 22 ppm (A4/LT LEF): B089 model Maximum 27 ppm (A4/LT LEF): B093 model Maximum 32 ppm (A4/LT LEF): B097 model
Printer Languages:	PCL6/PCL5e PostScript 3 (option) RPCS (Refined Printing Command Stream) - an original Ricoh PDL
Resolution (Driver):	1200 dpi (RPCS) 600 dpi (PCL 6/PCL5e/PS3/RPCS) 300 dpi (PCL5e/RPCS) 200 dpi (RPCS)
Resident Fonts:	PCL: 35 Intellifonts 10 True Type fonts PS3: 136 fonts (24 Type 2 fonts, 112 Type 14 fonts)
Host Interfaces:	Bi-directional IEEE1284 parallel x 1 (Standard) Ethernet (100 Base-TX/10 Base-T) (Option) IEEE1394 with SCSI Print and IP Over 1394 (Option) IEEE 802.11b Wireless LAN (Option) Bluetooth (Option) USB 2.0 (Option)
Network Protocols:	TCP/IP, IPX/SPX, NetBEUI, AppleTalk, SMB, IPP
Memory:	Maximum 192 MB (Standard 64 MB + 128 MB optional DIMM)

4. USB SPECIFICATIONS

USB connectivity is provided as an option for this machine.

Interface	USB 1.1, USB 2.0
Data rates	480 Mbps (high speed), 12 Mbps (full speed), 1.5 Mbps (low speed)
	High speed mode is only supported by USB 2.0.

5. IEEE 802.11B SPECIFICATIONS

Standard applied	IEEE802.11b	
Data transmission rates	Speed	Distance
	11 Mbps	140 m (153 yd.)
	5.5 Mbps	200 m (219 yd.)
	2 Mbps	270 m (295 yd.)
	1 Mbps	400 m (437 yd.)
Network protocols	TCP/IP, Apple Talk, NetBEUI, IPX/SPX, SMB	
Bandwidth	2.4GHz (divided over 14 channels, 2400 to 2497 MHz for each channel)	

6. IEEE 1394 SPECIFICATIONS

Interface	IEEE 1394 (firewire)	
Number of Ports	2 ports	
Data Transmission Speed	400 Mbps, 200 Mbps, 100 Mbps	
Available Features, Functions, Protocols	SCSI print	IP over 1384
	Print	Print, Scan
	SBP-2	TCP/IP

7. BLUETOOTH SPECIFICATIONS

Transmission Specifications	Based on Bluetooth V1.1
Data Transfer Speed	1 Mbps
Profile	Hard Copy Cable Replacement Profile (HCRP), Serial Port Profile (SPP), BIP
Distance Between Devices	10 m (The maximum distance when using outdoors, otherwise depends on the office environment.)

SPECIFICATIONS

8. SCANNER SPECIFICATIONS

Standard Scanner Resolution:	Main scan/Sub scan 600 dpi	
Available scanning Resolution Range:	100 ~ 1200 dpi;	When used as a Network TWAIN scanner.
	100, 200, 300, 400, 600 dpi;	When used as a network delivery scanner or for sending e-mail
Grayscales:	8 bits/pixel	
Scanning Speed Throughput:	0.8 sec./sheet (A4 LEF, 200 dpi without binary compression) 49 spm (A4 LEF, 200 dpi binary, MH)	
Interface:	Ethernet (100 Base-TX/10 Base-T for TCP/IP) IEEE 1394/IP Over IEEE 802.11b Wireless LAN	
Compression Method:	MH, MR, MMR (Binary Picture Processing) JPEG (Grayscale Processing)	
Video Memory Capacity:	192 MB	
Image Storage Capacity:	Number of originals per file: Maximum 2,000 pages Maximum of files: 3000 files	

9. SOFTWARE ACCESSORIES

9.1 PRINTER

The printer drivers and utility software are provided on one CD-ROM. An auto-run installer allows you to select which components to install.

Printer Drivers

Printer Language	Windows 95/98/Me	Windows NT4.0	Windows 2000, XP, Server 2003	Macintosh
PCL 6	Yes	Yes	Yes	No
PCL 5e	Yes	Yes	Yes	No
PS3	Yes	Yes	Yes	Yes
RPCS	Yes	Yes	Yes	No

- NOTE:** 1) The printer drivers for Windows NT 4.0 are only for the Intel x86 platform. There is no Windows NT 4.0 printer driver for the PowerPC, Alpha, or MIPS platforms.
- 2) The PS3 drivers are all genuine AdobePS drivers, except for Windows 2000/XP/Server 2003, which uses Microsoft PS. A PPD file for each operating system is provided with the driver.

Utility Software

Software	Description
Agfa Monotype Font Manager 2000 (Win 95/98/Me, NT4, 2000)	A font management utility with screen fonts for the printer.
SmartNetMonitor for Admin (Win 95/98/Me, NT4, 2000/XP/Server 2003)	A printer management utility for network administrators. NIB setup utilities are also available.
SmartNetMonitor for Client (Win 95/98/Me, NT4, 2000/XP/Server 2003)	A printer management utility for client users. Peer-to-peer printing utility and parallel/recovery printing functions are included.
1394 Utility (Win 2000/XP)	A utility for removal IEEE 1394 printers.
LAN-Fax M3 Driver (Win 95/98/Me, NT4, 2000/XP)	This driver allows use of the LAN-Fax functions by installing the LAN-Fax driver, Address Book, and LAN-Fax Cover Sheet Editor.
Printer Utility for Mac	This software provides several convenient functions for printing from Macintosh clients.
USB Printing Support	A utility for the USB 2.0 board. A computer running Windows 98 SE or Windows ME requires installation of this utility.
Acrobat Reader	A utility that allows reading PDF files.

SPECIFICATIONS

9.2 SCANNER

The scanner driver and utility software are provided on one CD-ROM.

Scanner Driver

- Network Twain Driver for Win95/98/Me/NT3.51/NT4.0/2000/XP

Scanner Utilities

- Scan Router V2 Lite for Win95/98/Me/NT4.0/2000/XP
- Desk Top Binder V2 Lite for Win95/98/Me/NT4.0/2000/XP/Server 2003

DataOverwriteSecurity Unit

Type A/B694-01

Type B/B692-01

DataOverwriteSecurityUnit B692/B694

TABLE OF CONTENTS

1. INSTALLATION.....	1
1.1 ACCESSORY CHECK	1
DataOverwriteSecurity (DOS) Unit Type A	1
DataOverwriteSecurity (DOS) Unit Type B	1
1.2 BEFORE YOU BEGIN.....	2
1.3 SEAL CHECK AND REMOVAL.....	2
1.4 INSTALLATION PROCEDURE	3
2. PREVENTIVE MAINTENANCE.....	5
3. REPLACEMENT AND ADJUSTMENT	6
3.1 HDD.....	6
3.2 NVRAM	7
3.3 DIMM OR SD CARD	9
4. TROUBLESHOOTING	10
4.1 SERVICE CALL CONDITIONS	10
4.1.1 SUMMARY	10
4.1.2 SC CODE DESCRIPTIONS	11
4.2 OVERWRITE ERASE ICON NOT DISPLAYED	12
5. SERVICE TABLES.....	13
5.1 COPY SP SERVICE TABLES	14
5.2 PRINT SERVICE TABLE.....	15
6. DETAILS.....	16
SPECIFICATIONS.....	21
1. HARDWARE.....	21
2. SOFTWARE	21

IMPORTANT SAFETY NOTICES

PREVENTION OF PHYSICAL INJURY

1. Before disassembling or assembling parts of the copier and peripherals, make sure that the copier power cord is unplugged.
2. The wall outlet should be near the copier and easily accessible.
3. Some components of the copier and the paper tray unit are supplied with electrical voltage even if the main power switch is turned off.
4. If any adjustment or operation check has to be made with exterior covers off or open while the main switch is turned on, keep hands away from electrified or mechanically driven components.
5. If the Start key is pressed before the copier completes the warm-up period (the Start key starts blinking red and green alternatively), keep hands away from the mechanical and the electrical components as the copier starts making copies as soon as the warm-up period is completed.
6. The metal parts of the fusing unit and other internal components become extremely hot while the copier is operating. Avoid touching those components with your bare hands.

HEALTH SAFETY CONDITIONS

1. Never operate the copier without the ozone filters installed.
2. Toner and developer are non-toxic, but if you get either of them in your eyes by accident, it may cause temporary eye discomfort. Try to remove with eye drops or flush with water as first aid. If unsuccessful, get medical attention.

OBSERVANCE OF ELECTRICAL SAFETY STANDARDS

1. The copier and its peripherals must be installed and maintained by a customer service representative who has completed the training course on the machines.
2. The NVRAM has a lithium battery which can explode if replaced incorrectly. Replace the NVRAM only with an identical one. The manufacturer recommends replacing the entire NVRAM. Never attempt to recharge or incinerate this battery. Used NVRAMs must be handled in accordance with local regulations regarding the disposal of such items.

SAFETY AND ECOLOGICAL NOTES FOR DISPOSAL

1. Never incinerate toner bottles or used toner. Toner dust may ignite suddenly when exposed to an open flame.
2. Dispose of used toner, developer, and organic photoconductors in accordance with local regulations. (These are non-toxic supplies.)
3. Dispose of replaced parts in accordance with local regulations.
4. When keeping used lithium batteries in order to dispose of them later, do not put more than 100 batteries per sealed box. Storing larger numbers or not sealing them apart may lead to chemical reactions and heat build-up.

LASER SAFETY

The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.

⚠ WARNING

Use of controls, or adjustment, or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

⚠ WARNING

WARNING: Turn off the main switch before attempting any of the procedures in the Laser Unit section. Laser beams can seriously damage your eyes.

CAUTION MARKING:



What This Manual Contains







This manual describes the DataOverwriteSecurity (DOS) Unit Type A/B for:


- B147/B149
- B135/B138
- B089/B093.

The DOS unit is an optional DIMM (or SD card) that contains special firmware. At the end of every job, this special firmware overwrites every cluster in temporary storage on the HDD twice with random data. Then each cluster is once again overwritten with a zero. This erases sensitive data on the disk which could be retrieved secretly.


Conventions in this Manual

This manual uses several symbols.

Symbol	What it means
	Refer to section number
	See Core Tech Manual for details
	Screw
	Connector
	E-ring
	Clip ring



Short Edge Feed (SEF)



Long Edge Feed (LEF)

1. INSTALLATION

1.1 ACCESSORY CHECK

Check the accessories and their quantities against the following list:

DataOverwriteSecurity (DOS) Unit Type A

This module is for B135/B138 and B089/B093.

Description	Q'ty
1. DIMM	1
2. Keytops for B089/B093 (Blank Covers)	2
3. Keytops for B135/B138 (Blank Covers)	2
4. Operation Instructions.....	1

DataOverwriteSecurity (DOS) Unit Type B

This module is for B147/B149.


Description	Q'ty
1. SD Card.....	1
2. Keytop (Blank Covers).....	2
3. Operation Instructions.....	1

CAUTION

The machine should always be switched off and its power cord disconnected before doing any of the following procedures.

1.2 BEFORE YOU BEGIN

1.2.1 SEAL CHECK AND REMOVAL



⚠ CAUTION

Before you start the installation, you must check the box seals to confirm that they have not been removed since the items were sealed in the box at the factory.

1. Check the box seals [A] on each corner of the box.
 - Confirm that a tape is attached to each corner.
 - The surfaces of the tapes should be blank. If you see “VOID” on the tapes **STOP, do not install the components, contact your supervisor.**
2. If the surfaces of the tapes are unmarked, remove from the corners of the box.
3. As you remove each seal, the “VOID” marks [B] appear. This prevents the tape from being reattached to the box.
4. Make sure that you have the correct security module for the machine. The machine model requires either the DIMM type or the SD Card type.

Model	Security Module Required
B135/B138 e/f	DOS Unit Type A (DIMM)
B089/B093	DOS Unit Type A (DIMM)
B147/B149	DOS Unit Type B (SD Card)

1.3 INSTALLATION PROCEDURE


1. If the machine is on, switch off the main power switch.
2. Disconnect the Network cable if the NIB is installed.
3. Disconnect the Fax module cable if the fax option is installed.
4. Switch the main power switch on.
5. Check that the following “Copy SPs” are set as indicated below:

SP No.	SP Name	Set To:
5871 001	HDD Function Disable	1 (On)
5967 001	Document Server Set Function	1 (Off)
5846 090	USC Settings - Plain Data Forbidden	1 (Check)
5836 001	Capture Settings – Capture Function	0 (Off)
5832 001	HDD Formatting (ALL)	
	• B089/B093 OR B135/B138	Press # to Execute
	• B147/B149	Press “Execute” key

6. Check that the following “Printer SPs” are set as indicated below:

SP No.	SP Name	Set To:
1006 001	Sample/Proof Print	1 (On)

7. Turn off the operation switch.
8. Turn off the main switch.
9. Disconnect the Fax cable (RJ11 connection) if installed
10. Disconnect the Network cable (RJ45 connection) if NIB is installed



11. Install either the DIMM [A] or the SD Card [B]:
 - The DIMM is installed for B135/B138 or B089/B093.
 - The SD Card is installed for B147/B149.

B692/B694
Data
Overwrite
Security Unit


INSTALLATION PROCEDURE

Model B147/B149

- If the PostScript 3 option is not installed, install the DOS option SD card in Slot 2.
- If the PostScript 3 option is installed, remove the Printer/Scanner card from Slot 1 and install the DOS option SD card in Slot 1.
- Follow the procedure in the B147/B149 Service Manual, section 5.7 SD Card Appli Move, to move the Printer/Scanner application data to the DOS option card. **(The Printer/Scanner software is now on the SD card with the DOS option.)**
- Remove Printer/Scanner card from Slot 3

NOTE: After the SD Card Appli Move procedure is completed the Printer/Scanner card will no longer function

- After the procedure is completed, the DOS card, with Printer/Scanner application data, will be in Slot 1. The PS3 card will be in Slot 2 and Slot 3 will be empty
12. Connect the network cable if the NIB option is installed.
 13. Connect the Fax cable if the fax option is installed.
 14. Switch the main power switch on.



15. Check the display and make sure that the overwrite erase icon [A] is displayed.
16. Make a Sample Copy.
17. Watch the overwrite erase icon.
 - The bottom of the icon becomes thicker [B].
 - "Next Copy" is displayed briefly below the icon.
 - The icon returns to its normal appearance [C].
18. Remove the Document Server and Scanner keytops and replace them with the blank keytops provided.

2. PREVENTIVE MAINTENANCE

There are no preventive maintenance checks or procedures for the DataOverwriteSecurity Unit.

3. REPLACEMENT AND ADJUSTMENT


3.1 HDD

1. Switch the operation power switch off.
2. Switch the main power switch off.
3. Disconnect the power cord from the power supply.
4. Replace the HDD. (Refer to the section "3. Replacement and Adjustment" in the Service Manual of the appropriate machine.)
5. Discard the used HDD

⚠ CAUTION

The customer engineer must consult with the key operator or system administrator to decide how to handle the old HDD.

6. Connect the power cord to the power supply.
7. Switch on the main power switch.
8. Make a Sample Copy.



9. Check the overwrite erase icon [A] in front of the date in the upper right corner of the operation panel display.
10. Confirm that the icon has changed from the display for data on disk [B] to no data on disk [C]

NOTE: No SP settings are required for replacement of a defective HDD.

3.2 NVRAM

1. Switch the operation power switch off.
2. Switch the main power switch off.
3. Disconnect the power cord from the power supply.
4. Disconnect the network cable if the NIB option is installed.
5. Disconnect the fax cable if the fax option is installed.
6. Insert a blank IC card or SD card into the controller slot:
 - B135/B138, B089/B093 require the IC card.
 - B147/B149 requires the SD card.
7. Connect the power cord to the power supply.
8. Switch the main switch on.
9. Enter the SP mode.
10. Do the following SPs.

SP No.	Name	Comment
5990 003	SMC Printout – SP	Prints a list of all the current User Tool settings
5990 002	SMC Printout – User Programs	Prints a list of all User Tool settings.
5824	NVRAM Data Upload	Uploads all SP and UT settings to the card.

11. When the upload is finished, switch the main power switch off.
12. Disconnect the power cord from the power supply, and remove the card.
13. Replace the NVRAM. (For more details about how to replace the NVRAM, refer to section “3. Replacement and Adjustment” in the Service Manual for the appropriate machine.)
14. Switch on the main power switch.
15. Do the following SPs:

SP No.	Name	Comment
5801 001	Memory Clear – All Clear	Clears entire memory.
5832 002	HDD Formatting – IMH	Initializes documents stored on the document server, stamp print data, scanner delivery images, fax delivery images.

NVRAM

16. Switch the main power switch off, then switch it on again.
17. Insert the IC card or SD card with the uploaded NVRAM data into the controller slot.
18. Enter the SP mode and do SP5825 (NVRAM Data Download).
19. In the “Copy SP” mode, confirm the correct settings of the following SPs:

SP No.	SP Name	Correct Setting
5871 001	HDD Function Disable	1 (On)
5967 001	Copy Server Set Function	1 (Disable)
5846 090	USC Settings - Plain Data Forbidden	1 (Check)
5836 001	Capture Settings – Capture Function	0 (Disable)

20. Exit the “Copy SP” mode and enter the “Print SP” mode.
21. Confirm the correct setting of SP1006.

SP No.	SP Name	Correct Setting
1006 001	Sample/Locked Print	1 (Enable)


22. Connect the network cable if the NIB option is installed.
23. Connect the fax cable if the fax option is installed.

3.3 DIMM OR SD CARD

1. Switch the operation switch off.
2. Switch the main switch off.
3. Disconnect the power cord from the power supply.
4. Disconnect the network cable if the NIB option is installed.
5. Disconnect the fax cable if the fax option is installed.
6. Make sure that you have the correct DOS unit for the machine.
7. The machine model requires the DIMM or the SD Card.

Model	Security Module Required
B135/B138	DOS Unit Type A (DIMM)
B089/B093	DOS Unit Type A (DIMM)
B147/B149	DOS Unit Type B (SD card)

8. Install either the DIMM or the SD Card in the controller slot:
 - B135/B138, B089/B093 require the DIMM.
 - B147/B149 requires the SD card.
9. Connect the network cable if the NIB option is installed.
10. Connect the Fax cable if the fax option is installed.
11. Switch the main power switch on.
12. Make a Sample Copy.



13. Check the overwrite erase icon [A] in front of the date in the upper right corner of the operation panel display.
14. Confirm that the icon has changed from the display for data on disk [B] to no data on disk [C].

4. TROUBLESHOOTING

CAUTION

Never turn off the main power switch when the power LED is lit or flashing. To avoid damaging the hard disk or memory, press the operation power switch to switch the power off, wait for the power LED to go off, and then switch the main power switch off.

NOTE: The main power LED lights or flashes while the platen cover or ARDF is open, while the main machine is communicating with a facsimile or the network server, or while the machine is accessing the hard disk or memory for reading or writing data.

4.1 SERVICE CALL CONDITIONS

4.1.1 SUMMARY

There are 4 levels of service call conditions.

Level	Definition	Reset Procedure
A	The LCD shows the SC code. The customer cannot continue to use the machine. The customer must call for service.	The customer engineer must: <ul style="list-style-type: none"> • Enter the SP mode. • Switch the main power switch off and on. • Troubleshoot the problem by following the procedures described in this section.
B	The LCD shows the SC code. The customer cannot continue to use the machine. This is a machine error.	The customer must: <ul style="list-style-type: none"> • Switch the operation switch off and on. • If the error occurs again, switch the main switch off and on. • If the error occurs again, user must call for service.
C	The LCD shows the SC code. However, only the unit that generated the error is disabled.	The customer must: <ul style="list-style-type: none"> • Switch the operation switch off and on. • If the error occurs again, switch the main switch off and on. • After recovery, the user can continue to use any feature other than the disabled function. For example, if an error occurs in Tray 1, the user can use other paper feed trays. • Customer should call for service if the affected function continues to return errors.
D	The LCD shows no SC code. The customer can continue to use the machine.	No action required. The machine updates the SC history.

4.1.2 SC CODE DESCRIPTIONS

SC828	B	Copy Countermeasure Error	B135/B138, B089/B093 Only
		A special chip on the ROM-DIMM installed in the machine is designed to prevent copying. After the command was sent to this chip, the chip generated an unexpected response.	<ul style="list-style-type: none"> ROM-DIMM

SC865	B	HDD Access Error	B135/B138, B089/B093, B147/B149
		During operation, the HDD generated an error.	<p>Hard Disk Failure</p> <ul style="list-style-type: none"> Do SP5832 001 (HDD Formatting - All) Do SP5832 002 (HDD Formatting - IMH) If normal operation of the HDD cannot be recovered after doing these two SPs, replace the HDD.


SC866	B	SD Card Recognition Error	B147/B149 Only
		The machine generated an error when it attempted to detect the electronic recognition license. An illegal program is on the SD card.	<ul style="list-style-type: none"> Use an approved SD card.

SC867	B	SD Card Removal Error	B147/B149 Only
		The SD card was removed from its slot while an application was executing.	<ul style="list-style-type: none"> Never remove an SD card from the controller slot while a program is executing. Switch the main power switch off and on, then start again.

SC868	B	SD Card Access Error	B147/B149 Only
		The SC card controller returned an error because the SD card is defective or the SC card controller is defective.	<ul style="list-style-type: none"> Replace the SD card. Replace the SD card controller.

OVERWRITE ERASE ICON NOT DISPLAYED

4.2 OVERWRITE ERASE ICON NOT DISPLAYED



If the overwrite erase icon [A] is not displayed, check the following SPs and make sure that they are set correctly.

Copy SPs


SP No.	SP Name	Set To:
5871 001	HDD Function Disable	1 (On)
5967 001	Copy Server Set Function	1 (Disable)
5846 090	USC Settings - Plain Data Forbidden	1 (Check)
5836 001	Capture Settings – Capture Function	0 (Disable)

Print SP

SP No.	SP Name	Set To:
1006 001	Sample/Locked Print	1 (Enable)

5. SERVICE TABLES

Service Table Key

Notation	What it means
[range / default / step]	Example: [-9 ~ +9 / +3.0 / 0.1 mm step]. The setting can be adjusted in the range ± 9 , value reset to +3.0 after an NVRAM reset, and the value can be changed in 0.1 mm steps with each key press.
*	Value stored in NVRAM. After a RAM reset, this default value (factory setting) is restored.
<i>1111</i>	An SP number set in bold-italics denotes a "Special Service Program" mode setting. To display the SSPs: 1. Enter the SP mode. 2. On the touch panel, press "Copy SP" and $\text{\textcircled{\#}}$ together.
DFU	Denotes "Design or Factory Use". Do not change this value.
Japan only	The feature or item is for Japan only. Do not change this value.
LEF	Long Edge Feed
SEF	Short Edge Feed
( 6.2 Image Processing)	Refer to "6.2 Image Processing" in "6. Details". Due to fundamental changes in how image processing adjustment is done with Group 4 SP codes, more details are provided in Section 6.

5.1 COPY SP SERVICE TABLES

5801 1	Memory Clear - All Clear
	Resets all data for process control and all software counters, and restores all modes and adjustments to their default values. To execute, hold down ① for over 3 seconds, and then turn the copier off and on again. Use this SP only after replacing the NVRAM, or after the copier has malfunctioned due to a damaged NVRAM.

5801 014	Clear DCS Settings
	Initializes SP setting related to DCS. DCS (Delivery Control Service) manages the Scan Router connection. To execute, hold down ① for over 3 seconds, and then turn the copier off and on again.

5824	NVRAM Data Upload
	Uploads the UP and SP mode data (except for counters and the serial number) from NVRAM on the control board to a flash memory card. <i>While using this SP mode, always keep the front cover open. This prevents a software module accessing the NVRAM during the upload.</i>

5825	NVRAM Data Download
	Downloads the content of a flash memory card to the NVRAM on the control board.

5832	HDD Formatting	
	Enter the SP number for the partition to initialize, then press #. When execution ends, cycle the machine off and on.	
5832 1	ALL	Initializes entire content of the HDD.
5832 2	IMH	Initializes 1) documents stored on the document server, 2) stamp print data, 3) scanner delivery images, 4) fax delivery images.

5836*	Capture Settings	
	5836 1*	Capture Function (0:Off 1:On) 0: Disable, 1: Enable
0: With this function disabled, the settings related to the capture feature cannot be initialized, displayed, or selected.		
1: With this function enabled, the settings screen for the capture features can be displayed.		

5846	UCS Settings	
	UCS (User Control Service) is the software that manages user codes, the fax address book, the scan-to-email address book, and the scan-to-folder address book.	
5846 50*	Initialize All Directory Info.	Clears all directory information managed by UCS, including all user codes

5871	HDD Function Disable	[0~1 / 0 / 1] (0: OFF, 1: ON)
	Disables the HDD functions by suppressing all functions that write data to the HDD. After this SP is executed, the machine must be switched off and on to enable the setting. This SP is used after the optional Security Module Type A has been installed on the machine. For more details about this installation, see "1. Installation".	

5872	HDD Overwrite Status Check	
	Determines whether the content of the hard disk has been overwritten. Range: 0 to 65535	

5967*	Copy Server Set Function	
	<p>Allows or denies access to the document server screen. After changing this setting, you must switch the main switch off and on to enable the new setting.</p> <p>0: Function enable. Pressing the Document Server button opens the Document Server screen.</p> <p>1: Function disable. Pressing the Document Server button does not display the Document Server screen. Free access to the document server is denied. However, files on the document server can still be accessed with the printer driver.</p>	

5990	SP Print Mode (SMC Printout)	
5990 1	All (Data List)	Execute to print a list of the settings for the selected item.
5990 2	SP (Mode Data List)	
5990 3	User Program	
5990 5	Diagnostic Report	

5.2 PRINT SERVICE TABLE


1006 001	Sample/Locked Print	
	<p>[0~1/0/1] 0: Linked, 1: On</p> <p>Enables and disables the document server. When you select "0", the document server is enabled according to the Copy Service Mode SP5967. If you select "1", the document server is enabled regardless of Copy Service Mode SP5967.</p> <p>Note: Set to "1" (On) for use of the Sample Copy and Locked Print features.</p>	

B692/B694
Data
Overwrite
Security Unit


6. DETAILS

When an original is scanned or printed, the data for the job is stored temporarily on the hard disk for jam recovery. After the copy or print job finishes, some of this temporary data remains on the HDD at random locations until it is overwritten by the next job.

At the end of every copy and print job, the DataOverwriteSecurity Unit automatically writes over unneeded temporary data with random data twice and with a zero (0) once. This is the method recommended by NSA.



Original Data



A copy or print job always starts writing data to disk, starting with the clusters at the outer edge [A] and progressing toward the center.


The overwrite, on the other hand, always begins at the center cluster [B] and progresses toward the edge.

Taking the first square as cluster 1 on the outermost track:

- A job starts writing from 1, 2, 3, and continues toward 32.
- At the end of the job, the Security module overwrite erase proceeds from the opposite direction, starting from 32, 31, 30 on the innermost track and continues to 1.

NOTE: Each number in the illustration represents 1 cluster, the smallest unit the operating system uses to handle data on the HDD.


If a copy or print job starts during data overwrite, the job has priority and the overwriting stops, and the copy or print job begins.



Original Data


1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32

1. A copy job writes data to the HDD as far as cluster 32 [A].



1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32


2. When the copy job is finished, the data overwrite starts at cluster 32 [B] can continues to overwrite each cluster twice with random data and once with a "0".



1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32

[C]


- In this example, a copy job starts when the overwrite reaches cluster 21 [C] and overwriting stops.



1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32


[D]

- Next, the job writes data to the disk as far as cluster 32. When the job finishes, the overwrite restarts, starting with cluster 21 [D].



1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32

5. As soon as the overwrite progresses as far as cluster 1, it starts again from cluster [E] and continues through 32, 31, and so on.



1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32

6. When overwriting reaches cluster 22 (in this example), the overwrite is finished.

SPECIFICATIONS

1. HARDWARE

SD Card	B147/B149	Either the DIMM or SD card is required.
DIMM	B135/B138, B089/B093	

2. SOFTWARE

The table below describes:

- The types of data overwritten automatically.
- Compatibility of the data overwrite function with other functions of the machine.

Types of temporary data that are overwritten	Copy jobs
	Print jobs
	Sample print/locked print jobs *1
	LAN fax printing
Types of temporary data that are not overwritten	Document server functions
	Scanner functions (except TWAIN)
	Internet fax
	Paperless/serverless fax
	PS3 (only for Type A) *2
	Spool printing
	SDK applications (Global Scan, Doc Mail, etc.)
Types of temporary data that are not originally stored on the HDD	File format converter functions
	Normal fax functions (except I-Fax, paperless/serverless fax) TWAIN scanner

*1 A sample print or locked print job can be overwritten after execution.

*2 The PS3 function cannot be used with the Type A DIMM because the Type A DIMM is inserted in the PS3 slot. However, B147/B149 is provided with an SD card merge function, so the PS3 function can be used with the Type B.

*3 User stamps are not overwritten and erased.

*4 Printer fonts, overlay forms, and RTIFF data are not overwritten.

- If the fax option is installed, the address book data is stored in the FCU (500 addresses maximum). If the Function Upgrade Kit is installed, up to 1200 addresses can be stored. The number of addresses that can be stored is determined by the capacity of the FCU and Function Upgrade Kit. The HDD does not store address book data.